SF Rush

User Manual

Table of Contents

Getting Started	2
Setting up your SF Rush	3
Downloading the App	4
Product Features	5
Product Specs	6
Precautions	7

Getting Started

Congratulations on getting an SF Rush!

Your SF Rush box includes the following:

- SF Rush
- Warranty Booklet

Setting Up Your SF Rush

 Once you have taken your SF Rush out of the box, long press on the touch area on the screen to wake up your SF Rush from deep sleep mode.

 Once your SF Rush is awake, tap on the touch area to scroll through the various screens. The screens are time, steps, calories, distance, percentage complete,

Downloading the App

 The 'SF Rush' app is available on both Android & iOS, and is compatible with Android 5.0 & above and iOS 11 & above.

Download the 'SF Rush' app on your device.

 Once the app is downloaded, open it and follow the on-screen instructions to complete the pairing of your SF Rush with your phone. Please ensure that all permissions asked for are approved so that the app can function properly.

Product Features

- Time, day & date
- Steps walked
- Calories burnt
- Distance covered
- Active time
- Vibration alarm
- Sedentary reminder
- Automatic sleep tracker

Product Specs

Bluetooth version

Screen resolution

Screen size

Battery type

Battery capacity / voltage

Strap material

Tracker head material

Buckle

Water resistance

Standby time

Motion sensor

4.2

128*32 pixels

0.91 inch

Lithium-ion rechargeable

50mAh / 3.7V

PU

ABS

Zinc Alloy

IPx6

7 days

3D

Precautions

- Avoid fire or contamination
- SF Rush is not suitable for swimming and is only Water Resistant upto IPX6.
- Do not disassemble the tracker head as it may lead to fire or defects.
- Do not use the product under very high or very low temperature.
- Do not keep or use the product at places where moisture or inflammables are present.
- In case the product gets contaminated by cosmetics, please clean it with a damp cloth immediately.



Wrning

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.