Go to www.vtechphones.com to register your product for enhanced warranty support and the latest VTech

vtech

Quick start quide



Full Color Pan and Tilt HD Video Monitor

VM919HD

VM919-2HD

This product is intended as an aid. It is not a substitute for responsible and proper adult supervision and should not be used as such.

ry, including the following:
Follow all warnings and instructions marked on the product.

IMPORTANT SAFFTY INSTRUCTIONS

equired.

swimming pool, or in a wet basement or shower.

CAUTION: Use only the battery provided. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altifuted eurino use. temperature and low air pressure at high affluide during use stronge or francopartation. Disposal of battery into fire or a hot oven, or mechanically cruziling or cutting or the battery can exult in an explosion. Leaving the battery in an extremely high temperature survivouring environment of part attery high temperature survivouring environment of gas, attery subjected to extremely low air pressure may receib in an explosion or the leakage of flammable liquid or gas. Dispose of used battery according to the information in The RBRC seal.

Power adapter inform VTech Telecommunications Ltd. Model: VT05EUS05100 Unit Output: 5V DC 2A VTech Telecommunication
Model: VT07EUS05200

Rechargeable battery information Zhuhai Great Power Energy Co., Ltd. Model: GSP806090-SAh-3.7V-1S1P

der-me-table or cabinet outlet. For pluggable equipment, the socket-outlet (power adapter shall be installed near the equipment and shall be easily

Inplug this product from the wall outlet before cleaning. To not use liquid or aerosol cleaners. Use a damp cloth for

no not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or

guipment is to be supplied from an identified USB port olyling with the requirements of the land of

complying with the requirements of Limited Power Source.

Do not overload wall outlets or use an extension cord.

Do not place this product on an unstable table, shelf, stand or other unstable surfaces.

push objects of any kind into this product through its because they may touch dangerous voltage points as a short circuit. Never spill liquid of any kind on the

or clusters are seen to the seen and the seen are seen as the seen

fronc devices, such as below monitors, codeless telephones, etc. To protect your privacy, make sure the product has never been used before purchase, reset the bably monitor period-ically by powering off and then powering on the units, and power off the bably monitor if you will not use it for some tim

with the product.

The small parts of this monitor can be swallowed by babies small children. Keep these parts out of reach of children.

Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating source.

Winning—Strangulation Hazard—
Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (IJ.7m) away). Do not remove this tag.

Nover place the camera untity indiced the baby's crib or playpen. Never cover the camera untity or parent unit with anything out to a love of a behalfer.

pacemaker.

Should NOT place wireless devices directly over the pacemaker such as in a breast nocket when it is turned ON.

Electromagnetic fields (EMF)
This VTech product complies with all standards regarding electromagnetic fields (EMF). If handled properly and acc

90

WHAT'S IN THE BOX







CONNECT THE BABY MONITOR

⊞NOTES

0

The rechargeable battery in the parent unit is built-in Use only the power adapters supplied with this product

Make sure the parent unit and the baby unit are not connected to the switch controlled electric outlets. Connect the power adapters in a vertical or floor mo Connect the power snappters in a vertical of floor mount position only. The adapter's promps are not designed to hold the weight of the parent unit and the baby unit, so do not connect them to any ceiling, under-the-table, or cabiner outlets. Otherwise, the adapter may not properly connect to the outlets.

Make sure the parent unit, the baby unit and the power adapter cords are out of reach of children.

mpliance with the ECC's RF exposure quidelines

place the baby unit at least 20cm from nearby per-





CONNECT THE BABY MONITOR (CONT'D)

Charge the parent unit battery before use When you have connected and turned on the parent unit, the batter will be charged automatically. **■Notes**

Before using the baby monitor for the first time, charge the parent unit battery for 12 hours. When the parent unit battery is fully charged, the battery icon becomes solid

battery icon becomes solid with.
It takes longer to charge the battery
when the parent unit is turned on. To
shorten the charging time, turn the
parent unit off while charging. The standby time varies der the sensitivity level you set, your actual use and the age of the battery.

The battery icon indicates the battery status (see the following table)

The screen displays The alight flashes.

The alight flashes.

The battery has very little charge and may be used for only a short time.

Charge without interruption (about 30 minutes). The battery icon becomes The battery is fully charged. To keep the battery charged, connect if to AC power when not in use.

POWER ON OR OFF THE BABY MONITOR

After the parent unit is fully charged, press POWER until the welcoming

screen appears

4 STATUS CHECK

0

0

baby unit and parent unit, your parent unit displays image from the baby unit, and the LINK LED

POSITIONING THE BABY MONITOR

The green LED light of the baby unit turns on.



To avoid interference from other electronic devices, place your baby monitor at least 3 feet

(1 meter) away from devices such as wireless routers, microwaves, cell phones and computers

The default volume of your parent unit is level 3, and the maximum volume is level 5. If you

experience high-pitched screeching noise from your baby monitor while positioning:

Make sure your baby unit and parent unit are more than 3 feet (1 meter) apart, OR Lower the volume of your parent unit.

IECHNICAL SPECIFICATIONS

speaker volume. It determines the volume of sound transmitted from your baby unit.



Talk to your baby via the baby unit

Press and hold the TALK key.

speak to your parent unit. Your voice is transmitted to the baby unit.

When finish talking, release the TALK key and hear your baby again.



Press @ to zoom in or out



Turn on/off the parent unit screen

Press POWER on the parent unit to

Press any keys on the parent unit to



While in the menu:

Hee the menu

sensitivity.

Press A, V, < or > to scroll among the

Press MENU to enter the menu, choose a

menu item, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby

unit lullaby, or to adjust the baby unit sound





OVERVIEW - PARENT UNIT



LINK LED light **■** LED light

TALK

Press and hold to talk to the baby unit. While in a submenu, press to exit.

Press to zoom in/our When in the main menu, press to go to the Help & Info page.



MENU/SELECT 11 Power jack

- VOL/ VOL+


15 Stand Microphone

12 DESET

ou can also call our Customer Support at 1 (800) 595-9511 [in US] or (800) 267-7377 [in Canada] for help.



OVERVIEW - BABY UNIT



Light sensor

Position the sensor horizontally for its optimal usage 10 Power jack

Threaded socket for wall mounting

12 Pair button

NEED HELP?


LED indicator

Infrared LEDs

6 ON/OFF switch

7 Antenna

For operations and guides to help you using your video monitor and for latest information and supports, go and check the online help topics and online FAQs



Scan the QR code on the right. Launch the camera app or QR code scanner app or your smartphone or tablet. Hold the device's camera up to the QR code and fame It. Tap the notification to right the telescition of the online help.

- If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer of further away until it is clear.









PARENT UNIT ICONS

Main menu icons

Monitoring mode (For VM919-2HD only



Baby unit 1 in Single mode



Melodies and soothing sounds

· Select play all melodies or play one of the five melodies and four soothing sounds



You can also set the timer to stop playing after 15, 30 or 60 minutes, or playing non

Alerts - Sound, motion and temperature

Select sound Sensitivity level

 Turn on/off Sound Detection Alert. Turn on/off Auto Wake Up function. section)

Main menu

Baby unit 2 in Single mod

Melodies and Soothing Sounds



(See Sound Detection and Auto Wake Up

Select motion Sensitivity level.

Temperature

 Turn on/off Temperature Alert. Set the parent unit to beep whenever the room temperature detected by the baby unit falls outside of the set temperature

Select Minimum temperature for alert

Select Maximum temperature for alert


range. Select temperature Format. Set temperature display in Fahrenheit (°F)

Parent unit settings

 Adjust parent unit screen Brightness Turn on/off Dim Mode.

or Celsius (°C)

Baby unit settings



Select Field of View

Choose Wide angle 🖾 or Standard 🖺 Adjust baby unit's speaker Volume.

General settings



 Turn on/off Low Battery Alert Tone Set the parent unit to beep when the battery is low.

Turn on/off No Link Alert Tone Set the parent unit to beep when the link between the parent unit and the baby unit

Status icons

① CAUTION • The default vo

. The haby unit number that is being viewed - Single CAM mode.

Patrol mode (* For VM919-2HD only). - Split mode (* For VM919-2HD only)

Split mode (* For VM919-2HD only)


(* For VM010-2HD only) Night vision feature is activated automatically.

£ Motion alert is turned on.


94 Sound detection alert is turned on. Melodies or soothing sound are turned on

Parent unit speaker is muted.

Displays when parent unit's battery is low and needs charging.



Temperature alert is turned on





Baby unit detects temperature is lower than the set minimum.



Baby unit detects temperature exceeds the





BASIC OPERATION - PARENT UNIT

The mean security and sound the was dreated by zarabadeu, and is used under the creative commons notices.

COURTS.
The Stroom Mokes sound files was created by Cavoline Ford, and is used under the Creative Commons licente.
The Bodgoround Mokes sound file was created by Cavoline Ford, and is used under the Creative Commons licentes.
The Chidest A Might sound file was created by Milke Koenig, and is used under the Creative Commons licentes.
The Morth Revi sound file was created by Milke Morth and is used under the Creative Commons licentes.

Parent unit power adapter: Output: 5V DC ⊚ 2A papy unit power adapter: Output: 5V DC @ 1A Parent unit: 3.7V 5000mAh, 18.5Wh Lithium-ion battery

Nominal effective range Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.

Adjust speaker volume Press -VOL / VOL+ to adjust your parent unit







turn off the screen.







13 Antenna 14 Speaker







Slide the switch to ON to power on your baby unit

•





12 Split mode









Sound Detection and Auto Wake UP

Adjust sound detection sensitivity

You can turn on Sound Detection Alert and adjust the Sound Sensitivity to detect sounds and turn on the parent unit while its screen is switched off or dimmed

When the baby unit detects sounds that exceed certain levels, the parent unit screen will turn on and the baby unit starts transmitting the sounds to the parent unit, and you can

If you have turned on **Sound Detection Alert**, the parent unit beeps when the baby unit

Level 3 (Highest)	Level 2 (Medium)	Level 1 (Lowest)
9	2.000	2
The parent unit screen and speaker turn on for very small sounds, including background noises from your baby's room.	The parent unit screen and speaker turns on for loud babbling and louder sounds from your baby. The parent unit remains quiet when your baby makes soft sounds.	The parent unit screen and speaker turn on for loud crying or screeching sounds from your baby. The parent unit remains quiet when your baby makes soft sounds.

Sound activated screen and audio - Auto Wake Up

When Auto Wake Up is turned on the parent unit screen stays off to save power when the baby unit detects no sound

detects no sound.

Once the baby unit detects sounds that are louder than the chosen sound sensitivity level, the parent unit screen and speaker turn on automatically. The parent unit will then turn of flaggin after 50 seconds of no sound detection.

■Notes

If you have muted the parent unit speaker, only the parent unit screen will turn on when a sound is detected.

will turn on when a sound is detected

If you have turned on Auto Wake

Up but turned off Sound Detection
Alert, the parent unit will wake up
when the baby unit detects sounds
that are louder than the chosen sound
sentitivity level







MOTION DETECTION

Adjust motion detection sensitivity

You can turn on Motion Alert and adjust the Motion Sensitivity to detect motions and turn on the parent unit while its screen is switched off or dimmed.

When the baby unit's camera detects motions that exceed certain levels, the parent unit screen will turn on and the baby unit starts transmitting the sounds to the parent unit, and you can see and hear your baby

If you have turned on Motion Alert, the parent unit beeps when the baby unit detects

	Level 3 (Highest)	Level 2 (Medium)	Level 1 (Lowest)
	* ***	*	* — — *
DESCRIPTION	The parent unit screen and speaker turn on for small motions, such as yawning or stretching.	The parent unit screen and speaker turns on for normal daily motions, such as people walking around the house.	The parent unit screen and speaker turn on for large motions, such as children are chasing or jumping around.

NIGHT VISION



The baby unit has infrared LEDs that allow Ine bary unit has intrared LEUs in that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and % appears on the screen.

Notes

- It is normal if you see a short white glare on your parent unit screen as the baby unit is adapting to the dark environment. When the infrared LEDs are on, the images are in black and white. This is normal.
- 8% Tip
- Depending on the surroundings and other Depending on the surrouncings and other interfering factors, like lightings, objects, colors and backgrounds, the video quality may vary. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry display.









Change different views - Patrol

Select Patrol mode as your monitoring mode to alternately view the image from baby units 11 man 2 man every 10 seconds



Select Split mode as your monitoring mode to view the images from both baby units at once.

■ Note

while in **Split mode**, you can press **<** or **>** to highlight the view of the baby unit 1 1 (1) or baby unit 2 (2) (1), and hear the sounds transmitted from the baby unit.


MOUNT THE BABY UNIT ON DRY WALL (OPTIONAL)

MOTES

- ita. Af the coult. Year many moned to more have the second and anothers consented at many at once habit contra
- a pencil to mark the top and the bottom holes as shown. Remove the wall mount bracket and drill two holes in the wall (7/32 inch drill bit).



- 2. If you drill the holes into a stud, go to step 3.
- If you drill the holes into an object other than a stud, insert the wall
 anchors into the holes. Tap gently on the ends with a hammer until the wall anchors are flush with the wall.



4. Place the baby unit on the wall mount bracket.

bottom to secure the baby unit

Tighten the screw into the threaded socket at the



3. Insert the screws into the holes and tighten the screws until only 1/4 inch



4. Place the baby unit on the wall mount bracket. Tighten the screw into the threaded socket at the bottom to secure the baby unit. Align the holes on the wall mount bracket with the screws on the wall, and slide the wall mount bracket down until it locks into place.





5. You can maximize your baby unit's viewing angles by tilting the wall mount bracket Hold the baby unit, and then rotate the knob in anticlockwise direction. This will loosen the joint of the wall mount bracket. Tilt your baby unit up or down to adjust to your preferred angle. Then, rotate the knob in clockwise direction to fighten the joint and





$^{\mathrm{Q}_{\mathrm{s}_{\!A}}}$ Frequently asked questions Below are the questions most frequently asked about the baby monitor.

Why does the baby

Try the following (in the order listed) for common cure:

Disconnect the power to the baby units and the parent unit.

2. Whilt a few seconds before connecting power back to the baby units and the parent unit.
3. Turn on the baby units and the parent unit.
4. Wait for the parent unit to synchronize with the baby units. Allow up to one minute for

Why don't the lights of the baby unit and parent unit so the baby unit and put the adapter in a wall socket. The parent unit will establish connection with unit go on when I switch the baby unit.

Serbang the baby unit.

Serbang the baby unit is not connected to the adapter in the same than the baby unit.

Perhaps the baby unit is not connected to the power. Insert the app baby unit and put the adapter in a wall socket. Then, slide the Φ **ON/OFF** to switch on the baby unit and to establish connection with the parent unit.

Make sure the power is not controlled by a wall switch.

onnected to AC power?

Why is my screen in black
The screen is in black and white during night-time or in a dark room when the night vision feature is activated. This is normal.

During night-time or in a dark room, the surroundings and other interfering factors, like lightlings, objects, colors and backgrounds may affect the image quality on your parent unit screen. Adjust the baby unit's angle or place the baby unit at a higher level to Why do I get glare or blurry display on my screen when viewing my baby at night? prevent glare and blurry display. Why does the baby

The parent unit and baby units may be too close to each othe Move the parent unit away from the baby units until the noise stops; OR
 Turn down the volume of your parent unit.

monitor produce a high-pitched noise? The baby units may be out of range. Move the parent unit closer to the baby units (but not less than 3 feet).

The parent unit may not have enough charge for the parent unit to perform norm Charge the battery in the parent unit until the battery icon becomes solid

The temperature of your baby's room may be too high or too low.

Why don't I hear a round / The parent unit meaker volume may be too low. Press VOI + to increase the w The parent unit speaker volume may be too low. Press VOL+ to increase the vol.

Why can't I hear my baby use the parent unit menu to change sound sensitivity level to the highest level.

re?

The baby units may be out of range. Move the parent unit closer to the baby units (but not less than 3 feet).

If you power on only one baby unit, your parent unit may display Make sure baby unit X is on or move closer to baby unit X, and the LINK LED light flashes. Switch to the baby unit

THE RBRC SEAL

The RBRC sail on the lithium-ion battery indicates that VTech Communications, inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States and Canada.

The program provides a convenient alternative to placing used lithium-ion batteries into the trash or municipal water, which may be liteligal in your area.

The RRRC Seal and 1 (800) 8 RATTERY® are registered trademarks of Californial Inc.

FCC AND IC REGULATIONS

improme has been rested and forced to comply with the requirements for a Class I digital device pricer by 1.5 of the impromessable command for the complex of the complex

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Connect the deeler or an experienced radioff VI scholina for help.
 WARNING: Change or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's sulthority to operate the equipment.

This Class B digital apparatus complies with Canadian requirement: CAN ICES-3 (B)/NMB-3(B)

Industry Canada

erm "IC." before the certification/registration number only signifies that the Industry Canada technical specifications were roduct meets the applicable Innovation, Science and Economic Development Canada technical specifications

RF radiation exposure statement

CALIFORNIA ENERGY COMMISSION BATTERY CHARGING TESTING MODE

This bady monitor meets the California Energy Commission (CEC) regulations for energy consumption. Your bady monitor is set up to comply with the energy-conserving standards right out of the loss. Follow the instructions to install and charge the battery. The CEC battery charging testing mode is activated while charging. Even if the parent unit is paired to bady units, the CEC battery charging testing mode is activated while it is powered off and charging.

FOR CETL COMPLIANCE ONLY

du bébé. Lorsque vous utilisez votre appareil, vous devriez toujours suivre certaines mesures de précaution de base afin de réduiré les risques d'incendie, d'électrocution et de blessures corporelles, dont ceux qui

l'installation par un adulte est requise. MISE EN GARDE: N'installez pas l'unité du bébé à une hauteur

mangort. Utilemation disk jaile dans id no oci dans in froid chaus, or l'accessement ou el néclousage méchanique de la piale pouvent au configuration de la configurat

Artisotateur de l'unité du bébé: Sortié : 5 V CC 1A.

Models: YT07EU502000

3.7V 500cmkh, 18.5Wh Ulman-ion Battery
Thurs Geral Proventions our les piles rechargeables:
2.7V 500cmkh, 18.5Wh Ulman-ion Battery
Thurs Geral Provention treby 52, 12.

Longalitis cent branchés dans une prite de courant, les adaptateurs section en el éto corque pour êtro relette correctionent, soi à la supporter le policit du bloc d'allimentation el la maintenir en glace dans une prite de de courant de la maintenir en glace de dans une prite au platford, sou une mable ou dant un marbille.

Pour les appareils raccordés, la prise de courant (de l'adaptateur sectouri doit être installée près de l'équipement et doit être

Débranchez ce produit de la prise de courant avant de procéder au nettoyage. N'utilisez pas de nettoyants en aérosois. Útilisez un chiffon humido pour la retternation.

chitron numide pour le nettoyer.

Ne coupez pas les cordons d'alimentation pour remplacer les fiches, car céci peut présenter un danger potentiel. Ne laissez aucun objet reposer ni appuyer sur le cordon d'alimentation. Minstallez pas cet appareil dans un endroit où l'on rignue d'écraser le combo d'alimentation.

d'alimentation. N'installes, pas ser le propriet.

Ton risque d'écrare le cordion d'alimentation ou de le piétiner.

Ne faite fonctionner cet appareil qu'avec le ly per d'alimentation dique du rifériquete. Il viole re commission per le lype d'alimentation dique du rifériquete. Il viole re commission per le lype d'alimentation de le violent de la cource d'energie limité.

Violent de l'USB aux conditions de la source d'energie limité, de l'use de la violent de la source d'energie limité.

source de chaleur ou d'un calorifère. De plus, ne placez pas l'appareil dans un endroit avant de vous assurer qu'il y ait une bonne circulation d'air.

A 6 6

Ω

us equas uars de produit.

Afin de réduire les risques d'électrocution, ne démontez pas cet
appareil, mais apportez-le dans un centre de service autorisé.
L'ouverture du boitler ou le retrait de toutes pièces que contient
est appareil, à l'exception de l'accès autorisé à certaines nortes

ou ouvertures, risque de vous exposer à des points de tension dangereux ou d'autres dangers. Un remontage incorrect peut par la suite présenter des risqués d'électrocution. Yous devriez tester la réception chaque fois que vous mettez l'appareil en fonction. l'appareil en fonction. Examinez les composantes afin de vérifier si celles-ci ne sont pas endommagees.

Il existe un très faible risque de perte de confidentialité avec

jouent pas avec rapparei.

S. Les petites pièces de ce moniteur peuvent être avalées par les bébés ou les petits enfants. Veuillez tenir ces pièces hors de portée des enfants.

Le produit riest pas conçu pour être utilisé par des personnes (incluant des enfants) aux capacités physiques, sensorialise ou mentalier réduités ou qui manquant d'appérience et de sou mentalier réduités ou qui manquant d'appérience et de separation ou d'instruction cellules par le la company de la com

CONSERVEZ CES INSTRUCTIONS Mises en garde

Utilisez et entreposez le produit à une température entre 0° C (32°F) et 40°C (104°F). Risque de brûlure, risque d'incendie, risque d'explosion associé à une mauvaise marripulation de la batterie. N'exposez pas cot appareil à des froids ou des chaleurs extrêmes, ainsi qu'à la lumière directe du soleil. Ne l'installez pas près d'une source de chauffage.

Averagement - Risque de strangulation
- Les enfants secont ETRANGLÉS dans des Cordons.
- Les enfants secont ETRANGLÉS dans des Cordons.
- Particulation of the Cordon of t

un article fal d'une serviotte ou une couverture. D'autres produits électroniques peuvent causer des interférences auprès de votre caméra IP. Essiyes d'installier votre caméra IP le puis loin possible de ces dispositifs decroniques, routieurs sans fil, puis loin possible de ces dispositifs decroniques, routieurs sans fil, téléviseurs, ordinateurs personnels, appareils électriques de cuisine et téléphones sans fil.

jumériques sans fil: organisme Wreless Technology Research, LLC [WTR], une firme le recherche indépendante, a mené une évaluation pluridisciplinate se interférences entre les téléphones sans fil portatifs et les des interférences entre les téléphones sans fil portatifs et de l'accommande de l'accommande de l'accommande de l'accommande Administration des aliments et droques (FDA) des États-Unis, la firme VIR recommande aux médicelrs.

Avis aux détenteurs de stimulateurs cardiaques

Vous devriez maintenir les dispositifs sans fil à au
du simulateur cardiaque. au simulateur cardiaque. Ils ne doivent PAS placer le téléphone sans fil directement sur le stimulateur cardiaque, tel que dans une poche de chemise, lor-

Neplaces pare det posselle our un dratiof, meuble, trépoid, apport de montégen fible du formatients. Les trous et ouvertures du boilles; juide à l'airrisée de l'apportel ou bous cubied, un pare 1 abert l'apportel, Pour l'empôcher de en l'empôcher par l'était par l'abert l'apporte de l'emporte de l'emporte de l'emporter de

LIMITED WARRANTY

The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmarship, pursuant to the following terms and

What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty

What will Vick his of the Product is not free from defects in materials and workmanichy during the limited warranty period ("Materially Defective Product").

Administration of the Conference of the Product of the Pro

How long is the immere warrany period or the Product extends for ONE (1) FEAR from the date of purchase. If VTech repairs or options as Marielly Deletiche Product under the terms of replaces a Marielly Deletiche Product under the terms of replaces or replaces and the product for a period of either (a) of days from the date the repaired or replaces. The product for a period of either (a) of days from the date the repaired or replaces. The product is shipped to you or (b) the time remaining on the original one-year warrany; whichever is longer.

This limited warranty does not cover Product that has been subjected to misuse, accident

Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or

vice representative of VTecn; or solucit to the extent that the problem experienced is used by signal conditions, network reliability, or cable or enna systems; or Product to the extent that the problem is caused by use with non-VTech accessories: or

with non-VTech accessories; or Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or

Product returned without a valid proof of purchase (see item 2 below); or

NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features m save you a service call

this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorise the cost of repair prior to any further repair activity. You must pay for the cost of repair ane return shipping costs for the repair of Products that are not covered by this limited warranty.

- Return the entire original package and contents includ the Product to the VTech service location along with a description of the malfunction or difficulty; and
- Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and

or province to province.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some state provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you

nay not apply to you





(L) 10s

resures de securite importantes a plaque signalétique appliquée est située au bas du socie de l'unité

observez toutes les instructions et mises en garde inscrites sur

modalcal.

Nutlikes pas can apparell prick de l'assa ni de toute autre source d'hardred, pas centre louis d'autre louis d'autre l'autre d'autre d'

VTech Telecommunications Ltd.
Modèle: VT0SEUSOSI00
Adaptateur de l'unité du parent: Sortie : 5 V CC 2A.
VTech Telecommunications Ltd.
Modèle: VT07EUSOS200

sque celui-ci est en marche. L'étude effectuée par l'organisme WRS n'a pas identifié de risque pour les détenteurs de similateurs cardiaques causés parles gens qui idissent dispositifs care fill à provimité de pou-cri

How long is the limited warranty period?

What is not covered by this limited warranty?

shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or

Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or

Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit

To obtain warranty service in the USA, please visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377.

Save you a service can.

Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. Vitech

What must you return with the Product to get warranty

Other limitations:

This warranty is the complete and exclusive agreement between you and Virech. It superredes all other written to accommunitations related to the Product. Virech provides on a communitation related to the Product. Virech provides by describes all of Virech's responsibilities regarding the Product. These are no other express warranties. Not one is authorized to make modifications to this limited warranty and you should not rely on any such modifications. State (Provincial Law Rights: This warranty gives you specific legal right, and you may do have defer right, which way from state to state when the product may be compared to the product of the product of

warranty lasts, so the above limitation may not apply to to in no event shall Vicke ble liable for any inclinicst, special, incidental, consequential, or similar diamages (including the Product or other associated equipment, the could for substitute equipment, and claims by third parties) results from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental cor-consequential diamages, so the above limitation or exclusion.

Please retain your original sales receipt as proof of purchase.