

CORFIDANT

BLUE TOOTH

FCC NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

CONFIDANT SIMPLIFIED USER MANUAL



TURNTHE CONFIDENT ON	In the OFF mode press and hold the power button for 4 seconds. The blue indicator light will flash 3 times. The blue light will flash on every 4 seconds for 5 minutes to indicate it is on and in standby mode.
TURNTHE CONFIDENT OFF	Press and hold the power button for 5 seconds. The blue indicator light will flash 2 times quickly and then turn off.
SYNCTHE CONFIDENT & YOUR BLUE TOOTH PHONE	In the OFF mode press and hold the power button for 4 seconds. CONTINUE to hold the power button for 3 more seconds (do not let go)The blue indicator light will flash 4 times. The blue indicator light will become a solid blue. Turn on your BT enabled phone and search for devices. Zeal Bluetooth will appear. Select and enter the password "0000" (4 zero's). Press OK or enter. The blue light will flash 10 times to confirm sync. You are ready to converse.
ANSWERTHECALL	The Earphone will bleep on an incoming call. Push the power button to answer. You will hear an audible bleep to confirm.
DIALINGACALL	Dial the #on your phone. Your CONFIDANT will bleep twice. You can hear the ringing sound through the earphone
ENDTHE CALL	Hang up the call or wait for the other party to hang up. An audible bleep will confirm disconnect.
VOLUMEUP	Pressthe power button once. You will hear an audible bleep
VOLUMEDOWN	Press the volume down button, You will hear an audible bleep.



For more information visit our website www.zealoptics.com

zeal optics

59 SouthMainStreet suite 3 pmb #143 Moab, UT84532 info@zealoptics.com