# Instructions for Easy Operation

## of Cube Camera

## —A3S1, A3S2

## 1. Download and install APP

1). Scan the QR codes shown below or search for "Yoocam" in APP Store or Google Play to download and install it;



iOS                    Android

## 2. Add Camera in the Yoocam

1). Connect your mobile phone to 2.4G WIFI network.(support 2.4G only);

2). Start the "Yoocam" APP, register and log in;

3). Click the "+" icon on the upper right corner of the page, as shown in picture 1. Then, the page jumps to "Select Device Type", as shown in picture 2, where select "Cube Camera";

| Picture 1 | Picture 2 |

4). Plug in the power adapter, and check whether the camera power indicator lights up or not, as shown in picture 3 below:

5). Press and hold the 'Set' button on the camera, wait for the camera sending a voice prompt of " Wait for receiving WIFI configuration information ", and click "I have heard the voice", as shown in picture 4 below:

Please connect to a power supply,
and check whether
The green light flashes

Press the reset button till the device
announce received the wireless
configuration

The green indicator does not flash?

Do not hear announcement?

The green indicator has flashed

I have heard the voice

Picture 3　　　　　　　　　Picture 4

6). Choose a WIFI network for the camera, enter the Wi-Fi password and click "Connect WIFI network", as shown in picture 5 below:

7). Click the "Send sound wave" button. After hearing a voice prompt of "Received successfully" from the camera, click "Next", as shown in picture 6 below:

Picture 5                                Picture 6

8) . While the camera is connecting, it will stay on the countdown page of "Connect to WIFI network", as shown in picture 7 below.

9). The page will jump to 'Set the device name' page until you hear a voice prompt of "Wifi connection successful ", as shown in picture 8 below:

**Picture 7**            **Picture 8**

10). Set the camera name and then click "Complete" button, after the camera is added, the page will jump to "Device List", as shown in picture 9 below:

Picture 9

## 3. Real Time Video Preview

1). Open the Yoocam App and chick the camera to activate it, and then enter the real-time video preview interface, as shown in picture 10 below:

Picture 10

**4. For further support, please visit https://www.worthcloud.cn,**

**or check the online document in the YOOCAM App .**

**FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled enviroment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

.