



RECON Dynamics
Proxlet Installation Guide
v1.1

Table of Contents

- Proxlet 3
 - Key Details 3
- Installation Preparation 4
- Installing the Proxlet..... 4
 - Tools..... 4
 - Equipment 5
- Numbering Tools 5
- Process for Gluing 5
- Process for Taping..... 6
- Alternate Installations (Cables) 6
- Proxlet Installation Preparation 7
 - Materials Needed 7
 - Tools needed..... 7
 - Workspace Environment 7
- Appendix A 8
 - Installation Examples..... 8
- Appendix B 13
 - Equipment and Material References 13
 - Attaching Proxlets to tools and equipment 13
 - Adding asset numbers to tools..... 13
- Appendix C 14
 - FCC 14

Proxlet

The Proxlet tag is the enabler of RECON Dynamics Asset Management Solution to actively manage assets such as equipment, tools and material providing unprecedented visibility for a company's operations. This tiny, rugged tag hides inside or on assets and wirelessly conveys information to the ProxBox™ hub. The Proxlet is designed to operate in the most extreme environments. When combined with the ProxBox, the Proxlet offers a full range of sensing and tracking capabilities. The Proxlet is part of RECON Dynamics unique web-based cloud-hosting solution for asset management providing information and metrics to any internet connected device.



Note

- This document provides guidelines for safe and permanent installation of RECON Dynamics tool tag (Proxlet) on tools and equipment.
- Please refer to your RECON Asset Management Solution (RAMS) user guide for additional information.



Caution

Read and understand all instructions and warnings provided for the Proxlet as well as any other supporting materials for such things as solvents or glues needed when installing the Proxlet.



Caution

Be careful not to damage the housing or peel off the Proxlet label during installation.

Key Details

- The antenna of the Proxlet is at the end designated by the pointed section of the label as shown in figure 1.
- The label on the Proxlet contains a unique alphanumeric serial number and a scannable barcode of that number.
- The barcode type is data matrix so the proper 2D reader must be selected to read the bar code.
- This product is designed for indoor/outdoor use and is weather-proof allowing it to be installed on most equipment and tools. If the seal of the Proxlet is compromised, it will not function long term in an outdoor environment.
- The housing is made of ABS plastic. Ensure any adhesives, chemicals or solvent used during installation is compatible with ABS.



Figure 1

Installation Preparation



Caution Metal objects blocking radio frequency (RF) transmission can affect the range of the Proxlet.

Below are some general do(s) and don't(s) to help identify a good Proxlet mounting location

DO	Mount the Proxlet inside tools when possible for protection while tool is in use.
	Look for a surface that is flat, well protected and free from dents and scratches.
	Look for cavities or small open areas where the Proxlet can be discretely tucked and easily secured.
	Mount the antenna end toward the outside of the tool or equipment and away from metal when possible.
	Mount the Proxlet such that the barcode is accessible if possible.
	Mount Proxlet on its bottom surface (surface opposite label) when possible.
	Mount the Proxlet such that it does not void any tool warranties.
DO NOT	Mount close to a heat source.
	Mount on surfaces which are fully exposed to damage while the tool or equipment is in use when possible.
	Mount where the Proxlet is fully surrounded by metal.
	Mount the Proxlet such that it affects the functionality of the tool or equipment.
	Mount to areas that do not have sufficient flat mounting surfaces.

Installing the Proxlet



- Ensure proper use of safety equipment prior to beginning the installation process

There are several ways and locations to properly install a Proxlet, depending widely on what it's being installed on. Below are a few examples:

Tools

- Inside plastic, fiberglass or wood sections, handles, covers, etc.
- Outside surface of tool in well protected flat areas
- In tools cases that are guaranteed to stay with the tool
- Heat shrink or taped onto cable
- Fit into sewn edges of bags or ground mats
- Make an attachment surface/bracket, for the Proxlet that can be added to the tool

Equipment

- Outside surface of equipment in well protected flat areas
- Inside plastic registration box or storage bin
- Inside cab area

First, try to find a location inside or on the tool or equipment where the Proxlet is less likely to be damaged. **In some instances, no glue or tape is required to secure the Proxlet inside a tool if it fits tightly and is contained from moving.** Remember, the Proxlet is a RF transmitter and can only be fully contained inside none metallic materials. If a tool is stored in a metal bin, ensure the bin door has a rubber weather seal. RF signal will penetrate through weather seals. In the case where a tool is stored in a metal bin, the RF signal strength will be degraded but likely still be received by ProxBoxes on vehicles or in tool rooms.



Metal objects blocking radio frequency (RF) transmission can affect the range of the Proxlet

Caution

Numbering Tools

The RAMS system generates a unique ID for tools which needs to be physically added to the tool. Refer to the appendix for reference to devices used for numbering. Equipment typically will have an asset number already. There are several ways to add these numbers, some are listed below:

- Engraving
- Stamping
- Permanent Paint Marker

Process for Gluing

A permanent fast setting epoxy is recommended for gluing the Proxlet to tools and equipment. In general, this technique will be the most widely used for installing Proxlets due to the wide variety of surfaces the installer will see. Refer to the appendix for reference to an epoxy. Below are steps to properly install a Proxlet to tools and equipment with a glue.



For fast setting epoxies, it is recommended to store the epoxy in ice while not in use to prolong the life of the mixing nozzle

1. Scan the Proxlet QR barcode and assign to a tool/equipment in the database, refer to the RAMS user guide for more instructions.
2. Identify the tool/equipment model number, serial number and any other identifier so it can be easily tracked and log information in the RAMS database.
3. Identify on the tool or equipment where the Proxlet will be installed

4. Use 120-grit sandpaper to slightly scuff contact surfaces and remove any remaining contaminants. This will enhance the contact strength of a glue.
5. Use an alcohol based solvent to thoroughly clean the surfaces where the Proxlet will be glued to.
6. It is recommended to also clean the Proxlet (steps 3 above) to prepare it for mounting.
7. Apply glue to Proxlet using a moderate amount and attached to tool or equipment. Remember, most permanent epoxies require a thin bond line for maximum strength. In the case where the mounting surface of the tool or equipment is not flat or has a very rough surface more glue may be required.
8. Depending on the glue chosen or ambient temperature the Proxlet may need to be held in place for a few seconds up to a minute or two to stay in place.
9. Add the RAMS generated number to the tool. Refer to the RAMS user guide for more instructions.



It is recommended to use nitrile gloves or equivalent when working with glues and solvents

Process for Taping

Strong double back tape rated for outdoor use can also be used for installing a Proxlet. Though not as adaptable as an epoxy, tape can create a permanent bond in the right application. Follow the process for gluing but do not rough the mating surface of the tool. Tape works best on smooth flat clean surfaces. Refer to the appendix for reference to a tape.

Alternate Installations (Cables)



DO NOT overheat the Proxlet while using a heating element such as a heat gun

1. Begin by referring to steps 1 and 2 above for installing the Proxlet.
2. Identify the length of cable and any other useful information.
3. Prepare the cable by removing cable clamp brackets and clamp from one of the cable ends.
4. Cut a 6" piece of an appropriately sized diameter transparent heat shrink tubing.
5. Slide the heat shrink over the end of the ground cable until it is about 8"-12" from the end.
6. Insert a prepared Proxlet into the heat shrink so that it is centered in the tubing.
7. Use a label printer to print the number generated by the RAMS system and add to visible surface of the Proxlet.
8. Use a heat gun on a low setting to shrink the tubing around the cable and Proxlet. **Be careful not to overheat the Proxlet by applying heat directly on it.**
9. Quickly wave the heat gun back and forth over the heat shrink until the tubing has contracted around the cable.
10. Reassemble the cable end and secure the clamp brackets.

Proxlet Installation Preparation

Materials Needed

- 0.5L Isopropyl (Rubbing) Alcohol
- 120-grit Sandpaper
- Epoxy
- Double Back Tape
- Heat Shrink Tubing
- Work related apparel
- Nitrile Gloves
- Safety glasses

Tools needed

- Engravers (for soft and hard materials)
- Metal stamp
- Permanent Paint Markers
- Heat Gun
- Power Driver and bit set for disassembly of tools and equipment


Workspace Environment

- All work should be performed on a long set of workbenches with ample space to setup different stations for each part of the install. General work stations typically consist of the following:
 1. Computer station for data input and scanning of Proxlet
 2. Tool disassembly and preparation
 3. Proxlet installation
 4. Glue curing and tool re-assembly
- It is recommended to cover the workbenches with tarps or drop clothes as needed to protect tools from scratches and guard against spills such as glue or solvents.
- It is recommended to work at room temperature - 68-72°F to maintain a reasonable curing time for glue or tack time for tape. If possible, work indoors in a dry space.

Appendix A

Installation Examples

- The following images are examples of Proxlets installed on tools and equipment.











Appendix B

Equipment and Material References

RECON recommends using a laptop and mouse with windows 7 or newer for scanning S/N of Proxlet into the system

The following links to products and material are for reference only.

2D barcode reader

<http://www.newegg.com/Product/Product.aspx?Item=N82E16838129176>

Part number is GD4430-BK. Most any 2D general purpose readers will work, if cable does not come with it order 90A052065.

Attaching Proxlets to tools and equipment

Double back tape for attaching to clean smooth surfaces

<https://www.amazon.com/3M-Automotive-Acrylic-Attachment-Black/dp/B000P18N76>

Epoxy for all other surfaces

Epoxy (DP8405 or DP8805 (sets faster)) - http://www.rshughes.com/p/3M-Scotch-Weld-DP8405NS-Green-Multi-Part-Duo-Pak-Standard-MMA-Acrylic-Adhesive-45-Ml-Cartridge-5-Min-Working-Time-Shear-Strength-4100/051115_68963/

Applicator - http://www.rshughes.com/p/3M-Scotch-Weld-EPX-Plus-II-50004-Applicator-Gun-Supports-50-Ml-Duo-Pack-Cartridges-Manual-2-1-Mix-Ratio/021200_50004/

Nozzle - http://www.rshughes.com/p/3M-Scotch-Weld-EPX-Noz-Nozzle-For-Use-With-45-Ml-Scotch-Weld-Duo-Pak-Cartridges-10-1-Mix-Ratio/051115_69043/

Plunger - http://www.rshughes.com/p/3M-Scotch-Weld-EPX-Plunger-Cartridge-Plunger-For-Use-With-Duo-Pak-Cartridges-10-1-Mix-Ratio/051115_69044/

Adding asset numbers to tools

Engraving Pen for soft surfaces

https://www.dremel.com/en-us/tools/pages/ToolDetail.aspx?pid=290#.V2mHc_krKcY

Dremel with small round tip for harder surfaces

<https://www.dremel.com/en-us/tools/Pages/ToolDetail.aspx?pid=4000-4%2f36H#.V2mIBvkrKcY>

Letter and number Stamp Set for some unique hard surfaces

http://www.homedepot.com/p/TEKTON-5-32-in-Letter-and-Number-Stamp-Set-36-Piece-6610/205642674?MERCH=REC--NavPLPHorizontal1_rr--NA--205642674--N

Paint markers for all other surfaces

http://www.staples.com/uni-Paint-Markers/product_SS1003205

Appendix C

FCC

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by manufacturer could void the user's authority to operate the equipment.

IMPORTANT! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

47 CFR 15.505- FCC

Class B

For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Radiation Exposure Statements

For FCC

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.