



2.4G RF Keyboard

User's Guide

Model: GR-75

www.a4tech.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

Federal Communications Commission Requirements

The equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THE CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Knowing the keyboard

2.4GHz wireless technology Errorless 2-Way Communication Technology

The 2.4GHz RF wireless technology is fine-tuned with exclusive 1,048,576 ID-codes; it offers precise and smooth wireless operation in active wireless environments. It allows many wireless devices to operate simultaneously in one area without interfering in the range up to 15 meters.

Errorless 2-way communication technology features error correction capability that speeds up data transmission and increases wireless precision. It saves valuable battery power and cost.

Specifications

RF Data Transmit Rate	500k bps	Frequency	2.407GHz~2.473GHz
ID Codes	1,048,576 sets		

Wireless Range

Any electrical device, such as the computer monitor, Zip drives, speakers, etc., can cause interference with the wireless keyboard. Most likely, this will effect tracking of pointing devices or the range of the device. To make sure that your keyboard transmits and receives properly, refer to the following instructions:

1. For optimal performance, place the receiver at least 8 inches (20 centimeters) away from other electrical devices, such as the computer monitor, Zip drives, speakers...etc.
2. The effective distance of wireless keyboard should be no farther than 15 meters. This will ensure optimal communication between the keyboard and the USB receiver.




NOTE: You should always get at least a 4 meters range. If you find that your cordless device gets less than 4 meters range, please replace the batteries with a fresh set, perform the synchronization procedure for the keyboard and test the range again. If the range is still below 4 feet, please test your device on another system, preferably in a different environment. If you find it gets the same range on another system, please contact us support to obtain information about a warranty replacement. However, if the range improves on another system, then it may be an environmental variable. Use the suggestions above to resolve the environmental interference issue.

Operating Warnings: For optimal performance and RF (Radio Frequency) reception:

Avoid using the wireless keyboard on a metal desk or a desk with a metal frame can cause problems with pointing device behavior and range.

Hardware Installation

Plug receiver into USB port of your computer or notebook.




Insert the supplied battery, making sure that the positive (+) and negative (-) ends of the battery match the polarity indicators inside the battery housing, and power will be automatically on. Now you can use the keyboard.

Software Installation

1. Before installing the keyboard software, please uninstall any previous installed keyboard software.
2. Insert enclosed CD to start installation.
3. Follow on-screen instructions to complete the installation.
4. The icon  will appear on your desktop, then you have successfully installed the software.

5. To launch the software, double click the icon  on your desktop or go to Start—Programs—**8 in Right**, then the icon will appear in the taskbar at the right corner of your screen.




Software Instructions

How to Pair the Wireless Devices


The keyboard have been preset the ID Code in the factory. But under the circumstances you lose receiver or want to use with the other receiver in the same product series, you need to refresh the ID Code before using it.

Step 1: Right click on the icon  in the taskbar  and select



“Pair ID Program”



Step 2: Press “Start Pair ID” to refresh ID Code.



Step 3: Remove the keyboard batteries and insert again in 15 seconds , 6 digits of matching code will be displayed on the menu as shown “Keyboard Pair ID OK”.



Notice: To ensure that your keyboard sends and receives perfectly, please read below instructions for your reference:

1. To avoid electromagnetic interference, place the receiver at least 8 inches (20 cm) away from other electrical devices, such as the computer, the monitor or external storage devices.
2. The operation distance depends on the working environment and can reach to 15 meters without any interference, to get optimal performance, please adjust the distance between keyboard and receiver according to different situations.
3. Avoid using the wireless keyboard on a metal surface. Metals such as iron, aluminum, or copper shield the radio frequency transmission and slow down the keyboard's response time or cause the mouse to fail temporarily.

Troubleshooting

If the keyboard are not working:

1. Check battery installation.
2. Check receiver installation.
3. Try another USB port.