

AL5621 Rev 2 Worldwide Wireless USB Device Radio Card Evaluation Board User Guide

INTRODUCTION

The AL5621 PCB Radio module is a complete compact device radio reference design that enables quick design of UWB enabled products. The AL5621 combines the Alereon AL5000 chipset along with on board power supplies, an antenna output, and three different system interfaces.

1.0 REFERENCE DESIGN FEATURES

- **Optimized Performance with AL5100 (3.1GHz to 10.6GHz) All Worldwide Bands.**
- **Complete Baseband Processor (BBP) and Media Access Controller (MAC)**
- **High Precision Data Path and Data Converters allowing reliable link at extended ranges**
- **Fully Integrated MAC Protocol Engine Supports All Industry Standards WiMedia Protocols**
 - Certified Wireless USB
 - WiMedia Link Layer Protocol
 - Bluetooth 3.0 (supported by future SW releases)
- **Industry Standard Interfaces**
 - ULPI 1.1 Interface: 8-Bit / 12 Pins for USB 2.0 PHYs
 - CF+ 3.0 / Generic Parallel Interface: 8 & 16-Bits
 - SDIO 1.1 Interface 1-Bit and 4-Bit Modes
 - UART interface for Cable Associate function
- **Operates from a single (+3.3 V, regulated) supply**
- **Small Form Factor (38.46 x 27.18 mm) (1.5 x 1 in)**
- **3 GPIO lines for LEDs or additional control signals**




Figure 1. AL5621 Worldwide Radio Card




Figure 2. Design Overview - Top Side




Figure 3. Design Overview - Bottom Side



2.0 BLOCK DIAGRAM




Figure 4. AL5621 Block Diagram

3.0 USER I/O INTERFACE HEADERS ULPI / SDIO / CF+ (BASE MOTHERBOARD CONNECTIONS)

AL5300		Cayman_Rev2 Connector - Molex 52885-0874		AL5300		
Signal	Function	Pin #	Pin #	Function	Signal	
		GND	1	2	+3.3V	
HSTIF_SEL_0	HSTIF_SEL_0		3	4	CARD_RESET#	N/A
HSTIF_SEL_1	HSTIF_SEL_1		5	6	SPARE	N/A
		+3.3V	7	8	GND	
HSTIF_38	CF_D_10 / ULPI_DIR		9	10	CF_IDIS16#	HSTIF_39
HSTIF_36	CF_D_2 / SD_D_2 / ULPI_D2		11	12	CF_D_9 / ULPI_NXT	HSTIF_37
HSTIF_34	CF_D_1 / SD_D_1 / ULPI_D1		13	14	CF_D_8 / ULPI_STP	HSTIF_35
HSTIF_32	CF_D_0 / SD_D_0 / ULPI_D0		15	16	+3.3V	
		GND	17	18	CF_STSCHG#	HSTIF_33
HSTIF_31	CF_A_0		19	20	CF_REG#	HSTIF_30
HSTIF_29	CF_A_1		21	22	GND	
HSTIF_27	CF_A_2		23	24	CF_INPACK#	HSTIF_28
HSTIF_25	CF_A_3		25	26	CF_WAIT#	HSTIF_26
HSTIF_23	CF_A_4		27	28	+3.3V	
		+3.3V	29	30	CF_RESET	HSTIF_24
HSTIF_22	CF_A_5		31	32	GND	
HSTIF_21	CF_A_6		33	34	CF_IREQ#	HSTIF_20
HSTIF_19	CF_A_7		35	36	CF_WE#	HSTIF_18
HSTIF_17	CF_A_8		37	38	+3.3V	
HSTIF_15	CF_A_9		39	40	CF_IOWR# / SD_CLK / ULPI_CLK	HSTIF_16
		+3.3V	41	42	GND	
HSTIF_14	CF_IORD#		43	44	CF_OE#	HSTIF_13
HSTIF_12	CF_A_10		45	46	GND	
HSTIF_10	CF_CE1#		47	48	CF_CE2#	HSTIF_11
		GND	49	50	+3.3V	
HSTIF_8	CF_D_7 / ULPI_D_7		51	52	CF_D_15	HSTIF_9
HSTIF_6	CF_D_6 / ULPI_D_6		53	54	CF_D_14	HSTIF_7
HSTIF_4	CF_D_5 / ULPI_D_5		55	56	CF_D_13	HSTIF_5
		+3.3V	57	58	GND	
HSTIF_2	CF_D_4 / SD_CMD / ULPI_D_4		59	60	CF_D_12	HSTIF_3
HSTIF_1	CF_D_3 / SD_D_3 / ULPI_D_3		61	62	CF_D_11	HSTIF_0
		GND	63	64	+3.3V	
GPIO_1	SECURITY_LED#		65	66	HUB_LED# (or DOCK_LED#)	GPIO_0
GPIO_3	DATA_LED#		67	68	AL_GPIO2_CA	GPIO_2
GPIO_5	AL_GPIO_5		69	70	AL_GPIO_4	GPIO_4
GPIO_7	HOST_BOOT		71	72	HOST_CONNECT_LED#	GPIO_6
		+3.3V	73	74	GND	
RXD	UART_RXD		75	76	UART_TXD	TXD
N/A	SPARE		77	78	SPARE	N/A
		GND	79	80	+3.3V	

4.0 DESIGN CONSIDERATIONS

4.1 Power

One +3.3 V power supply at max data rate average current of 500 mA with peak at 750 mA.

4.2 Board Reset

During power up, an "on board" power monitor holds the board Reset for approximately 150 ms. The card can also be reset at any time by asserting the "Card_Reset#" signal low.

It is also important to note that the Mode Pins HSTIF_SEL_0 & HSTIF_SEL_1 are sampled on the rising edge of Card_Reset#.

4.3 Mode Switching

During Power-Up, the HSTIF_SEL pins are sampled to configure the AL5300 HSTIF pins to one of three different host interface operating modes. The HSTIF_SEL pins must remain static for the duration of the operation of the AL5300 BBP/MAC.

Table 1 shows the proper settings of the HSTIF_SEL pins.

Table 1. HSTIF_SEL Pin Settings

Host Interface Mode	HSTIF_SEL[1:0]*
CF+/ Generic Parallel	00
SDIO	01
ULPI	10
Reserved	11
*Note: Please connect the HSTIF_SEL pins to GND for a "0" or do not connect them for a "1". Both HSTIF_SEL signals are pulled high on the daughter board through a 10K resistor to VDD. 0 = GND; 1 = No-Connect.	

4.4 Firmware Boot-Up

After completing the power-up cycle and after Card_Reset# is de-asserted, the AL5300 BBP/MAC automatically loads the Executable and Linking Format (ELF) firmware image into the chip's internal instruction memory. There are two boot modes, SPI and HOST. When utilizing SPI boot mode, the ELF image is loaded from an external EEPROM, which is connected to the AL5300 BBP/MAC using an industry standard 4-wire SPI port. When utilizing HOST boot mode, the ELF image is loaded directly over the HSTIF through either CF+, SDIO, or ULPI, and eliminates the need for an external EEPROM. Once the ELF image has been loaded, the AL5300 BBP/MAC will provide a software handshake to the Alereon software drivers indicating that the AL5300 BBP/MAC is ready for normal operation. The state of the HOST_BOOT pin determines which of two modes is used (refer to Table 2).

Table 2. Boot Modes

Boot Mode	HOST_BOOT*
SPI Boot Mode	0
Host Boot Mode	1
*Note: Please connect HOST_BOOT through a 330 Ω resistor to GND for "0" or No-Connect for "1". 0 = 330 Ω to GND; 1 = No-Connect.	

5.0 CF+ SIGNAL DEFINITIONS

The CF+/General Purpose Parallel interface can be configured as either a 8-bit or 16-bit parallel data port. The AL5300 BBP/MAC utilizes a FIFO memory buffer at the interface, allowing for simple and efficient high throughput data transfers without affecting the operation of the wireless link. The CF+/General Purpose Parallel interface can be configured and used in accordance to the CF+ specification (CompactFlash, Revision 3.0). When used as a CF+ port, the interface is compatible to both the I/O and Memory modes of operation.

The features of the AL5300 BBP/MAC CF+/General Purpose Parallel interface include:

- Interrupt-driven interface (the AL5300 BBP/MAC will interrupt the host system)
- 10 registers used to distinguish data and control spaces
- Payload data is ordered by a FIFO and is pushed or pulled through a single address
- Data and control registers can be accessed either as a 8-bit or 16-bit data word

Table 3 provides a listing of the CF+ interface pins and their functions.

Table 3. CF+/General Purpose Parallel Interface Pin Descriptions

AL5300 Pin	Name	Type	Description
P8, P7, P6, P5, L5, P4, N4, N3, P1, N1, L2	ADDR[10:0]	Input	Memory Mode: These address lines along with the CF_REG# signal are used to select the following: The I/O port address registers within the generic parallel interface/CF+ Card, the memory mapped port address registers within the generic parallel interface/CF+ Card, a byte in the card's information structure and its configuration control and status registers. IO Mode: This signal is the same as the Memory Mode signal.
L10, N11, N12, N13, P14, J1, J2, K1, P10, P11, P12, P13, N14, J4, K2, L1	DATA[15:0]	Bi-Directional	Memory Mode: These lines carry the Data, Commands and Status information between the host and the controller. DATA0 is the Least Significant Bit (LSB) of the Even Byte of the Word. DATA8 is the LSB of the Odd Byte of the Word. Note: When operating in 8 bit mode, DATA[15:8] are ignored. IO Mode: This signal is the same as the Memory Mode signal.
P3	CF_RESET	Input	Memory Mode*: The generic parallel interface/CF+ Card is Reset when the RESET pin is high with the following important exception: The host may leave the RESET pin open or keep it continually high from the application of power without causing a continuous Reset of the card. Under either of these conditions, the card shall emerge from power-up having completed an initial Reset. The generic parallel interface/CF+ Card is also Reset when the Soft Reset bit in the Card Configuration Option Register is set. IO Mode*: This signal is the same as the Memory Mode signal. *Note: CF_RESET is used to reset the CF+/General Purpose Parallel ports controller independently of the AL5300 BBP/MAC. Asserting CF_RESET will NOT reset the AL5300 BBP/MAC.
P9	CF_CE1#	Input	Memory Mode: These input signals are used both to select the card and to indicate to the card whether a byte or a word operation is being performed. CF_CE2# always accesses the odd byte of the word. CF_CE1# accesses the even byte or the Odd byte of the word depending on ADDR0 and CF_CE2#. IO Mode: This signal is the same as the Memory Mode signal.
N9	CF_CE2#	Input	Memory Mode: These input signals are used both to select the card and to indicate to the card whether a byte or a word operation is being performed. CF_CE2# always accesses the odd byte of the word. CF_CE1# accesses the even byte or the Odd byte of the word depending on ADDR0 and CF_CE2#. IO Mode: This signal is the same as the Memory Mode signal.
N8	CF_OE#	Input	Memory Mode: This is an Output Enable strobe generated by the host interface. It is used to read data from the generic parallel interface/CF+ Card in Memory Mode and to read the CIS and configuration registers. IO Mode: In I/O Mode, this signal is used to read the CIS and configuration registers.
L6	CF_WE#	Input	Memory Mode: This is a signal driven by the host and used for strobing memory write data to the registers of the generic parallel interface/CF+ Card when the card is configured in the memory interface mode. It is also used for writing the configuration registers. IO Mode: In I/O Mode, this signal is used for writing the configuration registers.
N5	CF_IREQ#	Output	Memory Mode: In Memory Mode, this signal is set high when the generic parallel interface/CF+ Card is ready to accept a new data transfer operation and is held low when the card is busy. At power up and at Reset, the CF_IREQ# signal is held low (busy) until the generic parallel interface/CF+ Card has completed its power up or reset function. No access of any type should be made to the generic parallel interface/CF+ Card during this time. Note, however, that when a card is powered up and used with CF_IREQ# continuously disconnected or asserted, the Reset function of the CF_IREQ# pin is disabled. Consequently, the continuous assertion of CF_IREQ# from the application of power shall not cause the READY signal to remain continuously in the busy state. IO Mode: After the generic parallel interface/CF+ Card has been configured for I/O operation, this signal is used as Interrupt Request#. This line is strobed low to generate a pulse mode interrupt or held low for a level mode interrupt.
L8	CF_IORD#	Input	Memory Mode: This signal is not used in this mode. IO Mode: This is an I/O Read strobe generated by the host. This signal gates I/O data onto the bus from the generic parallel interface/CF+ Card when the card is configured to use the I/O interface.
N7	CF_IOWR#	Input	Memory Mode: This signal is not used in this mode. IO Mode: The I/O Write strobe pulse is used to clock I/O data on the bus into the generic parallel interface/CF+ Card controller registers when thickens parallel interface/CF+ Card is configured to use the I/O interface. The clocking shall occur on the negative to positive edge of the signal (trailing edge).
K4	CF_STSCHG#	Output	Memory Mode: This signal is asserted high, as BVD1 is not supported. IO Mode: This signal is asserted low to alert the host to changes in the READY and Write Protect states, while the I/O interface is configured. Its use is controlled by the Card Config and Status Register.
M1	CF_REG#	Input	Memory Mode: This signal is used during Memory Cycles to distinguish between Common Memory and Register (Attribute) Memory accesses. High for Common Memory, Low for Attribute Memory. IO Mode: The signal shall also be active (low) during I/O Cycles when the I/O address is on the Bus.
N2	CF_INPACK#	Output	Memory Mode: This signal is not used in this mode. IO Mode: The Input Acknowledge signal is asserted by the generic parallel interface/CF+ Card when the card is selected and responding to an I/O read cycle at the address that is on the address bus. This signal is used by the host to control the enable of any input data buffers between the generic parallel interface/CF+ Card and the CPU.
H1	CF_IOIS16#	Output	Memory Mode: The generic parallel interface/CF+ Card does not have a write protect switch. This signal is held low after the completion of the reset initialization sequence. IO Mode: When the generic parallel interface/CF+ Card is configured for I/O Operation, this pin is used for the CF_IOIS16# function. A Low signal indicates that a 16-bit or odd byte only operation can be performed at the addressed port.
P2	CF_WAIT#	Output	Memory Mode: The CF_WAIT# signal is driven low by the generic parallel interface/CF+ Card to signal the host to delay completion of a memory or I/O cycle that is in progress. IO Mode: This signal is the same as Memory Mode signal.

6.0 SDIO SIGNAL DEFINITIONS

The SDIO interface supports both 1-bit and 4-bit Modes of operation and is fully compliant with SDIO Card Specification, Version 1.1. The SDIO interface can be double clocked, up to 50 MHz, providing twice the throughput of standard SDIO. Similar to the CF+/General Purpose Parallel interface, the SDIO interface utilizes a FIFO memory buffer at the interface to buffer the transactions on the host interface from those on the wireless link. Table 4 provides a listing of the SDIO interface pins and their functions.

Table 4. SDIO Host Interface Pin Descriptions

Pin	Name	Type	Description
L1	SDIO_DATA0	BiDirectional	SD 4-bit mode: Data Line 0 SD1-bit mode: Data Line
K2	SDIO_D1	BiDirectional	SD4 bit mode: Data Line 1 or Interrupt (optional) SD1 bit mode: Interrupt
J4	SDIO_D2	BiDirectional	SD4 bit mode: Data Line 2 or Read Wait (optional) SD1 bit mode: Read Wait (optional)
N14	SDIO_D3	BiDirectional	SD4 bit mode: Data Line 3 SD1 bit mode: Not Used
P13	SDIO_CMD	BiDirectional	SD4 bit mode: Command Line SD1 bit mode: Command Line
N7	SDIO_CLK	Input	SD Clock

Note: The host must pull-up SDIO_D0, SDIO_D1, SDIO_D2, and SDIO_D3 even if the host uses SD Memory Card as 1 bit mode-only in SD mode.

7.0 ULPI SIGNAL DEFINITIONS

The AL5300 BBP/MAC host interface complies with the ULPI Specification, Revision 1.1, which is compatible with USB 2.0. The ULPI specification provides a low-pin, low-cost, small form-factor transceiver interface for any USB application. Control and data timing requirements are given in Table 5 and illustrated in Figure 5. These timings apply to Synchronous Mode only. All timings are measured with respect to the clock as seen at the ULPI input clock pin (ULPI_CLKI). Control signals and 8-bit data are always clocked on the rising edge of the clock, while the optional double-edge 4-bit data signals are clocked on rising and falling edges. This interface runs at a clock speed of 60 MHz.

Table 5. ULPI Interface Timing

Parameter	Symbol	Min	Max	Units
Setup time (control in, 8-bit data in)	T _{SC} , T _{SD}		6.0	ns
Hold time (control in, 8-bit data in)	T _{HC} , T _{HD}	0.0		ns
Output delay (control out, 8-bit data out)	T _{DC} , T _{DD}		9.0	ns




Figure 5. ULPI Timing Diagram

8.0 CABLE ASSOCIATION SUPPORT

If the end product requires Cable Association support per the Wireless USB security specification, the following circuit must be added to the base motherboard design.




Figure 6. Cable Association Schematic Example

9.0 MECHANICAL MOTHERBOARD DESIGN CONSIDERATIONS

The AL5621 schematics and "AL5621 to Motherboard" connector data sheets can be found in the AL5621-RDK (Reference Design Kit). The following drawing shows the mechanical requirements for the placement of the two AL5621 interface connectors that are required for Electro-Mechanical connection between the product's base motherboard and the AL5621 Radio module.




Figure 7. AL5621 Module Mechanical Diagram

10.0 PRODUCT DESIGN UPDATES

Design enhancements for all Alereon design are continually made. Please visit the Alereon NDA web site periodically to ensure you stay up to date with the latest design changes, as well as schematic and Reference Design Kit revisions.

REVISION HISTORY

Date	Version	Description
01/03/2008	1.0	Initial Release Version
03/03/2008	2.0	Document updated to reflect Rev 2 board revision.

Work In Progress



Alereon, Inc.
7600 North Capital of Texas Highway
Building C, Suite 200
Austin, TX 78731

Telephone: (512) 345-4200
Fax: (512) 345-4201
info@alereon.com

The contents of this document are provided in connection with Alereon, Inc. products. Alereon makes no representations or warranties with respect to the accuracy or completeness of the contents of this publication and reserves the right to make changes to specifications and product descriptions at any time without notice. No license, whether express, implied, arising by estoppel or otherwise, to any intellectual property rights is granted by this publication. Except as set forth in Alereon's Standard Terms and Conditions of Sale, Alereon assumes no liability whatsoever, and disclaims any express or implied warranty, relating to its products including, but not limited to, the implied warranty of merchantability, fitness for a particular purpose, or infringement of any intellectual property right. Alereon's products are not designed, intended, authorized or warranted for use as components in systems intended for surgical implant into the body, or in other applications intended to support or sustain life, or in any other application in which the failure of Alereon's product could create a situation where personal injury, death, or severe property or environmental damage may occur. Alereon reserves the right to discontinue or make changes to its products at any time without notice.

© 2008 Alereon, Inc.
All rights reserved.

Trademarks

Alereon, the Alereon logo and combinations thereof are trademarks of Alereon, Inc.

Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.