

AZUMI

A50 Style LT


USER MANUAL




WELCOME

- Congratulations on your purchase of the Azumi mobile phone. Your phone provides many functions which are practical for daily use, such as a hands-free loudspeaker, camera, MP3 player, Ultra clear video, WIFI and GPS.
- You can read the manual to understand how to use Azumi mobile phone and experience the well-established functions and simple operation method. We suggest always use original accessories from your handset in order to achieve proper performance. Azumi shall not be responsible for any damage in machinery due to use of non-original components.

FRONT VIEW




BACK VIEW



CHARGE THE BATTERY

Connect this end to phone's USB port.


Your battery has been partially charged at the factory, but you may need to recharge it before you can switch the phone on for the first time.



Tip: Charge the battery before using it for the first time. Use only AZUMI approved chargers, batteries and cables.

INSERT SIM AND Micro SD CARD

Please insert the SIM card according to the label on the phone. Make sure that the clipped corner of the SIM card and the metallic contacts are facing the correct direction. Slide the SIM card into the slot until it doesn't move up any further.





Micro SD: Push the memory card into the memory card slot until it locks into place. Use only compatible memory cards approved for use with this device.

Tip: Your phone supports memory cards with a capacity of up to 32 GB.

TURN THE PHONE ON& OFF

Hold down the power button to turn the phone on.

Hold down the power button, then touch Power off to turn the phone off




DIM LOCK & WAKE THE PHONE

When the power is on and you want to dim the screen, press the power button.



When the screen is dimmed and you want to wake the phone, press the power button and then drag the lock to the right.

HOME SCREEN



Phone status bar and notifications.

Touch and hold an empty spot to change the wallpaper

All apps icons

Messages

Touch to enter Claro interface


Internet

Make a phone call

APPS



1. Touch it to enter app tray.



2. Touch an app to launch it

Shows phone's status information including the time, signal strength, battery status, and notification icons.



Status icons

The icons displayed at the top of the screen provide information about the status of the device. The icons listed in the table below are some of the most common ones.


| Icon | Statement | Icon | Statement |
|------|-------------------------|------|----------------------------|
| | Signal strength | | Headset connected |
| | Indicates battery level | | Bluetooth is activated |
| | Unread messages | | Wi-Fi is connected |
| | Missed calls | | Airplane mode is activated |
| | Alarm is activated | | USB is connected |

NOTIFICATION PANEL

Notifications alert you the arrival of new messages, calendar events, and alarms, as well as to ongoing events.

Drag down to display notifications

Touch a notification to respond




MAKE & ANSWER A CALL

1. From the Home screen touch
2. Dial a number using the dial pad.
3. Touch to initiate the call


Answer a call, Drag

Decline a call, Drag







VOLUME CONTROL WHEN CALLING

To adjust the in-call volume, use the Volume up and down keys of the phone.



SEND A TEXT

1. From the Home screen, touch 
2. Touch 
3. Enter a recipient.
4. Enter a message
5. Touch  Send the message


Use the following method to create a multimedia message: Touch  and attach pictures, videos, contacts, notes, events and other information.

ADDING EMAIL ACCOUNTS



Set up an email account when opening Email for the first time. After that, you can configure Email to send and receive email from additional accounts.

To add an email account:

1. Tap the e-mail icon. In Your account interface, tap Next. In e-mail address option, enter your e-mail address. In password option, → enter your e-mail password. Tap Next.
2. Filling the email address and password, tap next to setup email
3. Tap next to enter your email.



SET A RINGTONE

Press  **audio profile**  , select the profiles you want to set, you can customize the ringtone and volume of incoming call, notification ringtone in this interface


FM RADIO

1. Pull out the telescopic antenna or insert earphone, then Tap the Power icon to stop or play FM.

2. Tap the forward by 0.1 MHz or scroll the knob icon to change channel frequency. Press volume key to adjust the volume.

3. Tap Auto search, Settings, Record and Favorites icon to adjust.

MUSIC PLAYER






| Controls | |
|--|-------|
| Play/Pause | ▶ / ⏸ |
| Previous/Next | ⏮ / ⏭ |
| Now playing: Touch to open the current playlist. | ☰ |
| Shuffle: Touch to shuffle the current playlist. | 🔀 |
| Repeat: Touch to repeat the current playlist; touch again to repeat the current track. | 🔄 |

TAKE A PICTURE


1. Launch the camera by pressing the camera icon on the home screen.
2. In the camera app, touch the screen to focus on a specific area.
3. Press the camera button to take a picture.

SHOOT A VIDEO

1. Launch the camera by pressing the camera icon on the home screen.
2. In the camera app, select video  icon to start recording
3. Press the  icon to stop recording and  icon again to start recording.


VIDEO PLAYER

The videos can be played, in your device (for example, the video you captured by the camera) or video files stored in compatible SD card.




USE AS MODEM VIA USB

You can connect your phone to a computer with a USB cable, to transfer music, pictures, and other files between your phone's SD card and the computer.



CONNECT TO Wi-Fi NETWORKS

Activate the Wi-Fi feature to connect to a Wi-Fi network and access the Internet or other network devices.



Touch Settings>Wireless & networks > WLAN settings. Check Wi-Fi to turn it on. The phone scans for available Wi-Fi networks and displays the names of those it finds. Secured networks are indicated with a Lock icon.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is **0.322W/Kg** and when worn on the body, as described in this user guide, is **0.562W/Kg**(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). The maximum scaled SAR in hotspot mode is **1.156W/kg**. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RFexposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: **QRP-AZUMIA50STLT** Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **10mm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.