

Quick Installation Guide

Important Information

For Windows® XP, please visit our website at <http://www.emprex.com/> to download and install the "MouseMaestro Input Device Driver" to access the mouse functions of tilt wheel left and tilt wheel right.

For Windows® 7 & Windows Vista®, you can use the mouse immediately after plugging the dongle receiver into your PC USB port. If you want to enjoy the full functionality of the mouse, please go to the website at <http://www.emprex.com/> to install the "MouseMaestro Input Device Driver."

Mouse Button Function

Please refer to the mouse drawing picture :

1. Left button	2. Right button	3. Scroll wheel/middle button
4. Backward	5. Forward	6. Tilt wheel left (M969TAL ONLY)
7. Tilt wheel right (M969TAL ONLY)	8. LED indicator/battery low	

Hardware Installation

1. Plug the receiver into your available USB port on PC.
2. Make sure the batteries of the mouse are installed correctly, please follow the polarity signs in the battery compartment.
3. Please make sure the slide switch on the back of the mouse is switched to "on" before using the mouse. When not in use, you can either slide the power switch to "off" for power saving or store the receiver inside the mouse to turn the power off.
4. **Please hold the mouse close to the receiver within 30 cm and press any key to pair ID, and then you can use the wireless mouse immediately.**

Receiver Storage: You could have the receiver housed inside the receiver storage slot. By releasing the battery cover at the bottom of the mouse, and insert the receiver into the receiver storage slot between the batteries to store the receiver.

Pairing Procedure

Please follow the hardware installation procedure mentioned above to install the wireless mouse, and you can use the mouse immediately. If it can't work, please visit our website at <http://www.emprex.com/> to download and install the "Pairing Tool."

Note:

1. You don't have to pair ID again after changing batteries. If it can't work, please follow the steps above to complete ID pairing.
2. The mouse can operate freely up to 10 meter from the receiver.
3. Mouse battery life is up to 4 months. It depends on the intensity of usage.

Mouse Sensitive (Resolution) Adjustment

The resolution can be adjusted by pressing the middle button and right button of the mouse.

1600 DPI → 800 DPI (Default is 1600 dpi)	800 DPI → 1600 DPI
Press and hold the middle button (scroll wheel) & right button simultaneously about 3 seconds, and the LED indicator will light about 1 second.	Press and hold the middle button (scroll wheel) & right button simultaneously about 3 seconds, and the LED indicator will light about 3 seconds.

➤ Change the cursor pointer speed

You can modify the mouse pointer speed settings in the control panel.



1. Open the Start Menu by clicking "Start" at the lower-left corner on the screen
2. Then click on Settings / Control Panel / Mouse
3. In the Mouse Properties window that appears, click the Motion tab
4. Move the slide bar toward either the faster end or the slower end
5. Click OK to exit and make the change effective



System Requirements

- Available USB port
- Microsoft® Windows® 7, Windows® XP and Windows Vista® operating system

Driver Installation

For Windows® XP, please install the "MouseMaestro Input Device Driver" to access the mouse function of tilt wheel right and tilt wheel left.

1. After you download the driver, please find the "SetupKey.exe" in the directory and double-click this file.
2. Then follow the on-screen instruction to install the driver.
3. The driver icon  or  will show at the bottom right of the Windows system tray when the driver is loaded.





FCC GUIDELINES

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ♦ Reorient or relocate the receiving antenna.
- ♦ Increase the separation between the equipment and receiver.
- ♦ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ♦ Consult the dealer or an experienced radio/TV technician for help.
- ♦ Use only shielded cables to connect I/O devices to this equipment.

FCC Warning: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Information to user:

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

