

***** USER'S MANUAL *****

FCC ID : NHMCM108RF

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Warning : A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.

Use only shielded cables to connect I/O devices to this equipment.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.



CM108 RF Mouse User's Guide

◆ Connect your device :

1. Turn off your computer .
2. Locate the round 6-pin (PS/2)mouse port on the back of your computer .
3. Insert the mouse-port connector from your receiver into the mouse port .
4. Turn the mouse upside down, and remove the door to the battery compartment.
5. Insert the batteries making sure that you properly orient them for polarity, pointing the positive (+) end towards the "+" and the negative (-) end towards "-".
6. Close the battery compartment cover.

◆ Transmitter/Receiver Frequency Range: 27MHz

◆ Battery type: 3AAA*2

◆ System requirements

1. IBM PC & Pentium compatible

2. Connector : PS/2 ,

3. Support OS : WinNT,Win98, Win95, Win Me,Win2000