

WiFi Smart Socket Operating Instruction

1. Product Overview

Wi-Fi smart plug is a kind of smart products to control electric appliance via Wi-Fi wireless network. Via using smart phone client-side 【YD Home】 , user can switch the power on/off in any available Wi-Fi network areas. It also supports remote control, multi-timer tasks and countdown tasks. What's more, it support status tracking and timely feedback, family share and message notification. According to these features, users can efficiently control house appliances like lights, drinking fountain and heating, etc. Not Only Smart, But Also Reliable and Energy-efficient.

2. Technical Specification

Voltage:	120VAC, 50 Hz
Max Load:	15A, 1800W
WIFI Frequency:	2.4GHZ
Wireless Standard:	IEEE802.11b/g/n
Security Mechanism:	OPEN/WEP/WPA-PSK/WPA2-PSK
Product Type:	WFU-2
Operating temperature:	0 °C to +50 °C
Working Condition:	Indoor only

3. Product features

- Support device share
- Support 5 groups of mode setting
- Support 15 groups of timer settings
- Support 20 groups of countdown settings
- Support status tracking and timely feedback
- Support timer memory function when router is broken or offline
- Support message notification, e.g. timer execution notification
- Support WiFi/3G/4G remote control by smart phone or tablet device

4. Checklist before using WFU-2

- You require a router/modem with internet and Wi-Fi access.
- Make sure your smart phone or tablet device is Android4.0 or later and IOS 6.0 or later versions.
- Your smart phone or tablet device must be able to connect to the router/modem with internet and

5. Installation



search "YD Home", free download



Google play

search "YD Home", free download

6. Create 【YD Home】 account

After download and open App, then tap 【Sign up】 to create LifeMaster account.

Note: only support to use e-mail for creating an account

7. Add devices to your 【YD Home】 account

7.1 After signing up, then logging in, next tap 【+】 to start for adding device.

7.2 Following INSTRUCTION GUIDANCE which shows on the smart phone's interface to add device finally.

7.3 When the screen displays "adding device successfully", tap 【Save】 to enter into devices list.


8. Major Interface Functions


Tap "Socket icon" to enter into main operation interface.

8.1 ON/OFF Button: tap "power icon" to turn on/off the corresponding device.

8.2 Mode setting: tap 【Mode】 to enter into setting interface.

8.3 Timer and Count down: tap 【Timer】 and 【Countdown】 to enter into setting interface.

8.4 Device name amendment, Tip or timer setting and Device information: Tap "  ", then tap 【Settings】 to enter into setting interface.

8.5 Devices share: tap “  ”, then tap 【Family share】 to input your family members' YD Home account number, and then tap 【Share with your family】 to share your devices into their account.

9. FAQ

Q1: How to enter the Configuration mode?

A1: Press and hold Manual ON/OFF Button for 6 seconds until the red light flashes. Now your socket is in Configuration mode.

Q2: How to handle if configuration is not successful?

A2: Please make sure that your Android version is 4.0 or above and IOS 6.0 or above;

Please make sure that the WiFi password you enter is correct;

Please delete WiFi password and retype when you configure the second or third.... device;

Please make sure that your router network name (SSID) is not hidden;

Please make sure that your router network name (SSID) does not contain Chinese, Japanese or other special characters;

Please check if your router can be connected to network successfully;

Please check if your router has turned on the MAC address filtering feature;

Please check if your router is enabled AP isolation;

Please make sure that router supports the IEEE802.11b/g/n standard;

Please make sure that your router does not turn on some special settings;

Please make sure that your router is using WEP, WPA-PSK or WPA2-PSK encryption;

If none of the situations above happens, please restore factory settings for your socket and try configuring again.

Q3: Why timer tasks are not accurate to work or do not work?

A3: Please allow 【YD Home】 to access your location while you use the app. Your location is used for carrying out timer tasks.

Q4: When you use Family Share Function, the interface shows “The user is already your family member”.

A4: Please delete the user's account (More---Device Sharing---Delete), then operate 8.5 again to share all devices.

Q5: How to be more convenient to share devices to your family member?

A5: Directly share your YD Home account and password for using and controlling all devices together.

Q6: How many devices can be added and controlled by YD Home App?

A6: In theory, the App can support unlimited devices. But it depends on the capacity of your router.

Q7: Why smart socket cannot be used, after replacing router?

A7: Use your phone to connect with this router, then operate 7 again to add devices.

Q8: Is it true that the status of socket shows on the App?

A8: It's true. YD Home App supports socket's status tracking and timely feedback.

Q9: Can socket still work if router is broken or offline?

A9: Yes, it can. The socket has timer memory function. If router is broken or offline, Timer which you have already set up in YD Home can still be executed.

Note:

APP will be updated continuously. The interface and operation method may be different from this user manual.

10. Cautions

This device complies with Part 15 of the FCC Rules / Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux

appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions

suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de

l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est

susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power

(e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

11. MPE Reminding

To satisfy FCC / IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation.

To ensure compliance, operations at closer than this distance is not recommended.

Les antennes installées doivent être situées de façon à ce que la population ne puisse y être exposée à une distance de moins de 20 cm. Installer les antennes de façon à ce que le personnel ne puisse approcher à 20 cm ou moins de la position centrale de l'antenne.

La FCC des états-unis stipule que cet appareil doit être en tout temps éloigné d'au moins 20 cm des personnes pendant son fonctionnement.

12 .Region Selection

Limited by local law regulations, version for North America does not have region selection option.

13.After-sales Service

Please contact our company if there is any product failure that consumers cannot resolve. Contact



CIXI CITY YIDONG ELECTRONIC CO., LTD

Add:Guanhaiwei Industrial Zone, West Section, Cixi Ningbo, P. R. China

Tel: +86-574-63631599 63630759

Fax: +86-574-63630188

E-mail: cxyidong@cn-yidong.com

Web: www.cn-yidong.com

For safety, always switch off your appliances before connecting.

For indoor use only.

Whenever you change a wifi network, reconnection is required.

Do not plug in and out the device continually. Always wait for an interval of 10 seconds

For Pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.

To disconnect Voltage pull the plug.

Do not connect after each other.

Only used in dry place.