



Secure Print Jobs Release Administrator's Guide

Contents

Overview.....3

Configuring Secure Print Jobs Release.....4

 Configuring and securing the application.....4

Using Secure Print Jobs Release.....6

 Printing held jobs.....6

Troubleshooting.....7

 Secure Print Jobs Release issues.....7

 Secure Print Jobs Release licensing issues.....8

Appendix.....9

Notices.....11

Index.....16

Overview

Secure Print Jobs Release lets authenticated users view and release their held print jobs in the printer.

Additional required applications

For the security features of the application to work correctly, the following must be installed and running on the printer:

- **An authentication module application.** This is to secure access to the held jobs function by requiring users to log in to the printer when they attempt to use the function. To secure access to the application, set up a security template from the Embedded Web Server (for example, **Internal Accounts**). For more information, see the *Embedded Web Server — Security: Administrator's Guide* for your printer.
- **The Application Access Manager application.** This lets you secure access to the printer held jobs function by associating the function with the authentication module. For more information on Application Access Manager, see the *Application Access Manager Administrator's Guide*.

Notes:

- For a list of other application requirements, including supported printers and required firmware versions, see the *Readme* file.
- For information on physically setting up the printer or using the printer features, see the printer *User's Guide*. After completing initial setup tasks, see the *Networking Guide* that came with the printer for information on how to connect the printer to your network.

Configuring Secure Print Jobs Release

Even if the printer has been set up previously, make sure all settings have been configured to enable the security features of the application to work correctly.

Configuring and securing the application

- 1 From the Embedded Web Server, access the configuration page for the application.
- 2 Configure the following settings:
 - **Icon Text**—Specify a name for the application icon that appears on the printer home screen.
 - **Up Icon**—Browse to a new image file that represents the profile on the printer home screen.
 - **Down Icon**—Browse to a new image file that appears while the profile icon is being pressed.
- 3 Under Release Options, configure the following settings:
 - **Release Method**—Select whether to let users choose the jobs they want to print or to print all pending jobs.
 - **Display Print Jobs Sorted By**—Specify the order in which print jobs will be listed on the printer control panel.
- 4 Under Job Expiration, set the expiration for Verify and Repeat print jobs.

There are four types of held jobs:

- **Confidential**—This lets you store print jobs on the printer until you log in and release or delete them.
- **Verify**—This lets you print one copy of a print job and store the remaining copies on the printer. This enables you to make sure that the first copy is satisfactory before printing the remaining copies. The print job is automatically deleted from the printer after all copies are printed.
- **Reserve**—This lets you store print jobs on the printer. The print jobs are automatically deleted after they are printed.
- **Repeat**—This lets you print all copies of a print job and store the job on the printer so you can print additional copies later. You can print additional copies as long as the job is stored on the printer.

Note: To specify the expiration of Confidential and Reserve print jobs, click **Settings** or **Configuration**, and then click **Security > Confidential Print Setup**.

- 5 Under Advanced Settings, configure the following settings if necessary:
 - **Require All Jobs to be Held**—Select this check box to require all jobs to remain on the printer until they are released by an authorized user or until they expire.
 - **Clear Print Data**—Select this check box to clear the memory associated with each print job when the job is released.
- 6 Click **Apply**.
- 7 Secure access to Secure Print Jobs Release.

On printers running the Embedded Solutions Framework (eSF) version 3.0 or later:

- a From the Embedded Web Server, click **Settings** or **Configuration**.
- b Click **Security > Security Setup**.
- c Under Advanced Security Setup, click **Security Template > Add a Security Template**.
- d Type a name for the security template (for example, **Secure Print Jobs Release**).

- e** From the Authentication Setup menu, select the authentication module you want to use to secure access to Secure Print Jobs Release, and then click **Save Template**.
- f** Under Advanced Security Setup in [step c](#), click **Access Controls**.
- g** If necessary, expand the **Device Solutions** or **Apps** folder.
- h** From the Secure Print Jobs Release menu, select your security template, and then click **Submit**.

On printers running eSF version 2.0:

- a** From the Embedded Web Server, access the configuration page for the Application Access Manager application.
- b** From the Secure Print Jobs Release menu, select **Smart Card Authentication Client**.
- c** Click **Apply**.

Using Secure Print Jobs Release

Printing held jobs

- 1 With a document open, click **File > Print**.
- 2 Select the print-and-hold feature:
 - For Windows users, click **Properties, Preferences, Options, or Setup**. Then click **Print and Hold**, or click **Other Options > Print and Hold**.
 - For Macintosh users, select **Job Routing** from the print options or the "Copies & Pages" menu.
- 3 Select the print job type:
 - **Confidential**—This lets you store print jobs on the printer until you log in and release or delete them.
 - **Verify**—This lets you print one copy of a print job and store the remaining copies on the printer. This enables you to make sure that the first copy is satisfactory before printing the remaining copies.
 - **Reserve**—This lets you store print jobs on the printer.
 - **Repeat**—This lets you print all copies of a print job and store the job on the printer so you can print additional copies later. You can print additional copies as long as the job is stored on the printer.

Notes:

- Confidential, Verify, and Reserve print jobs are automatically deleted from memory after printing.
- Repeat print jobs are held in the printer until you delete them. If **Require All Jobs to be Held** is checked, then Repeat print jobs will be converted to Confidential print jobs.

- 4 Type the user name from the LDAP directory. For a Confidential print job, also enter a four-digit PIN.

Note: Because you are required to authenticate to use the printer or the application, you will not be prompted to enter this PIN when you print Confidential jobs using this application. The PIN is needed only for printing Confidential jobs using the built-in held jobs function on the printer.

- 5 Click **OK** or **Print**.
- 6 From the printer home screen, touch the application icon.
- 7 If prompted, enter your authentication credentials.
- 8 Select the job or jobs you want to print, specify the number of copies to print, and then print the job.

Note: Depending on how the application is configured, all jobs in your print release queue may print automatically when you touch the application icon.

If you want to delete selected jobs from your print release queue, then touch **Delete**.

Troubleshooting

Secure Print Jobs Release issues

“Unable to determine user id. Contact your system administrator” error message

This error indicates that the authentication module is not setting the user ID for the session. Try one or more of the following:

MAKE SURE THAT THE SESSION USER ID IS SET CORRECTLY

- 1 From the Embedded Web Server, access the application configuration page of the authentication module.
- 2 Make sure that the setting that specifies the user ID is configured correctly.
- 3 Save your changes.

MAKE SURE THAT THE APPLICATION IS SECURED

See [“Configuring and securing the application” on page 4](#).

“There are no jobs available for [user]” error message

Try one or more of the following:

MAKE SURE THAT THE SESSION USER ID IS SET CORRECTLY

- 1 From the Embedded Web Server, access the application configuration page of the authentication module.
- 2 Make sure that the setting that specifies the user ID is configured correctly.
- 3 Save your changes.

MAKE SURE THAT JOBS WERE SENT TO THE CORRECT PRINTER AND HAVE NOT EXPIRED

The user may have sent the job or jobs to a different printer, or the jobs may have been automatically deleted because they were not printed in time.

Jobs print immediately

MAKE SURE THE USER SELECTS THE PRINT-AND-HOLD FEATURE

For jobs to be held at the printer, users must select the print-and-hold feature in the printer driver when printing jobs. See [“Printing held jobs” on page 6](#).

Secure Print Jobs Release licensing issues

License error

Try one or more of the following:

MAKE SURE THE APPLICATION IS LICENSED

Applications require a license to run.

MAKE SURE THE LICENSE IS UP-TO-DATE

Make sure the license for the application has not yet expired. Check the license expiry date using the Embedded Web Server.

Appendix

Accessing application configuration settings using the Embedded Web Server

- 1 Obtain the printer IP address:
 - From the printer home screen
 - From the TCP/IP section in the Network/Ports menu
 - By printing a network setup page or menu settings page, and then finding the TCP/IP section

Note: An IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

- 2 Open a Web browser, and then type the printer IP address in the address field.
The Embedded Web Server appears.
- 3 From the navigation menu on the left, click **Settings** or **Configuration**, and then do one of the following:
 - Click **Apps > Apps Management**.
 - Click **Device Solutions > Solutions (eSF)**.
 - Click **Embedded Solutions**.
- 4 From the list of installed applications, click the application you want to configure, and then click **Configure**.

Exporting and importing a configuration using the Embedded Web Server

You can export configuration settings into a text file, and then import it to apply the settings to other printers.

- 1 From the Embedded Web Server, click **Settings** or **Configuration**, and then do one of the following:
 - Click **Apps > Apps Management**.
 - Click **Device Solutions > Solutions (eSF)**.
 - Click **Embedded Solutions**.
- 2 From the list of installed applications, click the name of the application you want to configure.
- 3 Click **Configure**, and then do one of the following:
 - To export a configuration to a file, click **Export**, and then follow the instructions on the computer screen to save the configuration file.

Note: If a **JVM Out of Memory** error occurs, then repeat the export process until the configuration file is saved.
 - To import a configuration from a file, click **Import**, and then browse to the saved configuration file that was exported from a previously configured printer.

Notes:

- Before importing the configuration file, you can choose to preview it first.
- If a timeout occurs and a blank screen appears, then refresh the Web browser, and then click **Apply**.

Licensing applications

Applications require a valid electronic license to run on select printers.

For more information on purchasing a license for an application, or for any other licensing information, contact your Dell representative.

Notices

Edition notice

June 2013

The following paragraph does not apply to any country where such provisions are inconsistent with local law: THIS PUBLICATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Trademarks

Information in this document is subject to change without notice.

Reproduction of this material in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden. Trademarks used in this text: *Dell* and the *DELL* logo are trademarks of Dell Inc.; *Microsoft* and *Windows* are registered trademarks of Microsoft Corporation. Other trademarks and trade names may be used in this document to refer to the entities claiming the marks and names of their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

GOVERNMENT END USERS

The Software Program and any related documentation are "Commercial Items," as that term is defined in 48 C.F.R. 2.101, "Computer Software" and "Commercial Computer Software Documentation," as such terms are used in 48 C.F.R. 12.212 or 48 C.F.R. 227.7202, as applicable. Consistent with 48 C.F.R. 12.212 or 48 C.F.R. 227.7202-1 through 227.7202-4, as applicable, the Commercial Computer Software and Commercial Software Documentation are licensed to the U.S. Government end users (a) only as Commercial Items and (b) with only those rights as are granted to all other end users pursuant to the terms and conditions herein.

GNU Lesser General Public License

View the GNU Lesser General Public License online at <http://www.gnu.org/licenses/lgpl.html>.

Dell End-User License Agreement

This is a legal agreement ("Agreement") between you, the user, and Dell Products L.P, a Texas limited partnership, or Dell Global B.V. (Singapore Branch), a Singapore branch of a company incorporated in The Netherlands with limited liability, on behalf of Dell Inc. and Dell Inc.'s subsidiaries and affiliates (together "Dell"). This Agreement covers all software (and upgrades, updates and feature enhancements thereto) that is distributed by Dell and for which there is no separate license agreement between you and the manufacturer or owner of the software (collectively the "Software"). This Agreement is not for the sale of Software or any other intellectual property. All title and intellectual

property rights in and to Software are owned and retained by the manufacturer or owner of the Software. All rights not expressly granted under this Agreement are reserved by the manufacturer or owner of the Software. By opening or breaking the seal on the Software packet(s), installing, downloading, activating the Software, click-accepting these terms, or using the Software, you agree to be bound by the terms of this Agreement. If you do not agree to these terms, you may not install, download, activate, or otherwise use the Software and must promptly return for a full refund all Software (including accompanying media, written materials, and packaging) or delete any Software, as directed by Dell; for software included with your purchase of hardware, you must return the entire hardware/software package. The right to a full refund does not apply to any updates or upgrades subject to the terms of this Agreement. If you are an entity, you acknowledge that the individual accepting these terms has appropriate authority to do so and to bind you.

Subject to the terms, conditions and limitations of this Agreement, Dell grants you a limited, nonexclusive, nontransferable (except as set forth herein), non-assignable license, to use the Software (in object code only) only on as many computers, devices, or in such configurations as you are expressly entitled, or one computer or device, if no other entitlement is specified, and for only such period as you are entitled, in the case of a term license, and perpetually, if no term is specified. You may use the Software only on Dell computers or devices, with the exception of mobile device application software specifically designed by Dell to be run on non-Dell hardware. "Use" means to install, store, load, execute, and display the Software. If you are a commercial customer of Dell, you hereby grant Dell, or an agent selected by Dell, the right to perform an audit of your use of the Software during normal business hours; you agree to cooperate with Dell in such audit; and you agree to provide Dell with all records reasonably related to your use of the Software. The audit will be limited to verification of your compliance with the terms of this Agreement. The Software is protected by United States and other applicable copyright laws and international treaties and may be protected under the patent laws of the applicable jurisdiction. You may make one copy of the Software solely for backup or archival purposes or transfer it to a single hard disk or storage device provided you keep the copy solely for backup or archival purposes. You shall reproduce and include copyright and other proprietary notices on and in any copies for the Software. You may not sublicense, rent, or lease the Software or copy the written materials accompanying the Software. You may transfer the Software and all accompanying materials on a permanent basis as part of a sale or transfer of the Dell product on which it was preloaded by Dell, where applicable, if you retain no copies and the recipient agrees to the terms hereof. Any such transfer must include the most recent update and all prior versions. You may not reverse engineer, decompile or disassemble, modify, or create derivative works of the Software. If the package accompanying your Dell computer or device contains optical discs or other storage media, you may use only the media appropriate for your computer or device. You may not use the optical discs or storage media on another computer, device, or network, or loan, rent, lease, or transfer them to another user except as permitted by this Agreement.

Limited Warranty and Limitation of Liability

Dell warrants that the Software media (if applicable) will be free from defects in materials and workmanship under normal use for 90 days from the date you receive them. This warranty is limited to you and is not transferable. Any implied warranties are limited to 90 days from the date you receive the Software. Some jurisdictions do not allow limits on the duration of an implied warranty, so this limitation may not apply to you. The entire liability of Dell and its suppliers, and your exclusive remedy, shall be, at Dell's option, either (a) termination of this Agreement and return of the price paid for the Software or (b) replacement of any media not meeting this warranty that is sent with a return authorization number to Dell, within the 90-day warranty period, at your cost and risk. This limited warranty is void if any media damage has resulted from accident, abuse, misapplication, or service or modification by someone other than Dell. Any replacement media is warranted for the remaining original warranty period or 30 days, whichever is longer.

Dell and its suppliers do NOT warrant that the functions of the Software will meet your requirements or that operation of the Software will be uninterrupted or error free. You assume responsibility for selecting the Software to achieve your intended results and for the use and results obtained from the Software. The terms of this Agreement do not entitle you to any maintenance or support for the Software.

DELL, ON BEHALF OF ITSELF AND ITS SUPPLIERS, DISCLAIMS ALL OTHER WARRANTIES, EXPRESS, IMPLIED, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A

PARTICULAR PURPOSE OR ANY WARRANTY REGARDING TITLE OR AGAINST INFRINGEMENT, FOR THE SOFTWARE AND ALL ACCOMPANYING WRITTEN MATERIALS. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS; YOU MAY HAVE OTHERS, WHICH VARY FROM JURISDICTION TO JURISDICTION.

IN NO EVENT SHALL DELL OR ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING WITHOUT LIMITATION DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION OR OTHER DATA, OR OTHER PECUNIARY LOSS) ARISING OUT OF USE OR INABILITY TO USE THE SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME JURISDICTIONS DO NOT ALLOW AN EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

Hosted and Internet-Accessible Software

Some or all of the Software may be remotely hosted or accessible to you through the Internet. In such case, Dell may suspend, terminate, withdraw, or discontinue all or part of the Software or your access to the Software upon receipt of a subpoena or law enforcement request, or when Dell believes, in its sole discretion, that you have breached any term of this Agreement or are involved in any fraudulent, misleading, or illegal activities. Dell may modify the Software at any time with or without prior notice to you. Dell may perform scheduled or unscheduled repairs or maintenance, or remotely patch or upgrade the Software installed on its and your computer system(s), which may temporarily degrade the quality of the Software or result in a partial or complete outage of the Software. Updates, patches or alerts may be delivered from Dell servers, which may be located outside of your country. Dell provides no assurance that you will receive advance notification of such activities or that your use of the Software will be uninterrupted or error-free.

Open Source Software

The Software may come bundled or otherwise distributed with open source software, which is subject to terms and conditions of the specific license under which the open source software is distributed.

THIS OPEN SOURCE SOFTWARE IS DISTRIBUTED IN THE HOPE THAT IT WILL BE USEFUL, BUT IS PROVIDED "AS IS" WITHOUT ANY WARRANTY, EXPRESS, IMPLIED, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY WARRANTY REGARDING TITLE OR AGAINST INFRINGEMENT. IN NO EVENT SHALL DELL, THE COPYRIGHT HOLDERS, OR THE CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS OPEN SOURCE SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Under certain open source software licenses, you are entitled to obtain the corresponding source files. You may find corresponding source files for the Software at <http://opensource.dell.com> or at such other locations indicated by Dell.

Export

You are advised that the Software is subject to U.S. export laws as well as the laws of the country where it is delivered or used. You agree to abide by these laws. Under these laws, the Software may not be sold, leased, or transferred to restricted countries (currently Cuba, Iran, North Korea, Sudan, and Syria), restricted end users, or for restricted end uses. You specifically agree that the Software will not be used for activities related to weapons of mass destruction, including but not limited to activities related to the design, development, production, or use of nuclear materials, nuclear facilities, or nuclear weapons, missiles, or support of missile projects, or chemical or biological weapons.

U.S. Government Restricted Rights

The software and documentation are "commercial items" as that term is defined at 48 C.F.R. 2.101, consisting of "commercial computer software" and "commercial computer software documentation" as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4, all U.S. Government end users acquire the software and documentation with only those rights set forth herein. Contractor/manufacture is Dell Products L.P., One Dell Way, Round Rock, Texas, 78682.

Evaluation Licenses

If you have received Software for trial or evaluation purposes ("Evaluation Software"), despite anything to the contrary in this Agreement, you may use the Evaluation Software solely for such limited evaluation period and for internal evaluation purposes only. Evaluation Software cannot be transferred save with the written authorization of the manufacturer or owner of the Software. You acknowledge that Dell may terminate your right to evaluate or use the Evaluation Software, for any or no reason, effective immediately upon notice to you. NOTWITHSTANDING ANYTHING TO THE CONTRARY IN THIS AGREEMENT, THE EVALUATION SOFTWARE IS PROVIDED TO YOU "AS IS" WITHOUT INDEMNITY OR WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. DELL BEARS NO LIABILITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, PUNITIVE, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM USE (OR ATTEMPTED USE) OF THE EVALUATION SOFTWARE THROUGH AND AFTER THE EVALUATION PERIOD AND HAS NO DUTY TO PROVIDE SUPPORT OF SUCH SOFTWARE TO YOU.

General

This license is effective until terminated. It will terminate upon the conditions set forth above or if you fail to comply with any of its terms. Upon termination, you agree that the Software and accompanying materials, and all copies thereof, will be destroyed. Except as may be prohibited by local law, this Agreement is governed by the laws of the State of Texas, without regard to principles of conflicts of laws. Each provision of this Agreement is severable. If a provision is found to be unenforceable, this finding does not affect the enforceability of the remaining provisions of this Agreement. This Agreement is binding on successors and assigns. Dell agrees and you agree to waive, to the maximum extent permitted by law, any right to a jury trial with respect to the Software or this Agreement. Because this waiver may not be effective in some jurisdictions, this waiver may not apply to you. You acknowledge that you have read this Agreement, that you understand it, that you agree to be bound by its terms, and that this is the complete and exclusive statement of the Agreement between you and Dell regarding the Software.

Your new Dell printer comes with patented print cartridges specially priced for a single use. Use of this cartridge confirms your agreement to only a single use. After this single use, the license to use the cartridge terminates. The cartridge is designed to stop working after delivering a fixed amount of printing. Regular cartridges, without these license terms, are available for sale that may be refilled. If you do not agree to these terms, contact Dell by visiting www.dell.com/contactdell.

Firmware updates may modify Dell printer settings and cause counterfeit and/or unauthorized products, supplies, parts, materials (such as toners and inks), software, or interfaces to stop working. Use of genuine Dell or Dell authorized products will not be impacted.

(Type S—Rev. 040512)

EU5D-0025

Additional copyrights

This product includes software developed by:

Copyright (c) 2002 Juha Yrjola. All rights reserved.

Copyright (c) 2001 Markus Friedl

Copyright (c) 2002 Olaf Kirch

Copyright (c) 2003 Kevin Stefanik

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions, and the following disclaimer.
2. Redistribution in binary form must reproduce the above copyright notice, this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution:

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Index

A

- accessing application configuration settings
 - using the Embedded Web Server 9
- additional required applications 3
- application configuration settings
 - accessing 9
- applications
 - licensing 10

C

- confidential print jobs 4, 6

D

- deleting held print jobs 6

E

- Embedded Web Server
 - accessing application configuration settings 9
- exporting a configuration
 - using the Embedded Web Server 9
- exporting a configuration using the Embedded Web Server 9

H

- held jobs
 - printing 6
- held print jobs
 - deleting 6
 - releasing 6
 - types 4, 6

I

- importing a configuration
 - using the Embedded Web Server 9
- importing a configuration using the Embedded Web Server 9

J

- job expiration settings
 - configuring 4
- jobs are not held at printer 7

- jobs print immediately 7

L

- license error 8
- licensing applications 10

N

- no jobs available for user 7

O

- overview
 - Secure Print Jobs Release 3

P

- print and hold
 - enabling 6
- print job expiration settings
 - configuring 4
- print release options
 - configuring 4
- printing held jobs 6

R

- releasing held print jobs 6
- repeat print jobs 4, 6
- reserve print jobs 4, 6

S

- Secure Print Jobs Release
 - additional required applications 3
 - configuring 4
 - overview 3
 - securing access to the application 4
 - using from the printer 6
- securing access to Secure Print Jobs Release 4

T

- troubleshooting
 - jobs are not held at printer 7
 - jobs print immediately 7
 - license error 8
 - no jobs available for user 7
 - unable to determine user id 7
- types of held print jobs 4, 6

U

- unable to determine user id 7

V

- verify print jobs 4, 6