Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

REV 16k



Greenhouse

6'10" L × 6'3" W × 6'3" H



97439

Visit our website at: http://www.harborfreight.com Email our technical support at: productsupport@harborfreight.com

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright[©] 2016 by Harbor Freight Tools[®]. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein.

Tools required for assembly and service may not be included.

AWARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Important Safety Information

In this manual, on the labeling, and all other information provided with this product:



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

A DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

AWARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

ACAUTION

CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to personal injury.

CAUTION

CAUTION, without the safety alert symbol, is used to address practices not related to personal injury.



WARNING Read all safety warnings and instructions.

Save all warnings and instructions for future reference.

The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Assembly Precautions

- 1. Assemble only according to these instructions. Improper assembly can create hazards.
- 2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
- 3. Keep assembly area clean and well lit.
- 4. Keep bystanders out of the area during assembly.
- 5. Do not assemble when tired or when under the influence of drugs or medication.

Use Precautions

- 1. Do not operate any fuel burning device inside the greenhouse. Asphyxiation hazard!
- Do not smoke or allow sources of ignition inside the greenhouse. Risk of fire! Greenhouse is not flame retardant.
- Snow/debris accumulation hazard.
 The heavy weight of accumulated snow or other debris can cause parts of this greenhouse to buckle suddenly. Do not allow snow or debris to accumulate on top of the greenhouse. DO NOT enter a greenhouse with accumulated debris on top.
- Assemble the Greenhouse in a smooth, level area that is sheltered from the wind.
- High winds can tear the Greenhouse loose from the Spikes and could result in property damage or personal injury. In case of severe weather or high winds, take the Greenhouse apart or move it under cover.
- 6. This product is not a toy. Do not allow children to play with or near this item.
- Use for intended purpose(s) only.
- 8. Inspect before use; do not use if parts loose or damaged.
- Maintain product labels and nameplates.
 These carry important safety information.
 If unreadable or missing, contact
 Harbor Freight Tools for a replacement.



Assembly Instructions



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Note: For additional information regarding the parts listed in the following pages, refer to the Assembly Diagram on page 11.

Note: The Greenhouse is heavy and unwieldy when fully assembled. It should be assembled near the area where it will be anchored. The area should be firm, level, and provide shelter from the wind.

Figure A: Slat Assembly (Steps 1-3)


- 1. Slide two Rafter Slats (O) into the sleeves on the top of the Front Panel (K).
- 2. Slide two Side Slats (P) into the sleeves on the sides of the Front Panel.
- 3. Slide Bottom Slat (Q) into the sleeve on the bottom of the Front Panel.

G G G H H H

Figure B: Pole Assembly (Steps 4-6)


- 4. Fit the covered Rafter Slats into the grooves in the Rafter Poles (G) and slide into place, with the holes on the Rafter Poles facing toward you (see insets above).
- 5. Fit the covered Side Slats into the grooves in the Side Poles (H) and slide into place, with the holes on the Side Poles facing toward you.
- 6. Fit the covered Bottom Slat into the groove in the Bottom Pole (F) and slide into place, with the holes on the Bottom Pole facing toward you.

Figure C: Connector Asm. (Steps 7-8)




- 7. Secure the Rafter Poles together at the peak of the roof using Connector A. Make sure the unconnected point on the Connector faces towards you.
- 8. Secure both top corners using a Connector B on the left side and a Connector C on the right side, again make sure the unconnected point on the Connectors face towards you.

Figure D: Hex Screws (Steps 9-10)




- 9. Secure the bottom left-hand corner of the Panel with Connector D. Use the Hex Wrench (T) to fasten a Hex Screw (S) into the hole on the bottom of the Bottom Pole.
- 10. Secure the bottom right-hand corner of the Panel with Connector E. Use the Hex Wrench (T) to fasten a Hex Screw (S) into the hole on the bottom of the Bottom Pole.
- 11. Repeat the above steps to assemble the Rear Panel (L).

Figure E: Panel Assembly (Step 12)



12. Line up the Connectors on the Front and Rear Panels and connect to the Body Panel (M). The uppermost pole in the Body Panel should be turned with the connection downward. All other poles should be turned with the connection upward, as shown.



- 13. Insert Rafter Bars (I) into the Sleeves at the top of the Body Panel (M).
- 14. Insert Side Bars (J) into the Sleeves at the sides of the Body Panel (M).




Figure G: Bar Connection (Steps 15-19)

- 15. Find the holes in the Bars (I, J) and line them up with the holes in the Poles (G, H).
- 16. Secure the Bars (I, J) to the Poles (G, H) using four Screws (R) per Bar. The Screws will be threaded directly through the cloth surrounding the Bars.
- 17. Choose an area for the Greenhouse that is flat, level and free of debris. If possible place the Greenhouse in an area that is sheltered from the wind. High winds can tear the Greenhouse loose from the Stakes (N) and could result in property damage or personal injury. In case of severe weather, take the Greenhouse apart.
- 18. Examine the area where the Greenhouse is to be placed. Make sure there are no utility lines beneath the surface that might be damaged by the Stakes.
- 19. Hammer the Stakes (N) into each corner of the Greenhouse to secure it to the ground. Use the two remaining Stakes to secure the door flap.

Maintenance and Servicing

- Periodically, inspect the general condition of the product. Check for loose screws cracked or broken parts, and any other condition that may affect its safe operation. If any defects are found have them repaired or the parts replaced immediately.
- 2. Clean external surfaces of the product with clean, moist cloth.

Parts List and Assembly Diagram

PLEASE READ THE FOLLOWING CAREFULLY


THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO.

Parts List

Part	Description	Qty.
Α	Connector A	2
В	Connector B	2
С	Connector C	2
D	Connector D	2
E	Connector E	2
F	Bottom Pole	2
G	Rafter Pole	4
Н	Side Pole	4
Ī	Rafter Bar	4
J	Side Bar	4

Part	Description	Qty.
K	Front Panel	1
L	Rear Panel	1
M	Body Panel	1
N	Stake	6
0	Rafter Slat	4
Р	Side Slat	4
Q	Bottom Slat	2
R	Screw	32
S	Hex Screw	4
T	Hex Wrench	1

Assembly Diagram



Record Product's Serial Number Here:_

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS DOCUMENT AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

