




Prox-DU

Dual Interface
Contact & Contactless
USB Smart Card Reader

Quick Installation Guide

Prox-DU view



Prox-DU computer installation

Plug the USB cable into the USB port of your computer and follow the on-screen instructions when the installation wizard appears.

Use the PC/SC driver package or web link available in the Gemalto web site <http://support.gemalto.com>

PC/SC driver OS support:

- ✦ Windows: 2000, XP 32/64 bits, Vista 32/64 bits, Seven 32/64 bits
- ✦ Windows: CE 5.0 / 6.0 / 6.0 R2
- ✦ Linux: Red Hat / Debian / Ubuntu distributions
- ✦ Mac OS: Tiger 10.4 / Leopard 10.5

For installation recommendation please refer to the Prox-DU installation guide available in the Gemalto web site <http://support.gemalto.com>

Prox-DU operation table

Card Indicator	Description
Off	The card interface is deactivated
Slow Blink (0,2 s / 2 s)	The card interface is ready
Blink (0,5 s / 1 s)	The card is present and inactive (powered off)
On	The card is present and active (powered on)
Flashing	The card communication is in progress

To protect the smart card from undesired operation the contactless interface is deactivated when a contact card is detected by the reader.

The contactless interface will be activated again when the smart card is removed from the slot or when a dedicated switch command is send to the reader by the application.

To change this default operating mode, please refer to the reference manual available in the Gemalto web site <http://support.gemalto.com>

Rating: 5V --- 200mA - Accessories for use with UL Listed Computers having limited power or class 2 output. Intended to be used with a Limited Power Source.

Regulatory information

Notice for the USA: FCC Statement

The Federal Communications Commission (FCC) Radio Frequency Interference Statement (USA Only)
 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Relocate the radio or television antenna.
- Plug the equipment away from the radio or television.
- Plug the equipment into a different electrical outlet, so that the equipment and the radio or television is on separate electrical circuits.
- Make sure that all your peripheral devices are also FCC class B certified.
- Make sure you use only shielded cables to connect peripheral devices to your equipment.
- Consult your equipment dealer or an experienced radio/television technician for help.

Warning: The system verification tests were conducted with Gemalto supported peripheral devices. Cables used with this equipment must be properly shielded to comply with the requirements of the FCC. Changes or modifications not expressly approved by Gemalto could void the user's authority to operate the equipment.

Déclaration de conformité à la directive R&TTE

Nous Société GEMALTO
 Sise à: Avenue du Pic de Bertagne, 13881 GEMENOS Cedex,
 Déclarons que les produits :

Lecteurs de cartes

Prox-DU

satisfont à la Directive 1999/5/CE du Parlement Européen et du conseil
 et sont conformes aux normes :

(Norme radio)	: ETSI EN 301 330-2 (V1.3.1 (2006))	
(Norme C.E.M)	: ETSI EN 301 489-1 (V1.8.1 (2008))	ETSI EN 301 489-3 (V1.48.1 (2002))
(Norme DBT)	: EN 60950-1/ A11	

Fait à La Ciotat, le 20/01/2010
 Pierre-André COLLET
 Responsable Homologations Produits



Instructions for disposal of waste equipment by users in private household



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.