

Maintenance Manual

SitePro

Controller Shelf Assembly

EA101209V1

Preliminary Document

NOTICE!

The voice coding technology embodied in this product is protected by intellectual property rights including patent rights, copyrights, and trade secrets of Digital Voice Systems, Inc. The user of this technology is explicitly prohibited from attempting to decompile, reverse engineer, or disassemble the Object Code, or in any other way convert the Object Code into a human-readable form.

NOTICE!

This manual covers products manufactured and sold by **Com-Net Ericsson Critical Radio Systems, Inc.**

NOTICE!

Repairs to this equipment should be made only by an authorized service technician or facility designated by the supplier. Any repairs, alterations or substitution of recommended parts made by the user to this equipment not approved by the manufacturer could void the user's authority to operate the equipment in addition to the manufacturer's warranty.

NOTICE!

The software contained in this device is copyrighted by **Com-Net Ericsson Critical Radio Systems, Inc.** Unpublished rights are reserved under the copyright laws of the United States.

This manual is published by **Com-Net Ericsson Critical Radio Systems, Inc.**, without any warranty. Improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by **Com-Net Ericsson Critical Radio Systems, Inc.**, at any time and without notice. Such changes will be incorporated into new editions of this manual. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of **Com-Net Ericsson Critical Radio Systems, Inc.**

EDACS is a registered trademark, and Aegis, ProVoice and SitePro are trademarks of **Com-Net Ericsson Critical Radio Systems, Inc.**

TABLE OF CONTENTS

Page

TABLE OF CONTENTS

1.0 SPECIFICATIONS ¹	7	
2.0 RELATED PUBLICATIONS.....	8	
3.0 SAFETY SYMBOLS.....	9	
4.0 INTRODUCTION.....	10	
4.1 APPLICATIONS.....	10	
4.2 COMMUNICATIONS.....	11	
4.3 COMPATIBILITY AND MIGRATION.....	12	
4.4 SYSTEM EXTERNAL INTERFACES.....	12	
4.4.1 Station Control.....	12	
4.4.2 Simulcast Control.....	14	
4.4.3 Conventional Control.....	15	
4.4.4 Voter Control.....	15	
4.4.5 Asynchronous Serial Ports.....	16	
4.4.6 Synchronous Serial Ports.....	16	
4.4.7 Power.....	16	
11. DESCRIPTION.....	18	
5.1 INDICATORS AND CONTROLS.....	18	
5.1.1 Indicators.....	18	
5.1.2 Controls.....	19	
5.2 ROCKWELL MODEM.....	19	
5.3 LOW SPEED AND HIGH SPEED DATA FILTERS.....	20	
5.3.1 Low Speed Data Decode Filter.....	20	
5.3.2 High Speed Data Encode Filter.....	20	
5.4 INTERFACE CONNECTIONS.....	20	
5.5 COMMUNICATION LINKS.....	21	
6.0 CIRCUIT ANALYSIS.....	24	
6.1 SHELF ASSEMBLY.....	24	
6.2 INTERCONNECT BOARD (A1).....	26	
6.3 CONTROLLER BOARD (A2).....	26	
6.3.1 Block Diagram.....	26	
6.3.2 System I/O.....	26	
6.3.3 Blackplane.....	32	
6.3.4 CPU.....	36	
6.3.5 Modem Daughter Board Connector.....	38	
6.4.5 Electrically Programmable Logic Device (EPLD).....	39	
6.7 Ethernet Ports.....	39	
6.4.6 I2C Bus.....	40	
6.4.7 Memory.....	41	
6.5.....		MODEM DAUGHTER BOARD
6.1 Modems.....	45	
6.2.3 V/5V Interface.....	45	
6.3 Microprocessor.....	45	
6.4 Code Memory.....	46	
6.5 Data Memory.....	46	
6.6 Dual Port Ram.....	46	
6.7 Troubleshooting Aids.....	47	
6.4 ROCKWELL MODEM INTERFACE CARD (A3).....	48	
7.0 QIUCC Connector.....	48	
6.2 Dual Port RAM.....	48	
6.3 Microcontroller.....	48	
6.48-bit Latch.....	48	
6.5 Address Buffer.....	48	
6.6 Data Buffer.....	48	
6.7 Code SRAM.....	48	
6.8 Data SRAM.....	48	

6.9	Page Connections.....	48
6.10	Address Decoder.....	48
6.11	Diagnostic Connector.....	48
6.12	3/5 Converter.....	48
6.13	I/O Connector.....	49
6.14	RF Modem.....	49
6.15	PL Modem.....	49
6.16	VDI Modem.....	49
6.4	ANALOG BOARD (A4).....	50
6.5.1	Quad ADC and Single DAC.....	50
6.5.2	8-Bit I/O Expander for I2C Bus.....	50
6.5.3	–5 Volt Generation.....	50
6.5.4	High-Speed Data Transmit Filters.....	51
6.4.4	9600 Baud Narrow Band.....	52
6.5.6	8:1 MUX.....	52
6.5.7	Dual Digital Pot.....	52
6.5.8	Inverting Buffer/Amplifier.....	52
6.5.9	Analog Switch.....	52
6.5.8	Clock Generation.....	52
6.5.9	Low Speed Data Decoder Filter.....	53
6.5.10	Low Speed Data Encode Filter.....	53
6.6	POWER SUPPLY (A5).....	53
6.7	MISCELLANEOUS INFORMATION.....	54
6.7.1	Serial Port Data Format.....	54
6.7.2	Failsoft Data Format.....	54
6.7.3	T1/E1 Interface.....	54
6.7.4	Phone Port Data Format.....	54
7.0	INSTALLATION.....	55
8.0	CONFIGURATION.....	56
9.0	PROGRAMMING.....	57
10.0	TROUBLESHOOTING.....	58
11.0	LIGHTNING PROTECTION GROUNDING.....	59
12.0	GLOSSARY.....	61
13.0	PARTS LIST.....	62
14.0	IC DATA.....	86
13.1	CONTROLLER BOARD (A2).....	86
6.8	MODEM DAUGHTER BOARD (A8).....	103
6.9	ROCKWELL MODEM INTERFACE CARD (A3).....	106
6.10	ANALOG FILTER BOARD (A4).....	107

1.0 SPECIFICATIONS¹

INPUT VOLTAGE	+13.8±20% VDC
CURRENT DRAIN	
Without 9600 baud modem	900ma (typical), 1.5 Amps (maximum)
With 9600 baud modem	1.5 Amps (typical), 2 Amps (maximum)
OPERATING TEMPERATURE	-22°F to +140°F (-30°C to +60°C)
DIMENSIONS (H x W)	1.75 x 19 inches (4.5 x 48.3 cm)
DATA TRANSMISSION	
High Speed	9600 ±1bps (EDACS Wideband) 4800 ±1bps (EDACS Narrow band)
Low Speed	150 ±1bps
COMMUNICATION INTERFACE	
Site Controller (trunked)	
Protocol	RS-232C
Data Format	1 start bit, 1 stop bit, and 8 data bits
Data Rate	19.2 kilobaud
Back-up Serial Link (Failsoft)	
Data Levels	0 to 13.8 VDC swing (nominal)
Data Format	1 start bit, 1 stop bit, and 8/9 data bits
Data Rate	19.2 kilobaud

¹ These specifications are intended to be used by the service technician during servicing. Refer to the appropriate Specification Sheet for the complete Specification.

2.0 RELATED PUBLICATIONS

The **SitePro Controller** trunking shelf is used in several applications, broadly including Voting, EDACS®, Aegis, and Digital Voice. In each of these applications the same SitePro Controller shelf is used, however, the Logic Board operates differently because of different jumper configuration, interfacing hardware, and software. Refer to the appropriate Com-Net Ericsson technical publication for additional information on each application as follows:

<u>Publication</u>	<u>Title</u>
MM101343V1	SitePro Installation Manual
MM#####V1	Rockwell Modem ROA 117 2247
LBI-31981	Digital Voice Voting Tone Board Maintenance Manual
LBI-38462	EDACS Voter Interface Board Maintenance Manual
LBI-38896	EDACS Site Downlink and CEC/IMC Uplink Configuration Manual
MM#####V1	EDACS Voter Digital Receiver and Selector ProSite Configuration Manual
LBI-38985	EDACS Site Controller Maintenance Manual
MM#####V1	SitePro Conventional Network Interface (CNI) Configuration Manual
MM#####V1	EDACS Single Channel Autonomous Trunking (SCAT) SitePro and Downlink SitePro Configuration Manual
MM#####V1	EDACS Station ProSite Configuration Manual
MM#####V1	EDACS Test Unit and Alarm Interface (TUAI) SitePro Configuration Manual.
LBI-39004	EDACS Guardog Installation and Operation Manual
MM#####V1	SitePro Shelf Programming Manual

3.0 SAFETY SYMBOLS



The **WARNING** symbol calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a **WARNING** symbol until the conditions identified are fully understood or met.



The **CAUTION** symbol calls attention to an operating procedure, practice, or the like, which, if not performed correctly or adhered to, could result in damage to the equipment or severely degrade the equipment performance.



The **NOTE** symbol calls attention to supplemental information, which may improve system performance or clarify a process or procedure.

h

The **ESD** symbol calls attention to procedures, practices, or the like, which could expose equipment to the effects of **E**lectro-**S**tatic **D**ischarge. Proper precautions must be taken to prevent ESD when handling circuit modules.

4.0 INTRODUCTION

The Com-Net Ericsson Critical Radio Systems group has developed a Motorola PowerQuicc-based CPU to replace the 8051-based GETC board due to memory limitations. In addition to replacing the functionality of the GETC module, other capabilities have been added, including support of ethernet.

This manual provides maintenance and servicing information for Com-Net Ericsson **SitePro Controller** Shelf Assembly EA101209V1². Production versions of this shelf consist of the following components:

- Shelf Assembly MA101080V1
Chassis MA101080V2
- Interconnect Board Assembly (A1) CB101073V1
- Controller board Assembly (A2) CD101069V1
- Modem Daughter Board (A8) CB101074V1
- Rockwell Modem Interface
Card Assembly (A3) ROA 117 2247
Rockwell Modem Assembly (A7) RYTUZ 921 01/1
- Analog Board (A4) CB101070V1
- Power Supply Module (A5) CONDOR DP1719
- Display Module (A6) MA101082V1
Display Board Assembly (A6-A1) CB101077V1
Cable (A6-W1) CA101222V1
- Input Cable to the Power Supply (W1) CA101211V1
- Output Cable from the Power Supply (W2) CA101212V1
- Data Cable (W#) CA101213V1

4.1 APPLICATIONS

The **SitePro Controller** can be installed and programmed for several different station applications. The basic programming is for the Station Trunking Shelf. This shelf enables the station to function as part of an EDACS trunked communication system by providing digital signaling and transmitter control of the associated base station. In addition, the **SitePro Controller** provides an interface between the base station repeater, the Site Controller or Site Interface Module (**SIM**) and other channel **SitePro Controller(s)** at the same time.

By reconfiguring the **SitePro Controller** shelf hardware and programming the operation through the programming port, located on the front panel, the **SitePro Controller** can be used as an/a:

- **Uplink/Downlink** – Configured as either an Uplink or Downlink, the **SitePro Controller** provides the communications link between the Transmit Site and the CEC/IMC switch.

² The Service Technician(s) should always consult application manuals, Software Release Notes (SRN), and Specific Customer information provided with the system whenever the equipment requires service or repair.

- **SCAT** – The **SitePro Controller** can be programmed to provide command and control of a **Single Channel Autonomous Trunking (SCAT)** Site.
- **CNI** – Programmed as a **Conventional Network Interface (CNI)**, the **SitePro Controller** provides the communication link between a conventional communications site (*analog*) and an EDACS trunking system (*digital*).
- **Satellite Receiver** – The **SitePro Controller** can be programmed to provide command and control of Satellite (*Auxiliary*) Receivers and communication to the Voter Digital Receiver.
- **Voter Digital Receiver** – The **SitePro Controller** can be programmed to process digital data from Satellite Receiver **SitePro Controller(s)** for input to the Voter Selector.
- **Voter Selector** – The **SitePro Controller** can be programmed to control the voting processes and select the sites with the best signals.
- **VDI** – Programmed as a **Voter Digital Interface**, the **SitePro Controller** provides a path for Voter and Simulcast systems to the Jessica PBX system when making digital calls.
- **Simulcast Control Point and Tx Site** – The **SitePro Controller** can be programmed to provide Simulcast system command and control.³

4.2 COMMUNICATIONS

The following communication modes are available:

1. The **SitePro Controller** can communicate with **Personal Computers (PC's)** through ethernet ports J5 and J6.
2. The **SitePro Controller** can communicate with other devices, such as Site Controllers or the CEC/IMC switch, through the Serial Ports at J14, using an RS-232 serial data format operating at 19.2 kilobaud. Connector J14 provides connection to 6 telephone lines and 6 serial ports.
3. The **SitePro Controller** can communicate with other **SitePro Controller(s)** in the Failsoft or Enhanced mode, over two **Backup Serial Links (BSL)** or two **Rockwell Modems (RM's)** through connector J4. This link uses 0-13.8 VDC levels at 19.2 kilobaud.
4. The **SitePro Controller** uses the **Frame Sync Line (FSL)**, also through connector J4, to communicate timing between **SitePro Controllers**. This line uses a 0-13.8 VDC bus that carries a periodic negative pulse.
5. A 9600 or 4800 baud full-duplex, synchronous communication interface over an RF Channel.
6. The **SitePro Controller** can use synchronous modem data to communicate with other sites via telephone lines or microwave links.
7. The **SitePro Controller** interfaces with an **Enhanced Digital Access Communication System (EDACS)** through 24 Pin connector J12.
8. Power is connected to the **SitePro Controller** through 4 Pin **POWER** connector J7.

³ Installation and configuration of Simulcast SitePro Controllers is documented in a specific Simulcast Application Manual.

9. The **SitePro Controller** interfaces with a Conventional MASTR III base station or Digital Signal Processor (DSP) through 20 Pin CONV/DSP connector J11.
10. The **SitePro Controller** interfaces with a GPS Simulcast system through 26 Pin SIMULCAST connector J13.



SitePro Controller interface functions vary from application to application and between EDACS systems using MASTR II or MASTR III repeaters. It is necessary to refer to the Application Configuration Manual for details regarding the specific hardware and software configuration of the **SitePro Controller**.

4.3 COMPATIBILITY AND MIGRATION

The **SitePro Controller** is compatible with Generic EDACS Trunking Card (GETC) compatible devices with the exception of the Site Controller.

The requirements are that the **SitePro Controller** will only switch modes if the Control Channel fails or a configuration command is received. The **SitePro Controller** will, however, change modes as currently implemented by the GETC. For example, the **SitePro Controller** Control Channel can switch modes, without failure or configuration command, if it detects carrier.

For High Speed Data Modulation, the **SitePro Controller** has a separate Analog Board (A4) providing software configurable filtering, which is compatible with high speed data types.

4.4 SYSTEM EXTERNAL INTERFACES

(SitePro Trunked Interface Specification)

The following is a description of all electrical connections to the **SitePro Controller**. All input/output definitions are relative to the **SitePro Controller**. This configuration supports EDACS and Simulcast. The analog and digital control signals provide an interface to a variety of base stations and are grouped by functionality.

4.4.1 Station Control

- **LocRxAudio** - Analog input
MASTR III level = 1 Vrms, Zin = 100Kohm, bias = ac coupled
MASTR IIe level = .750 Vrms
This signal is unfiltered local receiver audio from the base station also called Volume/Squelch or VolSq and carries either High Speed Data (control signaling/digital audio) or Low Speed Data with analog audio. The two components are internally separated.
- **RUS** - Digital TTL active high input
This signal is the Receiver UnSquelch signal from the base station and is activated when a carrier of sufficient signal strength (as determined by the squelch pot setting) is present.
- **LSD** - Analog output
level = 775 mVrms, Zout = 100ohm, bias = 0 volts

This signal is the Low Speed Data output to the base station. The signal is conditioned through a low pass filter to remove frequency components above 300 Hz to allow multiplexing with analog voice audio.

- **HSD** - Analog output

level = 775 mVrms, Zout = 100ohm, bias = 0 volts

This signal is the High Speed Data output to the base station modulator. The signal is conditioned through a specially designed filter needed to meet precise RF modulation bandwidth limitations.

- **LocPTT** - Digital active low open collector output

This signal is the Local PTT control. This line, when low, will key up the base station transmitter and select the local receiver audio source for transmission.

- **RemPTT** - Digital active low open collector output

This signal is the Remote PTT control. This line, when low, will key up the base station transmitter and select the remote audio source for transmission.

- **A/DmodCtrl** - Digital output TTL

This is the Analog/Digital Modulation Control signal. When high, HSD is routed to the base station transmit. When low, LSD/audio is routed to the base station transmit.

- **HSAcq** - Digital output open collector output

This is the High Speed Acquisition control signal. A high or low signal produces a corresponding high or low time constant in the limiter circuit.

- **LocRxMute** - Digital active low output (8.5 volt low Z source)

This signal is the Local Receiver Mute control. This line, when low, blocks the routing of receiver audio to the base station transmitter and line out. Muting occurs during HSD transmission, no valid carrier present, or no valid LSD present.

- **Walsh1/Walsh2** - Digital output TTL

These two signals are combined to form a two bit Walsh Function DAC. This signal is the Low Speed Data source.

- **Synth_Clk** – Digital open collector output

This signal provides the clock source for loading the base station frequency synthesizer (required for MIIE). Data is clocked on the negative edge of the clock. The baud rate is approximately 2.4Kbaud.

- **Synth_Data** – Digital open collector output

This signal provides the data source for loading the base station frequency synthesizer (required for MIIE). Data is clocked on the negative edge of the clock. The baud rate is approximately 2.4Kbaud.

- **Synth_LdEn** – Digital open collector output

This signal is the Synthesizer Load Enable control. This line, when high, permits the base station frequency synthesizer to be loaded and is used for protection against invalid transitions on the clock and data lines.

- **Synth_Locked** – Digital TTL active high input

This is the Synthesizer Locked signal. This line, when high, indicates that the base station synthesizer is locked. This is used for verifying successful synthesizer loading and is also continuously monitored as a failure mode.

- **PAFail** - Digital TTL active high input diode isolated with pullup

This is the Power Amp Failure indicator. This line, when high, indicates that the base station PA has failed. A floating line asserts PA Fail.

- **RemAudioFlag** - Digital TTL active low input, diode isolated

This is the Remote Audio Present indicator. This line, when low, indicates that remote audio from the IMC is present. This is generated by the base station in response to 2175Hz or E&M from the IMC.

- **FSL** - Digital open drain bi-directional

output: 100 mA sink (low), 10mA source (high)

input: $Z_{in} = 1Kohm$

This is the bi-directional Frame Sync Line. The line is used as an output in the Control Channel and as an input in the Working Channel.

- **ADCin** – Analog input

level = 0 to 5 volts, $Z_{in} = 100Kohm$

This is the 8-bit Analog to Digital Converter (ADC) input. This may be used to monitor station PA power.

4.4.2 Simulcast Control

- **ext_PTT** - Digital TTL active low input, diode isolated

This is the external source for Local PTT and is only active in a Simulcast configuration.

- **ext_A/Dmodctrl** - Digital TTL active low input, diode isolated

This is the external source for the Analog/Digital modulation control and is only active in a Simulcast configuration.

- **ext_150** - Digital TTL active low input, diode isolated

This is the external source for Low Speed Data and is only active in a Simulcast configuration.

- **ext_9600baud** - Digital TTL active low input, diode isolated

This is the external source for High Speed Data and is only active in a Simulcast configuration.

- **bypass** - Digital TTL active low input, diode isolated

This is the Simulcast bypass control signal. This line, when low, forces the site to operate in non-Simulcast mode and is driven by the Simulcast control equipment.

- **inhibit** - Digital TTL active low input, diode isolated

This signal is the Simulcast alarm indicator. This line, when low, indicates the presence of a Simulcast alarm and is driven by the Simulcast control equipment.

- **txclk_in** - Digital TTL active low input, diode isolated

This is the external source for High Speed Clock and is only active in a Simulcast configuration.

- **txclk_alarm** - Digital TTL active high output

This signal is the Simulcast Tx Clock alarm indicator. This line, when high, indicates that the external source for High Speed Clock is missing and is only active in a Simulcast configuration.

4.4.3 Conventional Control

- **CPTT** – Digital open collector output

This signal is the Combined PTT control. This line, when low, will key up the base station transmitter.

- **TxCGDis** – Digital open collector output

This signal is the Transmit Channel Guard Disable control. This line, when low, prevents the transmission of Channel.

- **CGMon** - Digital TTL active low input, diode isolated

This signal is the Channel Guard Monitor control.

4.4.4 Voter Control

- **vot_emsq** - Digital open collector output

This is the Voter E&M Squelch signal. This line, when low, indicates the presence of E&M from the Voter.

- **vot_rcvng** - Digital active low input

This is the Voter Receiving signal. This line, when low, indicates that the Voter is receiving.

4.4.5 Asynchronous Serial Ports

The following asynchronous serial ports provide control links to the SitePro.

Table 1 –Asynchronous Serial Ports

Port	Format	Function
ENet0	Ethernet 10baseT	Management
ENet1	Ethernet 10baseT	Spare
SCC1	RS232 19200 8N1	MASTR III
SCC2	RS232 19200 8N1	Spare
SCC3	RS485	Spare
Com1	BSL 38400 8N1	BSL
Com2	BSL 38400 8N1	BSL
Com3	RS232 19200 8N1	Spare
Com4	RS232 19200 8N1	Spare
SMC0	RS232 19200 8N1	Program/Debug
SMC1	RS232 38400 8N1	Spare

4.4.6 Synchronous Serial Ports

The following synchronous serial ports provide data and control paths from the **SitePro** to the base station (High Speed Data), to the IMC (Phone Line), and to optional Voter equipment (VDI).

Note that SSP0 is a new interface port providing unfiltered high speed data to/from a DSP based modulator.

Table 2 - Synchronous Serial Ports

Port	Format	Function	Signals
SSP0	4800/9600 baud	Local (RF) Comm Link	TxData, TxClock RxData, RxClock
SSP1	9600 baud	Remote (PL) Comm Link	TxData, TxClock RxData, RxClock CTS, RTS
SSP2	9600 baud	Voter (VDI) Comm Link	TxData, TxClock RxData, RxClock CTS, RTS

4.4.7 Power

- **+13.8V** - power supply input
+13.8 volts, 1.5 amps (nominal), input range 10 to 30 volts

This signal is the positive voltage supply for the **SitePro Controller** and should be

externally fused. An internal switching DC-DC converter will be used to supply +/- 12 and +5volts to the **SitePro Controller** sub-components.

- **GND** – power supply input

This signal is the ground connection for the **SitePro Controller**.

11.DESCRPTION

The **SitePro Controller** is essentially a processor with audio filtering and specialized I/O capability. Flexibility in design allows the **SitePro Controller** to be configured to function in many applications as suggested in the **INTRODUCTION**. Except for Configuration Data, the **SitePro Controller** software is stored in *flash* memory. Configuration Data is stored in **NO**nVolatile **R**andom Access Memory (**NOVRAM**).

The Controller Board, Rockwell Modem, Analog Board, Power Supply, Display Module, and Display Board are mounted on a tray and enclosed in a slide-out shelf (*Figure 1*). The **SitePro Controller** shelf is a one-rack unit assembly (1.75-inches x 19-inches), which mounts in a standard 19-inch wide equipment cabinet/rack.

Controller Board A2 uses Dual High Speed Diodes BAV99's for lightning protection on all RS-232C inputs and outputs. However, maximum lightning protection is achieved when the **SitePro Controller** is grounded to the cabinet earth-ground using Lightning Protection Circuitry Ground Kit 344A4500 and the Cabinet Grounding strap Kit 344A4730. Specific details for installing these grounding kits are found in the **LIGHTNING PROTECTION** section **LIGHTNING PROTECTION GROUNDING** of this manual.

5.1 INDICATORS AND CONTROLS

This section describes the indicators and controls visible and accessible from the front panel of the **SitePro Controller** Shelf Assembly.

There are two hinged doors on the front panel of the shelf assembly. Each door has a window so that indicators mounted on Control Board A2 and Rockwell Modem Interface Card A3 can be seen. Opening the Control Board door provides access to **Reset Pushbutton** switch S1. This door also provides access to **PROGRAMMING SERIAL PORT** J8. The circuit boards can be removed from the shelf assembly through these doors. An extender card can be inserted providing access to a board in a hot system.

5.1.1 Indicators

5.1.1.1 Controller Board Power Indicator

Green LED indicator D12 provided on the Controller Board indicates when power is applied to the shelf. This indicator is visible through the window in the hinged door on the front panel of the shelf.

5.1.1.2 Controller Board Status Indicators

Four Red LED status indicators L1 thru L4 (D1 thru D4) are visible through the window in the hinged door. These indicators show the state of operation of the **SitePro Controller**. The interpretation of these indicators depend on the system application (*refer to the **SitePro Controller** configuration manual for the specific application*).

Green **ETHERNET** indicators **ETH0** and **ETH1** are also visible through the window in the hinged door. These indicators indicate when something is connected to **ETHERNET 1** or **ETHERNET 2** ports.

There are six other LED indicators on the Controller Board that are not visible unless the board is on an extender board. Yellow LED's D7 and D10 indicate when there is transmit activity. Yellow LED's D6 and D9 indicate when there is receive activity. Green LED's D5 and D8 indicate when there is link activity (*refer to the 10 Base-T Transceiver section and the 10/100 Base-T Transceiver sections*).

5.1.1.3 Rockwell Modem Interface Card Indicators

There are five Red LED indicators on Rockwell Modem Interface Card A3. These LED's are visible through the window in the hinged door and indicate +5V, +12V, -12V, RLDS and CTS respectively.

5.1.1.4 Display

Eight-digit LED Display Board A6-A1 mounts between the two hinged doors on the front panel of the **SitePro Controller** Shelf Assembly. Green LED D1 indicates **POWER ON** to the Display Board. This display displays Channel Status and Channel Information.

5.1.2Controls

Reset Pushbutton Switch S1 is the only control available on the front panel of the **SitePro** Shelf Assembly. It is used to restart the logic of the **SitePro Controller**. It is especially useful when a circuit board has been hot swapped.

5.2ROCKWELL MODEM

The 9600 Baud Rockwell Modem Board RYTUZ 921 01/1 mounts on top of Modem Interface Card A3 (ROA 117 2247). This Modem Board is used to generate a fast-train, synchronous, serial data stream suitable for transmission over audio (phone) line or microwave link. The data stream is sent to a full-duplex, four-wire, dedicated 3002 grade telephone line.

Controller Board A2 (CB101069V1) controls the associated modem to provide a high speed synchronous serial interface between the **SitePro Controller** and other EDACS elements. Receive and Transmit Phone Data Lines are two balanced pairs carrying Modem data to and from the station where the data is combined with station audio (voice) and routed to the Remote Line input and Line output.

In addition to transformer isolation and conditioning provided by the **SitePro Controller**, the modem provides automatic adaptive signal equalization, allowing normal operation using input signal levels from -40 dBm to 0 dBm. The Rockwell Modem demodulates the input signal and the resulting data is transferred using a serial interface between the Rockwell Modem and the controller.

The modem senses a received signal by initiating a training state upon detecting an increase in the input signal level. The modem begins processing data at the end of the training state if the input signal is still above the nominal -40 dBm receiving threshold value. Otherwise, the modem returns to an idle mode at the end of the training state if the input signal is below the nominal receiving threshold value.

The duration of the modem training state is determined through control signals at the time of power up. Resetting the **SitePro Controller** (*pressing S1*) or cycling the **SitePro Controller** shelf operating power, initializes the Rockwell Modem for proper operation.

5.3 LOW SPEED AND HIGH SPEED DATA FILTERS

The **SitePro Controller** has software configurable high speed and low speed data filters. These filters are configured based on personality data.

5.3.1 Low Speed Data Decode Filter

The **Low Speed Data (LSD)** Decode Filter, part of Analog Logic Board A4, provides additional filtering to remove voice-audio from the receiver unfiltered audio (vol/sq hi), thus leaving only the low-speed subaudible data for input to the microprocessor.

5.3.2 High Speed Data Encode Filter

The **High Speed Data (HSD)** Encode Filter, part of Analog Logic Board A4, selects only the high-speed data (4800 or 9600 baud) from the receiver unfiltered audio (vol/sq hi). This data can be control signaling or digital voice. The data is processed by the RF modem and passed on to the microprocessor.

5.4 INTERFACE CONNECTIONS

Table 3 - Interface Connections

Connector	Interface Connections				
J1	32 Pin connector interfaces with Controller Board CB101069V1.				
J2	32 Pin connector interfaces with Analog Board CB101070V1.				
J3	32 Pin connector interfaces with Rockwell Modem Interface Card ROA 117 2247.				
J4	2 over 2 BSL/RM (Rockwell Modem). This connector consist of four RJ11 connectors as follows: <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>RM 0</td> <td>BSL 1 QUART A</td> </tr> <tr> <td>RM 1</td> <td>BSL 0 QUART B</td> </tr> </table>	RM 0	BSL 1 QUART A	RM 1	BSL 0 QUART B
RM 0	BSL 1 QUART A				
RM 1	BSL 0 QUART B				
J5	Ethernet 0. Connects to external PC's.				
J6	Ethernet 1. Connects to external PC's				
J7	4 Pin Power connector (+13.8 VDC).				
J8	Programming connector on the front of Controller Board A2				
J9	Power Supply Output +12V, -12V and +5V. Cable W2 connects between J9 and J2 on Power Supply Module A5				
J10	Connects through cable A6-W1 to Display Module A6.				
J11	20 Pin connector for interfacing with a Conventional/DSP system.				

Connector	Interface Connections												
J12	24 Pin connector for connecting to an Enhanced Digital Access Communication System (EDACS)												
J13	26 Pin connector for interfacing with a Simulcast System.												
J14	6 over 6 phone lines and serial ports. This connector consists of twelve RJ11 connectors as follows: <table border="1" data-bbox="418 443 1219 569"> <tbody> <tr> <td>RM 0</td> <td>QUART C</td> <td>SCC4 RS 485</td> <td>SCC3</td> <td>80C323 PORT 0</td> <td>N/U</td> </tr> <tr> <td>RM 1</td> <td>QUART D</td> <td>SCC2</td> <td>SMC2</td> <td>80C323 PORT 1</td> <td>N/U</td> </tr> </tbody> </table>	RM 0	QUART C	SCC4 RS 485	SCC3	80C323 PORT 0	N/U	RM 1	QUART D	SCC2	SMC2	80C323 PORT 1	N/U
RM 0	QUART C	SCC4 RS 485	SCC3	80C323 PORT 0	N/U								
RM 1	QUART D	SCC2	SMC2	80C323 PORT 1	N/U								

5.5 COMMUNICATION LINKS

Communication Modes available to the **SitePro Controller** are:

1. The **SitePro Controller** can communicate with other devices such as the Site Controller, IMC, and RF Station. Communication occurs primarily through an RS-232C serial interface normally operating at 19.2 kilobaud. for a **SitePro Controller** interfacing with a **Site Interface Module (SIM)** this is set to 38.4 kilobaud.
2. The **SitePro Controller** can communicate with other **SitePro Controllers** in the Failsoft mode of operation, over a **Backup Serial Link (BSL)**. The link uses 0-13.8 VDC levels and operates at 19.2 kilobaud and is ordinarily used in a bus configuration. For a **SitePro Controller** interfacing with a SIM this is set to 38.4 kilobaud.
3. A timing signal called the **Frame Sync Line (FSL)** helps arbitrate the use of the BSL serial bus in the Voter configuration. The FSL is also used for timing purposes. In the the station configuration, FSL signals use 0-13 VDC levels to produce a periodic negative going pulse.
4. A 9600/4800 baud full-duplex, synchronous communication interface over an RF channel.
5. A 9600 baud phone line or microwave communication interface (*this may be RS-232 or modem data*) through a Rockwell Modem.



NOTE

SitePro Controller interface functions vary from application to application and between EDACS systems using MASTR IIe or MASTR III repeaters. It is necessary to refer to the Application Configuration Manual for details regarding the specific hardware and software configuration of the **SitePro Controller**.



4-Pin POWER, 20-Pin CONV/DSP & 20-Pin SIMULCAST Connectors




24-Pin EDACS, 4-Pin POWER & 20-Pin CONV/DSP Connectors



Ethernet, SERIAL PORT & BSL/RM Connectors

Back Views



Top View



Front View

Modem Daughter Board

~~CIRCUIT~~

Power Supply (A5)

Figure 1 - SitePro Controller Shelf Assembly

6.0 CIRCUIT ANALYSIS

The Theory of operation of each circuit board/card and module used in **SitePro Controller** Shelf Assembly EA101209V1 is described in the following paragraphs. Refer to the Block Diagram in Figure 2 and Outline and Schematic Diagrams as listed in the **TABLE OF CONTENTS**.

The **SitePro Controller** is a Base Station Controller with redundant communication links [**Backup Serial Links (BSL's)**]. The BSL's provide for inter-channel communication with two 10Mbit Ethernet Ports. The BSL's provide trunking communications as well as site configuration and database messaging. One Ethernet port is dedicated to Management System information. The second Ethernet Port is *not* supported at this time.

The **SitePro Controller** and **System Interface Module (SIM)** will use the primary BSL for trunking information and limited management system information. The secondary link will ensure continued trunking operation in the event of a primary BSL failure

The **SitePro Controller**/base station interface for digital information, both receive and transmit, is 9.6k baud synchronous data. Additional digital control information is provided via discrete I/O at both the base station and controller. The following diagram (Figure 2) is a high level picture of the **SitePro Controller** and external interfaces.

The **SitePro** Controller, main controller board (A2) and AMPS modem board, replaces the CPTC GETC.

6.1 SHELF ASSEMBLY

SitePro shelf Assembly EA101209V1 is a 19" Rack Mount, one Rack Unit device. It is enclosed to reduce emissions and interference with other devices. Serial, Ethernet, power, and I/O connections are accessible at the back of the shelf (*Figure 1*). The Serial connections (**6 OVER 6 PHONE LINES & SERIAL PORTS**) are stacked, two high using RJ type connectors (J14). The Ethernet connectors J5 & J6 (**ETHERNET 0 & ETHERNET 1**) are single height RJ connectors. The power connector (J7) and I/O connector (J#) are Molex type.

The front panel has two hinged access doors for insertion/removal of the Controller Board and the Rockwell Modem card for troubleshooting and ease of maintenance. These doors have RF fingers to reduce emissions. Diagnostic LED's and the eight-digit display are viewable from the front panel.

The Shelf Assembly consists of Interconnect Board A1, which provides connectors to accommodate:

- Controller Board CB101069V1 (A2)
- Rockwell Modem Interface Card Assembly ROA 117 2247 (A3)
- Analog Board CB101070V1 (A4)
- Power Supply DP1719 (A5)
- Display Module MA101082V1 (A6)

SitePro Interface




Figure 2 - SitePro Shelf Assembly Block Diagram

6.2 INTERCONNECT BOARD (A1)

Interconnect Board CB101073V1 is a passive printed circuit board that provides interconnections between all internal components of the SitePro Controller shelf and interfaces the SitePro Controller shelf with the outside world (Refer to **Table 3 - Interface Connections**, and Interconnection, Outline and Schematic Diagrams). Pi filters U1 thru U29 eliminate any Electro Mechanical Interference (EMI).

6.3 CONTROLLER BOARD (A2)

Controller Board CB101069V1 contains all **SitePro Controller** logic and control functions except the power supply and Rockwell Modem (Refer to the Outline and Schematic Diagrams for the Controller Board as listed in the **TABLE OF CONTENTS**).

This Controller Board is based on an MPC860 microprocessor, the primary responsibility being message processing. This board has multiple high-speed serial ports, two of which are used for primary and secondary BSL's. It has hardware and dual port RAM to support the Modem Board and a 10/100 Mbit ethernet port. This port is available for Voice Over IP traffic. A second 10 Mbit ethernet port is available for management functions.

This board has sufficient memory to support 1M LID's and 64k GID's. It has LID and GID validation for all calls.

6.3.1 Block Diagram

Figure 3 – Controller Board Block Diagram shows the connection of major components from a high level viewpoint. Schematic Diagram WD-CB101069V1, Sheet 2 also provides a Block Diagram for the Controller Board. These diagrams show the major components of this board as:

- CPU (MPC860P)
- Ethernet 10 Base T
- Ethernet 10/100 Base T
- EEPROM
- Daughter Board
- Memory
- Electronically Programmable Logic Device (EPLD)
- Quad UART (QUART)
- Interconnect Board

6.3.2 System I/O

The System I/O circuits for the Controller Board are shown on Schematic Diagram WD-CB101069V1, Sheet 3 and include:

- Oscillator For PHY's
- JTAG Port
- Board Insert Detection Circuit
- 3.3V Power Monitor
- Test Points
- Programming Serial Port J8

- Hot Swap Controller
- 3.3V Regulator
- Decouplers




Figure 3 - Controller Board Block Diagram

6.2.1 Oscillator For Ethernet PHY'S

This circuit consists of crystal oscillator circuit Y1 powered by 3.3 V applied to Y1, Pin 4, Vcc. Oscillator circuit Y1 is biased on by resistor R49 connected to Y1, Pin 3, CTRL and produces 25 MHz on the output at Pin 3 through resistor R51 (OSC 25MHz). This output connects to the **CLK25** inputs to the Ethernet 10 and Ethernet 10/100 Mbit PHY's⁴.

6.2.2 JTAG Port

This JTAG PORT circuit consists of buffer U1 (NC7SZ125M5). This circuit allows programming directly to a microprocessor through connector J4.

The JTAG port is also routed to the Modem Daughterboard. This allows a future modem daughterboard to be designed with an Altera EPLD. If that future EPLD modem daughterboard is used, resistor R187 (0 ohms) must be removed from the board.

6.3.2.3.1 Board Insert Detection Circuit

This circuit consists of NPN transistors Q6 and Q7. When the Controller Board is inserted into a live Interconnect Board, the base circuits of these transistors are connected to ground through connector J1B, Pins B1 and B32. Connector J1B, Pin B1 is MATE-DETECT-A and J1B, Pin B32 is MATE-DETECT-B. With the base of both transistors at ground, they are held in the off state. This allows POWER ON to cycle high and low as the result of 555 timer U40 running at a programmed rate. The POWER ON voltage is applied to Pin 2 of Hot Swap™ Controller U37. If the base of either transistor (Q6 or Q7) is not connected to ground, POWER ON will not be applied to the HotSwap Controller.

6.2.4 Hot Swap™ Controller

Hot Swap™ controller (HSC) U37 allows Controller Board CB101069V1 to be safely inserted in or removed from Interconnect Board CB101073V1 while voltage is applied. Using external N-channel pass transistor Q5, the supply voltage to the Controller Board is ramped up at a programmable rate. A high side switch driver controls the N-channel gate for supply voltages ranging from 2.7V to 12V. A programmable electronic circuit breaker protects against shorts. The RESET output (U37, Pin 1) is used to generate a system reset when the supply voltage falls below the programmable voltage. The POWER ON input to U37, Pin 2 is used to cycle the Controller Board power or to generate a soft reset.

6.2.5 3.3V Regulator

The microprocessor is provided with 5 Volts and ±12 Volts from the Interconnect Board. Linear regulator U25 is used to provide 3.3 volts to be used by the majority of digital logic on the Controller Board and the Daughter Board.

The Hot Swap Controller (HSC) is used to ramp up the 5V power rail at a controlled rate. This, in addition to other considerations, will allow the Controller Board to be hot-swappable. The 5V output from this circuit will also power the 3.3 Volt regulator, thus

⁴ PHY is an Industry Standard for "Physical Interface."

causing the 3.3 V power rail to also ramp up at a controlled rate. As mentioned above, the HSC has a built-in electronic circuit breaker. The 555 timer circuit (U40) is connected to the HSC chip so that the HSC can be automatically reset in the case of a circuit breaker fault.

6.2.6 3.3V Power Monitor

The 3.3V Power Monitor (U31) uses a precision temperature-compensated reference and comparator circuit to monitor the status of the 3.3V supply. If a loss of power is detected an internal power-fail signal forces reset to the active state, which is low. When the 3.3V supply returns to a normal state, the reset signal is kept active for approximately 150 ms to allow the power supply and microprocessor to stabilize. This 3.3V Power Monitor circuit also monitors Reset Pushbutton S1 on the reset output, U31, Pin 1. If the reset is pulled low, by pressing S1, a reset signal is generated upon release. The output of U31 is held in reset output (low) for approximately 150 ms.

6.2.7 Test Points

Test Points TP1 thru TP10 are provided on the Controller Board as follows:

- TP1 thru TP3, TP7, TP8 and TP10 are ground connections
- TP4 is +12V
- TP5 is +3.3V
- TP6 is +5.0V
- TP9 is WALSHCLK

- **Programming Serial Port J8**

This port (J8) is located at the front of the Controller Board just behind the hinged door. It is provided so that a programmer can easily program the microprocessor from the front of the **SitePro Controller** without removing it from the cabinet.

6.2.9 Decouplers

Decoupling capacitors (Decouplers) are used to eliminate high-speed transient noise in high-speed digital circuits. There are a number of decoupling capacitors used on the Controller Board. On sheet 3 of Schematic Diagram WD-CB101069V1 there are two 3.3V decoupling capacitors, C2 and C87. On sheet 5 there are three 3.3V decoupling capacitors, C62, C83 and C113. There are also six 5.0V decoupling capacitors on sheet 5, C52, C74, C103, C104 and C110. On sheet 6 there are four 5V decoupling capacitors, C69, C81, C102 and C109. On sheet 7 there are three 5V decoupling capacitors, C76, C92 and C101. On sheet 9 there are ten CPU DECOUPLING CAPS, C8, C11, C12, C16, C27, C28, C39, C48, C51 and C71. On sheet 11 there are ten 3.3V decoupling capacitors, C26, C38, C61, C67, C76, C88, C89, C98, C99 and C100. There is also one 5.0V decoupling capacitor on sheet 11, C55. On sheet 12 there are ten 3.3V decoupling capacitors, C29, C30, C33, C34, C37, C40, C43, C58, C59 and C50. On sheet 13 there are ten 3.3V decoupling capacitors, C3, C4, C6, C7, C9, C13, C17, C22, C23 and C24. On sheet 14 there are three 5V decoupling capacitors, C64, C70 and C86. On sheet 15, there are five decoupling capacitors, C1, C5, C15, C18 and C21. On sheet 16 there are

five 3.3V decoupling capacitors, C32, C36, C42, C47 and C56. On sheet 17 there are four 3.3V decoupling capacitors, C77, C90, C91 and C105.

6.3.3 Blackplane

The Controller Board to Interconnect Board A1 (Backplane) connector circuits are shown on Schematic Diagram WD-CB101069V1, Sheets 4-7 and include:

- Board Connections
- Serial I/O
- I/O (1)
- I/O (2)

6.3.1 Board Connections

Schematic Diagram WD-CB101069V1, Sheet 4 shows the single DIN96 connector, J7. This 96-pin connector has three layers of pins, J7A, J7B and J7C. Each layer consists of 32 pins. J7B, Pins 1 and 32 are the MATE-DETECT-A and MATE DETECT-B connections. These two connections are used with the Board Insertion Detection circuit. Pins J7B; Pins 27 and 28 are the SCL and SDA connections. SCL and SDA make up the I²C bus. CPU I/O SIGNAL PROTECTION DIODES D27, D29 connected to SCL and SDA provide lightning protection for the I²C bus.

6.3.2 Serial I/O

Numerous asynchronous and synchronous serial ports are brought to the Interconnect Board (Backplane) from the microprocessor, Modem Daughter Board and QUART. Most serial ports convert to standard RS-232 levels using RS-232 transceivers U13, U24, U30 & U36. Serial port U21 converts to RS-485 differential signal levels and supports a multidrop network. One microprocessor RS-232 port is intended to be used as a diagnostic or local programming port and will be brought to RJ-11 connector J8 on the front of the board in addition to the I/O Interconnect Board. Two ports from the QUART use BSL signaling.

All Serial ports are designed for full-duplex 115.2 kbaud communications with the exception of the RS-485 port U21 from the microprocessor SCC. This port is a half-duplex HDLC port and supports speeds up to 2 Mbaud.

U21 is a differential bus transceiver for bi-directional data communication on multiport bus transmission lines. This device combines a 3-state differential line driver and a differential input line receiver. The driver and receiver have active-high and active-low enables that are connected together externally to function as a direction control. The driver differential outputs and the receiver differential inputs are connected internally to form differential input/output I/O bus ports. These ports are designed to offer minimum loading to the bus when the driver is disabled or V_{cc}=0.

BSL signaling is accomplished through two identical circuits consisting of hex inverting Schmitt Triggers U23A/U23B, inverter buffer drivers U35A/U35B, Field Effect Transistors (FET) Q3/Q4, amplifier transistors Q9/Q10 and diodes D23/D25. Inputs to the microprocessor from the Interconnect Board (backplane) are through diode D23/D25 to the input of U23A/U23B. Schmitt Trigger U23A/U23B provides a well-defined output for an input to the base of amplifier transistor Q9/Q10. The output of Q9/Q10 (RXA/RXB) is applied to the microprocessor. When the input (BKP-BSL0/BSL1) is high, diode D23/D25 is reversed biased making the input to U23A/U23B high and the output on the collector of Q9/Q10 also high. When the input is low, diode D23/D25 is

forward biased and the input to U23A/U23B is low. The output on the collector of Q9/Q10 is also low.

Outputs from the microprocessor to the backplane are through inverter buffer driver U35A/U35B, and FET Q3/Q4. The output RXA/RXB from the microprocessor is applied to the input of inverter circuit U35A/B35B. When this input to U35A/B35B is low, the output is high. This causes Q3/Q4 to conduct. Diode D32/D33 is forward biased and the output to BKP-BSL0/BSL1 is low. When the input to U35A/U35B is high Q3/Q4 does not conduct and the output to BKP-BSL0/BSL1 is high.

6.3.3 I/O

Other I/O's are shown on Schematic Diagram WD-CB101069V1, Sheets 6 and 7. Inputs to the microprocessor from the backplane consists of identical circuits for different inputs. These circuits consist of inverter buffer driver circuits U18A thru F, Schmitt Triggers U22B thru D and U23C thru F (Figure 4). Identical circuits for different inputs also include inverter buffer driver circuits U22A thru F, U29D and U32B (Figure 5).

In Figure 4 when the input from the backplane goes low the diode is forward biased and the input to the inverter goes low. This results in a sharp, well-defined output of the inverter going high. Outputs are:

- REM-AUDIO PRESENT (U18A)
- CAS (U18B)
- CGMON (U18C)
- LSDIN (U18D)
- PAFAIL (U18E)
- FSLIN (U18F)
- EXTPTTIN (U22B)
- EXTADIN (U22C)
- EXT150IN (U22D)
- RCVING-FROM-AV (U23C)
- SYNTH-LOCK DET (U23D)
- SIMULCAST-INHBIT (U23E)
- BYPASS (U23F)
-




Figure 4 - Input Circuits U18A thru F, U22B thru D and U23A thru F

In Figure 5 the Schmitt Trigger provides a sharp, well-defined input to the microprocessor




Figure 5 - Input Circuits U22A thru F, U29D and U32B

The FSL output from the microprocessor to the backplane is accomplished through inverter circuit U33A and FET Q2 (BKP-FSL).

The RX-MUTE output from the microprocessor to the backplane is accomplished through Inverter U33D and transistor circuit Q1 (BKP-RX_MUTE).

The EMSQTOAV output from the microprocessor to the backplane is accomplished through Inverter U35C and transistor circuit Q6 (BKP-EMSQTOAV).

Other outputs from the microprocessor to the backplane are connected through identical circuits as shown in Figures 6 & 7. Figure 6 shows circuits using Schmitt Triggers U29B, C, E, F and U32A & C to provide sharp, well-defined outputs to the backplane. These outputs are:

- BKP-WALSH1 (U29B)
- BKP-WALSH2 (U29C)
- BKP-A/DMODCTL (U29E)
- BKP-RFTXDAT (U29F)
- BKP-RFTXCLK (U32A)
- BKP-LSDOUT (U32C)




Figure 6 - Output Circuits U29B, C, E & F, U33C, E & F and U34A thru F

Figure 7 shows circuits using open collector inverters circuits U33B, C, E, F, U34A, B, C, D, E, F and U35C, D, E & F. These outputs are:

- BKP-SYNTH_DATA (U33B)
- BKP-SYNTH_DATA_CLK (U33C)
- BKP-RPTKEY (U33E)
- BKP-SPARE2 (U33F)
- BKP-CPTTOUT (U34A)
- BKP-SPARE1 (U34B)
- BKP-STNPTT (U34C)
- BKP- (U34D)
- BKP- (U34E)
- BKP- (U34F)
- BKP- (U35C)
- BKP- (U35D)
- BKP- (U35E)
- BKP- (U35F)




Figure 7 - Output Circuits U33B, C, E, F, U34A, B, C, D, E, F and U35C, D, E & F

6.3.4CPU

The Central Processing Unit (CPU) circuits for the Controller Board are shown on Schematic Diagram WD-CB101069V1, Sheets 8 & 9 and include:

- Microprocessor
- Microprocessor Support

6.3.4.1 Microprocessor

Microprocessor U9A is a Motorola MPC860P processor that has four SCC channels, two SMC channels, plus a 100 Mbit Fast Ethernet Controller. One of the SCC channels is used as a second ethernet port (10 Mbit) with all other SCC and AMC channels used as serial ports.

This microprocessor runs at 59 MHz using a 29.4912 MHz clock input. This frequency was selected for use by the baud rate generators to produce standard baud rates up to 115.2 kbaud without error. The microprocessor external bus runs at half the speed of the microprocessor (29.5 MHz).

The microprocessor provides a real-time clock that is used to provide time-of-day information to the application software. The real time clock runs off of a 32.768 kHz crystal and is provided with 3.0 Volt battery voltage via the **KAPWR** pin of the microprocessor to keep time when power is off.

Four external interrupts are used in this design. The remaining unused three connect to the EPLD for future use. Connecting them to the EPLD makes later modifications easier. The external interrupt signals are specified in the following table.

Table 4 - External Processor Interrupt Signals

Device	IRQ
(SPARE-EPLD)	IRQ (NMI)
QUART	IRQ1
MODEM DB DUAL-PORT RAM	IRQ2
(SPARE-EPLD)	IRQ3
ETHERNET 10/100	IRQ4
ETHERNET 10	IRQ5
(SPARE-EPLD)	IRQ6

All but one chip select are used in this design. The unused chip select is connected to the EPLD for future use. The microprocessor chip select signals are defined in the following table.

Table 5 - External Processor Interrupt Signals

Device	IRQ	Machine	Data Bus Width
FLASH	CS0	GPCM	32 Bit
SDRAM	CS1	UPMA	32 Bit
QUART REGISTERS	CS2	GPCM	8 Bit

Device	IRQ	Machine	Data Bus Width
QUART INTERRUPT VECTOR	CS3	GPCM	8 Bits
EPLD	CS4	GPCM	8 Bits
MODEM DB DUAL PORT RAM	CS5	UPMB ⁵	8 Bits
MODEM DB CODE RAM	CS6	GPCM	8 Bits
(SPARE-EPLD)	CS7	N/A	N/A

Note that there is both a 32-bit data bus and an 8-bit data bus. The 8-bit data bus is connected to the 32-bit processor data bus via an 8-bit transceiver. The output enable for the transceiver is controlled by ANDing all 8-bits chips selects together inside the EPLD.

6.4.2 Microprocessor Support

The microprocessor support as shown on Schematic Diagram WP-CB101069V1, Sheet 9 includes:

- BDM Debug Port Connector
- Power-On Reset Configuration
- 32 kHz Crystal
- VDDSYN Filter
- Silicon Serial Number
- KAPWR Switch
- 8-Bit Bus Transceiver
- MICTOR Logic Analyzer Connectors

BDM Debug Port Connector

For support, microprocessor U9A provides a dedicated serial port (BDM) for connecting a debugger/emulator. A debugger/emulator connected to this port allows a programmer to read/write registers and external peripherals, control program execution, etc. Many debuggers also have built-in capability to program on-board flash through this port. These serial port pins are brought to 10-pin header J1 using the standard BDM pinout

Power-ON Reset Configuration

The Power-On Reset Configuration consists of four octal buffer/drivers U6A, U6B, U8A and U8B with 3-state outputs. This circuit ensures that at Power-On all circuits are reset to the starting state. Inputs to these circuits are through 10K BUS8 resistor networks RN7 and RN10. The outputs tie into bus D[0.31]. Each package is organized as two 4-bit line drivers with separate output-enable (OE) inputs. These inputs are tied together and connect to RESET-N. When RESET-N is low, data passes from A inputs to Y outputs. When RESET-N is high, the outputs are in the high-impedance state.

32 kHz Crystal

This crystal circuit consist of crystal package Y3, resistors R90 and R98, capacitors C49 and C63. This circuits connects to U9A between pins N1 (EXTAL) and P1 (XTAL) and produces an oscillator frequency of 32.768kHz to drive the real-time clock.

⁵ UPMB is only required if the system makes use of the BUSY_N signal coming from the dual port memory. If BUSY_N is not used, then a GPCM machine can be used for this chip select.

29 MHz Clock

The 29 MHz Clock consists of oscillator circuit Y2 and resistors R82 and R105. This circuit produces the oscillator frequency of 29.4912 MHz and connects to U9A at N2 (EXTCLK).

VDDSYNC Filter

This circuit consists of inductor L1 and capacitors C50 and C57. It connects between the 3.3V supply and the VDDSYN connection through capacitor C68 to microprocessor U9A, Pin T2 XFC. **The primary purpose of this circuit is to**

Silicon Serial Number

A unique 64-bit electronic Serial Number chip U3 is used to store the board identification number. This chip has a 1-bit serial port, which interfaces to microprocessor U9A through an I/O port. In addition, four bits of hardware identification are made available to U9A through I/O ports. The Hardware ID is changed based by selectively populating a bank of resistors.

KAPWR Switch

The KAPWR switch consist of Schottky diodes D30 and D31 and battery BT1. This switch applies 3.3V supply or 3.3V battery to U9A, Pin **KAPWR**

8-Bit Bus Transceiver

This circuit consists of 8-Bit Bus Transceiver U19 and resistor network RN15. The 8-Bit Bus connects to the microprocessor through 8-Bit Bus Transceiver U19. The output enable OE for the transceiver is controlled by ANDing all 8-bit chip selects together inside EPLD U27.

MICTOR Logic Analyzer Connectors

These connections consists of J3, J5 and J6.

6.3.5 Modem Daughter Board Connector

The Modem Daughter Board connector circuits for the Controller Board is shown on Schematic Diagram WD-CB101069V1, Sheet 10 and include:

- QUICC Connector (J1)
- I/O Connector (J2)

6.5.1 QUIC Connector (J1)

The QUICC (J9) connector contains the microprocessor interface (Refer to the Modem Daughter Board Section).

6.5.2 I/O Connector (J2)

The I/O (J2) connector has miscellaneous I/O to/from the EPLD or Interconnect Board (Refer to the Modem Daughter Board Section).

6.4.5 Electrically Programmable Logic Device (EPLD)

The EPLD circuit for the Controller Board is shown on Schematic Diagram WD-CB101069V1, Sheet 11.

Access to various board inputs/outputs is made available through Electronically Programmable Logic Device (EPLD) U27. The EPLD contains numerous read/write latches with a simple 8-bit interface to the microprocessor.

The EPLD is in-circuit programmable via the JTAG port using an Altera byte-blaster cable. A 10-Pin header is made available for this purpose. The EPLD JTAG port is also brought to microprocessor I/O pins to allow the microprocessor to load the EPLD configuration.

In addition to being an interface to the discrete I/O, the EPLD also divides clocks and provides the output enable logic for the 8-bit data bus transceiver.

6.7 Ethernet Ports

There are two Ethernet Port circuits for the Controller Board and they are shown on Schematic Diagram WD-CB101069V1, Sheets 12 & 13 as:

- 10 Base-T (10 Mbit PHY)
- 10/100 Base-T (10/100 Mbit PHY)

The 10/100 Mbit port (10/100 Base-T Transceiver U5) uses the Fast Ethernet Controller inside the microprocessor and supports full duplex (10/100 Base-T). The 10 Mbit port (10 Base-T Transceiver U12) uses SCC1 and only supports half-duplex (10 Base-T). The ethernet physical layer transceivers are the same for both ports, but the 10/100 Mbit port uses the MASTR II interface whereas the 10 Mbit uses a **“7-wire”** interface. The ethernet transceivers support 10/100 Base-T with full auto-negotiation capability, while the 10 Mbit port only advertises 10 Mbit capability.

The RJ-45 ethernet connectors are actually located on Interconnect Board A1 (Interconnect Board). The ethernet physical layer chips and transformers reside on the Controller Board with the ethernet differential RX/TX signals brought to the RJ-45 connectors through the Interconnect Board connector. A single LINK OK status LED is provided for each ethernet port on the front of the Controller Board.

The 10Mbit Ethernet port uses the **“7-wire”** interface to connect the Ethernet physical transceiver to the microprocessor SCC1 serial channel. When SCC1 is in Ethernet mode, the SCC pins have different functions (refer to the following table).

Table 6 - 10 Mbit Ethernet Connections

SCC Ethernet Signal	SCC Pin Name	PHY Signal
TX	TXD1	10TXD
TENA	RTS1	10TXEN

TCLK	CLKx	10TXCLK
CLSN	CTS1	10COL
RENA	CD1	10CRS
RX	RXD1	10RXD
TCLK	CLKx	10RXCLK

In order to use both the SCC1 in Ethernet mode and I²C bus, the board software applies a small microcode patch at startup. This relocates the affected overlapped registers. Make sure to use the new register addresses in the code. To obtain the patch, go to: http://www.mot.com/SPS/ADC/pps/subpgs/etoolbox/8XXX/i2C_spi.html.

6.4.6 I²C Bus

The I²C-bus is a two-wire serial bus (SCL and SDA) used for microcontroller-based control. The I²C Bus circuits for the Controller Board are shown on Schematic Diagram WD-CB101069V1, Sheet 14. These circuits consist of Personality EEPROM U14, and 8-bit I/O expanders for the I²C bus U15 and U26.

32k of non-volatile data storage is provided by EEPROM U14. EEPROM U14 is organized as 32kx8 and is accessible via the I²C port of microprocessor U9A.

Serial EEPROM U14 has a write protect pin. It is active high and has an external pull-up to always make it active. To write to U14, port PB23 on the microprocessor is defined as an output and driven low. To write protect the EEPROM after writing to it, port PB23 is defined as an input and the pull-up activates the write protect signal.

Several peripherals are available to the microprocessor through the I²C Bus. In addition to a 32kbyte EEPROM, there is an 8-bit writable latch for driving 4 LED's and an 8-bit readable latch for reading the status of an 8-bit DIP switch. The I²C bus is also brought to the Interconnect Board for accessing other off-board peripherals (i.e. LED display). I²C bus addresses are as follows:

Table 7 - I²C Bus Addresses

Device	Addresses
LED's	0x40
DIP Switch	0x46
EEPROM	0xA0
Digital Pot	0x50
ADC/DAC	0x9E
16-Bit Expander	0x4C
Display	0x4A

6.4.7 Memory

The Memory circuits for the Controller Board are shown on Schematic Diagram WD-CB101069V1, Sheets 15 & 16 and include:

- DRAM Circuits U2 & U7
- Flash Circuits U10 & U11

6.9.1 DRAM

Two 128-Mbit, 16 bit wide synchronous DRAM Integrated Circuit modules U2 and U7 are organized in a 4M x 32 configuration. These two modules provide a minimum of 16 Mbytes of storage, upgradeable to 64 Mbytes. The following table shows the MPC860P bank addresses for the different DRAM memory sizes.

Table 8 - DRAM Bank Memory Ranges

Bank	64-Mbit (DRAM)	128-Mbit (2xDRAM)	256-Mbit (SDRAM)
Bank 1	0x003FFFFFFF – 0x00000000	0x003FFFFFFF – 0x00000000 0x013FFFFFFF – 0x01000000	0x003FFFFFFF – 0x00000000 0x013FFFFFFF – 0x01000000 0x023FFFFFFF – 0x02000000 0x033FFFFFFF – 0x03000000
Bank 2	0x007FFFFFFF – 0x00400000	0x007FFFFFFF – 0x00400000 0x017FFFFFFF – 0x01400000	0x007FFFFFFF – 0x00400000 0x017FFFFFFF – 0x01400000 0x027FFFFFFF – 0x02400000 0x037FFFFFFF – 0x03400000
Bank 3	0x00BFFFFFFF – 0x00800000	0x00BFFFFFFF – 0x00800000 0x01BFFFFFFF – 0x01800000	0x00BFFFFFFF – 0x00800000 0x01BFFFFFFF – 0x01800000 0x02BFFFFFFF – 0x02800000 0x03BFFFFFFF – 0x03800000
Bank 4	0x00FFFFFFF – 0x00C00000	0x00FFFFFFF – 0x00C00000 0x01FFFFFFF – 0x01C00000	0x00FFFFFFF – 0x00C00000 0x01FFFFFFF – 0x01C00000 0x02FFFFFFF – 0x02C00000 0x03FFFFFFF – 0x03C00000

6.9.2 FLASH

Two flash memory modules U10 and U11 are organized as 1M x 32 for non-volatile program storage (*Flash*). These two modules have 4 Mbytes of flash memory with the ability of expansion up to 8 Mbytes. The program execution takes place directly from flash so that performance is as important as is the ability to load new code while in the lab and while in the field.

6.9.3 Quad UART

The QUART circuit for the Controller Board is shown on Schematic Diagram WD-CB101069V1, Sheet 17.

Universal Asynchronous Receiver-Transmitter (UART) U28 is used to handle asynchronous serial data communication. Asynchronous means that the data is *not synchronous*, that is, it is not occurring at a steady constant rate, but is being transmitted intermittently through serial ports. In data transmission, serial means, transmitting one bit at a time.

The serial port is a general-purpose interface that conforms to the Recommended Standard–232C (RS-232C) and can be used to interface with almost any type of device (modem, mouse and serial printer, etc.).

Quad UART (U28) is accessible to microprocessor U9A for four additional serial ports. QUART U28 runs off 3.3 volts, forcing the microprocessor interface to be asynchronous and run at 14.75 MHz, the microprocessor bus clock divided by 2 inside the EPLD. The communication clock input will be 3.6864 MHz, the microprocessor bus clock divided by 8 inside the EPLD. None of the I/O ports of the QUART will be used, but the ports are connected to mod points in case of a later use.

The QUART uses two chip selects, CS2 and CS3. Chip select CS2 is used when accessing the QUART registers. Chip select CS3 is used after an interrupt to read the interrupt vector.

6.5 MODEM DAUGHTER BOARD

The Modem Daughter Board contains three synchronous serial ports (modems) and a local microprocessor. This board plugs into the Controller Board using two connectors, QUICC (J9) and I/O (J2). Refer to **Figure 4 – Modem Daughter Board Block Diagram**.

The microprocessor interface is a simple 8-bit asynchronous port with two separate chip selects. One chip select controls access to an 8k x 8 dual port RAM. The other chip select controls access to the Modem Daughter Board microprocessor local memory. The Controller Board microprocessor loads the Modem Daughter Board local memory with code before releasing the Modem Daughter Board reset. The Modem Daughter Board microprocessor runs from a 14.7 MHz clock generated by dividing down the 29.5 MHz Controller Board microprocessor output clock inside the EPLD.

Circuits for the Modem Daughter Board are shown on Schematic Diagram WD-CB101074V1, Sheet 1. The Outline Diagram is shown on PS-CB101074V1.

Modem Daughter Board CB101074V1 mounts on the Controller Board and exists primarily to support Modem chips, U9, U10, and U11. These modems process 9600 baud serial synchronous receive and transmit data from the RF path (U9), the **Phone Line (PL)** path (U10) and the **Voted Digital Interconnect (VDI)** path (U11).

Microprocessor U1, a Dallas 80C323, controls the three modem chips, generates the transmit data, and processes the receive data for use by the system.

The microprocessor communicates with the QUICC processor on the Controller Board via Dual Port RAM U3.

There is no non-volatile memory on the Modem Daughter Board. Code is loaded into Code RAM (U2) via an interface from the QUICC processor.

Most of the circuitry on the Modem Daughter Board operates from a 3.3V supply. The Modem chips, however, require 5V. Thus a 3.3V to 5V conversion (U6) is needed for all signals to the Modem chips.




Figure 8 - Modem Daughter Board Block Diagram

6.1 Modems

Each Modem chip interfaces to the 80C323 microprocessor via an 8-bit bi-directional address/data bus, and Chip Select (CS/), Read (RD/), Write (WR/), ALE, and Interrupt (INT/) signals.

During transmit, the microprocessor writes data to the Modem as requested by the Modem interrupt. The Modem converts the data to a 9600 baud synchronous serial data stream.

During receive, the Modem chip receives the 9600 baud synchronous serial data stream and interrupts the 80C323 microprocessor whenever it has a complete byte to transfer. The modem must also acquire bit sync and word sync from the data stream.

6.2 3.3V/5V Interface

Because the Modems require a 5V supply, and the microprocessor is on a 3.3V supply, it is necessary to convert the voltage of signals passing between them. This is done by U6, an IDT74FCT164245 3.3V/5V converter. Both output enable and direction can be controlled for the two 8-bit sections of this IC.

In this case, the outputs are always enabled, so the OE/ pins are tied low. Section 1 is used for signals, which only go from the microprocessor to the Modems, so Pin 1 (1DIR) is tied high. Section 2 is used for the bi-directional bus. Pin 24 (2DIR) is driven by logic which sets the direction from microprocessor to Modems (high) most of the time. Only during a read of one of the microprocessors is the direction reversed (low).

6.3 Microprocessor

The 80C323 microprocessor is a 3.3V version of the Dallas Speedy micro, an 80C32 derivative. It operates on a 14.7462 MHz. Clock, which is convenient for generating standard baud rates. It interfaces with the Modems, Code RAM, Dual Port RAM, and Data RAM via standard address and data busses.

The microprocessor has 2 asynchronous serial ports (TXD0/RXD0 and TXD1/RXD1) which may be used in the **SitePro** system for diagnostics. Both ports are available on the rear of the **SitePro** shelf.

Six bits of 80C323 microprocessor I/O are used in a **SitePro** configuration. WALCLK, WAL1, WAL2, and HSACQCTL are outputs, while LSRX and MODFSL are inputs.

The microprocessor has only two level sensitive interrupts, INT0/ and INT1/. The first, INT0/, is used for all Modem interrupts. The second, INT1/, is used for interrupts from the Dual Port Ram.

Since it is still necessary to distinguish between the three Modem interrupts, RFINT/ and PLINT/ are brought to I/O pins so the microprocessor can easily determine which Modem is interrupting. i.e. If a Modem interrupt occurs, the microprocessor looks at the two pins. If either or both are low, the corresponding interrupts are serviced. If neither is low, the VDI interrupt is serviced.

The 80C323 (U1) uses standard Intel multiplexed address/data bussing. During the first half of the bus cycle, U7 latches the lower 8 bits of address under the control of ALE.

Address decoder U5 generates the Chip Selects for the three modems and the Dual Port RAM using signals RD/, WR/, A13, A14, and A15.

Table 9 - Memory Map

MEMORY MAP		
Device	Range	Size
Code RAM	0-FFFF	64K Bytes
Dual Port RAM	0-1FFF	8K Bytes
Data RAM	8000-FFFF	32K Bytes
RF Modem	2000-2003	4 Bytes
PL Modem	4000-4003	4 Bytes
VDI Modem	6000-6003	4 Bytes

6.4 Code Memory

Code is stored in 128K byte RAM U2. The microprocessor can then access it via the Address and Data bus using PSEN/.

Code is loaded into U2 from the QUICC microprocessor. During loading, the QUICC holds the 80C323 reset with the RESETIN/ (low) signal. This is required so the 80C323 will not try to access U2 at the same time causing bus contentions. During loading, bus transceivers U12 (address bus) and U13 (data bus) are turned on. They are held inactive at all other times by the same RESETIN/ signal.

The QUICC controls Code memory access through signals RESETIN/, R/WL, CODECS/ and CODE_A16. While RESETIN/ is held low, the QUICC can write or read U2. CODE_A16 can be used to control which 64K byte half of U2 is used. Thus, for instance, Control Channel code could be stored in one half and working channel code in the other. The switch is performed while the 80C323 is held reset, so it is entirely transparent to the 80C323.

When RESETIN/ is high, the bus transceivers U12 and U13 are off and the 80C323 controls the bus.

6.5 Data Memory

Data is stored in 128K byte RAM U4, however, only 32K is used. Chip select is A15/, thus the RAM is addressed in the upper half of memory space.

6.6 Dual Port Ram

Dual Port RAM U3, an IDT70V05 8K byte device, is the communication path between QUICC and 80C323 during normal operation. Either microprocessor can read or write any location in the RAM. Protocols must be established in software to avoid contention. The QUICC can interrupt the 80C323 by writing to Address [REDACTED]. This causes interrupt line INTR/ to go low. It is cleared by a read of the same address by the 80C323.

Likewise, the 80C323 can interrupt the QUICC by writing to address [REDACTED], which causes a QUICC interrupt on line INTL/.

The 80C323 accesses the DPR via its address and data busses using signals DPRCS/, RD/, WR/, and INTI/.

The QUICC accesses the DPR via its address and data busses using corresponding signals CEL/, R/WL/, OEL/, and INTL/.

6.7 Troubleshooting Aids

Several signals are available on diagnostic connector J3 for troubleshooting purposes. Also probe points are provided for GND, 5V, and 3.3V.

6.4 ROCKWELL MODEM INTERFACE CARD (A3)

7.0 QIUCC Connector

6.2 Dual Port RAM

6.3 Microcontroller

6.4 8-bit Latch

6.5 Address Buffer

6.6 Data Buffer

6.7 Code SRAM

6.8 Data SRAM

6.9 Page Connections

6.10 Address Decoder

6.11 Diagnostic Connector

6.12 3/5 Converter

6.13 I/O Connector**6.14 RF Modem****6.15 PL Modem**

Phone Line Modem

6.16 VDI Modem

Voted Digital Interface Modem

6.4 ANALOG BOARD (A4)

Analog Board CV101070V1 contains programmable high speed filters, low speed encode and high speed decode. This board includes Simulcast Interface hardware, which eliminates the need for the older Simulcast Interface Board in Simulcast applications. Refer to Outline Diagram PS-CB101070V1 and Schematic Diagram WD-CB101070V1.

6.5.1 Quad ADC and Single DAC

AD/DA Converter U23 is an 8-bit CMOS data acquisition device with four analog inputs, one analog output and a serial I²C-bus interface. Three address pins A0 (Pin 5), A1 (Pin 6) and A2 (Pin 7) can be used for programming a hardware address, allowing the use of up to eight devices to be connected to the I²C-bus without additional hardware. In this application, these three leads are tied to +5V. Address, control and data to and from the device are transferred serially through the two-line bidirectional I²C-Bus. The PWR SENSE lead is connected to analog input AIN0 at U23, Pin 1, converted to digital and connected to the I²C-bus.

6.5.28-Bit I/O Expander for I²C Bus

8-Bit I/O Expander U4 consists of a 16-bit two-line quasi-bidirectional port and an I²C-bus interface. The two-line I²C inputs SCL and SDA connect to U4, Pins 22 and 23 respectively. These two-line inputs can be monitored at Test Points TP2 and TP3. The expanded outputs and connections are U4, Pin:

- 4 (P0) – HS-FILTERSEL0 (Monitored at TP19)
- 5 (P1) – HS-FILTERSEL1 (Monitored at TP24)
- 6 (P2) – HS-FILTERSEL2 (Monitored at TP25)
- 7 (P3) – HSACOCTL1 (Monitored at TP26)
- 8 (P4) – LSCTL (Monitored at TP30)
- 9 (P5) - (Monitored at TP29)
- 10 (P6) – MODCTL (Monitored at TP28)
- 11 (P7) – LSDATAACC (Monitored at TP27)
- 13 (P10) - ground
- 14 (P11) - ground
- 15 (P12) - ground
- 16 (P13) – ground
- 17 (P14) - ground
- 18 (P15) – Connects to +5V through voltage divider network R127, Pin 8
- 19 (P16) – Connects through voltage divider network R127, Pin 7 to Pin 5 to U4, Pin 20 (P17)
- 20 (P17) – Connects through voltage divider network R127, Pin 5 to Pin 7 to U4, Pin 19 (P16)

6.5.3–5 Volt Generation

-5 Volt generation is accomplished through voltage regulator U2. -12 Volts is applied to U2, Pin 4 IN. Capacitors C3 and C4 provide filtering of this input. The output is at U2, Pin 3 Out. The -5 Volts is filtered by capacitors C5 and C6. -5Volts can be monitored at

Test Point TP31 by connecting the negative lead to TP31 and the positive lead to ground (TP32 or TP33).

6.5.4 High-Speed Data Transmit Filters

Buffer/follower circuit U6A precludes the quad operational amplifier high-speed data transmit filter circuits for RFTXDAT. The output of this circuit can be monitored at TP1. The output of U6A is applied to the inputs of high-speed Data Transmit Filters:

- 9600 Baud Wide Band
- 4800 Baud Narrow Band
- 9600 Baud Wide Band ETSI⁶
- 4800 Baud Narrow Band ETSI
- 9600 Baud Narrow Band Switched Capacitor Filter Circuit

The **High Speed Data (HSD)** filter is an active **Gaussian Minimum Shift Keying (GMSK)** filter that filters the data transitions to minimize the high-speed-data transmission bandwidth. The frequency response of the HSD filter section is changed by selecting the output of only one filter circuit by 8:1 MUX U7.

High-speed data is a 4800 or 9600 bit per second data stream generated by the microcomputer through the RF data modem U9 on the Modem Daughter Board.

Each of the HSD filter circuits has two sections.

6.5.4.1 9600 Baud Wide Band

This HSD filter circuit consists of operational amplifier U5B followed by operational amplifier U5A. The output of U5A, Pin 1 is applied to the input of 8:1 MUX U7, Pin 4 (N01). This HSD amplifier filter output can be monitored at TP4.

6.5.4.2 4800 Baud Narrow Band

This HSD filter circuit consists of operational amplifier U5C followed by operational amplifier U5D. The output of U5D, Pin 14 is applied to the input of 8:1 MUX U7, Pin 5 (N02). This HSD amplifier filter output can be monitored at TP5.

6.5.4.3 9600 Baud Wide Band ETSI

This HSD filter circuit consists of operational amplifier U10B followed by operational amplifier U10A. The output of U10A, Pin 1 is applied to the input of 8:1 MUX U7, Pin 6 (N03). This HSD amplifier filter output can be monitored at TP6.

6.5.4 4800 Baud Narrow Band ETSI

This HSD filter circuit consists of operational amplifier U510C followed by operational amplifier U10D. The output of U10D, Pin 14 is applied to the input of 8:1 MUX U7, Pin 7 (N04). This HSD amplifier filter output can be monitored at TP7.

⁶ European Technical Standards Institute

6.4.4 9600 Baud Narrow Band

This HSD filter circuit consists of switched-capacitor filter circuit U11 required to produce a flat frequency response. This circuit is driven by an external 400 kHz clock on U11, Pin 1. The output on U11, Pin 5 is applied to the input of 8:1 MUX U7, Pin 12 (N05). This HSD filter circuit output can be monitored at TP8.

6.5.68:1 MUX

Multiplexer circuit U7 is used to select the applicable HSD to be passed on to Dual Digital Potentiometer U8. The inputs to U7 are applied to N01 through N05 (Pins 4, 5, 6, 7 and 12). The selection of HSD is made by the HS-FILTER_SEL inputs on U7, Pin 1 (A0), Pin 15 (A1) and Pin 15 (A2). EN (Enable) on Pin 2 is connected to +5V. The 8:1 MUX output COM is on U7, Pin 8.

6.5.7Dual Digital Pot

The output of the MUX circuit connects to the input of Addressable Dual Digital Potentiometer U8, Pin 14 (HO). This device has two independently controlled potentiometers. Only one pot is used in this application. The wiper can be set to one of 256 positions and is controlled by the microprocessor through the I²C data bus SCL (Pin 9) and SDA (Pin 10). The output on Pin 12 (WO) connects to the input of amplifier circuit U6B.

6.5.8Inverting Buffer/Amplifier

Amplifier circuit U6B is an inverting buffer/amplifier with a gain of approximately 1.5. The output of this circuit is connected to the input of analog switch U9. The output of this circuit can be monitored at TP9.

6.5.9 Analog Switch

Analog Switch U9 is a Single-Pole/Double Throw (SPDT) with one normally closed and one normally open switch. Switching times are less than 175 ns max for t_{ON} and less than 145 ns max for t_{OFF} . Analog Switch U9 switches between RFTXDATA (U9, Pin 2 (S1)) coming from inverting Buffer/amplifier U6B and ANALOG AUDIO (U9, Pin 8 (S2)). S1, Pin 2 (RFTXDATA) is the normally closed contacts. The output is on U9, Pin 1 (D) MOD. This device is controlled by MODCTL on U9, Pin 6 (IN). +5V connects to U9, Pin 5, (VL). +12V connects through Diode D1 to U9, Pin 4 (+V) and -12V connects through Diode D2 to U9, Pin 7 (-V).

6.5.8Clock Generation

Clock generation is accomplished by inverter circuits U32C and U32D and Dual 4-Stage Binary Ripple Counter U3. U32C and 400 kHz crystal Y1 form a 400 kHz oscillator circuit. The output of U32C connects to the input of U32D. The 400 kHz clock (CLK) output of U32D connects to U3, Pin 1 (CP1). This 400 kHz CLK can be monitored at TP10. Counter U3 divides the 400 kHz CLK down to produce a 25 kHz CLK. This output can be monitored at TP11. The 400 kHz CLK is further divided down to produce a 3.125 kHz CLK. This output can be monitored at TP12.

6.5.9 Low Speed Data Decoder Filter

The Low Speed Data Decode Filter is used to remove voice-audio (300-3000 Hz) leaving only the low-speed or subaudible data for an input to the microprocessor.

VOLSQ is coupled through capacitor C33 to the input of buffer/follower circuit U15A

6.5.10 Low Speed Data Encode Filter

The Low Speed Data Encode filter is used to smooth out transitions of data impressed upon the voice audio. Low-speed data is a 150 bit per second data stream generated by the microcomputer and used to produce subaudible data on the voice audio.

Low-Speed Data is generated by microcomputer U9A through EPLD U27, Pins 81 and 80, Walsh Bit 1 and Walsh Bit 2 respectively. For low-speed data, the two Walsh bits are scaled and summed through analog switch U22. The output of U22, Pin 1 (D) connects through operational amplifier U19A and buffer/follower U19B to the input of the low-speed-data encode filter U21. The output of U19B can be monitored at TP22. U21 is an active filter, which uses resistors R82, R90 and R93 with an external 3.125 kHz CLK to produce a low-pass filter. The output of U21 can be monitored at TP20. This output connects to the input of low pass filter U20, Pin14 (IN). This filter

6.6 POWER SUPPLY (A5)

6.7 MISCELLANEOUS INFORMATION

6.7.1 Serial Port Data Format

The serial ports transfer RS-232 asynchronous serial data at a rate of 19.2k using the half-duplex operating mode. That is, data flows in only one direction at a time. The characteristics of the communication link are:

Type:	RS-232C
Baud Rate:	19.2 kilobaud
Start Bits:	1
Stop Bits:	1
Parity:	None
Data Type:	Binary

6.7.2 Failsoft Data Format

Communication between SitePro's takes place along the Backup Serial Link (BSL) through J4. The characteristics of the communication link are:

Level:	0 to 13.8 VDC
Mark/Space:	13.8 volts (mark)/0 volts (space)
Baud Rate:	19.2 kilobaud/38.4 kilobaud (ES)
Start Bits:	1
Data Bits:	8
Stop Bits:	1
Parity:	None
Data Type:	Binary

SitePro's installed in **Enhanced Sites (ES)** must use a data rate of 38.4K baud to improve message throughput and alleviate any conflicts due to increased traffic.

6.7.3 T1/E1 Interface

In systems using a T1/E1 interface, a T1/E1 multiplexer provides an asynchronous serial interface between the **SitePro** and the IMC MIM.

6.7.4 Phone Port Data Format

The **SitePro** sends and receives modem data from its telephone port at 9600 baud using the full duplex mode. That is, data flows simultaneously in both directions. Refer to the Rockwell Modem section for a detailed description.

7.0 INSTALLATION

8.0 CONFIGURATION

9.0 PROGRAMMING

10.0 TROUBLESHOOTING

11.0 LIGHTNING PROTECTION GROUNDING

Maximum lightning protection is achieved when the GETC Lightning-Protection Grounding Kit (344A4500) is installed. This kit is normally installed at the factory for all trunking applications. The following procedure summarizes the installation process:

1. Two wires (black #16 AWG hookup wire, 2-feet long) are prepared as follows:
 - a. The wires are stripped and tinned ½-inch on one end and 1-inch on the other end.
 - b. A solderless terminal (19B209260P1), bent approximately 30-degrees so it will clear the board mounting screw, is attached to the end stripped back ½-inch on each wire as shown in Figure.




Figure 9 - Lightning-Protection Kit Installation Detail

2. The solderless terminal end of the wires is then attached to the **SitePro Controller Interconnect Board A1** using the lock washers and machine screw as shown in the above Figure. A chinch nut is already mounted to the solder side of the board.
3. The wires are then routed out of the shelf as shown in Figure 4.




Figure 10 - Lightning-Protection Kit Cabinet Installation

4. When the shelf is installed in the rack, use the split bolts to attach the wire ends stripped 1-inch to the cabinet earth-ground bus wire (part of the Cabinet grounding Strap Kit 344A4730) as shown in the split bolt side view in Figure 3.



NOTE


In order to be effective, the Cabinet Grounding Strap must be strapped to the building and/or earth ground.

12.0 GLOSSARY

13.0 PARTS LIST

SITEPRO SHELF ASSEMBLY
EV101209V1

	SYMBOL	PART NUMBER	DESCRIPTION
1		MA101080V1	Chassis Assembly.
2		19A116552P3	Clamp, Cable.
3		FM101081V1	Cover.
4		19A702381P60 8	Screw, Thread Form, TORX, M4 x 8mm.
5		19A701312P6	Flat washer, M4.
6		19A702364P50 8	Screw, Machine, TORX, M4X8mm.
7		19A700032P7	Lock washer, Internal Tooth, M4.
8		FM101231V1	Spacer Plate, Shelf Door.
9		FM101232V1	Lens keeper, Door.
10		AG101229V22	EMI Shielding Gasket, 22 Fingers.
11		AG101229V5	EMI Shielding Gasket, 5 Fingers.
12		AG101230V1	Lens, EMI Shielding.
13		19A700032P3	Lock washer, Internal Tooth, M2.5.
14		19A700034P3	Nut, M2.5 X 0.45.
15		NP101233V1	Rear Label.
16		FM101083V1	Support, Front.
	A1	CB101073V1	INTERCONNECT BOARD
			---- CAPACITORS ----
	C1 and C2		470pF, 2KV: sim to Arco MC1808X471KN202.
			---- JACKS ----
	J1 thru J3		DIN 96_ABC-P: sim to AMP 650895-4.
	J4 thru J5		RJ11_MULT: sim Stewart SS-7368H22-NF.
	J6		CON10: sim to Stewart SS-7188S-A-NF.
	J5		CON10: sim to Stewart SS-7188S-A-NF.
	J7	19A116659P17 3	CONN PWR 4-R.
	J8	19A116659P10 1	CONN PWR 3-P.
	J9	19A116659P10 5	CONN RCPT 6.

SYMBOL	PART NUMBER	DESCRIPTION
J10	19A704852P30	CONN RCPT 4.
J11		HEADER 20: sim to AMP 102160-4.
J12		CON24: sim to AMP 102160-5.
J13		HEADER 26: sim to AMP 102160-6.
J14		RJ45_MULT: sim to Stewart SS-73XXX. ----- RESISTORS -----
R1 thru R4	REP_623_642/ 75	75 Ohms, 1%, 0.63W. ----- Pi FILTERS -----
U1 thru U29		Capacitor: 100pF, 100WVDC@125° C, +80%/-20%: sim to Tusonix 4700 006. 4700 SERIES 
A2	CB101069V1	CONTROLLER BOARD ----- BATTERY ----- Coin: 3V. 165 mAh: Sim to Panasonic Thru-Hole. ----- CAPACITORS ----- Tantalum: 1.0µF, 20V ±20%. Ceramic: 0.1µF, 25V ±10%. Tantalum: 1.0µF, 20V ±20%. Ceramic: 470pF, 2kV ±20%. Ceramic: 470pF, 2kV ±20%. Tantalum: 1.0µF, 20V ±20%. Tantalum: 1.0µF, 20V ±20%.
BT1		
C1		
C2 thru C9?		
C10		
C11		
C12		
C13		
C14		
C15 thru C30		
?		
C31		
C39		
C42		

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
C46		Tantalum: 1.0 μ F, 20V \pm 20%.
C49		Ceramic: 10pF, 100V \pm 10%.
C57		Tantalum: 10 μ F, 16V \pm 20%.
C63		Ceramic: 10pF, 100V \pm 10%.
C65		Ceramic: 100pF, 100V \pm 10%.
C66		82pF
C68		Ceramic: 820pF, 25V \pm 10%.
C74		Tantalum: 1.0 μ F, 20V \pm 20%.
C93		Ceramic: 0.001 μ F, 25V \pm 10%.
C96 and C97		Tantalum: 10 μ F, 16V \pm 20%.
6 C10		Ceramic: 0.001 μ F, 25V \pm 10%.
1 C11		Ceramic: 0.001 μ F, 25V \pm 10%.
5 C11		Ceramic: 0.033 μ F, 25V \pm 10%.
7 C11		Tantalum: 10 μ F, 16V \pm 20%.
		---- DIODES ----
D1 thru D4		LED: Red, Thru-hole, RT ANGLE.
D5		LED: Green, Thru-hole, RT ANGLE.

SYMBOL	PART NUMBER	DESCRIPTION
D6 and D7		LED: Yellow, sim to Citizen 1206.
D8		LED: Green, Thru-hole, RT ANGLE.
D9 and D10		LED: Yellow, sim to Citizen 1206.
D11		Dual, High-Speed: sim to Philips, BAV99, SOT23.
D12		LED: Green, thru-hole
D13 thru D17		Dual, High-speed: sim to Philips, BAV99, SOT23.
?		
D30 and D31		Schottky, Vf=0.4
		----- JACKS -----
		----- INDUCTOR -----
L1		39µH ±15%.
		----- RESISTORS -----
R1	19A149818P10 3	Metal Film: 10k Ohms ±5%, 0.1W.
R2 thru R4	19A149818P10 2	Metal Film: 1k Ohms ±5%, 0.1W.
R5	19A149818P10 3	Metal Film: 10k Ohms ±5%, 0.1W.
R6 thru R8		0 Ohms.
R9 thru R13		39 Ohms.
R14 and R15	19A149818P75 0	Metal Film: 75 Ohms ±5%, 0.1W.
R16 and R17	19A149818P10 3	Metal Film: 10k Ohms ±5%, 0.1W.

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
R18		
R19	19A149818P22 2	Metal Film: 2.2k Ohms $\pm 5\%$, 0.1W.
R20		39 Ohms
R21		
R22		49.9 Ohms $\pm 1\%$.
R23	19A149818P33 1	Metal Film: 330 Ohms $\pm 5\%$, 0.1W.
R24	19A149818P15 2	Metal Film: 1.5k Ohms $\pm 5\%$, 0.1W.
R25	19A149818P10 2	Metal Film: 1k Ohms $\pm 5\%$, 0.1W.
R26		
R27		
R28 and R29	19A149818P10 3	Metal Film: 10k Ohms $\pm 5\%$, 0.1W.
R30		
R31		
R32 thru R34		49.9 Ohms $\pm 1\%$.
R35	19A149818P33 1	Metal Film: 330 Ohms $\pm 5\%$, 0.1W.
R36		
R37		
R38		10k Ohms $\pm 1\%$
R39		
R40 and R41	19A149818P75 0	Metal Film: 75 Ohms $\pm 5\%$, 0.1W.
R42	19A149818P33 1	Metal Film: 330 Ohms $\pm 5\%$, 0.1W.
R43		0 Ohms
R44		
R45		0 Ohms
R46		
R52		49.9 Ohms $\pm 1\%$.
and R53		

SYMBOL	PART NUMBER	DESCRIPTION
R54	19A149818P33 1	Metal Film: 330 Ohms \pm 5%, 0.1W.
R55	19A149818P12 1	Metal Film: 120 Ohms \pm 5%, 0.1W.
R56 thru R58	19A149818P10 2	Metal Film: 1k Ohms \pm 5%, 0.1W.
R59	19A149818P12 1	Metal Film: 120 Ohms \pm 5%, 0.1W.
R60		
R61	19A149818P12 1	Metal Film: 120 Ohms \pm 5%, 0.1W.
R62		
R63		
R64		
R65		
R66	19A149818P12 1	Metal Film: 120 Ohms \pm 5%, 0.1W.
R71 and R72	19A149818P12 1	Metal Film: 120 Ohms \pm 5%, 0.1W.
R73 and R74	19A149818P10 5	Metal Film: 1 Meg Ohm \pm 5%, 0.1W.
R75		3.01k Ohms \pm 1%.
R80		33k Ohms
R85		10.0k Ohms \pm 1%.
R86		
R87	19A149818P33 1	Metal Film: 330 Ohms \pm 5%, 0.1W.
R90		10 Meg Ohms \pm 5%, 1/16W.
R95		470k Ohms \pm 1%.
R98		200k Ohms

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
1 R11	19A149818P750	Metal Film: 75 Ohms \pm 5%, 0.1W.
6 R13	19A149818P222	Metal Film: 2.2k Ohms \pm 5%, 0.1W
0 R14		510
1 and R14		
2 R14		Metal Film: 2.2k Ohms \pm 5%, 0.1W.
3 and R14		
4 R14		
5 R14		510
6 R14		
7 R14		3.9k Ohms
8 R14		
9 R14		100
0 R15		3.9k Ohms
1 R15		510
2 R15		
3 R15		0.015 Ohms \pm 1%, 0.5W \pm 1%.
0 R16		3.9k Ohms
1 R16	19A149818P100	Metal Film: 10 Ohms \pm 5%, 0.1W
2 R16		100
7 R16		5.5k Ohms \pm 1%, 0.1W

SYMBOL	PART NUMBER	DESCRIPTION
8 R16		2.0k Ohms ±1%, 0.1W
9 R16		100
0 R17		3.9k Ohms
1 R17	19A149818P47 2	Metal Film: 4.7k Ohms ±5%. 0.1W.
2 R17		27k Ohms
7 R17	19A149818P47 2	Metal Film: 4.7k Ohms ±5%. 0.1W.
9 R17	19A149818P47 2	Metal Film: 4.7k Ohms ±5%. 0.1W.
1 R18		4.3 Meg Ohms ±5%, 1/16W.
3 R18		33k Ohms
		----- RESISTOR NETWORKS -----
5 RN1 thru RN1		10k Ohms, BUS8, ±5%, 0.063W.
		----- SWITCHES -----
S1		PUSHBUTTON, SPST N.O./SPST N.C.
S2		DIPSWITCH, 8 position.
		----- TEST POINTS -----
0 TP1 thru TP1		SM Test Point Loop – Surface Mount: sim to ADI/ SM-TESTPAD/Comp-CORP/TP-107/1.
		----- TRANSFORMERS -----
T1 and T2		1:1, 10/100Mbps: sim to TG110-S05N2.
		----- TRANSISTORS -----
Q1		NPN: Switching: sim to Phillips PMBT3904, SOT23.

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
Q2 thru Q4		FET: Small-Signal, N-Channel: sim to INFINEON, BSP295.
Q5		MOSFET: N-Channel, 5A, 20V: sim to ON Semiconductor, MMSF5N02HD.
Q6 and Q7		NPN: Switching: sim to Phillips PMBT3904, SOT23.
Q8		PNP: sim to Motorola, MMBT3906LT1, SOT23.
Q9 and Q10		NPN: Switching: sim to Phillips PMBT3904, SOT23.
- - - - INTEGRATED CIRCUITS - - - -		
U1		Single Buffer with 3-State Output: sim to Fairchild NC7SZ125M5, SOT23-5.
U2		8M x 16 SCRAM, PC100: sim to Micron MT48LC8M16A2TG-8E, TSOP54.
U3		Silicon Serial Number: sim to Dallas, DS2401P, TSOC6.
U4		Clock Buffer: sim to Cypress Cy2305SC-1, SOIC8.
U5		10/100-TX/FX Ethernet Transceiver: sim to AMD AM79C874VC, TQFP80.
U6		Octal Buffer, 3.3V: sim to TI 74LVC244ADB, SSOP20.
U7		8M x 16 SCRAM, PC100: sim to Micron MT48LC8M16A2TG-8E, TSOP54.
U8		Octal Buffer, 3.3V: sim to TI 74LVC244ADB, SSOP20.
U9		Microprocessor, 66MHz: sim to Motorola, XPC860PZP66D4, BGA357.
U10 and U11		1M x 16/2M x 8 Flash, simultaneous Read/Write: sim to AMD, AM29DL163DB90E1, TSOP48.
U12		10/100-TX/FX Ethernet Transceiver: sim to AMD AM79C874VC, TQFP80.
U13		RS232 Transceiver, 5V, 2-TX, 2-RX: sim to MAXIM, MAX202CSE, SOIC16..
U14		EEPROM, I ² C, 16k x 8, 3.3V: sim to Atmel, AT24C128, SOIC8.
U15		I ² C Bus 8-bit I/O: sim to Philips, PCF8574T, SOIC16.
U16		Phase-Lock-Loop (PLL): sim to TI, 74HCT4046ADB, SSOP20.

SYMBOL	PART NUMBER	DESCRIPTION
U17		Single Inverter: sim to Philips, 74HC1G04GW, SOT-353.
U18		HEX Buffer: sim to Philips, 74HC14PW, TSSOP14.
U19		Octal XCVR, BUS HOLD, 3.3V, sim to Philips, 74LVCH245APW, TSSOP20.
U20		Single Inverter: sim to Philips, 74HC1G04GW, SOT-353.
U21		RS485 Transceiver: sim to TI, 75176BD, SO8.
U22 and U23		HEX Buffer: sim to Philips, 74HC14PW, TSSOP14.
U24		RS232 Transceiver, 3V to 5.5V, 3-TX, 5-RX: sim to MAXIM, MAX3241CAI, SSOP28.
U25		+5V Regulator, 1.5A: sim to Linear Tech, LT1086CM-3.3, TO263.
U26		I ² C Bus 8-bit I/O: sim to Philips, PCF8574T, SOIC16.
U27		144 PIN CPLD, sim to Altera, EPM3256ATC144, TQFP144.
U28		Quad UART (QUART): sim to SC28L194A1BE, TQFP80.
U29		HEX Buffer: sim to Philips, 74HCT14PW, TSSOP14.
U30		RS232 Transceiver, 5V, 4-TX, 5-RX: sim to MAXIM, MAX213CAI, SSOP28.
U31		Reset Supervisor: sim to Dallas, DS1818R-10, SOT23.
U32		HEX Buffer: sim to Philips, 74HCT14PW, TSSOP14.
U33 thru U35		HEX Open-Collector Output Drivers: sim to Philips, 7406AD, SOIC14.
U36		RS232 Transceiver, 3V to 5.5V, 5-TX, 3-RX: sim to MAXIM, MAX3237CAI, SSOP28.
U37		Hot Swap Controller: sim to Linear Tech, LTC1422, SOIC8.
U38		Single 2-Input NAND Gate: sim to Phillips, 74AHC1G00GW, SOT353.
U39		HEX Open-Collector Output Drivers: sim to Philips, 74F06AD, SOIC14.
U40		555 Timer: sim to National, LMC555CM, TO263.
		----- OSCILLATORS -----

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
Y1		Crystal: 25MHz CLK \pm 50ppm, 40%/60% duty, 3.3V
Y2		Crystal: 29,4912 MHz CLK \pm 100ppm, 40%/60% duty, 3.3V.
Y3		Crystal: 32.786kHz CLK
Y4		Crystal: 11.0592 MHz CLK \pm 50ppm, 40%/60% duty, 3.3V.
A3	ROA 117 2247/1	ROCKWELL MODEM INTERFACE CARD

SYMBOL	PART NUMBER	DESCRIPTION
----- CAPACITORS -----		
C1 thru C4	RJE 584 3168/47	Tantalum: 47 μ F \pm 20%, 16V.
C6	RJC 464 3045/1	10nF \pm 10%, 50V.
C7	RJA 528 4064/1	1nF, \pm 5%, 16V.
C8	RJE 584 3168/47	Tantalum: 47 μ F 20%, 16V.
C9	RJE 584 3108/1	Tantalum: 10uF 20%, 10V.
C10 thru C15	RJC 464 3045/1	10nF \pm 10%. 50V.
----- FUSE -----		
F1	NGH 241 04/1	Glass-Tube: 1.0 A
F2 and F3	NGH 241 03/25	Glass-Tube: 0.25A
----- RESISTORS -----		
R1 and R2	REP 645 623/62	620 Ohms \pm 1%, 0.25W
R3	REP 645 623/22	220ohm 1% 0.25W
R4 and R5	REP 625 426/33	Chip: 330k Ohms 5%, 1/8W.
R6 thru R17	REP 625 425/1	Chip: 10k Ohms 5%, 1/8W.
R18 thru R21	REP 625 424/47	Chip: 4.7k Ohms 5%, 1/8W.

	SYMBOL	PART NUMBER	DESCRIPTION
R22 thru R27	REP 625 424/1	Chip: 1k Ohms 5%, 1/8W.	
R28	REP 625 425/1	Chip: 10k Ohms 5%, 1/8W.	
R29	REP 645 624/24	2.4k Ohms 1% 0.25W	
R30	REP 645 624/12	1.2k Ohms 1%, 0.25W	
R31 and R32	REP 645 623/62	620 Ohms 1%, 0.25W	
R33	REP 625 423/47	Chip: 470 Ohms 5%, 1/8W.	
R34	REP 645 623/24	240 Ohms 1%, 0.25W	
R35 and R36	REP 645 623/12	120 Ohms 1%, 0.25W	
R37 thru R40	REP 645 62	0.0 Ohms +50Meg Ohms, 0.25W.	
R41 and R42	REP 625 425/1	Chip: 10k Ohms 5%, 1/8W.	
			----- SWITCHES -----
S1	RMF 356 004/08	COMMUTATOR/DIP-SWITCH	
			----- TRANSFORMERS -----
T1 and T2	REG 135 57/1	Transformer/Telefon	
			----- INTEGRATED CIRCUITS -----
U1	RYT 306 2024/C	Dual Mono Flip-Flops: sim to 74HC4538D.	
U2	RYT 306 2019/C	MICROCIRCUIT: sim to 74HC86	
U3	RYT 108 6003/C	MICROCIRCUIT: sim to TLC555ID	
U4	RYT 101 6164/1	Dual Op Ampl: sim to RC4558D	
U5	RYT 109 6073/1	RS232 3+3 Transceivers ±5V: sim to MC145406DW.	
			----- DIODES & TRANSISTORS -----

PARTS LISTS

	SYMBOL	PART NUMBER	DESCRIPTION
V1 thru V3	RKZ 433 637/1		LED: 90-Degree, RED.
V4 thru V7	RKZ 223 01/8		Diode Regulator: 4.7V 5%, .225W.
V8 thru V10	RYN 121 675/1		NPN Transistor: 60V, 200mA.
V11 and V12	RKZ 433 637/1		LED: 90-Degree, RED.
V13 and V14	RYN 121 675/1		NPN Transistor: 60V, 200mA.
- - - - CONTACTS - - - -			
X1 and X2	RNV 403 843/031		Fork contact unit/socket conn. For pwb mounting.
X3 and X4	RPV 380 10/03		PIN STRIP/.
X5	RPV 403 209/102		Connector/96 Pol 4 GRD. Pins.
X6 and X7	RNV 207 03/1		U-LINK/.
X8 and X9	RPV 380 10/03		Pin Strip/.
XF1 thru XF3	NFN 102 04		Fuse Holder/.
4	NTM 201 1079		Set Of Materials/Hardware Kit
6	RNY 101 01/4		KEY4/
A4		CB101070V1	ANALOG FILTER BOARD
- - - - CAPACITORS - - - -			
C3			1μF ECS-T1CY105R
C4			10nF ECU-V1H103KBV
C5			1μF ECS-T1CY105R
C6			10nF ECU-V1H103KBV
C10			1nF ECU-V1H102KBV
C11			4.7nF ECU-V1H472KBV

SYMBOL	PART NUMBER	DESCRIPTION
C12 and C13	10nF ECU-V1H103KBV	
C14	2.2nF ECU-V1H222KBV	
C15	10nF ECU-V1H103KBV	
C16 and C17	22nF ECU-V1E223KBV	
C18	1.5nF ECU-V1H152KBV	
C19 and C20	47 μ F 593D476X9016D2T	
C21	10nF ECU-V1H103KBV	
C22	15nF ECU-V1H153KBV	
C23	22nF ECU-V1E223KBV	
C24	2.2nF ECU-V1H222KBV	
C25	15nF ECU-V1H153KBV	
C26	22nF ECU-V1E223KBV	
C27	33nF ECU-V1H153KBV	
C28	10nF ECU-V1H103KBV	
C29	3.3pF ECU-V1H033CCV	
C30	0.1 μ F ECJ-1VB1C104K	
C31	15nF ECU-V1H153KBV	
C32	10 μ F ECS-H1CC106R	
C33	22 μ F ECS-T1CD226R	
C34	10 μ F ECS-H1CC106R	
C39	3.3pF ECU-V1H033CCV	
C40	15nF ECU-V1H153KBV	
C41	10 nF ECU-V1H103KBV	
C42	47 μ F 593D476X9016D2T	
C47 thru C52	0.1 μ F ECJ-1VB1C104K	
C53 and C54	47 μ F 593D476X9016D2T	

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
C57 thru C60	47μF 593D476X9016 D2T	
C62 and C63	NM	
C64 thru C86	0.1μF ECJ-1VB1C104K	
C89 thru C91	0.1μF ECJ-1VB1C104K	
C93 thru C98	0.1μF ECJ-1VB1C104K	
0 C10 thru C10 4	0.1μF ECJ-1VB1C104K	
6 C10 thru C11 1	0.1μF ECJ-1VB1C104K	
3 C11 thru C12 1	0.1μF ECJ-1VB1C104K	
3 C12	4.7pF C0603C479K5GAC	
4 C12 and C12 5	0.1μF ECJ-1VB1C104K	
	----- DIODES -----	

SYMBOL	PART NUMBER	DESCRIPTION
D1 and D2	BAT54LT1	Dual High Speed: sim to BAL99.
D5	Dual High Speed: sim to BAL99	Dual High Speed: sim to BAL99
D11 and D12	BAT54LT1	----- JACK -----
D15	DIN96_ABC_R	----- RELAYS -----
J1	EB2-4.5S	----- TRANSISTOR -----
K1 and K2	MMBT3904LT1	----- RESISTORS -----
Q1	124k Ohms	SM/RP_EXB-D10C [EXB-D10C/SM]
R1	16k Ohms	1.21k Ohms
R2	5.11k Ohms	1k Ohms
R3	16k Ohms	1.21k Ohms
R4	5.11k Ohms	1k Ohms
R5	NM	31.6k Ohms
R6	0 Ohms	150k Ohms
R7	100k Ohms	1Meg Ohm
R8	NM	1Meg Ohms
R9	NM	
R10		
R11		
R12		
and		
R13		
R14		
R15		
R16		
R17		
R18		
R19		
R20		

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
R21		0 Ohms
R22		100k Ohms
R23 and R24		NM
R25		46.4k Ohms
R26		0 Ohms
R27		100k Ohms
R28		11k Ohms
R29		1.96k Ohms
R30		5.11k Ohms
R31		1.1k Ohms
R32		11k Ohms
R33		1.96k Ohms
R34		5.11k Ohms
R35		1.1k Ohms
R36		470 Ohms
R37 and R38		1Meg Ohms
R39		22.1k Ohms
R40		20K Ohms
R41		22.1k Ohms
R42		
R43		294k Ohms
R44 and R45		22.1k Ohms
R46		10k Ohms
R47		10Meg Ohms
R48		NM
R49		10k Ohms
R50		68k Ohms
R51		NM
R52		100k Ohms
R53		10k Ohms
R54		0 Ohms
R55		23.7k Ohms
R56 and R57		NM
R58		47k Ohms

SYMBOL	PART NUMBER	DESCRIPTION
R59 and R60	10k Ohms	
R61 and R62	0 Ohms	
R63	20k Ohms	
R64	NM	
R65	60.4k Ohms	
R66	NM	
R67	1k Ohms	
R68	4.7k Ohms	
R69	0 Ohms	
R70	60.4k Ohms	
R71	NM	
R72	22.1k Ohms	
thru R74		
R75		
R76		
R77	NM	
R78	10k Ohms	
and R79		
R80	NM	
and R81		
R82	10k	
R83	NM	
R84	0 Ohms	
R85		
R86	10k Ohms	
R87	18k Ohms	
R88	0 Ohms	
R89	32.4k Ohms	
R90	15k Ohms	
R91	82.5k Ohms	
R92	NM	
R93	46.4k Ohms	
R94	NM	
R95	221k Ohms	
R96	46.4k Ohms	
R97	0 Ohms	

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
R98		82.5k Ohms
R99		10k Ohms
R10		NM
0 thru R10		
2 R10		4.7k Ohms
3 and R10		
4 R10		470 Ohms
5 thru R10		
8 R10		NM
9 and R11		
1 R11		4.7k Ohms
2 R11		10 Ohms
3 R11		0 Ohms
4 R11		
5 R11		
6 R11		
7 R11		
8 R11		0 Ohms
9 and R12		
0 R12		20k Ohms
1 R12		39.2k Ohms
2		

SYMBOL	PART NUMBER	DESCRIPTION
3 R12	51.1K Ohms	
4 and R12		
5 R12	39.2k Ohms	
6 R12	332k Ohms	
7 R12	SM/RP_EXB-D10C [EXB-D10C/SM]	
8 R12	0 Ohms	
0 thru R13		
1 R13	10Meg Ohms	
	----- TEST POINTS -----	
2 TP3	TP-107-01 [T POINT R]	
3 And TP3		
	----- INTEGRATED CIRCUITS -----	
U2	: sim to Motorola, MC79M05BT.	
U3	: sim to Motorola, MC74HC393AD.	
U4	Remote 16-bit I/O Expander: sim to Philips, PCF8575CTS.	
U5	: sim to Motorola, MC33074D.	
U6	: sim to Motorola, MC33072D.	
U7	Fault-Protected, High-Voltage Single 8-to-1/Dual 4-to-1 Multiplexers: sim to Maxim, MAX4508ESE.	
U8	: sim to Dallas, DS1803Z-010.	
U9	SPST/SPDT Analog Switches: sim to Maxim, DG419DY.	
U10	: sim to Motorola, MC33074D	
U11	8 th -Order, Lowpass, Switched-Capacitor Filters: sim to Maxim, MAX292ESA.	
U12	: sim to Motorola, LM393D.	
U13	: sim to	
U14	: sim to Maxim, MAX294EWE.	
U15	: sim to Motorola, MC33072D.	
U16	: sim to Linear Tech, LTC4861S.	

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
U17		: sim to Motorola, MC33072D.
U18		SPST/SPDT Analog Switches: sim to Maxim, DG419DY.
U19		: sim to Motorola, MC33072D.
U20		Low Pass Filter: sim to Maxim, MAX294EWE.
U21		: sim to Linear Tech, LTC1059S.
U22		SPST/SPDT Analog Switches: sim to Maxim, DG419DY.
U23		8-Bit A/D and D/A Converter: sim to Philips, PCF8591TD.
U24		+5V-Powered, Multichannel RS-232 Drivers/Receivers: sim to Maxim, MAX232AESE.
U25		: sim to Linear Tech, LTC4861S.
U26		: sim to Linear Tech, LTC 4891S.
U27		Dual Peripheral Drivers: sim to TI, SN75451BD
U28		: sim to Motorola, MC33072D.
U29		: sim to
U30		: sim to
U31		: sim to
U32		: sim to
U33		: sim to Motorola, LM393D.
		---- CRYSTAL ----
Y1		400 kHz: sim to STATEK_CX-3V-SM
	A5	POWER SUPPLY Sim To CONDOR DP1719
	A6	DISPLAY MODULE
		EA101227V1
		FM101082V1 Display Cover
		AR-FM101082V1 Display Mkg Artwork.
		AG101230V1 Display Lens.
		FM101082V3 Display Lens Keeper.
		FM101082V2 Spacer Plate.
	A6- A1	CB101077V1 Display Board Assembly

SYMBOL	PART NUMBER	DESCRIPTION
A6- W1	CA101222V1	Cable
A7	RYTUZ 921 01/1	ROCKWELL MODEM ASSEMBLY
A8	CB101074V1	MODEM DAUGHTER BOARD ---- CAPACITORS ----
C1 thru C2		10 μ F
C3 thru C27		0.1 μ F
C28		27pF
		---- CONNECTORS ----
J1		QUICC:
J2		I/O Connector
J3		Diagnostic Connector
		---- RESISTORS ----
R1 thru R3		10k Ohms
R4		
R5 thru R8		10k Ohms
R9		
R10		
R11		
R12		
R13		
R14		270 Ohms
R15 thru R20		10k Ohms
		---- INTEGRATED CIRCUITS ----
U1		Local Microprocessor: sim to Dallas 80C323.
U2		SRAM 64 x 8k: sim to Integrated Circuit Devices IDT71V124SA.
U3		Dual Port RAM: sim to Integrated Circuit Devices IDT70V05L55PF.

PARTS LISTS

SYMBOL	PART NUMBER	DESCRIPTION
U4		SRAM 64 x 8k: sim to Integrated Circuit Devices IDT71V124SA.
U5		Address Decoder: sim to 74ALVC138ADB.
U6		3.3V - 5V Converter: sim to Integrated Circuit Devices IDT74FCT.
U7		8-Bit Latch: sim to 74LVC373APWOH.
U8		
U9		RF Modem: sim to Texas Instrument ROP101688/4C
U10		PL Modem: sim to Texas Instrument ROP101688/4C.
U11		VDI Modem: sim to Texas Instrument ROP101688/4C.
U12		Adder Bus Buffer: sim to Integrated Circuit Devices IDT74FCT163245C or A.
U13		Data Bus Buffer: sim to Integrated Circuit Devices IDT74FCT3245APG
U14		
U15		
U16		Quad 3-Input NAND Gate: sim to 74LVC10APWDH.
U17		Quad 2-Input NOR Gate: sim to 74LVC02APWDH.
U18		Hex Inverter: sim to 74LVC04APWDH.
U19		Quad 2-Input NAND Gate: sim to 74HC1G00GW.
U20 thru U22		Single Inverter: sim to 74HC1G04GW.
U23		Quad 2-Input NAND Gate: sim to 74HC1G00GW.
W1	CA101211V1	Cable: Input To Power Supply.
W2	CA101212V1	Cable: Output From Power Supply.

SYMBOL	PART NUMBER	DESCRIPTION


14.0 IC DATA

13.1 CONTROLLER BOARD (A2)


U1

Single Buffer with 3-State Output

(Fairchild, NC7SZ125M5, SOT23-5)



Connection Diagram



Pin Descriptions

Pin Names	Description
A, \overline{OE}	Inputs
Y	Output

Function Table

Inputs		Output
\overline{OE}	In A	Out Y
L	L	L
L	H	H
H	X	Z


H = HIGH Logic Level
 L = LOW Logic Level
 X = HIGH or LOW Logic Level
 Z = HIGH Impedance State

U2, U7

8M x 16 SDRAM, PC100


(Micron, MT48LC8M16A2TG-8E)

PIN ASSIGNMENT (Top View)



Continued on next page

Continued from previous page




U3
Silicon Serial Number
(DALLAS, DS2401P)



TSOC PACKAGE




DS2401 EQUIVALENT CIRCUIT



U4
Clock Buffer
(Cypress, CY2305SC-1)




U5, U12
10/100-TX/RX Ethernet Transceiver
(AMD, AM79C874VC)




Continued on next page

Continued from pervious page


BLOCK DIAGRAM



U6, U8
Octal Buffer, 3.3V
(TI, 74LVC244ADB)



logic diagram (positive logic)




FUNCTION TABLE
(each buffer)


INPUTS		OUTPUT
OE	A	Y
L	H	H
L	L	L
H	X	Z

U9
Microprocessor, 66MHz
(Motorola, XPC860PZP66D4, BGA357)

MPC860 Processor Block Diagram




MPC860 Series Part Numbering Key




U10, U11
1M x 16/2M x 8 Flash, Simultaneous Read/Write
(AMD, AM29DL163DB90E1)



CONNECTION DIAGRAMS




BLOCK DIAGRAM





U13
RS232 Transceiver, 5V, 2-TX, 2-RX
(MAXIM, MAX202CSE)



U14
EEPROM, I²C, 16k x 8, 3.3V
(Atmel, AT24C128N, SOIC8)





U15, U26
I²C Bus 8-Bit I/O
(Philips, PCF8574A)





PIN IDENTIFICATION

SYMBOL	PIN	DESCRIPTION
A0	1	Address Input 0
A1	2	Address Input 1
A2	3	Address Input 2
P0	4	Quasi-bidirectional I/O 0
P1	5	Quasi-bidirectional I/O 1
P2	6	Quasi-bidirectional I/O 2
P3	7	Quasi-bidirectional I/O 3
Vss	8	Supply Ground
P4	9	Quasi-bidirectional I/O 4
P5	10	Quasi-bidirectional I/O 5
P6	11	Quasi-bidirectional I/O 6
P7	12	Quasi-bidirectional I/O 7
INT	13	Interrupt Output (Active LOW)
SCL	14	Serial Clock Line
SDA	15	Serial Data Line
V _{DD}	16	Supply Voltage

U16
Phase-Lock-Loop (PLL)
(TI, 74HCT4046ADB)



U17, U20
Single Inverter
 ##### (Philips, 74HC1G04GW)





FUNCTION TABLE
 See note 1.

INPUT	OUTPUT
A	Y
L	H
H	L

Note

- 1. H = HIGH voltage level;
 L = LOW voltage level.

U18, U22, U23
HEX Buffer
 ##### (Philips, 74HC14PW)





FUNCTION TABLE

INPUT	OUTPUT
nA	nY
L	H
H	L

Notes

- 1. H = HIGH voltage level
- L = LOW voltage level

U19
Octal XCVR, BUS HOLD, 3.3V
(Philips, 74LVCH245APW)




FUNCTION TABLE


INPUTS		INPUTS/OUTPUTS	
OE	DIR	A _n	B _n
L	L	A = B	Inputs
L	H	Inputs	B = A
H	X	Z	Z

- H = HIGH voltage level
- L = LOW voltage level
- X = Don't care
- Z = High impedance OFF-state

U21
RS485 Transceiver
(TI, 75176BD)



logic diagram (positive logic)



Function Tables

DRIVER

INPUT D	ENABLE DE	OUTPUTS	
		A	B
H	H	H	L
L	H	L	H
X	L	Z	Z



RECEIVER

DIFFERENTIAL INPUTS A-B	ENABLE RE	OUTPUT R
$V_{ID} \geq 0.2V$	L	H
$-0.2V < V_{ID} < 0.2V$	L	T
$V_{ID} \leq -0.2V$	L	L
X	H	Z
Open	L	T

H = high level, L = low level, T = indeterminate,
X = irrelevant, Z = high impedance (off)


U24

RS232 Transceiver, 3V to 5.5V, 3-TX, 5-RX
(MAXIM, MAX3241CAI, SSOP28)




U25



+5V Regulator, 1.5A
(LINEAR TECH, LT1086CM-3.3)




BLOCK DIAGRAM



U27
144 PIN CPLD
(ALTERA, EPM3256ATC144)




U28
QUAD UART (QUART)
(Philips, SC28L194A1BE)




Pin Assignments

4 Vss_ic, 4 Vcc_i, 4 Vss_o, 2 Vcc_o, 2Vcc_c

1	I/O1a	28	TxDc	54	D6
2	I/O2a	29	Vcc_c	55	D7
3	I/O3a	30	Vcc_i	56	IRQN
4	Vss_o	31	Vss_ic	57	IACKN
5	RxDa	32	RESETN	58	Vss_o
6	TxDa	33	Gm0	59	X1
7	I/O2b	34	Gm1	60	X2
8	I/O1b	35	I/O0d	61-62	nc
9	Vcc_o	36	I/O1d	63	A7
10	Vcc_i	37	I/O2d	64	A5
11	Vss_ic	38	Gout0	65	A4
12	I/O2b	39-41	nc	66	A3
13	I/O3b	42	I/O3d	67	A2
14	RxDb	43	Gout1	68	A1
15	TxDb	44	Vss_o	69	BCN
16	I/O2c	45	D0	70	Vss_ic
17	I/O1c	46	D1	71	Vcc_c
18	Vss_o	47	D2	72	Vcc_i
19	I/O2c	48	D3	73	W_RN
20-23	nc	49	Vcc_o	74	A0
24	I/O3c	50	D4	75	CEN
25	RxDc	51	D5	76	DACKN
26	TxDc	52	Vss_ic	77	I/O0a
27	RxDd	53	Vcc_i	78-80	nc



U29, U32
HEX Buffer
 ##### (Philips, 74HCT14PW)





FUNCTION TABLE

INPUT	OUTPUT
nA	nY
L	H
H	L


Notes

1. H = HIGH voltage level
 L = LOW voltage level

U30
RS-232 Transceiver, 5V, 4-TX, 5-TX
 ##### (MAXIM, MAX213CAI)




U31
Reset Supervisor
 ##### (Dallas, DS1818R-10)





- | | | |
|---|-----------------|-------------------------|
| 1 | RST | Active Low Reset Output |
| 2 | V _{CC} | Power Supply |
| 3 | GND | Ground |


BLOCK DIAGRAM (OPEN-DRAIN OUTPUT)




U33, U34, U35, U39
HEX Open-Collector Output Drivers
 ##### (Philips, 74F06AD)




U36
RS232 Transceiver, 3V to 5.5V, 5-TX, 3-RX
 ##### (MAXIM, MAX3237CAI)




U37
Hot Swap Controller
(LINEAR TECH, LTC1422)



BLOCK DIAGRAM



U38
Single NAND Gate
(Philips, 74AHC1G00GW)





FUNCTION TABLE
 See note 1.

INPUTS		OUTPUT
A	B	Y
L	L	H
L	H	H
H	L	H
H	H	L

Note
 1. H = HIGH voltage level.
 L = LOW voltage level.



U40
555 Timer
(National, LMC555CM)



Top View

6.8MODEM DAUGHTER BOARD (A8)

U1
 Microprocessor
 ##### (Dallas 80C323)




U2 & U4
64k x 8 SRAM
(IDT71V124SA)


Pin Configuration



Functional Block Diagram




U3
Dual Port RAM
(IDT70V05L55PF)



Continued

Continued



U5
Address Decoder
 ##### (LVC138)

U6
3.3V – 5V Converter
 ##### (IDT74FCT)

U7
8-Bit Latch
 ##### (VC373A)

U8
 #####
 ##### (#####)

U9
RF Modem
 ##### (TI ROP101688/4C)

U10
PL Modem
 ##### (#####)

U11
VDI Modem
(#####)

U12
Adder Bus Buffer
(IDT74FCT163245C/A)

U13
Data Bus Buffer
(#####)

U14


6.9 ROCKWELL MODEM INTERFACE CARD (A3)

U1
Dual Mono Flip-Flops
RYT 306 2024/C (74HC4538D)

U2
MICROCIRCUIT
RYT 306 2019/C (74HC86)

U3
MICROCIRCUIT
RYT 108 6003/C (TLC555ID)

U4
Dual Operational Amplifiers
RYT 101 6164/1 (RC4558D)



CONNECTIONS



Terminal	Symbol	Function
1		Output A
2		Input A (-)
3		Input A (+)
4	V _{EE}	Ground
5		Input B (+)
6		Input B (-)
7		Output B
8	V _{CC}	Supply Voltage

U5
RS232 3+3 Transceivers ±5V
RYT 109 6073/1 (Motorola, MC145406DW)

6.10 ANALOG FILTER BOARD (A4)

U2
 ##### (Motorola, MC79M05BT)



U3
Dual 4-Stage Binary Ripple Counter
 ##### (Motorola, MC74HC393AD)



FUNCTION TABLE

Inputs		Outputs
Clock	Reset	
X	H	L
H	L	No Change
L	L	No Change
~	L	Advance to Next State


U4
Remote 16-Bit I/O Expander for I²C-Bus
 ##### (Philips, PCF8575CTS)




U5 & U10
High Slew Rate, Wide Bandwidth, Single Supply Operational Amplifier
 ##### (Motorola, MC33074D)

U6, U15, U17, U19 & U28
High Slew Rate, Wide Bandwidth, Single Supply Operational Amplifier
 ##### (Motorola, MC33072D)

U7
Fault-Protected, High-Voltage Single 8-to-1/Dual 4-to-1 Multiplexers
 ##### (Maxim, MAX4508ESE)




U8
Addressable Dual Digital Potentionmeter
 ##### (Dallas, DS1803Z-010)





PIN DESCRIPTION

- L0, L1 - Low End of Resistor
- H0, H1 - High End of Resistor
- W0, W1 - Wiper terminal of Resistor
- V_{CC} - 3V/5V Power Supply Input
- A0..A2 - Chip Select Inputs
- SDA - Serial Data I/O
- SCL - Serial Clock Input
- GND - Ground
- NC - No connection

U9, U18 & U22
SPST/SPDT Analog Switches
 ##### (Maxim, DG419DY)



U11
8th-Order, Lowpass, Switched-Capacitor Filters
 ##### (Maxim, MAX292ESA)




U12 & U33
Low Offset Voltage Dual Comparators
 ##### (Motorola, LM393D)

U14 & U20

8th-Order, Lowpass, Elliptic, Switched-Capacitor Filters

(Maxim, MAX294EWE)



PIN	NAME	FUNCTION
1	CLK	Clock input – use internal or external clock.
2	V-	Negative Supply pin. Dual supplies: -2.375V to -5.5V. Single supply: V-= 0V.
3	OP OUT	Uncommitted Op-Amp Output
4	OP IN	Inverting input to the uncommitted op amp. The noninverting op amp is internally tied to GND.
5	OUT	Filter Output
6	GND	Ground. In single-supply operation, GND must be biased to the mid-supply voltage level.
7	V+	Positive Supply pin. Dual supplies: +2.375V to +5.5V. Single supply: +4.75V to +11.0V
8	IN	Filter Input.


U16 & U25

(Linear Tech, LTC4861S)



U21

High Performance Switched Capacitor Universal Filter



(Linear Tech, LTC1059S)



U23
8-Bit A/D and D/A Converter
 ##### (Philips, PCF8591TD)




U24
+5V-Powered, Multi-Channel RS-232 Drivers/Receivers
 ##### (Maxim, MAX232AESE)



U26
 ##### (Linear Tech, LTC4891S)


U27
Dual Peripheral Drivers
 ##### (TI, SN75451BD)




FUNCTION TABLE
 (each driver)

A	B	Y
L	L	H (off state)
L	H	H (off state)
H	L	H (off state)
H	H	L (on state)

positive logic:
 $Y = \overline{AB}$ or $A+B$



U31
Fault-Protected, High-Voltage, Single 4-to-1/Dual 2-to-1 Multiplexers
 ##### (Maxim, MAX4534ESD)



U32
HEX Inverter
 ##### (Motorola, MC14069UBDR2)

