


Eclipse 1 User Manual

Product demo photos:

Tablet projector HEXA





Description of basic specifications :

Category	Description
CPU	Intel cherrytrail Quad-core
DDR	2GB
Flash	32GB
WIFI	2.4G、 5G(802.11ac)
Brightness	220ANSI lumens
Battery capacity	4350mAh

Description of interface:

(1) Power key : long press about 3-second to start ; long press about

8-second to forced shut down ; short press 1 second for sleep or wake up the tablet.

(2) Power port : connect with adapter to power and charge the tablet.

(3) HDMI socket: connect HDMI output device , such as PC、 DVD、 STB.

(4) TF card socket : standard TF card ; support maximum extension to 64G.

(5) Headset socket : standard headset socket, while using headset the speaker is cut off status

(6) USB 2.0 socket: connect external devices ;such as mouse、 keyboard、 usb disk.

(7) USB 2.0 socket: connect external devices ; such as mouse、 keyboard、 usb disk.

(8) RJ45 Internet port socket : link to wired network ; the maximum transmission speed is 100M.

(9) Focus Setting button: adjust the definition by distance

(10) Light Bulb : light screen

(11) stand hole

(12)Speaker

User Manual of Remote control:

Start button: No function

Separate projector switch : Turn on/off the light bulb.

Menu button : enter and exit OSD menu.

Menu upturning button:enter OSD menu then upturning

Menu page down button:enter OSD menu then go down

Projector brightness “+” button: increase projector brightness

Projector brightness “-” button: reduce projector brightness

Volume+ button: increase the volume

Volume - button: reduce the volume

HDMI input switch: switch to HDMI signal


Return button: return operation when using OSD Menu

Simply instruction


1.Guidance of power on

Press POWER button to start(long press about 3 second) ;


After starting up as picture show



Then click the small Icon on the right corner (as picture show), then click the tablet mode.



Click it to quit the tablet mode




Click any blank space on the desktop, the shortcut menu will be hidden and stich to Windows desktop.


Note: Every time start up the tablet will recover to tablet mode, if we want to back to desktop need do above steps every time

2.Virtual remote control APP.



There will be installed a remote controller App(WTRemoter) for customer on Windows desktop, long press that Icon to select open or use mouse double-clicking to open, then it will work as the real remote controller.




3.Description of Virtual remote control

1.) Press this  key on remote controller can shut down or start the projector ,


2.) No function for this 

3.) Press  or  button can adjust the brightness of light screen;


【Brightness adjusting has 4 rate, the lowest rate is sleep, the highest rate is the brightest, the third rate is default】 ;

4.) Press " MENU"  key call out OSD menu, brightness " + " " - " key and up down key can adjust items in OSD

menu , press  key to exit ;

5.) this  can switch to external HDMI mode , press again return to tablet mode;

6.) " + " or " - " key can adjust the sound volume, press return key can keep what you adjusted volume.

7.) This  key can chose tablet or HDMI mode;


Adjust the angle of placed tablet(above 5°), the light screen has sensitive G-sensor will automatic adjust to suit it.

4.Enter setting interface

1.) Select setting option on menu



2.) Enter setting interface



FCC Want you to known:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ALLP-ECLIPSE1