

Quick Start


Thank you for choosing the Mobile Broadband USB Stick. With your USB Stick, you can access a wireless network at high speed.

Note:

This manual describes the appearance of the USB Stick, as well as the procedures for preparation, connection steps.

Getting to Know Your USB Stick

The following figure shows the appearance of the USB Stick. It is provided only for your reference. The actual product may be different.



❶ **USB Connector**

It connects the USB Stick to a PC.

❷ **Indicator**

It indicates the status of the USB Stick.

- Steady blue: strong signal strength
- Steady yellow: weak signal strength
- Steady red: no signal
- Blinking red: The USB Stick is powering on.
- Blinking green: The USB Stick is upgrading.

❸ **Back cover**

Getting Your USB Stick Ready

1. Open the cover to remove it from the USB Stick.
2. Insert the SIM card into the corresponding card slots.
3. Replace the cover and click it into place.

Note:

- Ensure that the beveled edge of the SIM card is properly aligned with that of the SIM card slot.
- Do not remove the SIM card when the card is in use. Otherwise, the card as well as your USB Stick may get damaged and the data stored on the card may be corrupted.

Using Your USB Stick

The procedure for installation depends on your computer's operating system. The following sections are based on Windows OS.

Connecting to a Network

1. Insert the USB Stick into one of your computer's USB ports.

The computer identifies the new hardware and starts its installation automatically.

2. When the installation is complete, the USB Stick's web management page is displayed and the USB Stick connects to the network automatically. The USB Stick's web management page will be automatically displayed every time the USB Stick is inserted into the computer.

Note:

- If the computer does not start the USB Stick's installation automatically, find the **AutoRun.exe** file in the USB Stick's root directory, and double-click the file to run it.
- If you are not connected to the network, access <http://192.168.100.1> to check the device status.
- If you cannot access <http://192.168.100.1>, disconnect other network connections,

such as an Ethernet or Wireless Fidelity (Wi-Fi) connection, remove and then insert the USB Stick, or restart the computer.

Disconnecting from a Network

Remove the USB Stick from the computer.

Note:

- If you do not need to connect to a network, it is recommended that you remove the USB Stick from your computer to eliminate unwanted data traffic.
- Disconnect the USB Stick's dial-up connection through its web management page. Before you remove the USB Stick, make sure that the dial-up connection has been disconnected.

Viewing Service Information

Visit <http://192.168.100.1> to view your service information.