Welcome to Huawei



HUAWEI U8350-3 User Guide

Contents

1	Rea	Reading Before Proceeding	
	1.1	Personal Information and Data Security	1
	1.2	Safety Precautions	2
	1.3	Legal Notice	3
2	Gett	ing to Know Your Mobile Phone	6
	2.1	Mobile Phone View	6
	2.2	Installing Your Mobile Phone	8
	2.3	Power On or Off Your Mobile Phone	10
	2.4	Using the Touchscreen	11
	2.5	Locking and Unlocking the Screen	12
	2.6	Home Screen	13
		Using a microSD Card	
3	Call	ing	17
	2.4	Making a Call	47
		Answering or Rejecting a Call	
		Other Operations During a Call	
		Using Call log	
		Using Airplane Mode	
	5.5		20
4	Con	tacts	21
	4.1	Opening the Contacts Application	21
	4.2	Importing Contacts from a SIM Card	21
	4.3	Adding a Contact	21
	4.4	Searching for a Contact	22
	4.5	Editing a Contact	22
	4.6	Communicating with Your Contacts	22
	4.7	Deleting a Contact	23
	4.8	Managing Groups	23
	4.9	Joining and Separating Contacts	24

	4.10 Staying close to your friends	25
5	Using the Keypad	25
	5.1 Choosing an Input Method	25
	5.2 Using the Phone Keypad	25
	5.3 Customizing Keyboard Settings	27
6	Messaging	27
	6.1 SMS and MMS	27
	6.2 Email	29
7	Getting Connected	31
	7.1 GPRS/3G	31
	7.2 Wi-Fi	32
	7.3 Sharing Your Phone's Data Connection	33
	7.4 Browser	
	7.5 Bluetooth	35
8	Entertainment	
8		37
8	Entertainment	37 37
8	8.1 Taking Photos and Recording Videos	37 37 38
8	8.1 Taking Photos and Recording Videos 8.2 Using the Gallery Lower Statement Stat	37 37 38 40
	8.1 Taking Photos and Recording Videos 8.2 Using the Gallery L	37 37 38 40 41
	 8.1 Taking Photos and Recording Videos 8.2 Using the Gallery 8.3 Enjoying Music 8.4 Listening to FM Radio 	37 37 38 40 41
	8.1 Taking Photos and Recording Videos 8.2 Using the Gallery 8.3 Enjoying Music 8.4 Listening to FM Radio Google Services	37 37 38 40 41 42 42
	8.1 Taking Photos and Recording Videos 8.2 Using the Gallery 8.3 Enjoying Music 8.4 Listening to FM Radio Google Services 9.1 Creating a Google Account	37 37 38 40 41 42 42 42
	8.1 Taking Photos and Recording Videos 8.2 Using the Gallery L	37 37 38 40 41 42 42 42 43 44 45
	8.1 Taking Photos and Recording Videos 8.2 Using the Gallery L	37 37 38 40 41 42 42 42 43 44 45 46
	8.1 Taking Photos and Recording Videos 8.2 Using the Gallery L	37 37 38 40 41 42 42 42 43 44 45 46
9	8.1 Taking Photos and Recording Videos 8.2 Using the Gallery L	

	10.2	Customizing Your Account Synchronization	50
11	Usir	ng Other Applications	51
	11.1	Using the Calendar	51
	11.2	Using the Clock	52
	11.3	Using the Calculator	53
	11.4	Using the Notepad	54
12	Man	aging Your Mobile Phone	54
	12.1	Setting the Date and Time	54
	12.2	Setting the Display	55
	12.3	Setting Ringers	55
	12.4	Setting Phone Services	56
	12.5	Setting Text-to-Speech	57
	12.6	Protecting Your Mobile Phone	57
		Managing Applications	
		Resetting Your Mobile Phone	
13	Арр	endix	59
	13.1	FAQ	59
		Warnings and Precautions	

Reading Before Proceeding 1.1 Personal Information and Data Security

The use of some functions or third-party applications on your device could result in your personal information and data being lost or becoming accessible to others. Several measures are recommended to help you protect personal and confidential information.

- · Place your device in a safe area to prevent it from unauthorized use.
- · Set your device screen to lock and create a password or unlock pattern to open it.
- Periodically back up personal information kept on your SIM/UIM card, memory card, or stored in your device memory. If you change to a different device, be sure to move or delete any personal information on your old device.
- If you are worried about viruses when you receive messages or emails from a stranger, you can delete them without opening them.
- If you use your device to browse the Internet, avoid websites that might pose a security risk to avoid theft of your personal information.
- If you use services such as Wi-Fitether or Bluetooth, set passwords for these services to prevent unauthorized access. When these services are not in use, turn them off.
- Install or upgrade device security software and regularly scan for viruses.
- Be sure to obtain third-party applications from a legitimate source. Downloaded third-party applications should be scanned for viruses.
- Install security software or patches released by Huawei or third-party application providers.
- Some applications require and transmit location information. As a result, a thirdparty may be able to share your location information.
- Your device may provide detection and diagnostic information to third-party application providers. Third party vendors use this information to improve their products and services.

 If you have concerns about the security of your personal information and data, please contact mobile@huawei.com.

1.2 Safety Precautions

Please read the safety precautions carefully to ensure the correct use of your mobile phone.



Do not crash, throw, or puncture your mobile phone. Avoid the falling, squeezing, and bending of your mobile phone.



Do not use your mobile phone in a moist environment, such as the bathroom. Prevent your mobile phone from being soaked or washed in liquid.



Do not switch on your mobile phone when it is prohibited to use phones or when the phone may cause interference or danger.



Do not use your mobile phone while driving.



Follow any rules or regulations in hospitals and health care facilities. Switch off your mobile phone near medical apparatus.



Switch off your mobile phone in aircraft. The phone may cause interference to control equipment of the aircraft.



Switch off your mobile phone near high-precision electronic devices. The phone may affect the performance of these devices.



Do not attempt to disassemble your mobile phone or its accessories. Only qualified personnel are allowed to service or repair the phone.

Do not place your mobile phone or its accessories in containers with a strong electromagnetic field.



Do not place magnetic storage media near your mobile phone. Radiation from the phone may erase the information stored on them.



Do not put your mobile phone in a high-temperature place or use it in a place with flammable gas such as a gas station.



Keep your mobile phone and its accessories away from children. Do not allow children to use your mobile phone without guidance.



Use only approved batteries and chargers to avoid the risk of explosions.



Observe any laws or regulations on the use of wireless devices. Respect others' privacy and legal rights when using your wireless device.



Strictly follow the relevant instructions of this manual while using the USB cable. Otherwise your mobile phone or PC may be damaged.

1.3 Legal Notice

Copyright © Huawei Technologies Co., Ltd. 2011. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd. The product described in this manual may include copyrighted software of Huawei Technologies Co., Ltd. and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders. Trademarks and Permissions

Manual August and HUAWEI are trademarks or registered trademarks of Huawei Technologies Co., Ltd.

Android is a trademark of Google Inc.

Other trademarks, product, service and company names mentioned are the property of their respective owners.

Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and therefore may not be activated or may be limited by local network operators or network service providers. Thus the descriptions herein may not match exactly the product or its accessories you purchase.

Huawei Technologies Co., Ltd. reserves the right to change or modify any information or specifications contained in this manual without prior notice and without any liability.

Third-Party Software Statement

Huawei Technologies Co., Ltd. does not own the intellectual property of the third-party software and applications that are delivered with this product. Therefore, Huawei Technologies Co., Ltd. will not provide any warranty of any kind for these third-party software and applications. Neither will Huawei Technologies Co., Ltd. provide support to customers who use these third-party software and applications, nor be responsible or liable for the functions of these third-party software and applications.

Third-party software and applications services may be interrupted or terminated at any time. Huawei Technologies Co., Ltd. does not guarantee that any content or service would be maintained for any period during its availability. Third-party service providers provide content and services through network or transmission tools outside of the control of Huawei Technologies Co., Ltd. To the greatest extent permitted by applicable law, it is explicitly stated that Huawei Technologies Co., Ltd. shall not compensate or be liable for services provided by third-party services, or the interruption or termination of third-party contents or services.

Huawei Technologies Co., Ltd. shall not be responsible for the legality, quality, or any other aspects of any software installed on this product, or for any uploaded or downloaded third-party works, such as texts, images, videos, or software. Customers shall bear the risk for any and all effects, including incompatibility between the software and this product, which result from installing software or uploading or downloading the third-party works. This product uses the open-sourced Android[™] platform. Huawei Technologies Co., Ltd. has made necessary changes to the platform. Therefore, this product may not support all the functions that are supported by the standard Android platform or may be incompatible with third-party software. Huawei Technologies Co., Ltd. shall not be liable for any of such situation.

DISCLAIMER OF WARRANTIES

THE CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

LIMITATIONS OF LIABILITY

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL HUAWEI TECHNOLOGIES CO., LTD. BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOST PROFITS, BUSINESS, REVENUE, DATA, GOODWILL OR ANTICIPATED SAVINGS.

THE MAXIMUM LIABILITY (THIS LIMITATION SHALL NOT APPLY TO LIABILITY FOR PERSONAL INJURY TO THE EXTENT APPLICABLE LAW PROHIBITS SUCHA LIMITATION) OF HUAWE TECHNOLOGIES CO., LTD. ARISING FROM THE USE OF THE PRODUCT DESCRIBED IN THIS DOCUMENT SHALL BE LIMITED TO THE AMOUNT PAID BY CUSTOMERS FOR THE PURCHASE OF THIS PRODUCT.


Import and Export Regulations

Customers shall comply with all applicable export or import laws and regulations and be responsible to obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.

2 Getting to Know Your Mobile Phone

2.1 Mobile Phone View

- 2.1.1 Phone at a Glance
- All the pictures in this guide are for your reference only. The actual appearance and display features depend on the mobile phone you purchase.



1	Navigation key	2	Send key
3	OK	4	🛆 Home key
5	Menu key	6	alt Alt key
7	aA Cap key	8	Smiley key

9	Space key	10	sym Symbol key
11	- Enter key	12	← Delete key
13	Q Search key	14	5 Back key
15	End key	16	Volume keys
17	O Power key	18	Charge/Data port
19	Headset jack	20	Speaker
21	Camera		

2.1.2 Key Functions at Your Fingertips

0	 Press to power on your mobile phone. Press and hold to open the Phone options menu. Press to lock the screen when your mobile phone is active.
Ð	 Touch to return to the previous screen. Touch to exit any application you are running.
	Touch to open the menu on an active screen.
	 Touch to return to the Home screen. Touch and hold to show the most recently used applications.
Q	Touch to open Google search for searching your mobile phone and the web.
	 Press to make or answer a call. Press to go to the Call log screen.
-	Press to hang up a call.Press to return to the Home screen.




Press to navigate selectable items on the screen.

Press to select a highlighted item.

2.2 Installing Your Mobile Phone

2.2.1 Installing the SIM Card

There are two steps to install the SIM card:



- 1. Angle the edge labeled a (with the contacts) into the bottom end of the battery slot.
- 2. Push down the edge labelled b until the battery clicks firmly into place.

2.2.3 Charging the Battery

Before charging the battery, ensure that it has been properly inserted into your phone.



- 1. Connect the USB cable that came with your mobile phone to the charger.
- 2. Connect the USB cable to your mobile phone. Then, plug in the connector of the charger to an electrical outlet. The phone begins charging.

If your mobile phone is charged when it is powered on, the battery icon on the

Notification bar shows the charging status. When the battery icon changes to —, it indicates that your mobile phone is fully charged.

2.2.4 Important Information About the Battery

- If the battery has not been used for a long period of time, you may not be able to
 power on your mobile phone immediately after you begin charging the battery.
 Allow the battery to charge for a few minutes with the phone powered off before
 attempting to power on the phone.
- The battery will not hold a charge for the way it did when it was new. When the battery life becomes noticeably shorter than usual after being charged properly, replace the battery with a new one of the same type.
- Using data services increases demand on the battery and will reduce the length of time it can hold a charge.
- The time required to charge the battery depends on the ambient temperature and the age of the battery.
- When the battery is low on power, the phone plays an alert and displays a prompt.
 When battery power is almost exhausted, your phone will power off automatically.

2.2.5 Battery Saving Tips

The longevity of battery power depends on the network that you connect to, and how you use your mobile phone.

Try the following to conserve battery power:

• When you do not need 3G services, set your phone to connect to a 2G network.

- · When your mobile phone is not in use, switch off the screen.
- Reset the time it takes for your screen light to switch off when you leave your phone idle.
- · Lower the screen brightness.
- Use the AC adapter to plug your phone into an external power source whenever possible.
- Turn Bluetooth off when you are not using it. Only make your phone visible to other Bluetooth devices when you need to establish a Bluetooth connection.
- · Switch off Wi-Fi when you are not using it.
- · Turn off your phone connection to GPS satellites when you are not using it.
- · Lower the volume.
- · Close power-draining programs, when you do not need them.
- Turn off the data service.

2.3 Power On or Off Your Mobile Phone

2.3.1 Powering On Your Mobile Phone

Press (). The first time you power on your phone, you will be asked to sign in to your account and set up your mobile phone.

If personal identification number (PIN) protection is enabled on your mobile phone, you must enter your PIN before using the mobile phone.

2.3.2 Setting Up Your Mobile Phone

The first time you power on your mobile phone, the phone displays a setup wizard to help you set up the phone.

The setup wizard helps you:

- · Learn about your mobile phone
- · Create or sign into your account
- · Make some initial decisions about how you want to use your mobile phone