


QUICK GUIDE

Keyboard & Mouse RF Combo
Model No.: K363R-V2

Shortcut keys




Scroller

Left-click button


Right-click button

Connect button



1. Package Contents:

- a. Keyboard. b. Mouse. c. Receiver Box.
d. Software. e. Batteries.



System Requirements


To use the mouse software and the hot keys on your multimedia keyboard, you need the following:

- Windows XP/ME/2000/98SE/NT 4.0 or later
- PS/2 mouse and keyboard ports
- Sound Blaster compatible sound card (for CD/VCD/DVD, and MPEG operation)
- CD-ROM drive (for software installation and CD/VCD operation)

1

2. Install the Batteries:

- a. Mouse. b. Receiver. c. Keyboard




2


3. Notice Important

1. Place the RF receiver in a good location.

Place the receiver at least 8 inches (20cm) from electrical devices such as the computer or monitor.



2. Place the keyboard and the mouse in the proper location for your computer.




3


4. Installation:

- a. Turn off the computer. Connect the receiver cable to the PC via PS/2 ports.

keyboard PS/2 (purple)
mouse PS/2 (green)




- b. Place receiver away from electronic devices.



4

5. ID Select Important

- (A) ID connect for keyboard
Press ID select switch on Receiver and then keyboard within 10second.
- (B) ID connect for mouse
Press ID select switch on Receiver and then Mouse within 10second.



Note! Repeat this Step when connecting the Wireless RF Keyboard & Mouse for the first time and after replacing the batteries.

5

6. Installing Device Drivers

- After you have installed and connected Desktop Wireless, insert the Installation CD into the CD-ROM drive. The CD supports Windows Autoplay and starts running automatically. If not, access the CD from Windows Explorer, and then click the relevant CD-ROM drive. Double click the **Setup.exe** file.
- Select the driver and applications that you want to install, and then click the **OK** button.
- Follow the onscreen instructions to complete the installation.

7. Troubleshooting

Wireless RF Keyboard & Mouse not detected

If the keyboard and mouse don't respond to activity, follow these steps:

- Ensure that the receiver cable is properly connected to the PS/2 mouse and keyboard ports. Ensure that the purple connector is connected to the keyboard port, and the green connector is connected to the mouse port.
- Ensure that the batteries have been installed correctly.
- Ensure that there are no IRQ or I/O address conflicts. Refer to your operating system user's manual for information on resolving IRQ and I/O address conflicts.

6

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

Federal Communications Commission Requirements
The equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

7

Federal Communication Commission Interference Statement

The equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Important note: To comply with FCC RF exposure compliance requirements, only use the antenna that is equipped with this device. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.