L551 Quick Guide

Thanks for choosing the phone, Dual SIMs Android smart phone based on 1.25GHz Quad-Core Processor. This smart phone is running on Android OS, v6.0. If you'd like your phone to live a long and fruitful life, please read this guide carefully and keep it for future reference. You never know when you might need it. And don't worry if the pictures we use to demonstrate your phone's functions look a little different from what you see on its screen. It's the functions that matter.

* The Manufacturer reserves the right for the changes in the manual without advanced notice.

Contents

Safety	4
Using Your Phone Safely	
About Your Phone	8
Inserting Your Micro-SIM/Micro-SD Card	g
Charging Your Phone	10
Using Your Phone	11
Connect to Wi-Fi	18
Connect to Bluetooth	19
FCC Statement	20
Maintenance	20
Take Care of Your Device	23

Safety

Safety Precautions



Please read through the following briefings carefully. and act in accordance with these rules, so as to prevent causing any danger or violating any law.

Information about the meaning of Logo WEEE (Waste Electrical and Electronic Equipment):



The WEEE logo on the product or on its box indicates that this product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Isolated collection and proper recovery of your electronic and electrical waste equipment at the time of disposal will allow us to help conserving natural resources. Moreover, proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment

Caution: Risk of explosion if battery is replaced by an incorrect

Dispose of used batteries according to the instructions.

For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.

Using Your Phone Safely



On the Road

Using a phone while driving is illegal in many countries. Please follow local laws and drive safely at all times.



Near Sensitive Electronics

Don't use your phone near sensitive electronic equipment – particularly medical devices such as pacemakers – as it could cause them to malfunction. It can also interfere with the operation of fire detectors and other automatic-control equipment.

For more information about how your phone affects pacemakers or other electronic equipment, please contact the manufacturer or your local distributor.

Your phone may cause interference when used near TVs, radios or automated office equipment.



While Flying

Your phone can cause interference with aircraft equipment. So it's essential you follow airline regulations. And if airline personnel ask you to switch off your phone, or disable its wireless functions, please do as they say.



In Hospital

Your phone may interfere with the normal operation of medical equipment. Follow all hospital regulations and turn it off when you're asked to by posted warnings or medical staff.



At a Petrol Station

Don't use your phone at petrol stations. In fact, it's always best to switch off whenever you're near fuels, chemicals or explosives.



Around Water

Keep your phone away from water (or any other liquid). It's not a waterproof model.



Making Repairs

Never take your phone apart. Please leave that to the professionals. Unauthorized repairs could break the terms of your warranty.



Broken Antenna

Don't use your phone if the antenna is damaged, as it could cause injury.



Around Children

Keep your mobile out of children's reach. It should never be used as a toy and it might not be good for their health.



Original Accessories

Only use the original accessories supplied with your phone or those approved by the manufacturer. Using unapproved accessories may affect performance, make the warranty void, break national regulations on the use of mobile phones, or even cause injury.



Near Explosives

Turn off your phone in or near areas where explosive materials are used. Always obey local laws and turn off your phone when requested.



Emergency Calls

To make an emergency call your phone must be turned on and in an area where there's network coverage. Dial the national emergency number and press the dial key. Explain exactly where you are and don't hang up until help has arrived.




Working Temperature

The working temperature for the phone is between 0 Degree and 40 Degree Celsius. Please don't use the phone outside the range. Using the phone under too high or too low temperature might cause problems.

To prevent possible hearing damage, do not listen at high volume levels for long periods.

About Your Phone



Main Keys Explained


Power Key:

- Press and hold to turn on or off airplane mode, manage notification sound and vibration, restart, or to power off.
- · Press to turn off or on the screen display.

Volume Key: Press or hold to turn the volume up or down.

Inserting Your Micro-SIM/Micro-SD Card

1. Remove the back cover.




2. Insert the Micro-SIM/Micro-SD card.



3. Press the cover gently back into place until you hear a click.

Notes: SD Card Association trademark.

Charging Your Phone



Notes:

- Use only qualified factory supplied chargers and cables. The use of unapproved accessories could damage your phone or cause the battery to explode.
- You can directly use the Li-Polymer battery in the pack. Please normally use off the battery and fully charge the battery for its perfect performance.
- If the phone has been shut off for a long time or the battery has been used up, you should charge the phone for 3 to 5 minutes then turn on.
- Normal charge temperature: 0°C to 40°C.

Using Your Phone

Main Menu & its Functions

Press icon to enter main menu.

Allow you to view a list of features available in your phone.

1. Dial the Call



- Tap to see the recent calling.
- Tap icon to show the keyboard and dial the phone number.
- Tap 📇 to view contact information.

2. Answer and Reject Call



Tap the center of the screen,

- Slide to , answer the call.
- Slide to , reject the call.
 Slide to , quick reply by message.

3. Calling




During the call, you can operate according to the above.

4. SMS/MMS



- Tap icon on the top right corner of the screen to create and edit the message.
- Type the name or number, and message or you can also tap icon to attach files.
- Tap \geq icon to send message.


5. Email



Firstly, you will add an account. Then send and receive the emails.

Notes: Before use, you must connect to internet.

6. Camera



- Tap ⊕ on main screen--> Camera
- Tap or for photo taking or video recording. You may change the options during taking photo or video record by the control panel.

7. Video Player



You can watch videos if you have stored them in your phone.

8. Other Apps

You can also install some other third party APPs in your phone, for example: Facebook, Skype, WhatsApp, Twitter, and so on.

Connect to Wi-Fi



- Tap
 on main screen--> Settings--> Wi-Fi, and turn it on.
- Choose Wi-Fi network and connect to it.
- Input the correct password when needed.
- Connected, you can surf online...




Connect to Bluetooth

You can easily transfer your files to each other by Bluetooth.



- Tap
 on main screen--> Settings--> Bluetooth, and turn it on
- Search for Bluetooth devices already open.
- Connect to the destination device by the same passkey. And the connected device will be shown on the Paired devices list. You can transfer files or connect Bluetooth device such as



Federal Communication Commission Interference

Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- The country code selection is for non-US model only and is not available to all US model. Per FCC regulation, all Wi-Fi products marketed in US must fix to US operation channels

RF Exposure Information (SAR)

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the poser required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The highest SAR value for the model device as reported to the FCC when tested for use at the ear is 0.81 W/kg and when worn on the body, as described in this user guide, is 1.06 W/kg (Body-worn measurements differ among device models, depending upon available accessories and FCC requirements.)

While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the

Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: 2AG8KL551

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and be positioned a minimum of1cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the device at the ear, position the handset a minimum of 1cm from your body when the device is switched on

Maintenance

Use a dry soft cloth to wipe general dirt.

Do not use a hard cloth, benzene or thinner to wipe the phone, otherwise, the surface of the phone will be scratched or could even result in the fading of color.

Take Care of Your Device

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Always keep the small parts of the phone away from children.
- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use indoor chargers.