SIRIUS 1 it's_ON

America SR04

Satellite Radio

www.blaupunktusa.com

AMERICA 8824

NEW COUNTRY

Shania Twain She's Not Just A Pretty Face all We San & All& (1974)

B1

9993

SIRIUS

COUNTRY





Table of Contents

Main Unit	3
Remote Control Unit	5
Congratulations	7
How to Activate Your Sirius Subscription	7
Precautions	8
Installation	10
Vehicle	. 11
Home	14
Activation	16
	17
	17
Idining Control	17
Memory Button	19
Menu Options	21
Channel Mode	21
Category Mode	21
Password Setup	21
FM Transmitter	21
Time Features	21
Svstem	22
Clear All Memory	. 22
Eactory Default Setting	22
Footure Shortquite	22
	23
	24
LIMITED WARRANTY	25



Main Unit





Main Unit Key Function

Key	Press Term	Function			
POWER (Blue Button)	Short	- (When Power Off) Power On			
		- (At Menu or List) Select			
		- (At Tuning Mode) Display Channel List			
	Long	- Power Off			
	Short	- Change Mode (B1->B2->B3->Direct->B1->)			
		Preset Mode (B1, B2, B3), Direct Mode (input the Direct Number)			
Preset/Direct		- Input 000 in Direct Mode to display Sirius ID			
Flesel/Direct		- Change Favorite List in Favorite List			
		(Favorite 1-> Favorite2-> Favorite3-> Favorite1->)			
	Long	- Displays Favorite List			
	Short	- Exit from the Menu Display			
	Short + "1"	- "Lock" Mode			
FUNC	Short + "2"	- "Skip" Mode			
	Short + "3"	- Toggling the Channel mode and Category mode			
	Long	- Display MENU			
Numbers (0-9)	Short	- Recall the PRESET Channel (After selecting Band)			
	Long	- To Preset Channel (After selecting Band)			
CAT (UP/DN)	Short	- Change the Category (display Category List)			
	Short	- Move the Cursor in Menu or List			
	Short	- Change the Channel at Tuning			
		- (At Tune Mode) PDT Scroll			
DISP	Short	- (At Tune Mode) Display the PDT Information (per Page)			
		- Toggles PDT List (Artist/Title)			
MEM	Short	- Display PDT (Artist) List			



Remote Control Unit





Remote Control Key Function

Key	Press Term	Function			
POWER (Blue Button)	Short	- Power On/Off Toggle			
	Long	- Display MENU			
	Short	- Exit from the Menu Display			
FUNC	Short + "1"	- "Lock" Mode			
	Short + "2"	- "Skip" Mode			
	Short + "3"	- Toggling the Channel mode and Category mode			
Numbers (0-9)	Short	- Recall the PRESET Channel (After selecting Band)			
	Long	- To Preset Channel (After selecting Band)			
DIRECT	Short	- Set the Direct Channel Number			
Dirizon	Chieft	- Set '000' : Display Sirius ID			
CAT (UP/DN)	Short	- Change the Category (display Category List)			
CH (UP/DN)	Short	- Move Cursor in Menu or List			
		- Change the Channel at Tuning			
OK	Short	- Select Menu or List			
		- Display Channel List in (At Tuning Mode)			
	Short	- (At Tune Mode) PDT Scroll			
DISP		- (At Tune Mode) Display the PDT Information (per Page)			
		- Toggles PDT List (Artist/Title)			
BAND	Short	- Change Band (B1->B2->B3->B1->)			
		- In Favorite List change to other Favorite List			
		(Favorite 1-> Favorite2-> Favorite3-> Favorite1->)			
	Long	- Favorite List display			
MEM	Short	- Recall PDT List			
AV	-	- No Function with America SR04			



Congratulations

With your new AMERICA SR04 SIRIUS Satellite Radio Plug and Play Tuner, you have the ability to receive 100 channels of original programming in high-quality digital sound. Blaupunkt recommends reading this manual in its entirety before using your AMERICA SR04 to learn about the features of the tuner, so you can quickly and easily start enjoying your new product.

How to Activate Your Sirius Subscription

To activate the unit, turn the unit's power to the on position. After turning the unit on, call 1-888-539-SIRIUS and have your SIRIUS ID Number ready. You can obtain your SIRIUS ID Number by tuning to channel "000" or by looking at the back of the AMERICA SR04 chassis for a bar code starting with the letters SID.



WARNING

Take the following precautions to prevent fire and personal injury:

- Do not operate the unit in a way that will divert your attention away from the road. Use the unit responsibly and obey all traffic laws at all times.
- To avoid short circuits, never place metal objects inside the unit.
- Do not use the unit near water.
- Do not drop the unit or expose it to strong shock or vibration.
- If the LCD display is damaged or broken, do not touch the Liquid Crystal Display Fluid. The fluid may be hazardous to your health. If you come in contact with the fluid, immediately contact emergency assistance.

CAUTION:

Take the following precautions to keep the unit in working order:

- Be sure that the unit is supplied with 7.4V DC power with a negative ground. Use the supplied cable for best results. Supplying more than 7.4V DC may damage the unit.
- Do not store or operate the unit in direct sunlight.
- Do not store or operate the unit in the direct path of an air conditioning vent.
- Do not open the unit.
- When replacing fuses, only use new fuses with the same intended amperage ratings.
- When replacing fuses, always disconnect supply power.
- Do not open, drill holes in, or cut the chassis of the product. This can cause damage and will void your warranty.



Precautions

FCC WARNING:

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in this user guide. The user could lose authority to operate the equipment if an unauthorized change or modification is made.

This equipment has been tested and found to comply with Part 15 of the FCC rules. These rules are designed to provide reasonable protection against harmful interference in a residential installation. This equipment may cause harmful interference to radio communications if it is not installed and used in accordance with these instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the unit on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your local Blaupunkt dealer for further technical assistance.

Cleaning the Unit:

If the unit needs to be cleaned, use only a soft damp cloth to wipe the unit. Use of chemicals and solvents will cause damage to the finish.



To insert the tuner into the cradle, gently slide the tuner straight down onto the cradle's connector pin until it clicks into place.





To remove the tuner from the cradle, gently press the release button on the back of the tuner and pull the tuner straight up out of the cradle.



Installation in a Vehicle: Mounting the AMERICA SR04

(Do not insert the AMERICA SR04 into the Car Cradle until the following steps are complete)

- 1. Determine where in the vehicle you would like the unit to be mounted.
 - · Find a location where it easy to view the front display of the unit.
 - Do not install the unit:
 - On the windshield where it may interfere with your clear view of the road.
 - In front of an air conditioning vent.
 - In a place where it may hinder with vehicle controls.
 - In the direct deployment area of the vehicle air bag system. Doing so may cause severe injury or possibly death.
- 2. Thoroughly clean the area where you will mount the car cradle to promote maximum adhesion.
- 3. Remove the protective covering away from the adhesive tape on the bottom of the car cradle and stick the car cradle to the desired location. Apply firm pressure for a minimum 15 seconds.
- 4. If possible, reinforce the car cradle mount with the supplied mounting screws. When doing so, be sure to check where the screw(s) may protrude on the backside to ensure that they will not damage any wiring or structural points of the vehicle.
- 5. Connect the cigarette lighter power adapter to the back of the car cradle. Wait until the installation is complete to connect to the vehicle's cigarette lighter receptacle. It is recommended that when not in use, disconnect the cigarette lighter power adapter from the outlet.
- 6. Audio Connection from the AMERICA SR04 to your vehicle radio can be done two ways:
 - If your radio has AUXILIARY input, you can use the supplied audio cable to connect from the AUDIO OUT of the AMERICA SR04 Car Cradle to the AUX input of your radio.

OR

• The AMERICA SR04 has an onboard 12 channel Wireless FM Modulator. To access this, enter the MAIN MENU and select FM TRANSMITTER. (Details on how to navigate through the MENU



will be defined in the last section of this manual.) Enter the FM TRANSMITTER menu and select an FM frequency. Tune your FM radio to the same frequency and you should be able to hear SIRIUS Satellite Broadcasts on your FM radio. Note, in some areas, the FM Frequency you select may be occupied by a local FM station. In this case, select the next higher frequency in the AMERICA SR04 menu AND on your FM radio until you can hear the SIRIUS Satellite Broadcast on your FM radio.

Installation in a Vehicle: Mounting the Antenna

- 1. Plug the included antenna into the back of the car cradle in the receptacle labeled SAT.
- 2. Locate an area of the car where you can mount the antenna by the following conditions:
 - The Antenna should be ideally mounted on the exterior of the vehicle.
 - The Antenna should be mounted with the SIRIUS Logo facing UP.
 - The Antenna should be mounted parallel to the ground.
 - The Antenna should be mounted on metal.
 - The Antenna should not have any objects obstructing its view to the sky.
- 3. Insert the America SR04 tuner into the car cradle and temporarily plug the cigarette power cable into the cigarette power receptacle and turn the unit ON.
- 4. If the system is installed correctly, the AMERICA SR04 should start the "UPDATING CHANNEL LIST" cycle. If the unit is installed incorrectly, the AMERICA SR04 may read "ANTENNA ERROR." If this happens, un-plug power from the unit and double check all connections. After checking connections, go back to step 3. If errors continue, contact your local Blaupunkt dealer for support or call (800) 950-BLAU between the hours of 8am to 5pm CST for technical support.



Installation in a Vehicle: Running the Antenna Cable

After you have determined that the unit was temporarily installed correctly, and you had connection to SIRIUS Satellite Radio, you should permanently install the cables for the system. This will allow for a clean installation, and prevent any possibilities of driver or passengers of the vehicle tripping over or interfering with the cables.

- 1. Disconnect the antenna cable from the AMERICA SR04 Car Cradle.
- Starting with the Antenna, from the mounting location of the antenna, carefully track the antenna wire back into the vehicle cabin. Look for any pre-existing wire channels or conduit that will allow for easy tracking through the vehicle.
 - Avoid sharp metal edges where damage may occur to the antenna cable.
 - Avoid direct metal pinch points, such as the area of the door hinge, where damage may occur to the cable.
 - Avoid extra slack in the cable in the area where the driver or passengers place their feet. This may cause injury to the driver or passengers, and potentially damage the antenna cable.
 - Absolutely do not attempt to cut and/or patch the antenna cable. Any slack in the cable should be gathered and neatly wire tied behind an interior panel.
- 3. Track the cable to the rear of the car cradle and gently insert it into the receptacle labeled ANT.



Installation in the Home:

(Do not insert the AMERICA SR04 into the Car Cradle until the following steps are complete) You can also use your AMERICA SR04 with a home stereo. To do this, you must purchase an accessory kit, SR04 HOME KIT (Part Number 7 607 001 131).

The home kit includes:

- Home Cradle
- Home Antenna
- Home AC Power Cable
- Home Audio Cable
- 1. Determine where in the home you would like the unit to be mounted.
 - Find a location where it easy to view the front display of the unit.
 - Do not install the unit:
 - In front of an air conditioning vent.
 - Where the cables may be interfered with by a small child or animal.
- 2. Place the home cradle on a flat surface near your home audio system.
- 3. Connect the AC power adapter to the back of the home cradle. Wait until the installation is complete to connect the AC adapter to the wall outlet.
- 4. Audio Connection from the AMERICA SR04 to your home audio system can be done two ways:
 - If your radio has an AUXILIARY input, you can use the supplied audio cable to connect from the AUDIO OUT of the AMERICA SR04 Home Cradle to the AUX input of your home audio system.

OR

• The AMERICA SR04 has an onboard 12 channel Wireless FM Modulator. To access this, enter the MAIN MENU and arrow down to FM TRANSMITTER. Enter the FM TRANSMITTER menu and



select an FM frequency. Tune your FM radio to the same frequency and you should be able to hear SIRIUS Satellite Broadcasts on your FM radio. Note, in some areas, the FM Frequency you select may be occupied by a local FM station. In this case, select the next higher frequency in the AMERICA SR04 menu AND on your FM radio until you can hear the SIRIUS Satellite Broadcast on your FM radio.

Installation in Home: Mounting the Antenna

1. Plug the included home antenna into the back of the Home Cradle in the receptacle labeled ANT.

Due to the unique paths of the SIRIUS Satellite Network, the best location to place your home antenna will depend on where you live. Please reference the following to find maximum home antenna placement:

Area 1: Place the antenna at an EAST-FACING window.

Area 2: Place the unit OUTSIDE away from any obstructions.

- Area 3: Place the antenna at a WEST-FACING window.
- Area 4: Place the antenna at a NORTH or EAST-FACING window.
- Area 5: Place the antenna at a NORTH-FACING window.
- **Area 6:** Place the antenna at a WEST or NORTH-FACING window.



2. Plug the Home AC Adapter into a wall outlet and turn the unit ON.



3. If the system is installed correctly, the AMERICA SR04 should (a) start the "UPDATING CHANNEL LIST" cycle if the unit has never been used, or (b) start receiving SIRIUS channels. If the unit is installed incorrectly, the AMERICA SR04 may read "ANTENNA ERROR." If this happens, unplug power from the unit and double check all connections. After checking connections, go back to step 2. If errors continue, contact your local Blaupunkt dealer for support or call (800) 950-BLAU between the hours of 8am to 5pm CST for technical support.

Activating your SIRIUS Subscription:

Before enjoying SIRIUS Satellite Radio through your new AMERICA SR04 Tuner, you must first contact SIRIUS Satellite Radio to activate your account.

- 1. Ensure that your system is properly installed and the unit's power is turned ON.
- 2. When turning the unit on for the first time, the AMERICA SR04 will automatically look for SIRIUS Satellite Radio stream information.
 - You will see on the display "UPDATING STREAMS." (0%, 20%, 40%, 60%, 80%, 100%)
 - During this process, please do not press any buttons.
- 3. Once the streams are updated, the screen will change to the PREVIEW Channel 184. On this channel, you will see the message "Call 1-888-539-SIRIUS to Subscribe."
- 4. When you call, you will need the SIRIUS ID number of your AMERICA SR04. This is located in 3 places:
 - Directly access channel 000

OR

• Look on the gift box of the AMERICA SR04 Tuner for a bar code number starting with the letters SID.

OR

• Look on the back of the America SR04 Tuner for a bar code number starting with the letters SID.

5. Please have your credit card information available when you call for activation.

BLAUPUNKT

Basic Operation

After you have activated your SIRIUS subscription, you can start listening to the 100+ channels on your America SR04. The main display of the America SR04 will show the following information.

Category	Preset	
Channel #	Channel Name	
Artist Name Song Title		
Signal	Date / Time	

Tuning Control

You can select SIRIUS channels by the following methods:

- 1. Use the CHANNEL UP / DOWN button to move to the next or previous channel.
- Press the OK button for a list of channels to view. Use the CHANNEL UP / DOWN button to move through the channel list. Once you find the channel to which you wish to change, press the OK button again. In this mode, you can press the DISPL key to change to ARTIST VIEW. Pressing the DISPL button again changes to SONG VIEW. Pressing the DISPL button again changes to CHANNEL VIEW.

Channel View	Artist View	Song View
001 Channel Name	001 Artist Name	001 Song Name
002 Channel Name	002 Artist Name	002 Song Name
003 Channel Name	003 Artist Name	003 Song Name
004 Channel Name	004 Artist Name	004 Song Name



- 3. Use the CATEGORY UP / DOWN button to move to the next or previous category, and then select a channel from that category by highlighting the channel and pressing the OK button.
- 4. Press the DIRECT / PRESET button until the display shows "ENTER NUMBER." At this point, use the 0-9 buttons to enter a channel number. Once entered, the unit will automatically change to that channel 2 seconds after the last digit has been entered.



- Once you have selected a channel, you can store the channel as a preset. 30 presets total can be stored in the America SR04. 10 presets per preset bank B1, B2, and B3. To access Bank 2 and Bank 3, repeatedly press the DIRECT/PRESET button until you see the desired bank in the top right of your display.
- To store a preset channel, press and hold the 0-9 button where you would like to save the preset. If you store a preset in the 1st preset location of bank 1, you will see in the top left of the display B1-1.



Memory Button (S-Seek Function)

The S-Seek Function allows the user to save and search for 10 favorite songs whenever the America SR04 is powered on.

When a song is playing that you wish to save, press and release the MEM button. This will place that song's PDT (Program Definition Text) into the memory.



If you wish to view a list of the saved songs, press and hold the MEM button for 3 seconds. The first song will be displayed on the screen. Use the CHANNEL UP / DOWN button to scroll through the list of saved songs.

- 1. When in the mode, press the DISPL button to view the Song Name or Artist Name of each saved song.
- 2. When in this mode, press the OK button for each song to change the options for that song.
- 3. You can DELETE the song from the list. Select DELETE on the display and press OK. Highlight and press YES to continue the deletion or NO to return to the menu.
- 4. You can activate or deactivate S-SEEK for each of the saved songs. S-SEEK is defaulted on when you save the song to memory. To turn it off, highlight S-SEEK in this display and press OK. Select OFF to cancel this function for this song. Select ON to re-activate S-SEEK for this song.



When the AMERICA SR04 is powered on, it will actively search (S-SEEK) for these saved songs while you listen to other channels. If it finds one of the saved songs playing on another channel, you will hear a short alert tone and the display will show the name of the saved song. From here, you can press the OK button to change to that song. If you select nothing, the display will return to normal mode after 10 seconds.



The S-SEEK memory holds 10 songs. If you try to save a song and the memory is full, the display will show MEMORY FULL. The option to REPLACE a song or CANCEL the save will appear.

- 1. Select REPLACE to save the current song over an older song. The list of saved songs will appear. Use the CHANNEL UP / DOWN button to select the old song you wish to replace and press OK.
- 2. If you do not want to replace any songs, select CANCEL, and the unit will return to normal mode.

Catego	rv í	Preset	Categon	1	Preset	Replace
Chanr	anr Memory Full	2	Chanr	Replace	2	001 Artist Name
				Cancel		002 Artist Name
					003 Artist Name	
Signal	Date / Time		Signal	Date / Time		004 Artist Name



Menu Options

To enter the menu options, press and hold the MENU button for 3 seconds. When selecting MENU options, use the CHANNEL UP / DOWN to highlight the choice, and the OK button to confirm.

The MENU options are defined as follows:

CHANNEL MODE: Default tuning mode. This enables the CHANNEL UP / DOWN button to move through the channels in numerical order through all categories.

CATEGORY MODE: Select this tuning mode to limit the CHANNEL UP / DOWN button to move through the channels in numerical order only within the selected category.

SETUP PASSWORD: Selecting this option will ask you to ENTER CURRENT PASSWORD. The default password is 1379. To change this, enter the default password. You will then be asked to change your password and confirm the change. If you forget your new password, you can reset it by selecting the FACTORY DEFAULT option in the MENU, listed below.

FM TRANSMITTER: In the application where your America SR04 is using the FM Transmitter to transfer sound into your radio, this menu allows you to select which frequency the unit will use. Choices include: FM OFF, 88.1, 88.3, 88.5, 88.7, 88.9, 106.7, 106.9, 107.1, 107.3, 107.5, 107.7, 107.9.

TIME FEATURES: Select CLOCK to update clock settings. The America SR04 clock is automatically updated from the satellite time. The CLOCK menu allows you to change the following:

- FORMAT: 12 or 24 hour format
- TIME ZONE: Select your time zone to ensure the hour is correct.
- DST OBSERVANCE: Select ON or OFF based on Daylight Savings Time in your area.



AUTO SHUTDOWN is a feature that automatically turns off power to the America SR04 after 1 hour. Select ENABLE or DISABLE to use the feature.

SLEEP MODE: This feature will automatically turn the unit off after a selected amount of time. To use this feature, select 15, 30, 45, or 60 minutes.

SYSTEM: The SYSTEM menu allows you to change the following:

- AUDIO LEVEL: Select this feature to raise or lower the audio output from the America SR04 to match your sound system levels. Change the value using the CATEGORY UP / DOWN button and press OK to confirm.
- DISPLAY OPTIONS:
 - DIMMING CONTROL: Use this menu to change the brightness of the display. There are 5 Steps from which to select.
 - CONTRAST: Use this menu to maximize the viewing angle to the user. Change the value using the CATEGORY UP / DOWN button and press OK to confirm.

CLEAR ALL MEMORY: This menu clears preset data in the S-Seek function and all 30 manually stored presets. Select YES to use the feature or NO to return to the MENU.

FACTORY DEFAULT: This menu restores all MENU values to factory default. Select YES to use the feature or NO to return to the MENU.

To exit any MENU:

• Repeatedly press the MENU button until your are returned to the main screen.

OR

• Press nothing and the system will return to the main screen after 10 seconds.



Feature Shortcuts

- Some features can be quickly accessed by using the MENU button and a 0-9 key in combination. To access the features, press and release the MENU key and then press:
- #1 key to LOCK a channel. You will be asked for your password. Once the channel is locked, you must enter the password before you can reselect the channel. To unlock the channel, select the channel, enter your password, press and release MENU, and press and release #1.
- #2 key to SKIP a channel. You will be asked for your password. Once the channel is skipped, you will not see it in the numeric channel order when you use the tuning arrows. It is only selectable via direct channel access (See Tuning for Details). To restore the channel, directly select the channel, press and release MENU, and press and release #2, and enter your password.
- #3 key to change from Channel Tuning to Category Tuning. To change back, press and release MENU, then press #3.



Troubleshooting

Symptom	Possible Cause	Remedy
America SR04 does not turn on.	Lack of power to unit.	Check power cable connection and all fuses in-line with the power outlet. Also check that tuner is correctly inserted into cradle.
Check Antenna Message on display.	Bad connection to antenna.	Check the antenna connection. Also check to ensure the antenna cable was not damaged.
Audio Static and other noise.	FM Transmitter interference.	Change FM transmitter to another channel option.
No Sound	Audio Cable disconnected or FM transmitter turned off.	Check audio connection cable (if used) or check FM transmitter is on in the menu.
Sound output but no display information.	Extreme heat in the vehicle environment near the unit.	Ensure the unit is not mounted in direct sunlight or in front of a heater vent. A few minutes of operation in a normal human environment should return the screen to normal operation.



Limited Warranty (United States)

Robert Bosch Corporation (for products sold in the United States) warrants new Blaupunkt car audio products distributed in the United States through authorized Blaupunkt dealers, or which are imported as original vehicle equipment by the automobile manufacturer, to be free from defects in material and workmanship, in accordance with the following terms and conditions:

For twelve (12) months after delivery to you, the original consumer purchaser, we will repair or at our option replace at no charge to you any car audio product which, under normal conditions of use and service, proves to be defective in materials or workmanship. However, this warranty does not cover expenses incurred in the removal or reinstallation of any car audio product, whether or not proven defective, and does not cover products not purchased from an authorized Blaupunkt dealer. This warranty is limited to the original consumer purchaser and is not transferable. Repaired and replacement car audio products shall assume the identity of the original for purpose of this warranty and this warranty shall not be extended with respect to such products.

To obtain performance of this warranty, contact the nearest Blaupunkt authorized repair facility or our nearest office. A dated purchase receipt or other proof that the product is within the warranty period will be required in order to honor your claim. Carefully pack the unit and ship prepaid to the servicing location. For further information:

In the United States, write to the Robert Bosch Corporation, 2800 South 25th Avenue, Broadview, Illinois, 60155, attention Blaupunkt Customer Service Department or call 1-800-950-2528

Specifically excluded from this warranty are failures caused by misuse, neglect, abuse, improper operation or installation, dropping or damaging a radio faceplate, unauthorized service or parts, or failure to follow maintenance instructions or perform normal maintenance activities. Normal maintenance activities for car audio products include but are not limited to cleaning, such as cleaning radio faceplate connectors and tape heads, tape player head demagnetization and tape player lubrication, compact disc and lens cleaning, and other minor maintenance activities and adjustments that are outlined in the owner's manual or that are normally required for continued proper operation.



Limited Warranty (United States)

Also excluded from this warranty are the correction of improper installation and the elimination of any external electromagnetic interference.

THIS WARRANTY SETS FORTH YOUR EXCLUSIVE REMEDIES WITH RESPECT TO THE PRODUCTS COVERED BY IT. WE SHALL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR PUNITIVE DAMAGES ARISING FROM THE SALE OR USE OF ANY BLAUPUNKT CAR AUDIO PRODUCTS, WHETHER SUCH CLAIM IS IN CONTRACT OR TORT. NO ATTEMPT TO ALTER, MODIFY, OR AMEND THIS WARRANTY SHALL BE EFFECTIVE UNLESS AUTHORIZED IN WRITING BY AN OFFICER OF ROBERT BOSCH CORPORATION.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY IMPLIED BY LAW, WHETHER FOR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE <u>AND</u> SHALL BE EFFECTIVE ONLY FOR THE PERIOD THAT THIS EXPRESS WARRANTY IS EFFECTIVE.

ANY IMPLIED WARRANTY SHALL BE LIMITED IN DURATION TO ONE YEAR FROM DATE OF PURCHASE. SOME STATES IN THE U.S. DO NOT ALLOW LIMITATIONS ON HOW LONG IMPLIED WARRANTY LASTS. SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE IN THE U.S.

In the event any provision, or any part or portions of this warranty shall be held invalid, void or otherwise unenforceable, such holding shall not affect the remaining part or portions of that provision or any other provision hereof.

ROBERT BOSCH CORPORATION BLAUPUNKT CUSTOMER SERVICE 2800 SOUTH 25TH AVENUE BROADVIEW, IL 60155 TEL: 1-800-950-2528





Robert Bosch Corporation Sales Group - Blaupunkt Division 2800 S. 25th Avenue, Broadview, Illinois 60155 U.S.A. www.blaupunktusa.com

Copyright 2004 by the Robert Bosch Corporation

No portion of this work may be reproduced in any form without the written consent of the Robert Bosch Corporation

Printed in Korea (7/04)