

INNOVATION SERIES BED ASSEMBLY GUIDE

With Sleep IQ Firmness control system



Welcome to Sleep Number

Congratulations on your purchase of the SLEEP NUMBER® bed. You've not only made a great decision to sleep your very best, you've joined the more than 8 million well-rested Insiders who are part of our InnerCircleSM family.

As an Insider, you'll be the first to know about our latest innovations and you'll always receive special savings on *Sleep Number* beds and bedding. You can even earn rewards for sharing what you love about your bed with friends and family.^{*} Simply register your bed at sleepnumber.com/innercircle to start receiving all your exclusive benefits.

We believe the best sleep of your life begins with the Sleep Number® experience, and we look forward to further individualizing your comfort. Our 3,000 Sleep Professionals are dedicated to your sleep for life.

Sleep well, dream big.

Shelly Ibach

Shelly Ibach, President and CEO My SLEEP NUMBER® setting is 35



What's Inside

Setting up your new SLEEP NUMBER® bed only takes about an hour, but you'll enjoy the benefits of better sleep for years to come. You won't need any tools and, although it's nice to have a helper, you can do it by yourself.

Setting up your SleepIQ Firmness Control System	pg 4
Wi-Fi Configuration	pg 5
Wi-Fi Troubleshooting	pg 6
Assembling Your Mattress	pg 7
Individualizing Your Remote	pg 12
Getting Comfortable with Your Sleep Number® Setting	pg 17
Product Care	pg 19
Sleep Number® Bedding Collection	pg 21
Warranty	pg 23
Frequently Asked Questions	pg 25
Welcome to Sleep Number® InnerCircle"	pg 28



Getting Started

Decide where to put your new bed. Make sure there's an electric power source nearby to operate your Firmness Control[™] system.

You'll need a surge protector. Your 25-Year Limited Warranty does not cover damage to the Firmness Control[™] system due to a power surge, regardless of the source. See the Limited Warranty on page 28 for more details. **Open all boxes.** CAUTION: Immediately dispose of packaging as it can pose choking or other hazards to small children and pets.

Prepare your foam comfort layer(s). Foam comfort layer(s) should be stored at room temperature for at least four hours before mattress assembly. Carefully open the foam comfort layer(s) and set aside. They'll need at least 30 minutes to fully expand.

Sirmness Control[™] System

- Place the Firmness Control[™] system under the base at the head of the bed. (If base is placed directly onto floor, place Firmness Control[™] system next to the head of the base.)
- Open the door located above the hose connections on the end of the pump. Inside you will find the Sleep IQ module. Push on it to ensure fully engaged and close the door.
- Plug the two voice control modules into the connectors located in between the pump
 hose ports at the end of the pump.
- Plug the power cord into the Firmness Control[™] system and into a surge protector. IMPORTANT: Your Limited Warranty does not cover damage to the Firmness Control[™] system due to a power surge, regardless of the source. See the Limited Warranty on page 28 for more details. The first two lights on the LED panel will light up to indicate that the power is on and the remote bind window is open. At this time you need to simply grab your remote and the screen should light up and bind automatically to your pump, turning that second light solid

NOTE: Do not plug surge protector into an outlet that is controlled by a wall switch.

- Extend hoses in front of the head of the bed and toward their respective sides of the bed (for dual chamber beds) or to one side (for single chamber beds).
- Unplug the pump and begin Wi-Fi configuration set up



•Remove the USB stick from the pump box and go to a computer or device that both has a USB port and can connect to the internet

•Log into URL at: http://uitest.zepp.bamlabs.com/zep_webapp/#/signin

•Create your account if you haven't already done so utilizing the link and log on information you received via email when you purchased your bed

•Go to the account admin screen and enter in your home Wi-Fi network name and password. Be careful to use correct capitalization, spacing and spelling. For example, "NetworkName" versus "Networkname" versus "networkname" and "network-name" are all different!

• Plug your USB stick into your computer

•Select the "download Wi-Fi key" and save the file to your USB stick

•Safely remove the USB stick from your computer and return to your pump

• Unplug your pump from the wall

•Open up the plastic door above the hose connections. In the Sleep IQ module you will see a USB port on the left hand side (see photo to the right). Plug your USB stick into the USB drive on the Sleep IQ module

•Plug the pump back into the wall

•Once powered on your pump will begin booting and connect to your home Wi-Fi

•When all 5 of the LED lights are on you can remove the USB stick from the pump. To do so place a finger on the Sleep IQ module to ensure the connection between the module and the pump remains engaged

Go to Wi-Fi troubleshooting for issues or questions regarding installation



Light	On	Blinking	Off	Try this
1	Pump is receiving power	Pump is booting up	No power to pump	Check power connections
2	Pump is working and bound to a remote	Remote attempting to bind	Pump Non- Functional	Rebind your remote
3	Pump computer is connected to your home network	Attempting to connect to your network	No connection to your home network	 Return to your account settings and reenter your network name and password. Pay attention to case, spelling and spaces Check Wifi strength in your bedroom using another device
4	Pump connected to Internet	n/a	No internet connection	• Try to connect to internet with another device on your network
5	Data sent and received from your pump via the internet	Establishing contact	No connection to your account via the internet	• Return to your account settings and re- enter your network and password. Pay attention to case, spelling and spaces

If you experience further issues, please contact Customer Service at the number listed in the back of this manual





Before You Begin Assembling Your Mattress

Carefully check the contents of your mattress boxes.

Make sure you have the correct number of components for the size of bed you purchased. If you are missing any items listed to the right, please call 1.800.472.7185 or email Customer Service at **customerservice@selectcomfort.com**

Prepare your foam comfort layer(s).

Open and set aside. They'll need at least 30 minutes to fully expand.



Comfort. Individualized.[™]

Our most advanced SLEEP NUMBER® DualAir[™] technology allows you to find your SLEEP NUMBER® setting, name your side of the bed, select your language and more — all at the simple touch of a button.

Mattress: What's Included

	Twin Lor	e Extra- ng/Full	Do Q	uble*/ ueen	King/ California King
Mattress Cover		1		1	1
Foam Border Walls		4		4	4
Center Foam Wall		0		1	1
Foam Comfort Layer	i8 i10	1 1	i8 i10	1 2	i8 1 i10 2
Foam Base Pad		1		1	1
Air Chambers		1		2	2
Firmness Control [™] System		1	(2 r include	1 emotes ed with i10)	1 (2 remotes included with i10)
Corner Locks		0		4*	0
Voice control module				2	2



Assembling Your Mattress

1 Mattress Cover

- Place on base or on existing bed platform, making sure holes in the bottom of the mattress cover are at the head of the bed.
- Unzip mattress cover at zipper A (see below).
- Set top of mattress cover aside.





2 Foam Side Walls



Place long border walls along inside of mattress cover,

Make sure that the notches are facing the center of the bed.

extending the entire length of the bed.

Double Beds Only - Corner Lock Assembly

Place one corner lock in each corner of the mattress cover bottom.

IMPORTANT: Corner locks must be positioned under the border wrap.

 As you install the foam side and end walls, be sure the walls meet inside the corner locks at each corner. (Double beds use corner locks in place of notched side walls.)



Head of bed

3 Foam End Walls

- Place short border walls at the head and foot, between the side walls.
- Make sure the foam border walls are connected securely and squarely.
- Ensure that the zipper is aligned with the top edge of the foam border walls.

NOTE: It is okay if the foam walls bow to the inside of the bed at this point in the assembly.

4 Foam Base Pad

- Carefully shake out the pad.
- Place the foam base pad in the bottom of the mattress cover.





Head of bed

5 Air Chamber(s)

 Place air chamber(s) on top of foam base pad so the hose connectors face the head of the bed and lie on the bottom when inflated.







- Pass the left hose extension (marked with a white band) through the opening on the bottom left side of the mattress cover.
- Connect the hose extension to the left air chamber by pushing together until you hear a click.
- Connect the left Firmness Control[™] system hose (also marked with a white band) to the left hose extension by pushing together until you hear a click.



 Repeat for the right side of the mattress, using the hose extension marked with a blue band, and the Firmness Control[™] system hose marked with a blue band.

Firmness Control[™] System for Single Chamber Beds

- Pass hose extension through the opening on the bottom of the mattress cover.
- Connect the hose extension to the air chamber by pushing together until you hear a click.
- Connect the Firmness Control[™] system hose to the hose extension extending through the opening in the mattress cover by pushing together until you hear a click.

DualAir[™] Technology Inside

At the heart of the SLEEP NUMBER® bed is our most advanced DualAir™ technology. Adjustable air chambers and a Firmness Control[™] system easily find your ideal level of comfort and support on each side - your SLEEP NUMBER® setting.



Your Remote at a Glance

Ø Activate DualAir[™] Technology

- Unplug and re-plug your Firmness Control[™] system into a surge protector.
- Insert two AA batteries (included) into your remote.
- Your remote will turn on simply by picking it up or pressing any button. Easy-to-

follow instructions will guide you through the next steps.

- First, select English or Spanish. Next, DualAir[™] technology will engage automatically.
- Please wait while your mattress inflates. This will take a few minutes. When complete, you'll be prompted to complete your bed assembly.
- Proceed to step 8 in this manual.



Center Foam Wall (Dual Chamber Beds Only)

- Insert center foam wall between the air chambers.
- Zip air chambers together.



Ø Border Wrap

• Extend the border wrap over the foam border walls as shown below.

Important Safety Notice: To ensure compliance with federal flammability requirements, the border wrap must be positioned correctly within the mattress as shown.



Duvet Cover

- Reattach mattress cover at zipper A.
- Remove mattress cover top at zipper B and set aside.





Head of bed

Foam Comfort Layers

Place the foam comfort layer(s) on top of the duvet cover.

NOTE: If your comfort layer has notched corners, place them at the head of the bed.

- If you have an i8 mattress, make sure the smooth side of the foam faces down.
- If your foam has a dual-layer design, place either side up depending upon your preference.



Foam pattern varies by bed model.

Head of bed

Border Wrap

 Extend the border wrap over the foam comfort layers as shown below.

Important Safety Notice: To ensure compliance with federal flammability requirements, the border wrap must be positioned correctly within the mattress as shown.





Mattress Cover Top

- To close mattress cover, place it on the bed with the zipper pull at the head of the bed.
- Make sure the zipper pin is completely inserted into the zipper box. Zip the top of the mattress cover closed.

Proper zipper alignment





Now turn the page to individualize your remote.

Individualizing Your Remote

For your most individualized sleep ever, the intuitive, easy-to-use remote allows you to find your ideal level of comfort, name each side of the bed, and more. Follow these steps to make it your own.

Name Each Side of the Bed

Follow the steps on your remote to enter your names on each side of the bed. If you'd like to skip this step, you can enter them later by pressing the Menu button (), Settings and

Rename Side.

NOTE: You can choose your side of the bed at any time by

pressing the Side button



Press the Side button to choose your side of the bed. If you already know your SLEEP NUMBER® setting, press the Up (firmer) or Down (softer) arrow I to choose it, then press the Menu button I to select and save.

Find Your Sleep Number[®] Setting

There's nothing quite like finding your SLEEP NUMBER® setting. Your remote can easily guide you to your ideal level of comfort and support.

- Begin by lying on the bed in your preferred sleeping position.
- Press the Side button (I) to choose your side of the bed.
- Press the Menu button ()
- Use the Up or Down arrows \triangle ∇ to scroll
 - to Settings, then press the Menu button 🔘
- Choose Find Sleep Number.[®]
- Follow the instructions on your remote to find your favorite Sleep Number setting. This may take a few minutes.



More Sleep Number[®] Remote Features

Press the Menu button to bring up the menu. From here you can change your SLEEP NUMBER® setting, rename your side of the bed, contact customer support and more.

My Sleep Number®

Return to your favorite Sleep Number setting at any time.

Sleep Number® 100

Automatically adjusts one or both sides of the mattress to the firmest setting.

Settings

- Find Sleep Number[®] guides you to your ideal level of firmness, comfort and support.
- Set Sleep Number[®] to quickly select and save a new favorite setting.
- Rename Side to name either side of the bed.
- Customer Support gives you contact information if you have any questions.
- Back returns you to the main menu.

Exit

Displays your most recent Sleep Number setting.

Getting Comfortable with Your Sleep Number® Setting

Once you've found a comfortable SLEEP NUMBER® setting, it's a good idea to evaluate your support and alignment. As you lie in your preferred sleeping position, check whether or not your neck and back feel aligned. Make sure there's no pressure or discomfort in your shoulders and hips. The mattress should support the small of your back (for back sleepers) or the curve of your side (for side sleepers). It's also important to have a pillow that fits you properly otherwise it may interfere with your ability to sleep comfortably. At a SLEEP NUMBER® store, one of our Sleep Professionals can expertly determine which pillow keeps your head, neck and shoulders in alignment with our exclusive PillowFit® process.

Give It Time

Sometimes it takes a little while to discover your ideal Sleep Number setting. When you have found a Sleep Number setting where you feel comfortable, try it for three to five nights. After five nights, reevaluate your comfort level and only adjust the setting in increments of 5–10. Repeat the process until you have found the perfect setting for you. If, after trying four different *Sleep Number* settings, you have not found your ideal *Sleep Number* setting and would like additional assistance, visit sleepnumber.com and click on Customer Service or call 1.800.472.7185 to reach a Customer Service Representative. Our trained Customer Service Representatives will provide help to improve your comfort.



- Neck and back are aligned in the same position as when you are standing
- No discomfort at shoulder and hip pressure points
- You feel the mattress support the small of your back (back sleepers) or the curve of your side (side sleepers)



Wrong

- Body alignment is not straight
- Your pillow makes your head tilt at an angle from the rest of your body
- · You feel discomfort from pressure at your neck, shoulders, back, hips or legs

Things to Remember

Reasons you may wish to adjust the firmness of your bed:

- strained muscles
- back pain
- weight change
- pregnancy
- sunburn
- new sleeping position

Tips for a Great Night's Sleep

Not getting 8 hours of sleep a night? Don't despair. These tips from the experts at SLEEP NUMBER can help you fall asleep more easily and sleep more soundly.

- Keep a regular sleep schedule, even on the weekends.
- Avoid TVs, computers, phones and tablets before bedtime.
- Exercise regularly, but not too close to bedtime.
- Eliminate caffeine after noon.

Sleep Number® Setting Study

As you can see in the chart below, SLEEP NUMBER® bed owners find comfort at all settings from 5-100, however the majority of sleepers find their *Sleep Number* setting between 35 and 50.



Product Care

Cleaning Your Mattress

Spot clean the cover of your SLEEP NUMBER® mattress with carbonated water. Do not dry clean the mattress cover or put it in a washing machine. Do not apply stain guard; it may cause the fabric to turn yellow.

SLEEP NUMBER is an industry leader in the use of materials designed to inhibit the growth of allergens or microorganisms.

Advanced antimicrobial safeguards are incorporated into every SLEEP NUMBER® bed. Key components of the mattress have been treated to protect the bed from contaminants such as mold, mildew and bacteria growth. The unique, zip-open design of the *Sleep Number* bed allows you to easily open, ventilate or vacuum if you choose.

In rare instances and under the right conditions, mold or mildew can form inside many types of mattresses, bedding or upholstered products. Should this condition occur in your mattress, please contact our Customer Service department at 1.800.472.7185 so we can work with you to return your bed to factory-fresh condition.



Cleaning Your Remote

- Wipe the body with a clean cloth dampened with a mild soap and water solution.
- Wipe the display screen with a clean, dry, lint-free cloth.

CAUTION: Do not immerse in water or place in dishwasher.

Moving Your Sleep Number® Bed

- Always disassemble the base. Bag all hardware so that it is not lost.
- The mattress can be fully inflated, capped off and packaged in a mattress box for moving.
- If you don't have a mattress box, double-bag the cover and foam to prevent stains. Deflate and box the air chamber(s) to prevent possible damage.
- Pack the Firmness Control[™] system in a box with packing material. Transport with minimal exposure to shock and vibration.
- Tuck the remote, air chamber caps and instructions in the box with the Firmness Control[™] system to prevent them from being lost.

Sleep Number* Bedding Collection

Sleep your best with our exclusive bedding solutions. From temperature balancing to natural allergy defense, discover bedding innovations designed to meet your unique comfort needs. For a truly individualized sleep experience.

- PillowFit[®]
- Temperature Balancing
- Natural Allergy Defense
- All Natural
- Warming

Experience PillowFit®

Our Sleep Professionals will use PillowFit[®] expertise to find the firmness, fill and fit for you. Only at a SLEEP NUMBER[®] store.



Too high











Warranty

100 Night In-Home Trial and Return Policy

We are confident that you will be completely satisfied with your SLEEP NUMBER® bed. Please take into consideration that it may take several weeks to adjust and get completely comfortable. After 30 nights, if for any reason you decide to return the bed, contact Customer Service before packing your bed. Simply call us toll-free within 100 days of delivery to authorize its return. Upon receipt, we'll reimburse the full purchase price less your initial shipping or Home Delivery and Setup fees. You pay return shipping. There are no returns or exchanges on adjustable bases, closeout, Special/Limited Edition or demo bed models. All merchandise being returned must be in good condition and be given a Return Merchandise Authorization number from Customer Service, which will expire 30 days from date of issue. All refunds will be issued to the original method of payment within approximately 15 business days after all products have been received at SLEEP NUMBER. All shipping and incidental charges to return the bed are the customer's responsibility.

Defective or Damaged Components

If any component of the mattress or Firmness Control[®] system is found to be defective in materials or workmanship within the first two years of the original purchase date, they will be replaced by *Sleep Number* at no cost to you. Within the first two years, all shipping charges to replace a defective component will be covered by *Sleep Number*. If any component of the mattress or Firmness Control[®] system is found to be defective in materials or workmanship after two years from the original purchase date, the terms of the Limited Warranty will apply. After two years from the date of purchase, you will be responsible for the cost of shipping the defective component back to *Sleep Number* and any related costs. Contact our Customer Service department at 1.800.472.7185 for troubleshooting assistance and if you need to process a replacement order.

In the event that replacement components are required or if you wish to upgrade to newer components that are not covered in the warranty, you may purchase these items by simply providing proof of purchase. All component sales are final and carry a 2-Year Limited Warranty from the purchase date. Product discounts and bedding promotions do not apply to components. For current pricing and to process a component purchase, call our Customer Service department at 1.800.472.7185.

Sleep Number® Mattress and Modular Base Limited Warranty

Select Comfort Corporation ("Sleep Number") warrants this mattress and/or mattress base against defects in material or workmanship to the original purchaser for a period of twenty-five (25) years from the date of original purchase or invoice, whichever is later. WHAT WE WILL DO: At our option, *Sleep Number* will repair or replace the warranted product or part provided that it is returned to us as provided herein. During the first two (2) warranty years, any covered repairs or replacement parts will be at no cost to you. *Sleep Number* reserves the right to substitute products or parts of comparable quality and value or, where permissible by law, to use or deliver refurbished products or parts in

the repair or replacement of any product or part that does not come into contact with the sleep surface (e.g. the Firmness Control[™] system or the air chambers) under this limited warranty.

HOW WARRANTY COVERAGE IS CALCULATED: During the following warranty years, your repair or replacement cost will be calculated by adjusting our then-current prices for the product or part (or a comparable product or part if the original product or part is no longer in production) as follows:

Warran ty Year	Original Purchaser's Percent of Product/Part Cost
0-2	No Cost
3-20	20% plus 4% for each completed year from original purchase or invoice date, whichever is later
21-25	96%

WHO THIS WARRANTY PROVIDES COVERAGE TO: Your warranty is non-transferrable and sale, transfer or disposal of the warranted product or part will void this warranty. For the purposes of this warranty, an "original purchaser" is an individual who purchases the product directly from *Sleep Number* or an authorized reseller for personal, consumer use and not with the intent to resell the product or use for commercial purposes. This warranty does not apply to products purchased either with the intent to resell or through unauthorized resellers including, without limitation, third party websites such as Craigslist, eBay, or Amazon. If you are not the original purchaser, you take the product "as is" and with any and all faults.

CLAIMS THIS WARRANTY DOES NOT COVER: Your warranty excludes daims for conditions arising from normal wear and tear including but not limited to mattress cover compression, foam compression, discoloration of parts or normal body indentations. This warranty does not provide coverage for claims related to comfort preference (e.g. "The bed feels too hard/soft."). The warranty does not provide coverage and will become void if claims are a result of damage caused by tampering with or modifications to any component including the opening of the Firmness Control™ system or remote control. Damage caused from laundering or dry-cleaning the product or any part as well as damage caused by misuse or abuse including but not limited to stains, soil, burns, cuts, tears or spills or factors other than a product defect are also excluded under and will void this warranty. Lastly, this warranty does not provide coverage and will become void if damage is caused by acts of nature or relating to forces outside Select Comfort's control including but not limited to fire, flood or lightning damage or for damage caused by power surges. This warranty does not apply to beds sold as floor models or "demos." Changes in barometric pressure can impact the feel of your SLEEP NUMBER® mattress and may require you to occasionally adjust your Firmness Control[™] system to return to your preferred SLEEP NUMBER® setting. This is normal, is a function of the environment, and does not reflect any defect in your Sleep Number mattress or Firmness Control™ system. Consequently, this warranty will not cover claims caused by changes in barometric pressure.

COSTS THIS WARRANTY DOES NOT COVER: In connection with your warranty claim, you are responsible for returning the warranted product or part to us. If your claim occurs during the first two warranty years, we will incur both the cost of shipping the warranted product or part back to us as well as the cost of our shipment of any repaired or replaced product or part back to you. If your claim occurs after the first two warranty years, shipping of products or parts related to your warranty claim will be at your expense in both directions. In either case, you remain responsible for bringing your authorized return to your nearest UPS facility or drop-off location. This warranty does not provide coverage for or the cost associated with the transportation, inspection, removal or installation of any product or parts except as provided above. The responsibility for the installation of any product or part replaced under this warranty and any related installation costs are yours regardless of whether there is any cost to you for the repaired or replaced product or part. WHAT YOU MUST DO TO KEEP THE WARRANTY IN EFFECT:

- KEEP YOUR ORIGINAL RECEIPT. You may be required to provide your original receipt at the time of any warranty claim.
- USE AN APPROPRIATE FOUNDATION. Your SLEEP NUMBER® mattress is designed to work on a firm, solid, non-spring foundation or adjustable bed base that is sufficiently strong and stable so as being capable of supporting the weight of the mattress and its occupants. Failure to use an appropriate foundation will void your warranty.
- DO NOT REMOVE THE LAW LABEL. Do not remove the law label attached to your *Sleep Number* mattress. This label identifies your mattress as being a genuine *Sleep Number* mattress and may be required to establish warranty coverage.
- KEEP THE MATTRESS AND/OR BASE IN A SANITARY CONDITION. This warranty shall not apply to any product or part found to be in an unreasonably unsanitary condition. A product is in an unreasonably unsanitary condition if it is so pervasively soiled that an inspection is unable to be conducted due to the presence of body fluids, blood borne pathogens, insects or other substances that otherwise suggest that the product has been subjected to misuse or abuse beyond ordinary wear and tear.
- WHAT IS THE WARRANTY ON REPAIRED OR REPLACED PRODUCTS OR PARTS? No new warranty is provided with any mattress or any component part that is repaired or replaced under this warranty. The warranty for any replacement mattress or component part runs from the date of your original purchase or invoice date, whichever is later. Any mattress or component part that is replaced under this warranty will be required to be returned to SLEEP NUMBER at the time of replacement.
- WHERE DOES THIS WARRANTY APPLY? Your warranty provides coverage for products purchased and used in the United States excluding its territories and possessions (e.g. Guam, Puerto Rico and the Virgin Islands). It is not applicable to claims for products purchased or used in any other country.
- WHAT ARE THE LIMITATIONS ON THIS WARRANTY? Your exclusive remedy, in lieu of all incidental, special or consequential damages, including for negligence, is limited to repair or replacement of any product or component deemed to be defective under the terms and conditions stated in this warranty. SLEEP NUMBER SHALL NOT BE LIABLE IN ANY CASE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY EVEN IF IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.
- ARE THERE ANY IMPLIED WARRANTIES? EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE APPLICABLE TO YOUR SLEEP NUMBER® MATTRESS AND/

OR BASE IS LIMITED IN DURATION TO TWO YEARS. EXCEPT AS OTHERWISE MAY BE REQUIRED BY LAW, THERE ARE NO OTHER EXPRESSED OR IMPLIED WARRANTIES OTHER THAN THE WARRANTY DESCRIBED HEREIN. *Sleep Number* does not make any warranty and specifically disclaims any warranty that your *Sleep Number* mattress and/or base is suitable for your particular medical condition. No express or implied warranties are extended to any persons who purchased the product from anyone other than *Sleep Number* or its authorized retailers and all such warranties are hereby excluded. *Sleep Number* does not authorize any person or entity to create for it any other obligation or liability in connection with this warranty.

HOW STATE LAW RELATES TO THIS WARRANTY: Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts so the foregoing limitations may not apply to you. This warranty gives you specific legal rights. You may also have other rights. These rights may vary from state to state.

HOW TO FILE A WARRANTY CLAIM: You must contact our Customer Service department at the phone number printed on the back cover of your owner's manual to obtain a Return Merchandise Authorization (RMA) number prior to returning any products or parts to us. You may be asked to undertake certain steps to troubleshoot the product or part for which a claim is being made. These steps are essential to determining whether your warranty claim is covered and ensuring shipment of the correct replacement product or part. Products or parts returned to us without an RMA will be destroyed and no warranty claim will be honored. You may also contact us by email at customerservice@selectcomfort.com or in writing to: Sleep Number Customer Service, 9800 59th Avenue North, Minneapolis, MN 55442.

Firmness Control[™] System Notification The equipment described in this guide has been tested and found compliant with the limits for a Class B digital

device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna .
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Any attempt to make changes or modifications could void the user's authority to operate the equipment according to FCC certification.

Important Safety Instructions:

- Your SLEEP NUMBER® bed is intended for in-home, non-commercial use only. Any unintended use voids the limited warranty.
- . The remote is not a toy and should be used under adult supervision.
- Do not open the Firmness Control[™] system or remote(s) (with the exception of the battery compartment). The warranty is void if these units are tampered with.
- Keep the Firmness Control[™] system and remote(s) away from heat sources such as radiators, heat registers, etc.
- Firmness Control system and remote(s) are not water resistant. Do not use or store near water – for example, in a wet basement, near an open window, etc.

Mattress FAQ's

- Q. Where are the air chamber caps? And where should I store them?
- A. The caps are in the Firmness Control[™] system box. Please store these in the mattress cover at the head of the bed in case you should ever need to temporarily cap your air chamber(s).
- Q. What if my foam comfort layer appears to be too small or irregular?
- A. Gently shake the layer as you place it on your mattress and it will recover its full size overnight.
- Q. What if I feel like I'm rolling toward the edge or toward the center of the mattress?
- A. Although rare, these sensations could potentially be experienced if one side of the mattress is set quite firm and the other side quite soft. Call Customer Service at 1.800.472.7185 for a remedy to this situation if bothersome to you.

Q. What if I notice a rubber smell from the air chamber(s)?

A. The odor you may smell is non-toxic and will fade over time. To minimize the smell, unzip the mattress cover and allow the air chamber to air out for a few hours. Laying a couple of dryer sheets on top of the air chamber will also help mask any odor by adding a fresh scent.

Q. Why are there body impressions on the mattress cover?

A. For a fuller look, use your Sleep Number® 100 function. If there are still body impressions in the cover, remove and shake the quilted top to restore some of the loft. In addition, a household vacuum nozzle may be used to fluff the cover.

Body impressions in a normal innerspring mattress would indicate that the spring support is compressing or breaking down. The SLEEP NUMBER® bed features air, which we believe is superior in every way for comfort and support. Since air cannot break down, you receive the same support after years of use as you do on the very first day.

Firmness Control[™] System FAQ's

Q. Why does my Sleep Number® setting change?

- A. Your SLEEP NUMBER® setting is based on the combination of body weight, volume of air in the air chamber and sleep position. Several factors may contribute to fluctuations in your *Sleep Number* setting:
 - Temperature can cause changes in your Sleep Number setting.
 For example, a heated mattress pad will cause the Sleep Number setting to increase.
 - Barometric pressure related to weather and altitude can cause your Sleep Number setting to change.
 - Weight can affect your Sleep Number setting. The Firmness Control[™] system acts similarly to a scale. More weight means a higher Sleep Number setting.
 - Different sleep positions can affect your Sleep Number setting. The more concentrated the weight is, the greater chance the Sleep Number setting will be higher (e.g., when you lie on your side). When weight is distributed more evenly throughout the chamber, it is more likely that the Sleep Number setting will be lower (e.g., when you lie on your back or stomach).

Q. What do I do if the Firmness Control[™] system doesn't run?

A. Make sure the power cord is securely plugged into the Firmness Control[™] system and a surge protector. Verify that the power cord is plugged into an outlet that has power and is not connected to a wall switch.

Q. I feel the mattress is losing air. What should I do?

A. Air loss can be caused by an unsecured hose connection, a defective air chamber, or a defective Firmness Control[™] system. First, make sure the hoses and hose extensions are securely connected to the air chambers. If you do not find any damaged or loose connections, identify which of the following situations matches your situation and follow the instructions for remedying your issue. NOTE: To avoid variations in your *Sleep Number* setting or level of comfort, make sure that you are lying in your preferred sleep position when adjusting and checking your *Sleep Number* setting.

If you have a dual air chamber bed and suspect only one (1) side of your SLEEP NUMBER® bed is getting softer:

- Inspect the o-ring and connectors for cracking or damage.
- Switch the hoses on the air chambers so the left hose (marked with a white band) is attached to the right air chamber and the right hose (marked with a blue band) is attached to the left air chamber. You should hear a click when the hose is securely connected to the air chamber.
- Fill the air chambers to the appropriate Sleep Number setting(s) for the person sleeping on each side of the bed.
- Sleep on the bed and monitor the feel of the bed's firmness on both sides.
- If neither chamber feels softer over time, you may have had a loose connection that was fixed when the hoses were switched.
 Switch the hoses back to their correct positions and continue to use the bed as usual.
- If an air chamber feels softer after switching hoses, contact Customer Service with the results (the issue stayed on the same side of the bed or it moved to the other side after switching hoses).

If you have a dual air chamber bed and both (2) air chambers are getting softer or you have a single air chamber bed and feel the air chamber getting softer:

- Inspect the o-ring(s) and connector(s) for cracking or damage, then reconnect the Firmness Control[™] system to the air chamber(s).
- Lie down in your normal sleep position and fill the air chamber(s) with suspected air loss to your normal *Sleep Number* setting plus

an additional 15 points (e.g., if you sleep at 35, fill to 50). Overinflation will compensate for air that may escape in one of the next steps.

- · Locate the air chamber caps that came with your bed.*
- Disconnect the hose extension(s) from the air chamber(s) and quickly cap the chamber(s).
- Leave the air chamber(s) capped for a minimum of 48 hours.
- If the air chamber(s) become noticeably softer when capped, contact Customer Service.
- If the air chamber(s) hold air, reconnect the hose extension(s) and continue using the bed. The air loss issue may have been due to environmental factors or a connection issue. Contact Customer Service if the air loss issue returns after reattaching the Firmness Control[™] system.

*Air chamber caps are typically found at the head of the bed inside the mattress cover in a small plastic bag. If you cannot find the caps, they may be available at your nearest SLEEP NUMBER® store or you can request them by emailing SLEEP NUMBER at CustomerService@selectcomfort.com with your request, or by calling 1.800.472.7185.

Q. Will my bed deflate if there is a power surge or power loss?

A. No, your mattress will maintain its firmness. To protect your Firmness Control[™] system, we recommend using a surge protector. NOTE: The warranty does not cover damage to the Firmness Control[™] system due to a power surge. Using a surge protection device (not included) is recommended.

Q. How will I know if there's a problem, like the chamber isn't inflating or the system isn't receiving power?

A. The remote is designed to let you know if something isn't working

like it's supposed to. An error message will let you know an issue has been detected, along with prompts for how to fix it. If the error is still not resolved, you will be instructed to visit sleepnumber.com/chat or to call us at 1.800.472.7185.

Remote Control FAQ's

Q. How do I change my remote language to Spanish/English?

A. To change the language, hold the Menu/Select button for five seconds and follow directions on the remote.

Q. How do I capitalize a letter in the middle of my name?

A. Select the letter and press the up/down arrows simultaneously.

Q. How many characters can I use for my name?

A. Eleven.

Q. My remote says there's an inflation/connectivity error. What should I do?

A. An error message lets you know an issue has been detected, along with prompts for how to fix it. If the error is still not resolved, you will be instructed to visit sleepnumber.com/chat or to call us at 1.800.472.7185.

Q How do I restore the remote's original settings?

A. To erase all stored information, hold down all three buttons (Up/ Down/Menu)

Q. Why won't my remote turn on?

A. You may need to replace the batteries. Your remote comes with two AA batteries that should last about six months with normal use. If new batteries don't resolve the issue, please visit sleepnumber.com/chat or call us at 1.800.472.7185.

Welcome to Sleep Number® InnerCircle[™]

Congratulations on the purchase of your SLEEP NUMBER[®] bed. As a *Sleep Number* bed owner you are now an Insider, a member of our InnerCircle[™] Soon you'll be enjoying all the benefits of a better night's sleep on your new *Sleep Number* bed.

Register Today for Insiders-Only Benefits

Go to sleepnumber.com/innercircle

Simply register your bed to start receiving exclusive discounts. Plus, you'll get access to pass-along coupons to share with friends and family, and everyone you know who could use a better night's sleep.

Receive special savings.

You'll always get 10% off every purchase. And, throughout the year, we'll send you additional Insider-exclusive offers on beds and bedding.

Earn rewards.

Improve the lives of friends and family by sharing what you love about your *Sleep Number* bed. Enjoy an exclusive Insiders reward of \$100 for referrals ONE through NINE who purchase a bed. When your 10th referral purchases, you will receive another \$699 for a total of \$1,599 in rewards.

Be the first to know.

As an Insider, you'll be the first to know about our latest innovations, from new Sleep Number beds to bedding solutions that will improve your sleep.





Help is just a click or phone call away.

If you ever have questions or need help finding your ideal comfort, please visit us at sleepnumber.com/chat to chat with a live representative 7 a.m. – 11 p.m. (Central Standard Time) daily or call 1.800.472.7185

Representatives are available by phone (Central Standard Time):

Monday-Friday 8 a.m. – 8 p.m. Saturday 8:30 a.m. – 5 p.m. Sunday Closed



9800 59th Avenue North, Minneapolis, MN 55442

