### Your Mobile

#### Keys and connectors



# OICOICI IDOL 5


### QUICK START GUIDE



PLEASE CONSIDER THE ENVIRONMENT BEFORE PRINTING



English - CJB29J0ALAAA Printed in China



#### Now key

Touch to expand




### Navigation bar

- Touch to hide navigation bar.
- Swipe up to display navigation bar.



#### Getting started

- Charge the battery
- Insert the pin into the hole and pull out the tray
- Insert or remove your SIM card or microSD card



### Home screen

You can bring all of the items (applications, shortcuts, folders, and widgets) that you use most frequently to your Home screen for quick access.

Touching the **Home** button always takes you back to the main Home screen.



# Phone call

### Making a call

Enter the desired number from the keyboard and touch  $\bigcirc$  to make a call.


### Answering a call

When you receive a call, touch to:



### Contacts


You can view and create contacts on your phone and synchronize these with your Gmail contacts or other applications on the web or on your phone.



## Messaging


You can create, edit, and receive SMS and MMS.

An SMS will be converted to MMS automatically when media files (image, video, audio, slides, etc.) are attached or subject or email addresses are added.



# Email

The first time you set up your phone, you can select to use an existing Email account or to create a new one.



# Help

To get help:

- View user manual and FAQ Visit http://www.alcatel-mobile.com
- Update your phone's software

Open the **Updates** application to check software updates.

• Back up your personal data

Go to Settings > Backup & reset > Back up my data and turn it on.

• Reset your phone

Go to Settings > Backup & reset > Factory data reset, and then touch RESET PHONE.

To get more info, you can access the **Phone Guard > Support Center** application.