



Welcome


Start Guide



T-Mobile 4G HotSpot Z64




GETTING TO KNOW YOUR MOBILE HOTSPOT



Part	Description
Micro-SIM card slot	Install the micro-SIM card.
WPS key	<ul style="list-style-type: none"> Double-press to show SNTP time, SSID, Wi-Fi password and software version on the LCD screen. Double-press again to exit. When the Wi-Fi function is enabled, hold it for less than 3 seconds to disable the Wi-Fi function. When the Wi-Fi function is enabled, hold it for more than 3 seconds to activate the WPS function. When the Wi-Fi function is disabled, hold it for more than 3 seconds to enable the Wi-Fi function only.
ON/OFF switch	Slide it to turn on/off the HotSpot.
LCD Screen	It shows the signal type, signal strength, battery, Wi-Fi, etc.
Charging/USB port	<ul style="list-style-type: none"> Charge your device. Connect the client to your device via USB cable.


Reset point

Insert a pin and hold it for 3 seconds to reset your device.



Coverage not available in some areas. Please see coverage details at T-Mobile.com. Device and screen images are simulated. Capable device is required to achieve 4G speed.


INDICATORS



	Indicates that your Mobile HotSpot is on T-Mobile's 2G network.		Indicates how many devices are connected to the Mobile HotSpot.
	Indicates that your Mobile HotSpot is on T-Mobile's 3G network.		Indicates that the Wi-Fi function is disabled.
	Indicates that your Mobile HotSpot is on T-Mobile's 4G network.		New text message in your message Inbox.
	There is no signal.		There is no battery installed.
	Indicates that your device is connected to the Internet.		Indicates that the battery power is low.
	Indicates that your device is disconnected from the Internet.		Indicates that the battery power is full.

SET UP YOUR MOBILE HOTSPOT

1. Lift SIM cover and Install SIM card.




2. Power on.



Charge your Mobile HotSpot

You can charge your Mobile HotSpot using the charger included in the box or by plugging it into your computer using the USB cable.



CONNECT & GO

Connect your Wi-Fi device to your Mobile HotSpot

- Power on your Mobile HotSpot.
- On your computer or other Wi-Fi enabled device, search for available Wi-Fi Networks and select the default Network Name (SSID) for your Mobile HotSpot.
- Enter the default password and click **OK**.

Note:

- It may take up to a minute to establish a connection.
- Then the default Network Name (SSID) and password will appear in the screen on your Mobile HotSpot or lift off the battery cover to find your default Network Name (SSID) and password



- It may take up to a minute to establish a connection.
4. Open a web browser and go to www.T-Mobile.com/ConnectMe
 - Simply follow the on-screen instructions to set up your No Annual Contract data service.

Note: Service or use is your agreement to T-Mobile's Terms and Conditions. **T-Mobile requires ARBITRATION of disputes UNLESS YOU OPT-OUT WITHIN 30 DAYS OF ACTIVATION.** See T-Mobile's Terms and Conditions for details at www.T-Mobile.com/terms-conditions.


USE THE WPS

If your client device supports WPS, you don't have to input the password manually after WPS has been available. Please do the following steps:

1. Power on your Mobile HotSpot and enable the Wi-Fi function.
2. Press and hold the WPS key on your device for more than 3 seconds to start Wi-Fi Protected Setup authentication process.
3. Enable the WPS function on your client to respond to this authentication process.
4. Follow the system prompts on your client to finish the connection.

Note: For the detailed operations about the client, please refer to the client's instruction

MANAGING YOUR MOBILE HOTSPOT



Access T-Mobile 4G Mobile Hotspot


You can access your 4G Mobile Hotspot device information, using an Internet browser

To access using a browser, do the following:

1. Connect to your hotspot device via Wi-Fi using the network connection software on your computer. Provide the Wi-Fi network password, if requested.
2. Open a browser and enter <http://mobile.hotspot> in the address bar. The T-Mobile 4G Mobile Hotspot login screen appears.
3. Enter your **Password** in the field provided. The default password is admin.
4. Select the **Save Password** checkbox if you wish to bypass the login screen in the future.

5. Click **Login**. If you entered the correct password, the Dashboard screen appears.

To access via USB cable, do the following:

1. Connect your hotspot device to the PC with USB cable.
2. Power on your device.
3. The OS detects and recognizes new hardware and finishes the installation automatically. After successful installation, the icon  will appear on your desktop.

NOTE: If the system does not launch installation automatically, you can run the installation program in path of My Computer > Mobile Hotspot.

4. Double click the icon to open the login screen.
5. Enter your **Password** in the field provided. The default password is admin.
6. Select the **Save Password** checkbox if you wish to bypass the login screen in the future.
7. Click **Login**. If you entered the correct password, the Dashboard screen appears.

Change Mobile Hotspot Admin Password

1. Access <http://mobile.hotspot>
2. Click **Settings** in the navigation area.
3. Select the **Device Settings** tab
4. Follow steps under Account Management to update your **Password**

5. Click **Apply**. If everything is entered correctly, the Admin Password Changed dialog appears indicating the password was successfully changed.

Change Mobile Hotspot Network Name (SSID)

1. Access <http://mobile.hotspot>.
2. Click **Settings** in the navigation..
3. Select the **Wi-Fi Settings** tab.
4. Change the name that appears in the **Network Name (SSID)** field in the Wi-Fi Settings area.
5. Select or deselect the **Broadcast Network Name** checkbox to enable or disable broadcasting the hotspot's Network Name (SSID).
6. Click **Apply** to save your changes on the Wi-Fi Settings tab of the Settings screen.

Change Mobile Hotspot Wi-Fi Password

1. Access <http://mobile.hotspot>.
2. Click **Settings** in the navigation area.
3. Select the **Wi-Fi Settings** tab.
4. Change the value that appears in the **Pass Phrase** field in the Wi-Fi Settings area.
5. Click **Apply** to save your changes on the Wi-Fi Settings tab of the Settings screen.

ADDITIONAL INFORMATION

Capable device(s) required to achieve 4G speeds.

Wi-Fi: Capable devices required. Devices using wireless connections may be vulnerable to unauthorized attempts to access data and software stored on the device. Plan data allotment applies to use by connected devices sharing Wi-Fi. Use of connected devices subject to T-Mobile Terms and Conditions.


Mobile Internet Postpaid Data Passes: Qualifying postpaid plan and qualifying credit required. SIM Starter Kit may be required. Passes do not include voice or messaging. Pass charges will appear on bill statement for effective date of the pass. May purchase one add'l pass in same category prior to expiration of active pass. Partial megabytes rounded up. Full speeds available up to specified data allotment then slowed to up to 2G speeds. No domestic or international roaming, unless Pass is specifically for roaming. Service available for time/usage amount provided by pass. For time period, a day is 12 am to 11:59 pm Pacific Time. Usage applied first to passes, next to any applicable promotional data, then monthly plan allotment.

Mobile Internet Pay In Advance Data Passes: Limited time offer; subject to change. Not all features available on all devices. SIM starter kit may be required. Service available for time period and/or usage amount provided by Pass. For time period, a day is 12:00 am to 11:59 pm, Pacific Time. Usage rounded up to the nearest MB each

session. Only one Pass may be active at a time. Account suspended after 365 days of inactivity. Data only; does not include voice, messaging or Wi-Fi services. Domestic only; no roaming. Usage applied first to on demand passes, next to free data, then monthly Mobile Internet allotment.

Device and screen images simulated. **Coverage:** Service not available in some areas. See brochures and **Terms and Conditions (including arbitration provision)** at www.T-Mobile.com, for additional information, coverage maps, and restrictions and details. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. © 2014 T-Mobile USA, Inc.

ADDITIONAL HELP

- T-Mobile Mobile HotSpot URL: <http://mobile.hotspot/> or IP address: 192.168.0.1.
- From <http://mobile.hotspot>, click  for help.
- Get in touch, free of charge: Just dial 611 from your T-Mobile phone or call 1-877-453-1304. Customer Care representatives are available from 3 a.m. to 10 p.m. Pacific time, daily. Automated account help is available 24 hours a day, 7 days a week.