

D2-4/D2-4P

API Register Specification (D2 Audio DSP Sound Enhancement Algorithm Support)

Abstract

This application note describes the Applications Programming Interface (API) for control, register addressing and audio processing data parameters of the D2-4 ([D2-41051](#)), and the D2-4P ([D2-45057](#)) devices. This document accompanies the IC product datasheets for the D2-4 and D2-4P devices.

Signal flow and audio path architecture are internally-defined within the D2-4. However, the audio processing blocks within the signal path are programmable, and their parameters are adjusted by the register control described in this document.

Only the specific register addresses defined in this document are valid. All other addresses are reserved and no data should be written to any of these reserved addresses.

The D2-4/D2-4P devices support either the D2 Audio DSP Sound Enhancement Algorithm or SRS WOW/HD™ audio enhancement algorithms. These device-specific functions are integrated within the firmware as part of the standard audio processing signal flow, and algorithm support is device part-number specific.

This document describes the signal flow and audio enhancement processing for the D2-41051 (D2-4) and D2-45057 (D2-4P) devices that support the D2 Audio DSP Sound Enhancement Algorithm processing.

Unless otherwise noted, all references to D2-4 within this document also apply to the D2-4P device, and except for the enhancement algorithms, all other audio processing functions and register control are identical for all devices

Contents

1. Registers and Control	3
1.1 Hexadecimal Addresses and Data	3
1.2 Round-Off Discrepancies In Calculations	3
1.3 Default Settings And Parameter Values	3
1.4 Storing Parameters to EEPROM	3
1.5 Reading and Writing Registers	3
1.6 Register Address Table Map	5
2. Audio Processing	5
2.1 Channel Number Reference	8
2.2 Enhancement Audio Processing Options	8
3. Input Select Register	8
4. Master Volume Control	9
4.1 Volume and Trim Control Parameters	9
4.2 Master Volume Gain Parameter Calculations	10
5. Output Trim Volume Controls	10
5.1 Output Trim Volume Parameter Calculation	11
5.2 Output Trim Volume Register Addresses	11
6. Mixers	11
6.1 Mixer Gain	12
6.2 Mixer Register Addresses	13
7. Stereo Router	13
7.1 Router Register Parameter Data and Addresses	13

8. Compressors (Limiters)	14
8.1 Threshold	14
8.2 Ratio	14
8.3 Attack and Release Time	14
8.4 Makeup Gain	15
8.5 Compressor Register Addresses	15
9. Tone Controls	16
9.1 Tone Control Parameters and Registers	16
9.2 Tone Control Corner Frequency Calculation	16
9.3 Tone Control Gain Calculation	17
10. Multi-Band Equalizers	17
10.1 Equalizers Center Frequency	17
10.2 Equalizers Quality Factor	18
10.3 Equalizers Gain	18
10.4 Multi-Band Parametric Equalizer Register Addresses	18
11. Loudness Contour	20
11.1 Loudness Contour Register Data	20
12. High-Pass and Low-Pass Crossover Filters	20
12.1 Corner Frequency	21
12.2 Quality Factor	21
12.3 Configuration Settings	21
13. D2 Sound Enhancement Suite Algorithms Processing	22
13.1 D2 Sound Enhancement Suite Algorithm Bypass Register	23
13.2 Wide Sound Processing	23
13.3 Deep Bass Processing	24
13.4 Audio Align Processing	25
13.5 Clear Voice Processing	25
14. Signal Flow Option Register	27
15. Hardware Option Register	28
16. Revision History	29

List of Figures

Figure 1. I ² C Write Sequence Operation	3
Figure 2. I ² C Read Sequence Operation	4
Figure 3. D2-4 Family Audio Processing Signal Flow	6
Figure 4. D2-4P Family Audio Processing Signal Flow	7

Related Literature

For a full list of related documents, visit our website:

- D2-4 ([D2-41051](#)) device page
- D2-4P ([D2-45057](#)) device page

1. Registers and Control

Registers are accessed through the I²C control interface, where the D2-4 operates as an I²C slave device that receives communication and control from a system controller operating as the I²C master.

1.1 Hexadecimal Addresses and Data

Unless otherwise noted, all address and data values in this document are 24-bit hexadecimal numbers.

1.2 Round-Off Discrepancies In Calculations

Equations in this document represent the reference design's firmware algorithm calculations for defining the data parameters. Often the values displayed from the D2 Audio DSP Customization GUI user interface screen may appear in error by a very small difference from the true calculated equation values. This is due to round-off of internal calculations for presentation on the user screen and is not an error in actual parameter value.

1.3 Default Settings And Parameter Values

Default parameter settings listed in this document are the default settings internally defined by the D2-4 firmware. Additional parameter settings can be stored in a parameter table within an on-board EEPROM, where upon booting from that EEPROM, its data defines register settings within this address range. Parameter settings can also be written from a system controller during booting or during operation.

1.4 Storing Parameters to EEPROM

An EEPROM can be installed in the application, where the D2-4 device can read saved parameter settings from the EEPROM upon reset or power-up, loading the programmable audio processing registers with the settings previously saved to EEPROM. The firmware within the D2-4 supports writing audio processing register parameter settings to this EEPROM to save setting changes.

To store parameters to EEPROM:

- Write This Default Value: 000000
- To Register Address: 800000

This initiates the sequence for the D2-4 to write all of its programmable audio processing data parameters to EEPROM.

1.5 Reading and Writing Registers

All reads or writes to registers begin with a Start Condition, followed by the Device Address byte, three Register Address bytes, three Data bytes, and a Stop Condition. The I²C channel address is defined internal to D2-4 at a single address:

- I²C device address for D2-4/D2-4P is 0xB2.

1.5.1 Writing to Registers

[Figure 1](#) shows the write sequence. [Table 1 on page 4](#) describes each byte of the write sequence. Initiate a write by setting the read/write bit (R/W bit) within the device address byte.





Figure 1. I²C Write Sequence Operation

Table 1. I²C Write Sequence

Byte	Name	Description
0	Device Address	Device Address, with R/W bit set
1	Register Address [23:16]	Upper 8 bits of address
2	Register Address [15:8]	Middle 8 bits of address
3	Register Address [7:0]	Lower 8 bits of address
4	Data [23:16]	Upper 8 bits of write data
5	Data [15:8]	Middle 8 bits of write data
6	Data [7:0]	Lower 8 bits of write data

1.5.2 Reading from Registers

All reads to registers, shown in [Figure 2](#), require two steps. First, the master must send a write command consisting of the device address with the read/write bit (R/W bit) set to indicate a write, followed by three register address bytes. However, instead of following the address with three data bytes as in a write command, the master must then send a repeated Start, this time with the R/W bit set to read. The master then reads the next three data bytes. The master must “ACK” the first two read bytes and send a “NACK” on the third byte received, and finally a Stop condition to complete the transaction. The device's control interface acknowledges each byte by pulling SDA low on the bit immediately following each write byte. These bytes are described in [Table 2](#).

**Figure 2. I²C Read Sequence Operation****Table 2. I²C Read Sequence**

Byte	Name	Description
0	Device Address	Device Address, with Write bit set
1	Register Address [23:16]	Upper 8 bits of address
2	Register Address [15:8]	Middle 8 bits of address
3	Register Address [7:0]	Lower 8 bits of address
4	Device Address	Device Address, with Read bit set
5	Data [23:16]	Upper 8 bits of write data
6	Data [15:8]	Middle 8 bits of write data
7	Data [7:0]	Lower 8 bits of write data

1.6 Register Address Table Map

Assigned register locations are shown in [Table 3](#). See the specific audio processing block's individual register address assignment for specific register function definition.

Only the specific register addresses defined in this document are valid. All other addresses are reserved and no data should be written to any of these reserved addresses.

Table 3. Register Addresses

Address Ranges (hex)		Function
From	To	
000000		Master Volume Adjustment Control
020001		Input Select Write Address
020002		Input Select Read Address
000001	000005	Output Volume Trim Controls
000006	000009	2x2 Input Mixer
00000A	000011	Tone Controls
000012		Stereo Router
000013	00001E	Input Compressors (Limiters)
00001F	00003C	5-Band Equalizers
00003D	000060	3-Band Equalizers
000061	00007E	Speaker Equalizers
00007F	0000AE	High-Pass and Low-Pass Filters (Output Channels 1-4)
0000AF	0000B0	Stereo Mixer
0000B1	0000BC	High-Pass and Low-Pass Filters (Output Channel 5)
0000BD	0000DA	Output Compressors (Limiters)
0000DB	0000E9	Loudness Contour Controls
0000EC	00013B	D2 Audio DSP Sound Enhancement Algorithm Processing Controls
000166		Signal Flow Option Register
000167		Hardware Option Register
-		All Other Addresses Reserved

2. Audio Processing

The audio processing and signal flow within the D2-4 devices is defined by the internal ROM firmware and executed by the device's internal DSP. This firmware defines the audio flow architecture and the processing blocks used in that definition, but also provides for programmable parameters for those processing blocks.

[Figure 3 on page 6](#) shows the signal flow for the D2-4 devices. Signal flow and programmable audio processing for the D2-4P devices, shown in [Figure 4 on page 7](#), is identical. [Table 3](#) lists the programmable audio processing blocks described in this document.




Figure 3. D2-4 Family Audio Processing Signal Flow




Figure 4. D2-4P Family Audio Processing Signal Flow

2.1 Channel Number Reference

Channel number designations that are either zero-based or one-based are used interchangeably in documents or software tools supporting the D2-4/D2-4P devices. References of “Channels 1 through 5” therefore correlate to similar references of “Channels 0 through 4.” A “one-based” reference is used in this document (for example, input channels are referenced as 1 and 2, and output channels are referenced as 1, 2, 3, 4, and 5).

2.2 Enhancement Audio Processing Options

The D2-4/D2-4P devices support either the D2 Audio DSP Sound Enhancement Algorithms or SRS WOW/HD audio enhancement algorithms. These device-specific functions are integrated within the firmware as part of the standard audio processing signal flow, and are supported per device as:

- D2 Audio DSP Sound Enhancement algorithm (Wide Sound, Deep Bass, Audio Align, and Clear Voice) Audio Processing
 - Supported in the D2-41051 and D2-45057 devices
- SRS WOW/HD Audio Processing
 - Supported in the D2-41151 and D2-45157 devices

Each of these enhancements uses its own algorithms, where choice of enhancement is specified by the D2-4 device's part number. The D2-41051 and D2-45057 include only D2 Audio DSP Sound Enhancement Algorithm support. The D2-41151 and D2-45157 include only SRS WOW/HD support. These enhancements also have their own unique set of programmable parameters to control their operation. The location of these enhancement blocks within the signal flow is shown as the “Licensed Audio Processing Algorithm” block in [Figures 3 and 4](#).

Each enhancement algorithm support is unique only to devices referenced by its particular part number, and operates only within the devices of that part number. To avoid conflict with any software writes to address locations used by each of the enhancement algorithms, any read/write instructions to register locations of algorithms not included or supported within each part number device are ignored. Only the instructions to addresses included for the device's supported algorithms are acknowledged.

This document describes register assignments for only the D2 Audio DSP Sound Enhancement Algorithms. Register assignments for SRS WOW/HD operation are provided separately.

3. Input Select Register

The Input Select register assigns the source input that is presented to the audio processing path. The D2-4 devices support two input choices of S/PDIF Digital, or Serial Audio Input (SAI) Digital inputs. The default firmware setting is to use SAI inputs.

The input sources specified by the Input Select register route to the on-chip Sample Rate Converters (SRC) where they are then presented to the on-chip audio processing.

The input select register operates at two different register addresses:

- Address 020002 is read-only
- Address 020001 is write only

The first two data bits (bits [23:22]) of the Input Select register must be set to “1”. Bit zero (0) defines the input selection. All other bits of this register are reserved and must be set to “0”.

The input to the audio processing path is assigned by writing this data to address 020001:

- C00001 assigns S/PDIF as the input
- C00000 assigns SAI as the input

Table 4. D2-4 Input Select Register

Register Bits [23:0]																							
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
																				Input Channel Source			
1	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Always 0xCx				All bits = 0																Assigns SAI to Input Channels			
																				0	0	0	1
																				Assigns S/PDIF Digital to Input Channels			

4. Master Volume Control

A software-controlled Master Volume control is used to adjust the global volume for all audio processing channels. One single register is used for the Master Volume adjustment.

Volume level is represented as attenuation, and does not introduce additional gain ([Note 1](#)).

- The Master Volume control register address is:
 - 000000
- The default value is:
 - 800000, which corresponds to 0dB, or no attenuation

4.1 Volume and Trim Control Parameters

The Master Volume controls and Channel Volume Trim controls are both implemented to provide attenuation, and do not introduce additional gain ([Note 1](#)). Maximum level with no attenuation is 0dB, and maximum attenuation is 100dB. Setting their register parameter values to 000000 causes full cut off (infinite attenuation) of the signal.

The Volume Control gain parameter is a signed, 24-bit number. Signal polarity can be inverted through the volume gain control block, where the magnitude of the signal attenuation is identical, but the signal polarity is inverted in phase. The Most Significant Bit (MSB) of the 24-bit parameter defines this signal polarity. In normal (non-inverted) application, the 24-bit gain parameter is represented as a negative number, and its MSB is set. Clearing this MSB (representing a positive number) inverts the polarity. Calculations for both normal and inverted parameters are shown in [Equations 1](#) and [2](#), which is accomplished simply removing the negative sign from the gain formula and recalculating the gain parameter. This yields a positive instead of negative 24-bit parameter value, but represents the same attenuation level.

Regardless of the sign of the 24-bit hex parameter value, the magnitude of the gain (attenuation) adjustment does not change. Only the signal polarity changes with the corresponding sign change of the parameter. A negative 24-bit hex parameter therefore represents normal polarity, whereas a positive 24-bit hex parameter represents inverted polarity but with the same magnitude.

Maximum level with no attenuation is 0dB, and maximum attenuation is 100dB. **Note:** It is possible to enter parameter values correlating to attenuation beyond this 100dB limit, but only values within the specified range are valid.

Setting the register parameter value to 000000 causes full cut off (infinite attenuation) of the signal.

4.2 Master Volume Gain Parameter Calculations

(EQ. 1)	Volume Gain Parameter = $\left\lceil 2^{23} \times 10^{\left(\frac{\text{Gain}}{20}\right)} \right\rceil$	Normal Polarity, Non-Inverted
(EQ. 2)	Volume Gain Parameter = $\left\lceil 2^{23} \times 10^{\left(\frac{\text{Gain}}{20}\right)} \right\rceil$	Inverted Polarity
where: Gain is in dB, and is a negative (or zero) term (Note 1).		
	Minimum	Maximum
Valid Range (Note 2)	-100dB	0dB
	FFFFAC	800000
	000054	7FFFFFFF
		000000
		Signal Path Cut-Off
Default Setting	0dB	800000

Notes:

1. The term "Gain" is often used to indicate level adjustment, and within general discussions, can actually represent either increase or attenuation of level. In this terminology, positive gain is an increase in signal level, while negative gain is attenuation. The Master Volume control implements attenuation and does not introduce gain. As such, the "Gain" term used in the equations is a negative value that actually represents an attenuation.
2. The maximum parameter value of 800000 may be appear as 800001 from the D2 Audio DSP Customization GUI user interface screen. This is due to round-off of internal calculations for presentation on the user screen and is not an error in actual parameter value.

5. Output Trim Volume Controls

A dedicated per-channel output volume level adjustment provides individual channel gain or attenuation as a final adjustment to trim signal levels at each of the outputs.

These output level settings provide a gain ([Note 1](#)) from +12dB to -88dB. Each of the output volume adjustments has its own register address and level setting.

The Output Volume gain parameter is a signed, 24-bit number. Signal polarity can be inverted through the gain control blocks, where the magnitude of the signal attenuation or gain is identical, but the signal polarity is inverted in phase. The MSB of the 24-bit parameter defines this signal polarity. In normal (non-inverted) application, the 24-bit gain parameter is represented as a negative number, and its MSB is set. Clearing this MSB (representing a positive number) inverts the polarity. Calculations for both normal and inverted parameters are shown in [Equations 3](#) and [4](#), which is simply removing the negative sign from the gain formula and recalculating the gain parameter. This yields a positive instead of negative parameter value.

Regardless of the sign of the 24-bit hex parameter value, the magnitude of the gain (attenuation) adjustment does not change. Only the signal polarity changes with the corresponding sign change of the parameter. A negative 24-bit hex parameter therefore represents normal polarity, whereas a positive 24-bit hex parameter represents inverted polarity but with the same magnitude.

Maximum level (gain) is +12dB, and minimum level (attenuation) is -88dB. **Note:** It is possible to enter parameter values correlating to attenuation beyond these limits, but only values within the specified range are valid.

Setting the register parameter value to 000000 causes full cut off (infinite attenuation) of the signal.

5.1 Output Trim Volume Parameter Calculation

$$(EQ. 3) \quad \text{Output Trim Gain Parameter} = \left\lceil 2^{23} \times 10^{\left(\frac{\text{Gain} - 12}{20}\right)} \right\rceil \quad \text{Normal Polarity, Non-Inverted}$$

$$(EQ. 4) \quad \text{Output Trim Gain Parameter} = \left\lceil 2^{23} \times 10^{\left(\frac{\text{Gain} - 12}{20}\right)} \right\rceil \quad \text{Inverted Polarity}$$

where: Gain is in dB (positive for gain; negative for attenuation)

	Minimum	Maximum	
Valid Range (Note 2)	-88dB	+12dB	
	FFFFAC	800000	Normal Polarity, Non-Inverted
	000054	7FFFFFFF	Inverted Polarity
		000000	Signal Path Cut-Off
Default Setting	0dB	E00000	

5.2 Output Trim Volume Register Addresses

Register Parameter	Output Trim Addresses
Channel 1 Address	000001
Channel 2 Address	000002
Channel 3 Address	000003
Channel 4 Address	000004
Channel 5 Address	000005

6. Mixers

The D2-4 audio processing path includes two mixers.

- A 2-input by 2-output (2x2) mixer routes the input sources to each of the two audio processing input paths.
- A 2-input Stereo mixer routes the outputs of the two input channels to drive the fifth output processing channel.

The Input mixer contains four registers, and the Stereo mixer contains two registers. Each register defines the gain of its specific input channel that is mixed into its specific output channel.

Either input of the Input mixer can be mixed at adjustable gains into either or both of its two outputs. Default setting is 0 dB for Channel 1 input to Channel 1 output, and for Channel 2 input to Channel 2 output. Gains across channels are set at defaults of cut-off.

The two stereo inputs from Channel 1 and Channel 2 can be mixed and/or routed to Channel 5 through the Stereo mixer. This configuration typically provides a mix of both stereo input channels for crossover processing and becoming the source for the subwoofer channel. Gains for both input channels are adjustable to feed the single stereo mixer output.

Operation and calculations for the mixer parameters are identical for both mixer blocks.

6.2 Mixer Register Addresses

6.2.1 2x2 Input Matrix Mixer Register Addresses

Register Parameter	Input Channel 1	Input Channel 2
Output Channel 1	000006	000007
Output Channel 2	000008	000009

6.2.2 Stereo Mixer Register Addresses

Register Parameter	Input Channel 1	Input Channel 2
Output Channel	0000AF	0000B0

7. Stereo Router

A 4x4 stereo router assigns any one of the four input channel paths to each of the four output paths. The router performs path assignment only. It does not have provision for gain or signal level adjustment.

The lower 8 bits at a single address location (000012) are used for the router path assignment, and these 8 bits are divided into four groups of 2 bits each, where each group corresponds to the router's output channel. The contents of each 2 bits within these groups defines the input channel that is assigned to that particular output.

7.1 Router Register Parameter Data and Addresses

	Reserved	Output Channel 4	Output Channel 3	Output Channel 2	Output Channel 1
Register Bits	[23:8]	[7:6]	[5:4]	[3:2]	[1:0]
Default Value	0x000	11	10	01	00

7.1.1 Input Channel Value Definitions

The bit values correspond to the input channel that is assigned to the output channel:

Bit Value	Input Channel
00	1
01	2
10	3
11	4

The default data value for the router is 0000E4, which corresponds to:

Input Channel	Output Channel
1	1
2	2
3	3
4	4

8. Compressors (Limiters)

Audio compressors are provided in both the input and output audio processing paths. Both audio input channels have one compressor. Each of the five output channels also has one compressor. Each compressor has configurable Compression Ratio, Threshold, Attack and Release Time, and Makeup Gain. The compressors operate and are implemented independently. Their audio processing operation (compressor or limiter function) is determined by their programmable settings.

8.1 Threshold

The compressor/limiter function operates to reduce the gain of its output signals when its input exceeds a given threshold. The Threshold parameter is a signed, 24-bit number. The threshold value is entered in dB. The valid range for threshold is -90dB to 0dB.

8.1.1 Limiter Threshold Parameter Calculation

$$(EQ. 7) \quad \text{Limiter Threshold Parameter} = 2^{23} \times \frac{1}{32} \left[\left(\frac{\text{Threshold}}{10 \times \log_{10}(2)} \right) + 31 \right]$$

where: Threshold is in dB (-90dB to 0dB)

	Minimum	Maximum
Valid Range	-90dB 000000	0dB 7C0000
Default Setting	0dB	7C0000

8.2 Ratio

The Limiter Ratio is the number of dB above the threshold that the input level must increase to increase the output level by 1dB. The Ratio parameter is a signed, 24-bit number. The Ratio value is entered as a ratio-to-one number. The valid range for the Ratio parameter is 1 to 100. **Note:** A ratio of 1 disables the limiter, and values above 10 are typically used to provide a limiting function.

8.2.1 Limiter Ratio Parameter Calculation

$$(EQ. 8) \quad \text{Limiter Ratio Parameter} = 2^{23} \times \left[1 - \frac{1}{\text{Ratio}} \right]$$

	Minimum	Maximum
Valid Range	1:1 000000	100:1 7EB852
Default Setting	100:1	7EB852

8.3 Attack and Release Time

The Attack Time is the rate at which the gain is reduced when the input exceeds the threshold. The Release Time is the rate at which the gain is increased when the input falls below the threshold. Calculations and parameters for both Attack and Release times are identical.

The Attack and Release Time parameters are signed, 24-bit numbers. The time value is entered as milliseconds. The valid ranges for both the attack and release times are 1ms to 1000ms.

8.3.1 Limiter Attack and Release Time Parameter Calculation

$$(EQ. 9) \quad \text{Attack or Release Time Parameter} = 2^{23} \times \left[a + \sqrt{a^2 - 2a} \right]$$

Where:

$$a = \left[\cos\left(\frac{1}{3 \times T}\right) - 1 \right]$$

T is in milliseconds

	Minimum	Maximum	
Valid Range	1ms 24011D	1000ms 000AEC	
Default Settings	10ms 100ms	04322A 006D08	Attack time Release time

8.4 Makeup Gain

Depending on the settings for Threshold and Compressor Ratio, additional Makeup Gain may be necessary to reach a full-scale output.

The Makeup Gain parameter is a signed, 24-bit number. The Makeup Gain value is entered in dB. The valid range for Makeup Gain is -70dB to +36dB.

8.4.1 Limiter Makeup Gain Parameter Calculation

$$(EQ. 10) \quad \text{Makeup Gain Parameter} = 2^{23} \times \left[\frac{10^{\left(\frac{\text{Gain}}{20}\right)}}{64} \right]$$

where Gain is in dB

	Minimum	Maximum
Valid Range	-70dB 000029	+36dB 7FFDBD
Default Settings	0dB	020000

8.5 Compressor Register Addresses:

8.5.1 Input Channel Compressor Register Addresses

Register Parameter	Channel 1	Channel 2
Threshold	000014	00001A
Ratio	000015	00001B
Attack Time	000016	00001C
Release Time	000017	00001D
Makeup Gain	000018	00001E

8.5.2 Output Channel Compressor Register Addresses

Register Parameter	Channel 1	Channel 2	Channel 3	Channel 4	Channel 5
Threshold	0000BE	0000C4	0000CA	0000D0	0000D6
Ratio	0000BF	0000C5	0000CB	0000D1	0000D7
Attack Time	0000C0	0000C6	0000CC	0000D2	0000D8
Release Time	0000C1	0000C7	0000CD	0000D3	0000D9
Make Up Gain	0000C2	0000C8	0000CE	0000D4	0000DA

9. Tone Controls

A tone control block is included for each of the audio processing channels. Each of the filters (bass or treble) is implemented with a first-order (6dB/octave) roll-off that uses programmable corner frequency and a boost or attenuating gain. The signal flow processing automatically provides a smooth transition between tone control changes.

9.1 Tone Control Parameters and Registers

Each bass and treble filter includes its own frequency register and gain register to provide a total of four registers per each tone control block.

9.1.1 Tone Control Register Addresses

Register Parameter	Channel 1	Channel 2
Bass Corner Frequency Parameter	00000A	00000E
Bass Gain Parameter	00000B	00000F
Treble Corner Frequency Parameter	00000C	000010
Treble Gain Parameter	00000D	000011

9.2 Tone Control Corner Frequency Calculation

The Corner Frequency of the Tone Control is defined as the frequency at which the gain of the filter is -3dB. The Corner Frequency parameter is a signed, 24-bit number.

9.2.1 Tone Control Corner Frequency Parameter Calculation

(EQ. 11) Corner Frequency Parameter = $2^{23} \times \left[\frac{\sin\left(\frac{\pi \times F}{24000}\right) - 1}{\cos\left(\frac{\pi \times F}{24000}\right)} \right]$			
where F = Frequency in Hz			
Valid Range	Minimum	Maximum	
	10Hz	22kHz	
	802ADD	FFFFFF	For 10Hz to 11.999kHz
	000000	6237C4	For 12kHz to 30kHz
Default Settings	200Hz	834ED4	Bass Default
	2000Hz	9DC83B	Treble Default

9.3 Tone Control Gain Calculation

The gain parameter is a signed, 24-bit number. Gain is entered in dB. The valid range for Tone Control Gain is -14dB to +14dB. A setting of 000000 sets gain to unity (0dB) for no boost or cut.

9.3.1 Tone Control Gain Parameter Calculation

$$(EQ. 12) \quad \text{Tone Control Gain Parameter} = 2^{23} \times \left[\frac{10^{\left(\frac{\text{Gain}}{20}\right)} - 1}{4} \right]$$

where Gain is in dB

	Minimum	Maximum	
Valid Range	-14dB	+14dB	
	E6667A	7FFE1D	
	000000	0dB, no boost or cut	
Default Settings	0dB	000000	Bass Default
	0dB	000000	Treble Default

10. Multi-Band Equalizers

Three sets of multi-band parametric equalizers are provided in the audio signal processing path.

Two sets of 5-band equalizers are included in each of the two input channels, and four 3-band equalizers are located in the four output channels. These equalizers operate identically and provide separate equalization blocks, such as EQs that are adjustable by the end user, and EQs for implementing end product presets that are defined during production.

The equalizer blocks are implemented from individual identical cascaded stages (three stages for the 3-band, and five stages for the 5-band equalizers). Each stage operates completely independently, but all are configured identically. Each equalizer band stage uses three register parameters to define its operation. These parameters are Center Frequency, Quality-Factor (Q), and Gain. All parameters are calculated identically for each of the equalizer stages.

10.1 Equalizers Center Frequency

The Center Frequency parameter is a signed, 24-bit number. The frequency value is entered in Hz. The valid range for the frequency parameter is 10Hz to 22000Hz.

10.1.1 Equalizer Center Frequency Parameter Calculation

$$(EQ. 13) \quad \text{Frequency Parameter} = 2^{23} \times \left[\frac{F}{24} \times 10^{-3} \right]$$

where F = Frequency in Hz

	Minimum	Maximum	
Valid Range	10Hz	22kHz	
	000DA7	755555	
Default Settings	400Hz	022222	

10.2 Equalizers Quality Factor

The Quality Factor (Q) parameter is a signed, 24-bit number. The valid range for the Q parameter is >0.5 to 10. Note: A setting of 0.5, producing a parameter value of 800000 is invalid.

10.2.1 Equalizer Q-Factor Parameter Calculation

(EQ. 14) Q-Factor Parameter = $2^{23} \times \left[\frac{1}{2 \times Q} \right]$		
Valid Range	Minimum	Maximum
	0.5 ⁺	10
	7FFFFFF	066666
(Q>0.5; a value of 0.5 creates a hex value of 800000 which is invalid)		
Default Settings	Q = 4.323	0ECE1F

10.3 Equalizers Gain

Gain is defined at the equalizer block stage's center frequency. The gain parameter is a signed, 24-bit number. Gain is entered in dB. The valid range for gain is -30dB to +6dB.

10.3.1 Equalizer Gain Parameter Calculation

(EQ. 15) Equalizer Gain Parameter = $-2^{23} \times \left[1 - 10^{\left(\frac{\text{Gain}}{20} \right)} \right]$		
where Gain is in dB		
Valid Range	Minimum	Maximum
	-30dB	+6dB
	840C37	7FFF3F
	000000	Bypasses EQ filter stage element
Default Settings	0dB	000000

10.4 Multi-Band Parametric Equalizer Register Addresses

10.4.1 3-Band Parametric Equalizer Addresses

Register Parameter	Channel 1 Address	Channel 2 Address	Channel 3 Address	Channel 4 Address
Band 1 Frequency	00003D	000046	00004F	000058
Band 1 Damping/Bandwidth	00003E	000047	000050	000059
Band 1 Gain/Bypass	00003F	000048	000051	00005A
Band 2 Frequency	000040	000049	000052	00005B
Band 2 Damping/Bandwidth	000041	00004A	000053	00005C
Band 2 Gain/Bypass	000042	00004B	000054	00005D
Band 3 Frequency	000043	00004C	000055	00005E
Band 3 Damping/Bandwidth	000044	00004D	000056	00005F
Band 3 Gain/Bypass	000045	00004E	000057	000060

10.4.2 5-Band Parametric Equalizer Addresses

Register Parameter	Channel 1 Address	Channel 2 Address
Band 1 Frequency	00001F	00002E
Band 1 Damping/Bandwidth	000020	00002F
Band 1 Gain/Bypass	000021	000030
Band 2 Frequency	000022	000031
Band 2 Damping/Bandwidth	000023	000032
Band 2 Gain/Bypass	000024	000033
Band 3 Frequency	000025	000034
Band 3 Damping/Bandwidth	000026	000035
Band 3 Gain/Bypass	000027	000036
Band 4 Frequency	000028	000037
Band 4 Damping/Bandwidth	000029	000038
Band 4 Gain/Bypass	00002A	000039
Band 5 Frequency	00002B	00003A
Band 5 Damping/Bandwidth	00002C	00003B
Band 5 Gain/Bypass	00002D	00003C

10.4.3 Speaker (5-Band) Equalizer Addresses

Register Parameter	Channel 1 Address	Channel 2 Address
Band 1 Frequency	000061	000070
Band 1 Damping/Bandwidth	000062	000071
Band 1 Gain/Bypass	000063	000072
Band 2 Frequency	000064	000073
Band 2 Damping/Bandwidth	000065	000074
Band 2 Gain/Bypass	000066	000075
Band 3 Frequency	000067	000076
Band 3 Damping/Bandwidth	000068	000077
Band 3 Gain/Bypass	000069	000078
Band 4 Frequency	00006A	000079
Band 4 Damping/Bandwidth	00006B	00007A
Band 4 Gain/Bypass	00006C	00007B
Band 5 Frequency	00006D	00007C
Band 5 Damping/Bandwidth	00006E	00007D
Band 5 Gain/Bypass	00006F	00007E

11. Loudness Contour

An individual software-controlled Loudness Contour is included for each of the five output channels. The Loudness Contour curve is customized to allow for dynamically and automatically enhancing the frequency response of the audio program material relative to the Master Volume Level setting. The Loudness Contour models the frequency response correction as defined by the Fletcher/Munson audio response curve. It provides for amplitude or volume changes to those signals to which the ear does not respond equally at very low listening levels.

This Loudness Contour feature is disabled by default, but may be enabled through its register control. Contact Renesas Applications [support](#) for additional information about the implementation of this algorithm.

11.1 Loudness Contour Register Data

	Channel 1	Channel 2	Channel 3	Channel 4	Channel 5
Address					
Enable Loudness	0000DB	0000DE	0000E1	0000E4	0000E7
Tone Low Pass	0000DC	0000DF	0000E2	0000E5	0000E8
Tone High Pass	0000DD	0000E0	0000E3	0000E6	0000E9
Default Value					
Enable Loudness	000000	000000	000000	000000	000000
Tone Low Pass	81AA26	81AA26	81AA26	81AA26	81AA26
Tone High Pass	EF2603	EF2603	EF2603	EF2603	EF2603

11.1.1 Enable Loudness Settings

	Enable Loudness	Bypass Loudness
Loudness Mode	000001	000000

12. High-Pass and Low-Pass Crossover Filters

High-Pass and Low-Pass filter blocks are provided for each of the output channels. These filter blocks provide a flexible Crossover function for all the output channels, including provision for defining the subwoofer channel's frequency response, if applicable.

Four cascaded filter blocks are available for each channel. Each filter can be configured for low-pass or high-pass operation with adjustable slope and Q. Higher order slopes and bandpass functions can be achieved by using multiple low or high pass filters.

The High and Low Pass blocks operate together, and are implemented as a total of four cascaded elements. Two of the elements are allocated for High Pass, and the other two elements are allocated for Low Pass functionality. However, complete flexibility allows each element to be defined for either High or Low Pass. Each element is selectable for a slope of 6dB, 12dB, 18dB, or 24dB, or can be bypassed. Any or all of the parameters can be defined independently based on system requirements.

The D2 Audio DSP Customization GUI software includes preset options for choosing Butterworth, Bessel, or Linkwitz-Riley filter implementations, and sets the parameters appropriately for these implementations.

Each element within the filter block uses three different parameters, for a total of 12 parameters for the channel's filter function. These three per-element parameter definitions are identical for all elements. These parameters are Filter Configuration, Corner Frequency, and Quality Factor.

Combinations of settings for the individual elements within the filter block determine the block's overall characteristics.

12.1 Corner Frequency

The Corner Frequency parameter is a signed, 24-bit number. The frequency value is entered in Hz. The valid range for the frequency parameter is 10Hz to 22000Hz.

Note: While it is possible to enter parameter values beyond the specified valid range, only values within this range are actually used during audio processing operation. Values beyond the range specified are not used, and if entered, the processing uses the value shown for the maximum range. For example, the default parameter value is 7FFFFFFF, which corresponds to 24kHz. This value is beyond the operational range, and if entered beyond the specified range, audio processing uses the maximum (22kHz) value limit.

12.1.1 Filter Corner Frequency Parameter Calculation

$$(EQ. 16) \quad \text{Frequency Parameter} = 2^{23} \times \left[\frac{F}{24} \times 10^{-3} \right]$$

where F = Frequency in Hz

	Minimum	Maximum
Valid Range	10Hz 000DA7	22kHz 755555
Default Settings	24Hz	7FFFFFFF

Note: The default setting of 7FFFFFFF is beyond the maximum operational range of 755555, or 22kHz. Although entry beyond the valid range is possible, operation is within the valid range. The maximum valid range (22kHz) is assumed for operation. Values beyond this range are ignored and use the maximum 22kHz value instead.

12.2 Quality Factor

The Quality Factor (Q) parameter is a signed, 24-bit number. The valid range for the Q parameter is >0.5 to 10. (Note that a setting of 0.5, producing a parameter value of 800000 is invalid.)

12.2.1 Filter Q-Factor Parameter Calculation

$$(EQ. 17) \quad \text{Q-Factor Parameter} = 2^{23} \times \left[\frac{1}{2 \times Q} \right]$$

	Minimum	Maximum
Valid Range	0.5+ 7FFFFFFF (Q>0.5; A value of 0.5 creates a hex value of 800000 which is invalid)	10 066666
Default Settings	Q = 0.5412 Q = 1.3066	7641AF 30FBC5
		First Biquad Block Second Biquad Block

12.3 Configuration Settings

Bit assignments within the Configuration parameter determine whether the block's filter element is active, bypassed, or unused; selects whether the block is a high pass or low pass configuration; and whether it implements a first or second order function. These bit combinations are shown in the High/Low-Pass Filter register data table in ["High/Low Pass Filter Register Addresses" on page 22](#).

12.3.1 Filter Configuration Mode Definition

Each High-Pass and Low-Pass filter block is implemented as two biquad elements. The filter slope shown (6dB or 12dB/octave) is for each biquad element only. The total filter block slope of 6dB, 12dB, 18dB, or 24dB/octave is accomplished through combinations of slope selections of each biquad element within the complete filter block.

Mode Settings	x00000	Low-Pass, Second-Order, 12dB/octave slope
	x00001	Low-Pass, First-Order, 6dB/octave slope
	x00002	High-Pass, Second-Order, 12dB/octave slope
	x00003	High-Pass, First-Order, 6dB/octave slope
	8xxxxx	Bypass
Default Settings	800000	Filter Bypassed.

12.3.2 High/Low Pass Filter Register Addresses

Register Parameter	Channel 1 Address	Channel 2 Address	Channel 3 Address	Channel 4 Address	Channel 5 Address
Low-Pass Biquad 1 Configuration	00007F	00008B	000097	0000A3	0000B1
Low-Pass Biquad 1 Frequency	000080	00008C	000098	0000A4	0000B2
Low-Pass Biquad 1 Damping/Q-Factor	000081	00008D	000099	0000A5	0000B3
Low-Pass Biquad 2 Configuration	000082	00008E	00009A	0000A6	0000B4
Low-Pass Biquad 2 Frequency	000083	00008F	00009B	0000A7	0000B5
Low-Pass Biquad 2 Damping/Q-Factor	000084	000090	00009C	0000A8	0000B6
High-Pass Biquad 1 Configuration	000085	000091	00009D	0000A9	0000B7
High-Pass Biquad 1 Frequency	000086	000092	00009E	0000AA	0000B8
High-Pass Biquad 1 Damping/Q-Factor	000087	000093	00009F	0000AB	0000B9
High-Pass Biquad 2 Configuration	000088	000094	0000A0	0000AC	0000BA
High-Pass Biquad 2 Frequency	000089	000095	0000A1	0000AD	0000BB
High-Pass Biquad 2 Damping/Q-Factor	00008A	000096	0000A2	0000AE	0000BC

13. D2 Sound Enhancement Suite Algorithms Processing

The D2 Audio DSP Sound Enhancement Suite audio processing provides a full set of enhancements to audio that greatly adds to the quality and listening experience of sound in wide scopes of consumer devices. The D2 Sound Enhancement Suite algorithms use psycho-acoustic processing that creates a rich-sounding environment from small speakers and synthesizes the sound and quality equivalent to more complex systems. It is especially suited to consumer products that include televisions, docking stations, and mini hi-fi stereo products. Processing is included within the audio signal flow path. The D2 Sound Enhancement Suite algorithms are completely included within the D2-41051 and D2-45057 devices.

D2 Sound Enhancement Suite Processing includes:

- D2 Audio DSP Wide Sound
 - An advanced Two-Channel Image Field Enhancement
- D2 Audio DSP Deep Bass
 - A sophisticated bass enhancement using psycho-acoustics and Dynamic Filtering
- D2 Audio DSP Audio Align
 - Sound Positioning and Alignment to the Video Display
- D2 Audio DSP Clear Voice
 - Enhancement of Vocal Clarity

13.1 D2 Sound Enhancement Suite Algorithm Bypass Register

By default, the D2 Sound Enhancement Suite algorithm functions are bypassed. Each of the four D2 Sound Enhancement Suite algorithm processing blocks can be enabled or disabled independently through setting or clearing the bits in the Input Select Register, shown here:

Register	D2 Sound Enhancement Suite Algorithm Bypass Status					
Register Address	00010B					
Default Value	00001F					
Enable Function	Reserved	Clear Voice	Reserved	Audio Align	Deep Bass	Wide Sound
Register Bits	[23:5]	[4]	[3]	[2]	[1]	[0]
Default value	00000	1	1	1	1	1

Bit	Description
Bits [23:5]: Reserved	Always set to zero ('0') when writing to the D2 Sound Enhancement Suite Algorithm Bypass Register.
Bit 4: Clear Voice Bypass	By default, this bit is set to '1'. To enable Clear Voice, set this bit to '0'.
Bit 3: Reserved	Bit 3 is reserved. It should always be written as '1', its default setting.
Bit 2: Audio Align Bypass	By default, this bit is set to '1'. To enable Audio Align, set this bit to '0'.
Bit 1: Deep Bass Bypass	By default, this bit is set to '1'. To enable Deep Bass, set this bit to '0'.
Bit 0: Wide Sound Bypass	By default, this bit is set to '1'. To enable Wide Sound, set this bit to '0'.

13.2 Wide Sound Processing

D2 Audio DSP's Wide Sound is targeted at products that use small, closely-spaced speaker systems to significantly enhance perceived audio quality. Wide Sound accomplishes this by improving, shaping, and expanding the stereo sound field. This three-dimensional audio image expands the sound field across the vertical and horizontal listening planes. The dramatic sound expansion allows manufacturers of portable consumer products, televisions, and small form-factor products to improve the product's audio performance while still maintaining a small speaker footprint or using low-cost drivers.

In operation, Wide Sound uses signal Phase and Sum/Difference information to create listening cues that give the end listener the impression that the sound stage is much wider than it actually is. The Wide Sound algorithms also add a "pleasing effect" when playing back other two-channel sources. Wide Sound ensures consistent wide-field sound reproduction, regardless of the audio source.

13.2.1 Wide Sound Effect Level Registers and Calculations

$(EQ. 18) \text{ Wide Sound Effect Level Parameter} = -2^{23} \times \left[\frac{10^{\left(\frac{\text{Wide Sound Effect Level}}{20} \right)}}{4} \right]$		
Wide Sound Effect Level is in dB		
Valid Range	Minimum -12dB F7FFB8	Maximum +12dB 800487
Default Settings	0dB	E00000
Register Address	0000F0	

13.3 Deep Bass Processing

D2 Audio DSP's Deep Bass significantly enhances perceived bass performance through innovative psycho-acoustic techniques. This approach creates the perception of low frequency tones by using the harmonics present in the original analog or digital audio source. When the human ear hears harmonic frequencies relative to a missing tone(s), the ear psychoacoustically fills in the missing tone(s). Deep Bass amplifies the second and higher harmonics of a fundamental tone, which artificially creates the presence of the low frequency bass information. The low frequency bass is perceptible even if the fundamental frequency is below the speaker's performance limitations.

Deep Bass enhances bass performance in speakers of all sizes including those found in common consumer products such as home theater systems, high-end subwoofers, and even small headphones. Because Deep Bass improves the output range of a wide range of speakers, designers can use smaller magnets and plastic enclosures to reduce speaker manufacturing costs.

Deep Bass enhancement delivers the perception of deep rich bass up to an octave below the physical low frequency limitation of small, medium, or large speakers. The most noticeable effect is evident on speakers with a frequency response starting in the range of 100Hz to 150Hz. Deep Bass offers several controls to adjust the frequency range of the enhancement effect. This allows D2 Audio DSP to work closely with the customer to optimize the bass enhancement to the specific product. Even though Deep Bass enhances bass performance, audio quality is not degraded.

Note: If a subwoofer (in a stereo 2.1 or bi-amp system) or woofer (in a bi-amp system) that is capable of truly reproducing low-frequency energy is present in the end-system, disable the Deep Bass processing block to avoid a "double bass effect" for the listener.

Contact the [factory](#) for how to obtain specific firmware with custom configured Deep Bass parameters specific to your end-product and drivers which result in the optimal Deep Bass effect.

13.3.1 Deep Bass Parameters

A single variable adjusts Deep Bass. This variable is a gain factor that controls the level of input signal (input Channels 1 and 2), which is used as input to the Deep Bass process. Gain range is from -100dB to 0dB. Default setting is 0dB.

There are two registers that adjust the Deep Bass level, one for each of the two input channels. Each register sets its own gain, but both registers should be written with identical data values.

13.3.2 Deep Bass Effect Level Registers and Calculations

$$(EQ. 19) \quad \text{Deep Bass Effect Level Parameter} = -2^{23} \times \left[10^{\left(\frac{\text{Deep Bass Effect Level}}{20} \right)} \right]$$

where: Deep Bass Effect Level is in dB

	Minimum	Maximum
Valid Range	-24dB F7EC7B	0dB 800000
Default Settings	0dB	800000
Register Address	000106	Bass Mix Level from Input Channel 1
	000108	Bass Mix Level from Input Channel 2

13.4 Audio Align Processing

In most audio/video environments the loudspeakers are not located directly in front of the listener at ear level. This speaker placement is not optimal, and reduces the movie or television watching experience. Many televisions have speakers mounted below the listening plane that makes it ever more challenging to generate a dynamic audio experience that still places the vocals accurately in the middle of the screen. D2 Audio DSP Audio Align solves this problem by elevating and aligning the audio image for a pair of speakers to the physical height position of the video display. This helps integrate the audio sound with the visual experience. Audio Align overcomes the design challenges of non-optimally placed speakers typically found in cars or projection HDTVs where speakers are low to the floor, or in certain models of flat panel HDTVs that allow for the side-mounted speakers to be placed below the screen.

Audio Align can change the sound image coming from a pair of speakers and “trick” the human ear into interpreting the sound as coming from a specific angle or location. This audio image can be moved vertically (upwards) in reference to a set of speakers.

In operation, Audio Align corrects for speaker elevation by selectively shaping the frequency characteristics of the input signal to create the appropriate perception of image height. When combined with Wide Sound, Audio Align creates a completely immersive sound image field that still anchors the on-screen vocals to where they should be emanating from.

Note: Regarding the use of Audio Align with products that have speakers located to the left and right of the TV: The Audio Align filter should only be enabled for end-products that ship with speakers that are permanently located below the TV screen or are capable of being moved by the consumer to a location below the TV screen. For end-products that ship with speakers that are permanently located to the left and right of the TV screen, inclusion of the Audio Align feature is optional.

13.4.1 Audio Align Parameters

A single variable adjusts Audio Align. This variable is a time delay factor that allows an adjustment from 0 to 15 internal audio processing sample periods. (Each period corresponds to approximately a 0.3ms delay. The hex data value that is entered for the signed 24-bit number equals the number of programmed sample periods. The maximum value allowed is 15 samples.

There are two registers that adjust the Audio Align settings, one for each of the two input channels. Each register sets its own number of samples delay, but both registers should be written with identical data values.

13.4.2 Audio Align Registers and Calculations

Audio Align Register Parameter: This is a single hex data value, where each data bit within the register corresponds to a sample delay period. Each period corresponds to approximately a 0.3ms delay.

Valid range is 0 to 15 samples, for hex parameter of 000000 to 00000F

	Minimum	Maximum
Valid Range	0 samples 000000	15 samples 00000F
Default Settings	6 Samples	000006
Register Address	0000F9	Delay for Mix Level from Input Channel 1
	0000FA	Delay for Mix Level from Input Channel 2

13.5 Clear Voice Processing

D2 Audio DSP Clear Voice is an audio effect that enhances the audibility and intelligibility of voice or vocal audio content. It acts as a voice-to-background ratio control, which automatically separates the voice content and elevates it above the level of the other audio content. Voice content is enhanced, while not altering other aspects of the total audio. Clear Voice uses sophisticated DSP technology to identify, enhance, and clarify the vocal content of highly compressed audio material.

13.5.1 Clear Voice Parameters

A single variable adjusts Clear Voice. This variable is a gain factor that controls the level of input signal (input Channels 1 and 2) and inputs to the Audio Align process. Gain range is from -100dB to 0dB. Default setting is -3dB.

There are two registers that adjust the Clear Voice settings, one for each of the two input channels. Each register sets its own gain value, but both registers should be written with identical data values.

13.5.2 Clear Voice Effect Level Registers and Calculations

$(EQ. 20) \quad \text{Clear Voice Effect Level Parameter} = -2^{23} \times \left[10^{\left(\frac{\text{Clear Voice Effect Level}}{20} \right)} \right]$			
where: Clear Voice Effect Level is in dB			
Valid Range	Minimum	Maximum	
	-24dB	0dB	
	F7EC7B	800000	
Default Settings	-3dB	A56208	
Register Address	000128	Clear Voice Mix Level from Input Channel 1	
	00013A	Clear Voice Mix Level from Input Channel 2	

14. Signal Flow Option Register

The Signal Flow Option register is a single 24-bit control word that controls optional signal flow components. The register and its bit assignments are described below.

Defined Bits: Only 9 bits (Bits 8:0) are defined and implemented in normal device operation.

Unused Bits: Bits 23:9 are not used and reserved. The unused bits should always be written as zero (0).

Bit Function Definitions: Each of the nine defined bits specifies whether their assigned function is active. If the bit is zero, the function is bypassed, and if the bit is a one, the function is active.

Signal Flow Option Default Setting: The Signal Flow Option register default bit settings are:

- 0x0000FF (hex)

Signal Flow Option Register Address: The Signal Flow Option register is located at address:

- Address 0x000166 (hex)

Table 5. D2-4 Signal Flow Register

Register Bits [23:0]																							
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reserved Bits; Default = all 0															Default Bit Settings of defined bits:								
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1
															See Table 6 for bit definitions.								

Table 6. Signal Flow Register Bit Definitions

Bit	Name	Function
0	Sound Enhancement Algorithms	Enables Sound Enhancement algorithms when = 1. When set = 0, bypasses all Sound Enhancement Algorithm functions. (Regardless of bit setting, these Sound Enhancement Algorithms are only enabled on the Sound Enhancement Algorithm-specific (D2-4/D2-41051 and D2-4P/D2-45057) hardware-enabled licensed assignment of those specific device part number.)
1	SRS Algorithms	Enables SRS algorithms when = 1. When set = 0, bypasses all SRS functions. (Regardless of bit setting, these SRS algorithms are only enabled on the SRS-specific (D2-4/D2-41151 and D2-4P/D2-45157) hardware-enabled licensed assignment of those specific device part number.)
2	(Reserved)	Reserved. Default = 1. However, function is not enabled within any production D2-4 or D2-4P hardware. Writing of either 0 or 1 is ignored.
3	(Reserved)	Reserved. Default = 1. However, function is not enabled within any production D2-4 or D2-4P hardware. Writing of either 0 or 1 is ignored.
4	Input Compressors	Enables audio processing path Input Compressors when = 1. Bypasses Input Compressors when = 0.
5	Speaker EQ	Enables Speaker EQs in audio processing path when = 1. Bypasses Speaker EQs when = 0.
6	Output EQ	Enables Output EQs in audio processing path when = 1. Bypasses Output EQs when = 0.
7	Green Function	Enables Green Function when = 1. Disables Green Function when = 0.
8	Master Volume Off	Master Volume zero-setting PWM shutdown. When set = 1, setting the Master Volume to minimum invokes PWM shutdown, through Green Function. When = 0, PWM shutdown not affected by Master Volume.

15. Hardware Option Register

The Hardware Option register is a single 24-bit control word used to enable hardware features on the device. The register and its bit assignments are described below.

Defined Bits: Only 13 bits (Bits 12:0) are defined and implemented in normal device operation.

Unused Bits: Bits 23:13 are not used and reserved. The unused bits should always be written as zero (0).

Bit Function Definitions: Each of the 13 defined bits controls its respective feature. If the bit is zero, the feature is disabled, and if the bit is a one, the feature is active.

Hardware Option Default Setting: The Hardware Option register default bit settings are:

- 0x00027F (hex)

Hardware Option Register Address: The Hardware Option register is located at address:

- Address 0x000167 (hex)

Table 7. D2-4 Hardware Register

Register Bits [23:0]																							
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reserved Bits; Default = all 0											Default Bit Settings of defined bits:												
0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	1	1	1	1	1	1	1
											See Table 8 for bit definitions.												

Table 8. Hardware Option Register Bit Definitions

Bit	Name	Function
0	Master Volume	Enables Master Volume control when = 1. When set = 0, Master Volume setting ignored.
1	Mute Input	Enables Mute Input when = 1. When set = 0, Mute Input ignored.
2	SPDIF TX	Enables SPDIF Transmit output when = 1. When set = 0, SPDIF Transmit disabled.
3	Host Error	Enables Host Error output when = 1. When set = 0, Host Error output disabled.
4	Temperature Sense	Enables Temperature Sensor when = 1. When set = 0, Temperature Sensor ignored.
5	PSSYNC	Enables Power Supply Sync (PSSYNC) output when = 1. When set = 0, PSSYNC disabled.
6	Master Clock	Enables Master Clock (MCLK) output when = 1. When set = 0, MCLK disabled.
7	SPDIF Pass	Enables SPDIF Pass Through when = 1. When set = 0, SPDIF Pass Through disabled. (The SPDIF Pass Through function overrides the SPDIF input source selection.)
8	PSSYNC Rate 0	When set = 1, and when bit 5 (PSSYNC) is also enabled set = 1, PSSYNC operates at 2x the PWM switch rate. (Only 1 of these 3 PSSYNC rate bits should be set = 1 at one time, and the other 2 should be set = 0.)
9	PSSYNC Rate 1	When set = 1, and when bit 5 (PSSYNC) is also enabled set = 1, PSSYNC operates at 1x the PWM switch rate. (Only 1 of these 3 PSSYNC rate bits should be set = 1 at one time, and the other 2 should be set = 0.)
10	PSSYNC Rate 2	When set = 1, and when bit 5 (PSSYNC) is also enabled set = 1, PSSYNC operates at 1/2 (half) the PWM switch rate. (Only 1 of these 3 PSSYNC rate bits should be set = 1 at one time, and other 2 should be set = 0.)
11	PSSYNC Duty	When set = 0 PSSYNC output (when enabled) operates at 50% duty cycle. When set = 1, (and when enabled) PSSYNC operates at a 10% duty cycle.
12	DspStop	Setting = 1 stops DSP clocks in the background wait loop. When set = 0, DSP clocks operate normally.

16. Revision History

Rev.	Date	Description
0.00	Jun.11.19	Initial release

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
 2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
 3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
 4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
 6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
 7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
 9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
 11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
- (Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.4.0-1 November 2017)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan
www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/