



Xerox® WorkCentre® 3655/3655i
Multifunction Printer
2016 Xerox® ConnectKey® Technology
System Administrator Guide



© 2019 Xerox Corporation. All rights reserved. Unpublished rights reserved under the copyright laws of the United States. Contents of this publication may not be reproduced in any form without permission of Xerox Corporation.

Copyright protection claimed includes all forms of matters of copyrightable materials and information now allowed by statutory or judicial law or hereinafter granted, including without limitation, material generated from the software programs which are displayed on the screen such as styles, templates, icons, screen displays, looks, and so on.

Xerox® and Xerox and Design®, Phaser®, PhaserSMART®, PhaserMatch®, PhaserCal®, PhaserMeter™, CentreWare®, PagePack®, eClick®, PrintingScout®, Walk-Up®, WorkCentre®, FreeFlow®, SMARTsend®, Scan to PC Desktop®, MeterAssistant®, SuppliesAssistant®, Xerox Secure Access Unified ID System®, Xerox Extensible Interface Platform®, ColorQube®, ConnectKey®, Global Print Driver®, and Mobile Express Driver® are trademarks of Xerox Corporation in the United States and/or other countries.

Adobe® Reader®, Adobe® Type Manager®, ATM™, Flash®, Macromedia®, Photoshop®, and PostScript® are trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Apple, Bonjour, EtherTalk, TrueType, iPad, iPhone, iPod, iPod touch, Mac and Mac OS are trademarks of Apple Inc., registered in the U.S. and other countries. AirPrint and the AirPrint logo are trademarks of Apple Inc.

HP-GL®, HP-UX®, and PCL® are trademarks of Hewlett-Packard Corporation in the United States and/or other countries.

IBM® and AIX® are trademarks of International Business Machines Corporation in the United States and/or other countries.

Mopria™ is a trademark of the Mopria Alliance.

Microsoft®, Windows Vista®, Windows®, and Windows Server® are trademarks of Microsoft Corporation in the United States and other countries.

Novell®, NetWare®, NDPS®, NDS®, IPX™, and Novell Distributed Print Services™ are trademarks of Novell, Inc. in the United States and other countries.

SGI® and IRIX® are trademarks of Silicon Graphics International Corp. or its subsidiaries in the United States and/or other countries.

Sun, Sun Microsystems, and Solaris are trademarks or registered trademarks of Oracle and/or its affiliates in the United States and other countries.

McAfee®, ePolicy Orchestrator®, and McAfee ePO™ are trademarks or registered trademarks of McAfee, Inc. in the United States and other countries.

UNIX® is a trademark in the United States and other countries, licensed exclusively through X/ Open Company Limited.

PANTONE® and other Pantone, Inc. trademarks are the property of Pantone, Inc.

Document version 2.0: November 2019

BR9382_en-us

Contents

1	Introduction	13
	Overview	14
	Configuration Steps	15
	More Information	16
2	Initial Setup	17
	Physically Connecting the Printer	18
	Assigning a Network Address.....	19
	Connecting the Printer to a Wireless Network.....	20
	Accessing Administration and Configuration Settings.....	21
	Accessing the Control Panel as a System Administrator	21
	Accessing Xerox® CentreWare® Internet Services as a System Administrator.....	21
	Initial Setup at the Control Panel.....	22
	Installation Wizard.....	22
	Using Installation Wizards	22
	Setting the Measurement Units	22
	Installing Optional Software Features	23
	Initial Setup in Xerox® CentreWare® Internet Services.....	24
	Printing the Configuration Report.....	24
	Restricting Access to the Printer	24
	Using the Configuration Overview Page.....	25
	Assigning a Name and Location to the Printer	25
	Selecting Services to Appear on the Touch Screen	25
	Installing Optional Software Features	26
	Supplies Plan Activation Code	26
	Physical Connection Settings.....	27
	Changing the System Administrator Password.....	28
	Changing the System Administrator Password at the Control Panel.....	28
	Setting the Date and Time	29
	Setting the Date and Time in Xerox® CentreWare® Internet Services	29
	Setting the Date and Time at the Control Panel	30
3	Network Connectivity	31
	Connecting to a Wireless Network	32
	Configuring Wireless Settings Manually.....	33
	Connecting Directly to a Wireless Network	33
	Wi-Fi Direct	35
	Configuring Wi-Fi Direct	35
	AirPrint	36
	Configuring AirPrint.....	36

Mopria.....	37
Configuring Mopria.....	37
USB Settings	38
Configuring USB Settings	38
AppleTalk	39
Before You Begin	39
Configuring AppleTalk	39
FTP/SFTP Filing	40
Configuring FTP and SFTP Filing Settings.....	40
HTTP	41
Enabling HTTP at the Control Panel	41
Configuring HTTP Settings in Xerox® CentreWare® Internet Services.....	41
Accessing HTTP Web Services	41
HTTP Web Services	42
Accessing HTTP Advanced Settings	42
HTTP Advanced Settings.....	42
IP	43
Enabling TCP/IP	43
Configuring the Network Address Manually at the Control Panel	43
Configuring DNS Settings at the Control Panel	44
Configuring IP Settings in Xerox® CentreWare® Internet Services	45
IPP	48
Configuring IPP	48
LDAP	49
Adding LDAP Server Information.....	49
Adding or Editing LDAP Servers in Xerox® CentreWare® Internet Services	50
Configuring a Secure LDAP Connection.....	50
Configuring LDAP Server Optional Information	50
LDAP Server Contexts	51
Configuring LDAP User Mappings.....	52
LDAP Custom Filters	52
LPR/LPD.....	54
NetWare.....	55
Configuring NetWare General Settings	55
Enabling SAP	55
Bindery Settings.....	56
Configuring NetWare Directory Services (NDS) Settings.....	56
NDPS/NEPS	56
NTP	57
POP3.....	58
Proxy Server	59
Configuring the Proxy Server.....	59
Raw TCP/IP Printing	60
Configuring Raw TCP/IP Settings	60
Configuring Raw TCP/IP Advanced Settings	61

SLP	62
Configuring SLP	62
SMB Filing.....	63
Configuring Kerberos Authentication Options for SMB	63
SMTP Server	64
Configuring SMTP Server Settings	64
Configuring SMTP Authentication Settings	64
Configuring SMTP Connection Encryption Settings	65
Configuring SMTP File Size Management.....	65
Testing SMTP Configuration Settings	65
SNMP	66
Enabling SNMP	66
Configuring SNMPv1/v2c.....	66
Configuring SNMPv3.....	67
Configuring SNMP Advanced Settings.....	68
SSDP	69
WSD.....	70
Enabling WSD	70
4 Security	71
Setting Access Rights.....	72
Authentication.....	72
Authorization.....	73
Personalization	73
Setting the Login Method.....	73
Configuring Authentication Settings.....	74
Configuring Local Authentication Settings	74
Configuring Network Authentication Settings	76
Configuring Xerox Secure Access Unified ID System Authentication Settings	78
Configuring Convenience Authentication Settings.....	80
Configuring Smart Card Authentication Settings	81
Configuring Authorization Settings.....	84
Setting the Authorization Method	84
Configuring Local Authorization Settings	84
Configuring Network Authorization Settings	84
User Permissions	85
Editing Services and Tools Permissions for the Non-Logged-In Users Role	88
Creating a New Role	88
Assigning Users to a Role for Local Authorization.....	89
Assigning User Groups to a Role for Network Authorization.....	89
Editing a Logged-In User Role.....	90
Specifying Job Override Policies	90
Troubleshooting Conflicting Permissions	91
Secure HTTP (SSL)	92
Using SSL for all HTTP Communication	92
FIPS 140-2.....	93

Enabling FIPS 140 Mode and Checking for Compliance	94
Stored Data Encryption	95
Enabling Encryption of Stored Data	95
IP Filtering	96
Creating or Editing an IP Filter Rule.....	96
Editing an IP Filter Rule.....	97
Arranging the Execution Order of IP Filter Rules.....	97
Audit Log	98
Enabling Audit Log.....	98
Enabling Automatic Log Transfer	98
Enabling Protocol Logs	99
Saving an Audit Log	99
Saving an Audit Log to a USB Flash Drive	99
Interpreting the Audit Log.....	100
Installation Policies	101
McAfee Embedded Control.....	102
Setting the Security Level.....	103
Setting the Alert Options.....	104
IPsec	105
Enabling IPsec.....	105
Managing Actions	105
Managing Protocol Groups.....	106
Creating a New Action	106
Editing or Deleting an Action.....	108
Managing Host Groups.....	109
Managing Security Policies.....	109
Security Certificates	110
Installing Certificates	110
Creating and Installing a Xerox® Device Certificate	111
Installing the Generic Xerox® Trusted CA Certificate.....	112
Creating a Certificate Signing Request	112
Installing Root Certificates	113
Installing Domain Controller Certificates	114
Viewing, Saving, or Deleting a Certificate	114
Specifying the Minimum Certificate Key Length	115
802.1X	116
Enabling and Configuring 802.1X in Xerox® CentreWare® Internet Services	116
System Timeout	118
Setting System Timeout Values	118
Overwriting Image Data	119
Manually Deleting Image Data	120
Scheduling Routine Deletion of Image Data	121
Immediate Job Overwrite.....	122
PostScript Passwords	123
Enabling or Creating PostScript Passwords	123
USB Port Security	124

Enabling or Disabling USB Ports	124
Displaying or Hiding Network Settings	125
Hiding User Names on the Control Panel	126
Verifying the Software	127
Restricting Print File Software Updates	128
Specifying Email and Internet Fax Recipient Restrictions.....	129
Disabling the System Administrator Password Reset	130
5 Printing	131
Paper Management	132
Setting Default Paper Type and Color	132
Enabling Required Paper Policies	132
Setting Paper Size Preference	132
Selecting Paper Tray Settings	133
Selecting Tray 1 Settings.....	133
Saving and Reprinting Jobs	134
Enabling the Reprint Saved Jobs Feature	134
Create and Manage Saved Jobs Folders	134
Saving and Printing Jobs	135
Backing up Saved Jobs	135
Restoring Saved Jobs from an FTP Repository	136
Printing Jobs from Xerox® CentreWare® Internet Services.....	137
Configuring General Print Settings.....	138
Printing an Error Sheet.....	139
Managing Banner Page Printing Options.....	140
Enabling Banner Page Printing in Xerox® CentreWare® Internet Services.....	140
Enabling Banner Page Printing at the Control Panel.....	140
Enabling Banner Page Printing in the Print Driver.....	141
Configuring Secure Print Settings	142
Configuring Secure Print Device Policies	142
Configuring Secure Print Driver Defaults	142
Hold All Jobs	143
Configuring the Hold all Jobs Feature	143
UNIX, Linux, and AS/400 Printing.....	144
Xerox® Printer Manager	144
Printing from a Linux Workstation	145
Adding the Printer	145
Printing with CUPS.....	145
AS/400	146
Print from USB	147
Enabling Print from USB	147
Print from Mailbox	148
Enabling Print From Mailbox	148
AirPrint	149

Mopria.....	150
Allowing Users to Interrupt Active Print Jobs	151
Specifying Output Settings.....	152
6 Copying	153
Setting Copy Presets	154
Specifying Default Copy Settings	154
Specifying Feature Defaults for Copying at the Control Panel	155
Setting the Presets Screen for Copying Settings	155
Setting Edge Erase Presets	156
Setting Image Shift Presets.....	156
Setting Reduce/Enlarge Presets	157
Setting the Reading Order Options	157
Disabling Automatic Image Rotation.....	157
Specifying ID Card Copy Settings	158
Specifying Output Settings.....	159
7 Scanning	161
Scanning to a Folder on the Printer	162
Enabling or Disabling Scan to Mailbox	162
Setting Scan Policies	163
Managing Folders and Scanned Files	163
Scanning to an Email Address	166
Email	166
Workflow Scanning	171
Enabling Workflow Scanning.....	171
Configuring File Repository Settings.....	171
Configuring the Default Template.....	176
Configuring Workflow Scanning General Settings	177
Configuring Single-Touch Service	178
Configuring Custom File Naming	178
Setting Template Display Settings for the Control Panel	179
Enabling Remote Scanning using TWAIN	179
Configuring a Validation Server	179
Configuring Template Pool Repository Settings.....	180
Configuring Unspecified Defaults	180
Scan to USB	181
Enabling Scan to USB	181
Scanning to a User Home Folder.....	182
Configuring the Printer for the Xerox Scan Utility	184
Configuring Scan To Destination.....	185
Before You Begin	185
Configuring Default Scan Settings	185
Configuring Default Scan Settings for Address Book.....	185
Configuring Default Scan Settings for Security.....	185

8	Faxing	187
	Fax Overview.....	188
	Fax.....	189
	Configuring Required Fax Settings at the Control Panel	189
	Configuring Embedded Fax Settings.....	190
	Fax Security.....	190
	Setting Fax Defaults.....	191
	Setting Fax Feature Defaults	193
	Fax Forwarding	194
	Fax Mailboxes	196
	Fax Reports	197
	Internet Fax.....	204
	Accessing the Internet Fax Setup Page	204
	LAN Fax.....	208
9	Accounting	209
	Xerox Standard Accounting.....	210
	Enabling Xerox Standard Accounting	210
	Setting Service Tracking Options	211
	General and Group Accounts	211
	Adding a User and Setting Usage Limits	212
	Managing User Information	213
	Assigning Users to an Account	215
	Usage Limits.....	215
	Configuring Validation Policies and Print Job Exceptions	216
	Network Accounting	218
	Enabling Network Accounting	218
	Setting Network Accounting Workflow Options	219
	Configuring Job Limits Server Settings	219
	Configuring User Prompts	220
	Disabling the Job Limits Web Service	220
	Configuring Validation Policies and Print Job Exceptions	221
	Accounting Using an Auxiliary Access Device	223
	Enabling Accounting Using an Auxiliary Access Device.....	223
	Displaying Your Company Logo on the Blocking Screen	223
	Setting the Auxiliary Access Device Type	223
	Selecting Services to Restrict or Track.....	224
	Setting the Job Timeout	224
	Enabling Accounting in Print Drivers.....	225
	Enabling Accounting in a Windows Print Driver.....	225
	Enabling Accounting in an Apple Macintosh Print Driver	225
	Printing a Copy Activity Report	226
10	Administrator Tools	227
	Monitoring Alerts and Status	228

Alert Notification	228
Energy Saving Settings	230
Setting Energy Saver Mode	230
Remote Control Panel	232
Entry Screen Defaults	233
Smart eSolutions and Billing Information	234
Smart eSolutions	234
View Usage and Billing Information	236
Billing Impression Mode	237
Cloning	238
Creating a Clone File	238
Installing a Clone File	238
Address Books	239
Device Address Book	239
Network Address Book	244
LAN Fax Address Book	244
Font Management Utility	245
Network Logs	246
Downloading a Network Log	246
Downloading a Network Log to a USB Flash Drive	246
Customizing Printer Contact Information	247
Display Device Information	248
Xerox Online Support	249
Enabling Xerox Online Support	249
Restarting the Printer in Xerox® CentreWare® Internet Services	250
Restarting the Printer at the Control Panel	251
Taking the Printer Offline	252
Erase Customer Data	253
Resetting the User Interface to Factory Default Settings	254
Updating the Printer Software	255
Enabling Upgrades	255
Manually Updating the Software Using a USB Flash Drive	255
Software Upgrade	256
Adjusting Color, Image, and Text Detection Settings	257
11 Customization and Expansion	259
Xerox Extensible Interface Platform	260
Configuring Extensible Services	260
Auxiliary Interface Kit	261
Driver Download Link	262
Customizing or Hiding the Driver Download Link	262
Displaying or Hiding ConnectKey Apps	263
Creating a Custom Single-Touch Scan Service	264

Creating a Custom Single-Touch Scan Service Overview	264
Creating a Single-Touch Scan Service	264
Customizing the Appearance of Your Service	265
Managing Scan Templates.....	266
Locking or Hiding Your Service from Appearing on the Control Panel.....	267
Weblet Management	268
Installing a Weblet.....	268
Configuring Weblet Settings	269
A Audit Log Event Identification Numbers	271
Audit Log Event Identification Numbers	272
B External Keyboard	277
External Keyboard Shortcuts	278

Introduction

1

This chapter includes:

- [Overview.....](#) 14
- [More Information.....](#) 16

Overview

This guide is designed for a system administrator with network administrator rights who understands networking concepts and has experience creating and managing network user accounts.

Use this guide to help you install, configure, and manage your printer on a network.

Notes:

- Network features are not available when you are connected over USB.
- Embedded fax features are not available for all printer models.

Configuration Steps

When you configure the printer for the first time, complete the following tasks.

1. Ensure that your printer is connected physically to your network, and to the fax line, as needed.
2. Confirm that your printer is recognized on your network. By default, the printer is configured to receive an IP address from a DHCP server over a TCP/IP network. If you have another type of network, or want to assign a static IP address, see [IP](#) on page 43.
3. Complete the installation wizards. These wizards help you configure basic printer settings such as your location, time zone, and date and time preferences.
4. Print a configuration report listing the current printer configuration. Review the report and locate the printer IPv4 address. For details, see [Configuration Report](#) on page 24.
5. Open a Web browser and type the IP address of your printer to access Xerox® CentreWare® Internet Services. Xerox® CentreWare® Internet Services is the administration and configuration software installed on the embedded Web server in the printer. For details, see [Accessing Xerox® CentreWare® Internet Services](#) on page 21.

Note: You can access most configuration settings on the Properties tab in Xerox® CentreWare® Internet Services.

6. Print the Configuration Checklist. The Configuration Checklist provides space for you to write down important information as you go through the configuration process. Use it to record information about your network settings, including passwords, network paths, and server addresses. To access the checklist, In Xerox® CentreWare® Internet Services, click **Properties > Configuration Overview**, then click **View Checklist**.
7. Create a host name for the printer. For details, see [DNS](#) on page 44.
8. Configure Authentication. For details, see [Setting Up Access Rights](#) on page 72.
9. Configure Security. For details, see [Security](#) on page 71.
10. Enable services in Xerox® CentreWare® Internet Services. For details, see [Selecting Services to Appear on the Touch Screen](#) on page 25.
11. Configure Print, Scan, and Fax features. For details, see [Printing](#) on page 131, [Scanning](#) on page 161, and [Faxing](#) on page 187.
12. Configure Accounting. For details, see [Accounting](#) on page 209.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

More Information

Resource	Location
<i>Installation Guide</i>	Packaged with the printer.
Other documentation for your printer	www.xerox.com/office/WC3655docs www.xerox.com/office/WC3655i_docs
Recommended Media List	United States: www.xerox.com/rmlna European Union: www.xerox.com/rmleu
Technical support information for your printer; including online technical support, Online Support Assistant, and driver downloads.	www.xerox.com/office/WC3655support www.xerox.com/office/WC3655i_support
Information about menus or error messages	Press the control panel Help (?) button.
Information pages	To print from the control panel, press Machine Status > Machine Information > Information Pages . To print from Xerox® CentreWare® Internet Services, click Status > Information Pages .
Xerox® CentreWare® Internet Services documentation	In Xerox® CentreWare® Internet Services, click Help .
Order supplies for your printer	www.xerox.com/office/WC3655supplies www.xerox.com/office/WC3655i_supplies
A resource for tools and information, including interactive tutorials, printing templates, helpful tips, and customized features to meet your individual needs.	www.xerox.com/office/businessresourcecenter
Local sales and support center	www.xerox.com/office/worldcontacts
Printer registration	www.xerox.com/office/register
Xerox® Direct online store	www.direct.xerox.com/
Third party and open source software	To locate third party and open source software disclosure notices and terms and conditions, go to the product page at: www.xerox.com/office/WC3655support www.xerox.com/office/WC3655i_support

Initial Setup

2

This chapter includes:

- [Physically Connecting the Printer](#) 18
- [Assigning a Network Address](#) 19
- [Connecting the Printer to a Wireless Network](#)..... 20
- [Accessing Administration and Configuration Settings](#) 21
- [Initial Setup at the Control Panel](#) 22
- [Initial Setup in Xerox® CentreWare® Internet Services](#) 24
- [Changing the System Administrator Password](#) 28
- [Setting the Date and Time](#) 29

Physically Connecting the Printer

1. Connect the power cord to the printer, and plug it into an electrical outlet.
2. Connect one end of a Category 5 or better Ethernet cable to the Ethernet port on the back of the printer. Connect the other end of the cable to a correctly configured network port.
3. If your printer has fax installed, connect it to a correctly configured telephone line.
4. Turn on the printer.

Assigning a Network Address

The printer automatically acquires a network address from a DHCP server by default. To assign a static IP address, configure DNS server settings, or configure other TCP/IP settings, see [IP](#) on page 43. If the printer does not detect a DHCP server, the printer uses an IPv4 self-assigned address. Address information is listed on the configuration report. For details, see [Configuration Report](#) on page 24.

Connecting the Printer to a Wireless Network

If the printer is connected to your wired network, you can configure wireless settings in Xerox® CentreWare® Internet Services. You can also connect directly to a wireless network. For details, see [Connecting to a Wireless Network](#) on page 32.

Note: You cannot connect to a wired network and a wireless network at the same time.

Accessing Administration and Configuration Settings

You can access the administration and configuration settings from the Tools tab on the control panel or from the Properties tab in Xerox® CentreWare® Internet Services. The control panel consists of a touch screen and buttons you press to control the functions available on the printer. Xerox® CentreWare® Internet Services is the administration and configuration software installed on the embedded Web server in the printer. It allows you to configure and administer the printer from a Web browser.

The administrator password is required when accessing locked settings in Xerox® CentreWare® Internet Services or at the control panel. Most printer models have a default configuration that restricts access to some settings. Access is restricted for settings on the Properties tab in Xerox® CentreWare® Internet Services, and settings on the Tools tab on the control panel touch screen.

Accessing the Control Panel as a System Administrator

1. At the printer control panel, press the **Log In/Out** button.
2. Type **admin** and touch **Next**.
3. Type the administrator password, then touch **Done**.

Note: Depending on when the device was manufactured, the default administrator password may be the device serial number or **1111**.

Accessing Xerox® CentreWare® Internet Services as a System Administrator

Before you begin:

- Locate your printer IP address using the Configuration Report. For details, see [Printing the Configuration Report](#) on page 24.
- Ensure that TCP/IP and HTTP are enabled. If you disabled either of these protocols, enable them at the control panel before accessing Xerox® CentreWare® Internet Services.

To log in to Xerox® CentreWare® Internet Services as the administrator:

1. At your computer, open a Web browser, in the address field, type the IP address of the printer, then press **Enter** or **Return**.
2. In the top right area of the page, click **Login**.
3. Under User ID, type **admin**.
4. Under password, type the administrator password. Depending on when the device was manufactured, the default administrator password may be the device serial number or **1111**.
5. Click **Login**.

Initial Setup at the Control Panel

Installation Wizard

The Installation wizard starts the first time you turn on the printer. The wizard prompts you with a series of questions to help you configure basic printer settings.

Note: You can complete the wizard at any time.

- To assign a static IP address or change the default dynamic addressing settings, use the IP Address Settings wizard.
- To add phone numbers for support or supplies contacts, use the Contact Numbers wizard.
- To configure basic embedded fax settings, use the Fax Setup wizard.

Using Installation Wizards

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > Additional Install Options**.
3. To start a wizard, touch **IP Address Settings**, **Contact Numbers**, or **Fax Setup**.
4. Follow the onscreen instructions.

Setting the Measurement Units

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > General > Measurements**.
3. To show dimensions in metric or imperial units, under Units, select an option.
4. To specify the decimal mark symbol that the printer uses, under Numeric Separator, select **Comma** or **Period**.
5. Click **OK**.

Installing Optional Software Features

When you purchase an optional software feature, to enable it, provide a feature installation key. Some features come with an activation code that you use to request a feature installation key. Go to the Xerox® Software Activation Portal website at www.xeroxlicensing.xerox.com/fik to enter the activation code. The website generates a feature installation key that you can use to enable the feature.

You can also install optional software features by sending a print file. You can install features on multiple printers by sending a formatted **.csv** file as a print job to the printers. A Xerox representative creates this file and provides installation instructions.

Installing a Software Feature at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > General > Feature Installation**.
3. Touch **Enter Feature Installation Key**, then type the key.
4. Touch **OK**.

Initial Setup in Xerox® CentreWare® Internet Services

Printing the Configuration Report

The Configuration Report lists all current settings of the printer. A configuration report prints at startup by default.

1. In Xerox® CentreWare® Internet Services, click **Status > Configuration Report**.
2. To print the report, click **Print Configuration Page**.

To turn off automatic printing of a Configuration Report at startup, see [Disabling the Configuration Report at Startup](#) on page 24.

Disabling the Configuration Report at Startup

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Printing > General**.
3. For Configuration Report, clear **Print at Power on**.
4. To save the new settings, click **Apply**.

Restricting Access to the Printer

You can lock or unlock the printer by selecting preset services and tools permissions for non-logged-in users. For details about roles and user permissions, see [Setting Up Access Rights](#) on page 72.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. Under Action, next to User Permission Roles, click **Edit**.
4. Under Actions, click **Edit**.
5. Click the **Services and Tools** tab.
6. Under Presets, select an option.
7. Click **Apply**.

Using the Configuration Overview Page

The Configuration Overview page contains links to the commonly-accessed pages on the Properties tab. Use the Configuration Overview page to help you install your printer successfully.

1. In Xerox® CentreWare® Internet Services, click **Properties > Configuration Overview**.
2. Select an option:
 - To open the Configuration Checklist page, click **View Checklist**.
 - To open the configuration page for a service or feature, next to the desired service or feature, click **Settings**.
 - To create a clone file, under Cloning click **View**. Cloning allows you to save your current printer settings to a file to use as a backup and restore file for your printer. You can also use a clone file to copy your printer settings to other printers.

Assigning a Name and Location to the Printer

The Description page displays the printer model information and product code or serial number. It also provides a place to assign a name and location to the printer. Asset tags let you enter unique identifiers for inventory management.

1. In Xerox® CentreWare® Internet Services, click **Properties > Description**.
2. For Device Name, type a name for the printer.
3. For Location, type the location of the printer.
4. For Customer Asset Tag and Xerox® Asset Tag, type unique identifiers as needed.
5. Click **Apply**.

Selecting Services to Appear on the Touch Screen

Services must be enabled before they can be managed through the Tools and Feature Access page. A standard service is a service that comes standard with the printer. An extensible service is an optional, third-party service installed on the printer.

To specify the services to display on the touch screen:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Display**.
2. Click **Show/Hide**.
3. To select all of the services in the list to appear on the touch screen, click **Show All**.
4. To hide all of the services in the list so that none appear on the touch screen, click **Hide All**.
5. To select individual services to appear on the touch screen, for Displayed, select the services that you want to appear.
6. Click **Apply**.

To arrange the order that services appear on the touch screen:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Display**.
2. Click **Order**.
3. To arrange the order that services appear on the control panel, click, drag, then drop the buttons in the preferred order.
4. Click **Apply**.

Installing Optional Software Features

When you purchase an optional software feature, to enable it, provide a feature installation key. Some features come with an activation code that you use to request a feature installation key. Go to the Xerox® Software Activation Portal website at www.xeroxlicensing.xerox.com/fik to enter the activation code. The website generates a feature installation key that you can use to enable the feature.

You can also install optional software features by sending a print file. You can install features on multiple printers by sending a formatted **.csv** file as a print job to the printers. A Xerox representative creates this file and provides installation instructions.

Installing a Software Feature in Xerox® CentreWare® Internet Services

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Feature Installation**.
3. Under Feature Installation Key Entry, click **Enter Installation Key**, or under Action, next to the feature you want to install, click **Install**.
4. Type the key.
5. Click **Apply**.

Supplies Plan Activation Code

Your Xerox® equipment supplier offers supplies and service plans such as PagePack® and eClick®.

PagePack® and eClick® are cost-per-page-based programs that include all service and supplies for your printer in one contract. If you have enrolled in a supplies program, you must activate the supplies plan at regular intervals. To enable your printer for your purchased plan, contact your Xerox® equipment supplier to get a Supplies Activation Code. Contact a Xerox representative to get your supplies plan activation code.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Supplies Plan Activation Code**.
3. Type the code, then click **Apply**.

For more information about Xerox® supplies and service plans, contact your Xerox representative.

Physical Connection Settings

You can specify Ethernet and USB settings, such as Ethernet Rated Speed, USB Connection Mode, and Print Timeout for USB printing.

Setting Ethernet Options

The Ethernet interface on the printer automatically detects the speed of your network. Any auto-sensing devices connected to the network, such as a hub, do not always detect the correct speed. Refer to the configuration report to ensure that the printer detects the correct network speed.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Next to Wired Connection, click **Edit**.
3. To configure Ethernet settings, next to Ethernet, click **Edit**.
4. For Rated Speed, select a connection speed.
5. Click **Save**.

Note: For the new settings to take effect, restart your printer.

Configuring USB Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Action, next to USB Settings, click **Edit**.
3. Under USB Connection Mode, select an option:
 - **Software Tools** disables Direct Printing via Driver. If you use Xerox® Copier Assistant, select this option. Xerox representatives also use this feature to connect directly to the printer and use diagnostic software and other utilities.
 - **Direct Printing via Driver** allows you to connect to the printer using a USB cable.
4. For Print Timeout, type the amount of time in seconds that the printer waits inactive before disconnecting from a device connected to the port. Type **0** to disable the timeout.
5. Click **Save**.

Changing the System Administrator Password

Xerox recommends that you change the default system administrator password after you configure the printer. Be sure to store the password in a secure location. Depending on when the device was manufactured, the default administrator password may be the device serial number or **1111**.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Password Policies > Admin Password**.
3. Type the old password.
4. Type the new password, then type the password again to verify.
5. Click **Apply**.

Changing the System Administrator Password at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Security Settings > Change Admin Password**.
3. If changing the password, type the old password.
4. Type the new password, then type the password again to verify.
5. Touch **OK**.

Setting the Date and Time

Setting the Date and Time in Xerox® CentreWare® Internet Services

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Date and Time**.
3. Under Date and Time Setup, select:
 - **Automatic using NTP** to allow the NTP service to set the time automatically.
 - **Manual (NTP Disabled)** to set the date and time manually.
4. If you are using an NTP server, select the address type. Options are **IPv4 Address** or **Host Name**. Type the appropriately formatted address, alternate address, and port numbers. The default port number is 123.

Note: Changes to these settings cause the printer to restart.

5. Select the date and time format, and type the date and time in the appropriate fields. Select the **Display 24 hour clock** check box to show the time in 24 hour format.
6. Under Time Zone, select your time zone from the drop-down menu.
7. Click **Apply**.

Setting the Date and Time at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > General > Date and Time**.

Note: If this feature does not appear, log in as a system administrator. For details, see [Logging In as the System Administrator at the Control Panel](#) on page 21.

3. To set the time zone, touch **Time Zone**, touch the **Geographic Region** drop-down list, then touch your region. Use the **Up** or **Down** arrows to navigate and select your Time Zone.

Note: The date and time are set automatically through Network Time Protocol (NTP). To modify these settings, go to the Properties tab in Xerox® CentreWare® Internet Services and change the Date and Time Setup to **Manual (NTP Disabled)**.

4. To set the date:
 - a. Touch **Date**.
 - b. Touch **Year** field, then to set a number, use the arrows.
 - c. Touch **Month** field, then to set a number, use the arrows.
 - d. Touch **Day** field, then to set a number, use the arrows.
 - e. Touch **Format**, touch the date format that you wish to use.
5. To set the time:
 - a. Touch **Time**.
 - b. To specify the 12-hour or 24-hour format, touch **Display 24 hour Clock**.
 - c. Touch the **Hours** field, then to set a number, use the arrows.
 - d. Touch the **Minutes** field, then to set a number, use the arrows.
 - e. If your printer is set to display the 12-hour clock, touch **AM** or **PM**.
6. Touch **OK**.

Network Connectivity

3

This chapter includes:

• Connecting to a Wireless Network.....	32
• Wi-Fi Direct	35
• AirPrint.....	36
• Mopria	37
• USB Settings.....	38
• AppleTalk	39
• FTP/SFTP Filing.....	40
• HTTP	41
• IP	43
• IPP	48
• LDAP	49
• LPR/LPD	54
• NetWare	55
• NTP	57
• POP3	58
• Proxy Server.....	59
• Raw TCP/IP Printing	60
• SLP	62
• SMB Filing	63
• SMTP Server.....	64
• SNMP	66
• SSDP	69
• WSD	70

Connecting to a Wireless Network

If the printer is connected to your wired network, you can configure wireless settings in Xerox® CentreWare® Internet Services.

Note: You cannot connect to a wired network and a wireless network at the same time.

Before you begin, purchase and install the Xerox® Wireless Network Interface.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Next to Xerox® Wireless Network Interface, click **Edit**.

Note: The Edit button is available after you install the Xerox® Wireless Network Interface.

3. To configure IPv4, IPv6, and DNS settings, on the Wireless Profile page, next to IP, click **Edit**. Configure settings as needed, then click **Apply**. The printer uses separate IP settings for wired and wireless network connections. For details, see [IP](#) on page 43.
4. On the Wireless Profile page, next to Wireless Settings, click **Edit**.
5. On the Wireless Settings page, click **Scan for Available Networks**. A list of detected networks appears.
6. Next to the SSID name of the network you want to join, click **Configure and Select**.
7. The printer detects the security mode that your network uses. Configure the following security mode settings as needed:
 - Under WEP Setting and Key, select the bit strength and key.
 - Under Encryption Algorithm, select an encryption method. **Auto** automatically detects the algorithm that your wireless network uses.
 - Under Authentication Method, select the authentication method that your wireless network uses.
 - To require the printer to validate certificates, under Server Validation, select the certificate that you want to use. Install the validation server root certificate on the Security Certificates page at **Properties > Security > Security Certificates**. For details, see [Security Certificates](#) on page 110.
 - Under Device Certificate (TLS) - Authentication Certificate, select the device certificate that you want to use. Install the device certificate on the Security Certificates page at **Properties > Security > Security Certificates**. For details, see [Security Certificates](#) on page 110.
 - Under Outer Identity, configure the external User ID.
 - Under User Name, type the user name that the printer uses to access the wireless network.
 - Under Password, type and confirm a password. Click **Select to save new password** as needed.
8. Click **Save**.
9. Navigate back to the Setup page, then click **Properties > Connectivity > Setup**.
10. Next to Xerox® Wireless Network Interface, click **Make Active**.

To verify the wireless status and see the wireless IP address, print a Configuration Report. For details, see [Configuration Report](#) on page 24. See the Connectivity Physical Connections, and Connectivity Protocols, TCP/IPv4 sections of the report.

Note: When you switch from a wired connection to a wireless connection, the IP address of the printer changes. The connection to Xerox® CentreWare® Internet Services through your Web browser closes. To reconnect to Xerox® CentreWare® Internet Services, type the new IP address or host name of your printer in the address field of your Web browser.

Configuring Wireless Settings Manually

If the printer does not detect your wireless network, configure wireless settings manually and provide information about your wireless network.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Next to Xerox® Wireless Network Interface, click **Edit**.
3. To configure IPv4, IPv6, and DNS settings, on the Wireless Profile page, next to IP, click **Edit**. The printer uses separate IP settings for wired and wireless network connections. For details, see [IP](#) on page 43.
4. On the Wireless Profile page, next to Wireless Settings, click **Edit**.
5. On the Wireless Settings page, click **Join Other Network**.
6. Under Network Name, type the name of your network.
7. Under Security Mode, select the security method that your wireless network uses.
8. Configure the following security mode settings as needed:
 - Under WEP Setting and Key, select the bit strength and key.
 - Under Encryption Algorithm, select an encryption method. **Auto** automatically detects the algorithm that your wireless network uses.
 - Under Authentication Method, select the authentication method that your wireless network uses.
 - To require the printer to validate certificates, under Server Validation, select the certificate that you want to use. Install the validation server root certificate on the Security Certificates page at **Properties > Security > Security Certificates**. For details, see [Security Certificates](#) on page 110.
 - Under Device Certificate (TLS) - Authentication Certificate, select the device certificate that you want to use. Install the device certificate on the Security Certificates page at **Properties > Security > Security Certificates**. For details, see [Security Certificates](#) on page 110.
 - Under Outer Identity, configure the external User ID.
 - Under User Name, type the user name that the printer uses to access the wireless network.
 - Under Password, type and confirm a password. Click **Select to save new password** as needed.
9. Click **Save**.
10. Navigate back to the Setup page, then click **Properties > Connectivity > Setup**.
11. Next to Xerox® Wireless Network Interface, click **Make Active**.

Connecting Directly to a Wireless Network

Before you begin, purchase and install the Xerox® Wireless Network Interface.

1. Ensure that the printer is not connected to a wired Ethernet network.
2. Restart the printer.
3. Refer to the Configuration Report to find the self-assigned IP address of the printer, in the 169.254.x.x range. For details, see [Printing the Configuration Report](#) on page 24.
4. Using an Ethernet cable, connect a computer to the printer.

Notes:

- Depending on your computer hardware, use a crossover cable or adapter as needed.
 - Ensure that wireless connectivity is disabled on your computer.
5. Find the IP address of the computer.
 6. Ensure that the computer obtains an automatic private IP address, in the 169.254.x.x range, and is therefore on the same subnet as the printer.
 7. On the computer, access Xerox® CentreWare® Internet Services. Type the IP address of the printer in the address field of a Web browser, then press **Enter** or **Return**.
 8. Configure wireless settings in Xerox® CentreWare® Internet Services. For details, see [Connecting to a Wireless Network](#) on page 32.

Note: When you switch from a wired connection to a wireless connection, the IP address of the printer changes. The connection to Xerox® CentreWare® Internet Services through your Web browser closes. To reconnect to Xerox® CentreWare® Internet Services, type the new IP address or host name of your printer in the address field of your Web browser.

Wi-Fi Direct

Wi-Fi Direct enables devices to connect with each other without requiring a wireless access point.

Wi-Fi Direct does not require manual configuration. The Wi-Fi Direct Protected Service (WPS) Name and subnet address prefix generate automatically.

If the Device Name field is blank, the WPS Name field displays a default value. If the Device Name is changed, the value for Wi-Fi Protected Setup (WPS) Name changes to the value of Device Name.

Configuring Wi-Fi Direct

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Network, next to Wi-Fi Direct, click **Edit**.
3. To modify the Wi-Fi Protected Setup (WPS) Name, for Device Name, select **Edit**.
4. For Subnet Address Prefix, type the subnet address prefix as needed.
5. Click **Apply**.

AirPrint

AirPrint is a software feature that allows you to print from wired or wireless Apple iOS-based mobile devices and Mac OS-based devices without the need to install a print driver. AirPrint-enabled printers allow you to print or fax directly from a Mac, an iPhone, iPad, or iPod touch.

Notes:

- Not all applications support AirPrint.
- When AirPrint is enabled, HTTP, Internet Printing Protocol, and mDNS are enabled by default.
- Internet Printing Protocol enablement results in a Web Server reset.
- The device that submits the AirPrint job must be on the same subnet as the printer. To allow devices to print from different subnets, configure your network to pass mDNS traffic across subnets.
- AirPrint-enabled printers work with devices running the latest version of iOS. AirPrint-enabled printers work with the iPad, iPhone (3GS or later), and iPod touch (third generation or later).

Configuring AirPrint

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Mobile Workflows, next to AirPrint, click **Edit**.
3. To configure HTTP, IPP, or Multicast DNS Registration as needed, for each protocol click **Edit**.
4. For AirPrint Enablement, click **On**.
5. To edit the name or location for your printer, for Device Name, Device Location, or Geographic Location, click **Edit**.
6. Click **Save**.

Note: To use AirPrint with accounting, you can create IPP accounting exceptions.

Mopria

Mopria is a software feature that enables users to print from mobile devices without requiring a print driver. You can use Mopria to print from your mobile device to Mopria-enabled printers.

Configuring Mopria

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Mobile Workflows, next to Mopria Discovery, click **Edit**.
3. To configure HTTP, IPP, or Multicast DNS Registration as needed, for each protocol click **Edit**.
4. For Mopria Discovery, click **On**.
5. To configure your Device Name, click **Edit**.
6. Click **Save**.

USB Settings

USB Settings allow you to set the USB connection mode and the print timeout value.

Configuring USB Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Hardware Ports, next to USB Settings, click **Edit**.
3. For USB Connection Mode, select an option:
 - **Software Tools:** This option disables Direct Printing via Driver. If you use Xerox® Copier Assistant, select this option. Xerox representatives also use this feature to connect directly to the printer and use diagnostic software and other utilities.
 - **Direct Printing via Driver:** This option allows you to connect to the printer using a USB cable.
4. For Print Timeout, type the amount of time in seconds that the printer waits inactive before it disconnects from a device that is connected to the port. Type **0** to disable the timeout.
5. Click **Save**.

AppleTalk

AppleTalk is a proprietary suite of protocols developed for networking computers by Apple, Inc. An AppleTalk zone is a group of nodes or networks organized by departments or physical locations.

Before You Begin

- Ensure that there is an existing operational AppleTalk network.
- Determine the AppleTalk Name you wish to assign to your printer.
- Determine the AppleTalk Zone, if used, to assign to your printer.

Configuring AppleTalk

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to AppleTalk, click **Edit**.
3. For Protocol, select **Enabled**.
4. Under Printer Name, type the printer name.
5. Under Zone Name, type a name.
6. Click **Save**.

FTP/SFTP Filing

File Transport Protocol (FTP) is a standard network protocol used to pass and manipulate files over a TCP/IP network. Several services running on your printer, including Network Scanning, Saved Jobs Backup, and Software upgrade can use FTP as a filing service.

Secure FTP (SFTP) is a standard network protocol that is used with SSH to ensure that data is encrypted and transferred securely.

Configuring FTP and SFTP Filing Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to FTP/SFTP Filing, click **Edit**.
3. To configure FTP or SFTP filing settings for each service listed under Within Services, click the link.
4. Under Mode, select an option:
 - **Passive** mode transfers data over a random port specified by the FTP server from a connection made from the printer.
 - **Active** mode transfers data over a fixed, known port from a connection made from the server.
5. Click **Save**.

HTTP

Hypertext Transfer Protocol (HTTP) is a request-response standard protocol between clients and servers. Clients that make HTTP requests are called User Agents (UAs). Servers that respond to these requests for resources, such as HTML pages, are called Origin Servers. There can be any number of intermediaries, such as tunnels, proxies, or gateways between User Agents and Origin Servers.

Enabling HTTP at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Network Settings > Advanced Settings**.
3. Touch **HTTP Settings**.
4. Touch **Enabled**, then touch **OK**.
5. To apply the settings, touch **Finish**.

Configuring HTTP Settings in Xerox® CentreWare® Internet Services

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to HTTP, click **Edit**.
3. For Connection, select **Enabled**.
4. Type a connection port number as needed.
5. To encrypt HTTP communication, for Force Traffic over Secure Connection (HTTPS), select **Yes**. When Force Traffic over Secure Connection (HTTPS) is enabled, all Web pages contain https:// in the URL.
 - a. For the Choose Device Certificate menu, for HTTPS, select the Device Certificate.
 - b. To view the selected certificate details, or to save the certificate to your computer, click **View/Save**.
 - c. If you select Xerox® Default Device Certificate, you can install the Generic Xerox® Trusted CA Certificate in your Web browser. Installing the Generic Xerox® Trusted CA Certificate ensures that your browser trusts the printer. To download the certificate, click **Download the Generic Xerox® Trusted CA Certificate**.
 - d. Change the Secure HTTP Port Number as needed.
6. To configure the printer to wait before it terminates a connection, for Keep Alive Timeout, type a time from 1–60 seconds.

Note: Increasing the Keep Alive Timeout can cause slow connections.

7. Click **Save**.

Accessing HTTP Web Services

To access the HTTP Web Services page, from the HTTP page, click **Web Services**.

HTTP Web Services

You can enable or disable Web Services on the Web Services page. This page provides a list of all available Web services on your printer, and displays the configuration status of each service.

- To disable a Web service, clear the check box next to the Web service name.
- To view Web service port numbers or to remove login restrictions, click **Advanced Settings**.

For more information about Xerox Extensible Interface Platform® and Web services, see the documentation included in the Xerox Extensible Interface Platform® Software Development Kit (SDK). For information on how to download the SDK, go to www.office.xerox.com/eip/enus.html.

Accessing HTTP Advanced Settings

To access the HTTP Web Services Advanced Settings page, from the HTTP page, click **Web Services > Advanced Settings**.

HTTP Advanced Settings

The Advanced Web Services page displays all services currently enabled on the printer and their port numbers.

To remove all login restrictions for web services on the printer, under Web Services IP Lockout, click **Clear Lockout**.

IP

Internet Protocol (IP) is a protocol within the Internet Protocol Suite that manages the transmission of messages from computer to computer.

Enabling TCP/IP

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Network Settings > TCP/IP Settings**.
3. Touch **TCP/IP Enablement**.
4. For IPv4 or IPv6, touch **Enabled**, then touch **OK**.
5. To apply the settings, touch **Finish**.

Note: By default, IPv4 is enabled. If you disable IPv4, before you can access Xerox® CentreWare® Internet Services, enable IPv4 or IPv6 at the printer control panel. For details, see [IP](#) on page 43 and [HTTP](#) on page 41.

Configuring the Network Address Manually at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Network Settings > TCP/IP Settings**.
3. Touch **Dynamic Addressing**.
4. Touch **Disabled**, then touch **OK**.
5. Touch **IPv4**, then type the IPv4 Address, IP Gateway Address, and Network Mask Address. After each address, touch **OK**.
6. When you are finished, touch **OK**.
7. To apply the settings, touch **Finish**.

Configuring DNS Settings at the Control Panel

Domain Name System (DNS) is a system that maps host names to IP addresses.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Network Settings > TCP/IP Settings**.
3. Touch **DNS Configuration**.
 - a. Touch **Host Name**.
 - b. Type a host name.
 - c. Touch **OK**.
 - d. Touch **Close**.

Note: If DHCP is enabled, your DHCP server can provide the Domain Name and the Requested Domain Name.

- e. Touch **Domain Name**.
 - f. For Requested Domain Name, type the domain name.
 - g. Touch **OK**.
 - h. Touch **Close**.
4. Touch **DNS Servers**.
 - a. Touch **Primary DNS Server**, type the server address, then touch **OK**.
 - b. Touch **Alternate DNS Server #1**, type the server address, then touch **OK**.
 - c. Touch **Alternate DNS Server #2**, type the server address, then touch **OK**.
 - d. Touch **Close**.
5. Touch **Close**.
6. To apply the settings, touch **Finish**.

Configuring IP Settings in Xerox® CentreWare® Internet Services

If your printer has a valid network address, you can configure TCP/IP settings in Xerox® CentreWare® Internet Services. For details, see [Assigning a Network Address](#) on page 19.

Configuring IPv4

You can use IPv4 or IPv6 in addition to or in place of the other.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Network, next to a connection type, click **Edit**.

Note: The printer uses separate IPv4, IPv6, and DNS settings for wired and wireless network connections. Before you configure wireless IP settings, install the Xerox® Wireless Network Interface, then connect to a wireless network. For details, see [Connecting to a Wireless Network](#) on page 32.

3. For Configuration Settings, next to IP, click **Edit**.
4. To configure IPv4, click **Show IPv4 Settings**.
5. For Protocol, select **Enabled**.
6. For IP Address Resolution, select an option.
 - **BOOTP:** This option permits the printer to obtain an IP address from a BOOTP server that does not respond to DHCP requests.
 - **DHCP:** This option permits the printer to obtain an IP address from a DHCP server. This option permits the printer to obtain an IP address from a BOOTP server that is configured to accept DHCP requests. The printer requests that the server register the IP address and hostname of the printer with the DNS server.
 - **STATIC:** This option disables dynamic addressing and allows you to type a static IP address. Type a Machine IP Address, Subnet Mask, and Gateway Address.
7. For Broadcast, select **Enabled** as needed.

Note: If the printer does not obtain an IP address from a DHCP/BOOTP server, enable broadcast. Enable broadcast when your DHCP/BOOTP server is on a different subnet than the printer and communicates through a relay agent router.

8. For Zero-Configuration Networking, for Self Assigned Address, select **Enable** as needed. This option instructs the printer to assign itself an address when a DHCP server does not provide one.
9. Click **Apply**.

Note: If you select Default All, the printer disables FIPS 140 mode.

Configuring IPv6

IPv6 hosts can automatically configure themselves when connected to a routed IPv6 network using the Internet Control Message Protocol Version 6 (ICMPv6). ICMPv6 performs error reporting for IP along with other diagnostic functions. When first connected to a network, a host sends a link-local multicast router solicitation request for configuration parameters. If suitably configured, routers respond to this request with a router advertisement packet containing network-layer configuration parameters.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Network, next to connection type, click **Edit**.

Note: The printer uses separate IPv4, IPv6, and DNS settings for wired and wireless network connections. Before you configure wireless IP settings, install the Xerox® Wireless Network Interface, then connect to a wireless network. For details, see [Connecting to a Wireless Network](#) on page 32.

3. For Configuration Settings, next to IP, click **Edit**.
4. To configure IPv6, click **Show IPv6 Settings**.

Note: If both IPv4 and IPv6 are disabled, you cannot access Xerox® CentreWare® Internet Services. To access IPv4 and IPv6 settings in Xerox® CentreWare® Internet Services, enable IPv4, IPv6, or both, at the printer control panel. If you disable IPv4 and IPv6 or change the IP addresses, any dependent protocols are disabled.

5. For Protocol, select **Enabled**.
6. To allow the router to assign address prefixes, for Stateless Addresses, select **Use Router Supplied Prefixes**.
7. To select how DHCP operates for IPv6, for Default Dynamic Host Configuration Protocol (DHCP) Settings, select an option.
8. To enter the address manually, for Manual Address Options, select **Enable Manual Address**.
9. From the menu, select a router prefix, or type a new router prefix, then click **Add**.
10. To save the new settings, click **Apply**.

Configuring DNS

Domain Name System (DNS) is a system that maps host names to IP addresses.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Network, next to a connection type, click **Edit**.

Note: The printer uses separate IPv4, IPv6, and DNS settings for wired and wireless network connections. Before you configure wireless IP settings, install the Xerox® Wireless Network Interface, then connect to a wireless network. For details, see [Connecting to a Wireless Network](#) on page 32.

3. For Configuration Settings, next to IP, click **Edit**.
4. To configure DNS, click **Show DNS Settings**.
5. For Requested Host Name, type a unique name for your printer. If the host name registers to the DNS server successfully, the host name appears as a Verified Host Name. The default host name is XRXxxx, where xxx is the MAC address of the printer.

Note: If no host name appears, the host name did not register to the DNS server successfully. Configure your DHCP server to perform updates on behalf of the DHCP clients.

6. For Requested Domain Name, type the name of the domain to which the printer is connected. If the domain name registers to the DNS server successfully, the domain name appears as a Verified Domain Name.

Note: If no domain name appears, the domain name did not register successfully to the DNS server. Configure your DHCP server to perform updates on behalf of the DHCP clients.

7. To allow users to see and connect to the printer using Bonjour, for Multicast DNS Registration, select **Enabled**.
8. For Release this connection's DHCP leases and DNS registrations, select **Enabled** as needed. This option allows the printer to send a release request to the DHCP and DNS servers. If the servers grant the request, the servers release the current IP address and dynamic DNS names. The IP addresses and DNS names renew immediately and when the printer is turned off.
9. For Additional DNS Server Addresses, type addresses as needed. If you have a DHCP server, recognized addresses appear in the DNS Server Addresses list.
10. For DNS Connection Timeout, type the time in seconds that the printer waits to connect to a DNS server. After the timeout period, the printer attempts to connect to any additional DNS servers.
11. To add the printer domain to the Domain Name Search List, for Append Device Domain, select **Enabled**.
12. To add the parent domains of the printer to the Domain Name Search List, for Append Parent Domains, select **Enabled**.
13. If you have a DHCP server, recognized search domain names appear in the Domain Name Search List. The list of domain names allows the DNS server to recognize unqualified host names. If you want the printer to search for other domain names, for Additional Search Domains, enter the names.
14. To set the printer to use an IPv6 address before it uses an IPv4 address, select **Prefer IPv6 Address over IPv4**.
15. Click **Apply**.

IPP

Internet Printing Protocol (IPP) is a standard network protocol that allows you to print and manage jobs remotely. When IPP is configured, IPP authentication allows users to authenticate their identities using IPP through HTTP authentication methods. An IPP client can pass user credentials to the printer to use for authentication.

Configuring IPP

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to IPP, click **Edit**.
3. Enable HTTP.
4. For IPP Enablement, select **On**.

Notes:

- IPP enablement requires a Web service reset.
 - Enabling IPP authentication impacts AirPrint job submissions because AirPrint utilizes IPP.
5. To enable IPP authentication, for Require Authentication, select **HTTP Basic**.
 6. If HTTP basic authentication is enabled, for Validation Location, select an option.
 - **Validation on the Device:** This option enables IPP authentication of users that are configured in the device user database. For more information on user, see [Device User Database](#) on page 75.
 - **Validation on the Network:** This option enables IPP authentication of users that are configured on the network authentication server for the printer.

Note: The same network authentication configuration is used on the printer for each login method that is configured for Network Authentication.

7. To configure the IPP identify printer functionality, for Identify printer, select an option.
 - **On:** This option enables an IPP client to request the printer to identify itself through a graphic or sound.
 - **Off:** This option revokes the ability of an IPP client to request the printer to identify itself through a graphic or sound.

Note: When the IPP client requests sound, the Identify Printer feature uses the Fault tone. You can configure the Fault tone on the printer control panel. For details, see the *System Administrator Guide* for your printer model.

8. Click **Save**.

LDAP

This section includes:

• Adding LDAP Server Information.....	49
• Adding or Editing LDAP Servers in Xerox® CentreWare® Internet Services.....	50
• Configuring a Secure LDAP Connection.....	50
• Configuring LDAP Server Optional Information.....	50
• LDAP Server Contexts	51
• Configuring LDAP User Mappings.....	52
• LDAP Custom Filters	52

Lightweight Directory Access Protocol (LDAP) is a protocol used to process queries and updates to an LDAP information directory, on an external server. LDAP can also be used for network authentication and authorization. LDAP directories are heavily optimized for read performance. Use this page to define how the printer retrieves user information from an LDAP directory.

Adding LDAP Server Information

The LDAP Server page displays the current LDAP servers configured for your printer. You can configure a maximum of nine LDAP servers for your printer.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to LDAP, click **Edit**.
3. Click **Add New**.
4. Under Server Information, select the preferred address type.
5. Under Friendly Name, type a name for the LDAP server.
6. Type the appropriately formatted address or host name of your server and change the default port number as needed.
7. Type the appropriately formatted address or host name of your backup server and change the default port number as needed.
8. Under LDAP Server, select an LDAP server type:
 - **Exchange** for use with Microsoft Exchange.
 - **Domino** for use with Lotus Domino.
 - **NDS** for use with Novell NetWare Directory Service.
 - **ADS** for use with Microsoft Active Directory Service.
 - **Netscape** for use with Netscape or OpenLDAP.
9. Click **Apply**.

Adding or Editing LDAP Servers in Xerox® CentreWare® Internet Services

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to LDAP, click **Edit**.
3. To configure an LDAP server, click **Add New**.
4. To edit an LDAP server configuration, in the Actions column of the server to edit, click **Edit**.
5. To copy an LDAP server configuration, select the server to copy, then click **Copy From**.
6. To delete all LDAP servers configured to your printer, click **Delete All**.
7. To enable SASL binds, click **LDAP Policies**.

Configuring a Secure LDAP Connection

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to LDAP, click **Edit**.
3. On the LDAP page, click **Add New**.
4. To enable a secure connection to the LDAP server, select **Enable SSL**.
5. To validate the SSL certificate used for HTTPS, select **Validate Repository SSL Certificate**.
6. To view a list of external root or intermediate trusted SSL certificates, click **View Trusted SSL Certificates**.
7. For Trusted SSL Certificates, select a certificate.
8. To view the selected certificate details, or to save the certificate to your computer, click **View/Save**.

Configuring LDAP Server Optional Information

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to LDAP, click **Edit**.
3. Click **Add New**.
4. For Optional Information, in the Search Directory Root field, type the root path of the search directory in Base DN format.

Note: For details on Base DN, see the *RFC 2849 - LDAP Data Interchange Format Technical Specification* on the Internet Engineering Task Force website.

5. Specify the login credentials required to access the LDAP directory.
 - **None:** This option instructs the printer to access the LDAP directory.
 - **Logged-in User:** This option instructs the printer to log in to the repository and provide the credentials of the logged-in user.
 - **System:** This option instructs the printer to use specific credentials when the printer accesses the repository. If you select System, type the credentials in the Login Name and Password fields. To update an existing password, select **Select to save new password**.

6. To use SSL, for Secure LDAP Connection, select **Enable SSL (Secure Socket Layer)**.
 - a. To allow the printer to validate certificates, select **Validate Repository SSL Certificate (trusted, not expired, correct FQDN)**.
 - b. To select a security certificate, for Trusted SSL Certificate, click the menu, then select an option.
 - c. To view the selected certificate details, or save the certificate to your computer, click **View/Save**.

Note: If the LDAP Server has encryption enabled, ensure that a certificate issued from the LDAP server certificate authority is installed on the printer.
7. To define the number of addresses returned in a search, for Maximum Number of Search Results, type a number from 5–100. The default number is 25. To use the maximum number of search results specified by the LDAP server, select **Use LDAP Server Maximum**.
8. To allow the printer to use the current settings for the LDAP server, for Search Timeout, select **Use LDAP Server Timeout**. To specify a time that the printer waits before it times out, select **Wait**, then type the number of seconds from 5–100. The default is 30 seconds.

Note: If you experience trouble retrieving results from your LDAP server, use the Wait option.
9. If you connect your primary LDAP server to other servers, to include more LDAP servers in your searches, select **LDAP Referrals**.
10. For Perform Search on Mapped Fields, select an option.
 - **Name:** This option instructs the printer to query the configured name field.
 - **Surname and Given Name:** This option instructs the printer to query the configured surname and given name fields.
 - **Display Name:** This option instructs the printer to query the configured display name field.

Note: If you want to sort your search results, for Sort Results by Mapped Field, select an option.
11. Click **Apply**.

LDAP Server Contexts

Contexts are defined starting points in an LDAP database from which the search function begins searching. Contexts are used with the Authentication feature. You can configure the printer to add an authentication context automatically to the Login Name provided by the user.

Note: Contexts are used only if you configure LDAP server settings and select NDS as the server type.

Configuring LDAP Contexts

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to LDAP, click **Edit**.
3. Click **Add New**.
4. Click the **Contexts** tab.
5. For Default Login Context, type details as needed.
6. Click **Apply**.

Configuring LDAP User Mappings

LDAP servers display different results depending on how they implement mappings. Use this page to map LDAP fields to fields on your printer. Editing current map settings allows you to fine-tune server search results.

Defining User Mappings

1. At the top of the LDAP Server page, click **User Mappings**.
2. Under Search, type a user name in the Enter Name field, then click **Search**.
3. Under Imported Heading, click the drop-down menu for each field, then remap them as needed. The schema on the LDAP server defines the headings.

Notes:

- If using Internet fax, ensure that the Internet Fax field is not set to **No Mappings Available**. This setting prevents the Network Address Book from displaying on the Internet fax screen on the printer control panel. If your LDAP server does not contain a unique Internet fax address field, it can be set to match the heading for email address.
 - If the user mapping is incorrect, an LDAP search in Xerox® CentreWare® Internet Services can work properly, but authentication at the printer panel still fails.
4. Click **Apply**.

LDAP Custom Filters

You can edit custom filters so that text strings typed at the control panel are changed to match the format that the LDAP server requires.

There are three types of filters that you can customize:

- **LDAP Authentication Filter** allows you to add text to the beginning or end of a User ID, or the Login Name configured as the System Login Name for the server. Typical filters are domain_name\USERID or USERID@domain_name.
- **Email Address Book Filter** allows you to customize the standard filter that is used when a user types a name to search in the Network Address Book.
- **User ID Query Filter** allows you to customize the standard filter that the printer uses when searching for the name of the logged-in user. For example, when remote authorization is configured, and a user logs in at the control panel, the printer searches the authorization server using this filter. The standard filter looks in the field mapped as the Login Name field. If you are using an ADS LDAP server, this field is typically sAMAccountName. If you want a search for a specific person to return an exact match, do not use wildcard characters.

Configuring Custom Filters

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to LDAP, click **Edit**.
3. Click the **Custom Filters** tab.
4. Under LDAP Authentication, select **Prepend Domain Name**. This setting prepends the base Domain Name (DN) to a user Relative Distinguished Name (RDN) when authenticating the user. Use the Common Name (CN) attribute to specify USERID in the base DN.

Notes:

- If Authenticated User is selected for Login Credentials to Access LDAP Server, some UNIX/Linux LDAP servers can require setting the Prepend Domain Name attribute.
 - For details on Base DN formatting, see the *RFC 2849 - LDAP Data Interchange Format (LDIF) Technical Specification* on the IETF website.
5. Under Email Address Book Filter, select **Enable Custom Filter**.
 6. Type the LDAP search string or filter as needed, where LDAP represents the string provided for the query. The filter defines a series of conditions that the LDAP search must fulfill to return the desired information. For example, to find people only, type **(ObjectClass=Person)&(cn=LDAP*)**.
 7. Under User ID Query Filter, select **Enable Custom Filter**.
 8. Type the LDAP search string or filter where LDAP represents the string provided for the query. The filter defines a series of conditions that the LDAP search must fulfill to return the desired information. For example, to ensure that only a person is returned rather than equipment or conference rooms, type **(objectClass=user) (sAMAccountName=LDAP)**.
 9. Click **Apply**.

LPR/LPD

The Line Printer Daemon (LPD) and Line Printer Remote (LPR) protocols provide printer spooling and network print server functionality for UNIX-based systems, such as HP-UX, Linux, and Macintosh.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to LPR/LPD, click **Edit**.
3. For Protocol, select **Enabled**.
4. Under Port Number, type a value.
5. Under PDL Switching, to allow multiple printer languages in a single job, select **Enabled**. This option allows the printer to process a single print job that contains two or more printer languages. An example is a PostScript print job with a PCL header.
6. Under PDL banner page attributes to override LPR control file attributes for job name and owner, select **Enabled**. This feature allows you to replace the standard information displayed on a banner page with the user name and job name from the print job.
7. Under Place temporary hold on which jobs, select an option:
 - **None (Use printer's default banner sheet job name if data file 1st)** does not wait to receive the job control information. This selection can cause banner page information to print incorrectly.
 - **Only those with data file received 1st** holds the job when the data file for the job is received first. This option ensures that the printer waits to receive the control file information to print banner page details correctly.
 - **All (consistent with older implementations)** puts all jobs on hold. The job prints when the printer receives all job data. This setting can cause jobs to print slowly but results in accurate banner page information.
8. Click **Save**.

NetWare

NetWare is a network operating system developed by Novell to run various services using cooperative multitasking.

Before you begin:

- Ensure an existing operational NetWare network is available.
- Verify that you have administrator rights to log in to a NetWare file server or tree.
- Ensure that the printer is connected to the network.
- Set up a print server object using the appropriate Novell utility. Refer to the Novell system documentation for help.

Configuring NetWare General Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to Netware, click **Edit**.
3. In the General pane, under Protocol, select **Enabled**.
4. Under Frame Type, select an option.
5. Under Queue Poll Interval, type a rate from 1 through 240 seconds.
6. Under Printer Server Name, type a name.
7. Under New Print Server Password, type a server password. Retype the password to confirm.
8. Enable **Select to save new password**.
9. Click **Save**.

Enabling SAP

Service Advertising Protocol (SAP) sends periodic broadcast messages to other network components about available services on the printer. SAP facilitates dynamic adding and removing of services on an IPX internetwork. As servers start up and shut down, they can advertise and remove their services using SAP.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to Netware, click **Edit**.
3. In the SAP pane, under Protocol, select **Enabled**.
4. Under SAP Frequency, type a value from 15 through 300 seconds.
5. Click **Save**.

Bindery Settings

Bindery services are a stand-alone database system that contains user information and security data. NetWare can use Bindery services for authentication.

If you are using Bindery mode, under Bindery Settings, in the File Server fields, type the names of up to four primary file servers.

Note: When the printer uses Bindery mode, the NDS Tree and NDS Context fields are ignored.

Configuring NetWare Directory Services (NDS) Settings

NetWare Directory Services (NDS) is a hierarchical, object-oriented database that represents all of the assets of an organization in a logical tree structure. Assets can include printers, servers, computers, people, organizations, and more.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to Netware, click **Edit**.
3. In the NetWare Directory Services (NDS) pane, select an option:
 - **IPv4** sets a static IPv4 address.
 - **Host Name** is configured with an NDS server.

Note: Select NDS server only if using Workflow Scanning or server fax.

4. Under NDS Tree, type a name. If using bindery or bindery emulation, leave blank.
5. Under NDS Context, type a name. If using bindery or bindery emulation, leave blank.
6. Under NDS Server, type an IP address as needed.
7. Click **Save**.

NDPS/NEPS

Novell Distributed Print Services (NDPS)/Novell Enterprise Print Services (NEPS) allow you to manage printers in an NDPS environment. To configure and manage network print services, the Xerox NDPS solution provides Xerox® plug-ins for Novell NWAdmin and iManager tools.

NetWare users do not need to install individual print drivers. When users connect to a printer, the proper print driver is downloaded. Printer objects are created automatically in the NDS Tree. Users can monitor real-time printer and job status.

To download the Xerox NDPS/NEPS Agent documentation and print drivers, go to www.xerox.com/office/support.

NTP

The Network Time Protocol (NTP) synchronizes the internal clocks of computers over a network connection at system startup and every subsequent 24-hour period thereafter. If your printer uses DHCP and an NTP server, or if a DHCP server provides Greenwich Mean Time (GMT) offset, these settings are ignored.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to NTP, click **Edit**.
3. Under NTP Enabled, select **Enabled**.
4. Select **IPv4 Address** or **Host Name**.
5. Under IP Address: Port and Alternate IP Address: Port, type the address and port numbers.
6. Click **Save**.
7. For the new settings to take effect, restart your printer.

POP3

Post Office Protocol, version 3 (POP3) is a protocol that allows email clients to retrieve email from remote servers over TCP/IP on network port 110. This printer uses POP3 for the Internet fax and email features to retrieve fax jobs over email. POP3 is not compatible with IPv6.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to POP3 Setup, click **Edit**.
3. Under Server Information, select **IPv4** or **Host Name**.
4. Type the address or server name.
5. Under Login Name, type the name assigned to the printer used to log in to the POP3 server.
6. Under Password, type and confirm a password.
7. To save the new password, click **Select to save new password**.
8. In the POP3 Settings pane, select **Enable receipt of Email via POP3**.
9. Under Polling Interval, type a value from 1 through 60.
10. Click **Save**.

Proxy Server

A proxy server acts as a go-between for clients seeking services and servers that provide them. The proxy server filters client requests and if the requests meet the proxy server filtering rules, it grants the request and allows the connection.

A proxy server has two main purposes:

- To keep any devices behind it anonymous for security purposes.
- To cache content from resources, such as Web pages from a Web server, to increase resource access time.

Configuring the Proxy Server

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to Proxy Server, click **Edit**.
3. In the HTTP Proxy Server pane, select **Enabled**.
4. Select the Proxy Server address type. Options are **IPv4 Address**, **IPv6 Address**, or **Host Name**.
5. Type the appropriately formatted address and port number.
6. Click **Save**.

Note: Proxy server settings apply to features that use HTTP or HTTPS. Examples are, Smart eSolutions, Xerox Online Support, Workflow Scanning destinations and template pool repositories using HTTP or HTTPS. Not all printer models support these features.

Raw TCP/IP Printing

Raw TCP/IP is used to open a TCP socket-level connection over Port 9100, and stream a print-ready file to the printer input buffer. It then closes the connection either after sensing an End Of Job character in the PDL or after expiration of a preset timeout value. Port 9100 does not require an LPR request from the computer or the use of an LPD running on the printer. Raw TCP/IP printing is selected in Windows as the Standard TCP/IP port.

Configuring Raw TCP/IP Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to Raw TCP/IP Printing, click **Edit**.
3. On the Raw TCP/IP Printing tab, for Protocol, select **Enabled**.
4. For TCP Port Number, ensure that Port 1 is set to **9100**.
Note: To emulate HP JetDirect EX Plus 3, set Port 2 to **9101** and Port 3 to **9102**.
5. Next to Bidirectional, for each active port, select **Enabled**.
6. Next to Maximum Connections per Port, for each active port, type a number from 1 through 32.
7. Next to For End of Job Timeout, for each active port, type a time in seconds from 0 through 1800.
8. Next to PDL Switching, for each active port, select **Enabled** as needed.
Note: PDL Switching allows the printer to switch automatically between multiple supported PDLs within a single job.
9. To save the new settings, click **Apply**.
10. To return all settings to the default status, click **Default All**.

Configuring Raw TCP/IP Advanced Settings

1. On the Raw TCP/IP Printing page, click the **Advanced** tab.
2. Under Connections, set the following:
 - Set the Maximum Connections per port between **1–32**. The default port value is 32.
 - To allow concurrent jobs to process for each port connection, type a number between **0–500** jobs in each port. Type **0** to allow unlimited concurrent jobs.
 - To limit the number of jobs that are active for each port connection, type a number between **0–32768**. Type **0** to allow unlimited number of active jobs.
3. Under Job Boundary Determination:
 - Type the End of Job Timeout between **0–1800** seconds to specify the amount of time to pass before a job processes with an End of Job character. The default time is 300 seconds. Type **0** to disable end of job detection by timeout.
4. Under Backchannel Data:
 - Enable **Backchannel Data Transmission to Client**, then, enable **Out of Order Backchannel Data** to allow data from several jobs to be interspersed.

Note: Out of Order Backchannel Data is only available when Backchannel Data Transmission to Client is enabled.

5. Under Banner Page Printing:
 - To restrict banner pages to print for specific jobs only, select the job types from the Banner Page Enabled drop-down menu. Options are **First Job Only**, **No Jobs**, or **All Jobs**.
 - To enable banner pages to print before each PDL document within a single job, select **Enabled** for Banner Page for Each Document of Job.
 - To restrict banner pages to print for jobs that specifically request them through PJL, select **Enabled** for Banner Page for Job Containing only PJL Commands.
6. Miscellaneous
 - To allow the printer to switch between multiple PDLs within a single job, select **Enabled** for Language (PDL) Switching within PJL Job.
 - To force parsing of job data, select **Enabled** for Job Data Parsing Override.

Note: Job data is not parsed when bidirectional communication and PDL switching are disabled.

7. Click **Apply** to save the new settings or **Undo** to retain the previous settings.
Click **Default All** to reset settings to default values.

SLP

Printers use Service Location Protocol (SLP) to announce and look up services on a local network without prior configuration. When SLP is enabled, the printer becomes a Service Agent (SA) and announces its services to User Agents (UA) on the network using SLP.

Directory Agents (DA) are components that cache services. They are used in larger networks to reduce the amount of traffic. DAs are optional. If a DA is present, then User Agents (UAs) and System Agents (SAs) are required to use it instead of communicating directly with the printer.

Configuring SLP

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to SLP, click **Edit**.
3. For Protocol, select **Enabled**.
4. For Directory Agent, type the IP address for the Directory Agent (DA) as needed.
5. To group services, under Scope 1, 2, and 3, type a name as needed. Printers cannot recognize services that are in different scopes.
6. For Message Type, select an option.
 - **Multicast** routes multicast packets between subnets.
 - **Broadcast** does not route packets between subnets.
7. Under Multicast Radius, type a value from 0 through 255.
Multicast Radius defines how many routers the multicast packet can cross.
8. For Maximum Transmission Unit (MTU), type a value from 484 through 32768.
Note: The maximum MTU for IP over Ethernet is 1500 bytes.
9. Click **Save**.

SMB Filing

You can specify Kerberos authentication options for features that file images to an SMB-shared network location.

Configuring Kerberos Authentication Options for SMB

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to SMB Filing, click **Edit**.
3. Under With Kerberos Tickets, for Workflow Scanning, Server Fax, and Scan to Home features, select an option:
 - **Always File with Kerberos Ticket** instructs the printer to attempt to use Kerberos authentication to the SMB shared network location. Configure Network Authentication or Smart Card Authentication using a Kerberos server.
 - **Prefer Filing with Kerberos Ticket** instructs the printer to authenticate to the SMB shared network location with a Kerberos ticket if available. If a Kerberos ticket is not available, or Kerberos authentication fails, the printer attempts to authenticate using other methods, such as NT, or NTLM.
 - **Do Not File with Kerberos Ticket** instructs the printer to attempt to authenticate to the SMB shared network location using other methods, such as NT, or NTLM. Do not select this option when Smart Card authentication is enabled. If you select this option when Smart Card authentication is enabled, SMB file transmission fails, and an error message appears on the touch screen.
4. Under Without Kerberos Tickets, click the appropriate link to navigate to the Configuration Page for features that use SMB as needed. Features listed use SMB, but cannot use Kerberos authentication. Disable these features or configure them to use a protocol other than SMB for FIPS 140 compliance.
5. Click **Save**.

SMTP Server

Simple Mail Transfer Protocol (SMTP) is an Internet standard used to transmit email across IP networks. Your printer uses SMTP to transmit scanned images, Internet fax jobs, and alerts through email.

Configuring SMTP Server Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to SMTP, click **Edit**.
3. To allow the printer to use DNS to identify an SMTP server on your network automatically, under Server, select **Use DNS**.
4. To specify an SMTP server manually, select **Specify SMTP Server manually**.
 - a. For address type, select an option. Options are **IPv4 Address**, **IPv6 Address**, or **Host Name**.
 - b. Type the appropriately formatted address and port number.
5. Under Device Email Address, type the email address of the printer.
6. Click **Apply**.

Configuring SMTP Authentication Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to SMTP (Email), click **Edit**.
3. On the SMTP (Email) page, click the **SMTP Authentication** tab.
4. For SMTP Login credentials applied to email jobs sent from the touch interface of the printer, select an option.
 - **None**: The server does not require the printer to provide a user name or password.
 - **System**: The printer uses the information provided in the Login Name and Password fields to access the server.
 - **Logged-in User**: The printer provides the credentials of the authenticated user to the server.
 - **Prompt at User Interface**: This option requires users to type a login name and password at the control panel.
5. For SMTP Login credentials for the printer to Access the SMTP Server to send automated emails, select an option.
 - **None**: The server does not require the printer to provide a user name or password.
 - **System**: The printer uses the information provided in the Login Name and Password fields to access the server.
6. Click **Apply**.

Configuring SMTP Connection Encryption Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to SMTP (Email), click **Edit**.
3. On the SMTP (Email) page, click the **Connection Encryption** tab.
4. To encrypt SMTP communication, for **Encryption Mechanism used by devices when Communicating with the SMTP Server**, select an option.

Note: If you do not know the encryption method that your server supports, select **STARTTLS (if available)**. If you select **STARTTLS (if available)**, the printer attempts to use STARTTLS. If your server does not support STARTTLS, SMTP communication is not encrypted.

5. Click **Apply**.

Configuring SMTP File Size Management

1. On the SMTP (Email) page, click the **File Size Management** tab.
2. To define a maximum message size for messages with attachments, type a value between **512–20480** KB in the Maximum Message Size field.
3. To improve transmission speed, set messages to fragment between **1–500** times.
4. To set a maximum job size, type a value between **512–2000000** KB in the Total Job Size field.
5. If you selected more than 1 fragment in Number of Fragments, under Email Job Splitting Boundary, select an option:
 - **Page Boundary** instructs the mail client not to reassemble the job on receipt.
 - **Automatic Boundary** instructs the mail client to reassemble the job on receipt.
6. Click **Apply**.

Testing SMTP Configuration Settings

1. On the SMTP (Email) page, click the **Test Configuration** tab.
2. Under To Address, type an email address.
3. To send a test email to the address, click **Send Email**.
If the email transmission succeeds, a confirmation message appears. If the transmission fails, an error message appears.

SNMP

Simple Network Management Protocol (SNMP) is a set of network protocols designed to allow you to manage and monitor devices on your network.

You can use the SNMP configuration pages in Xerox® CentreWare® Internet Services to:

- Enable or disable Authentication Failure Generic Traps.
- Enable SNMPv3 to create an encrypted channel for secure printer management.
- Assign privacy, authentication protocols, and keys to Administrative and key user accounts.
- Assign read and write access to User accounts.
- Limit SNMP access to the printer using hosts.

Enabling SNMP

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to SNMP, click **Edit**.
3. Select an option:
 - To enable SNMP v1/v2c, select **Enable SNMP v1/v2c Protocols**.
 - To enable SNMP v3, select **Enable SNMP v3 Protocol**.
4. To prompt the printer to generate a trap for every SNMP request processed with an invalid community name, for Authentication Failure Generic Traps, select **Enabled**.
5. Click **Save**.

Configuring SNMPv1/v2c

SNMP version 1 (SNMPv1) is the initial implementation of the SNMP protocol. SNMPv1 operates over protocols such as User Datagram Protocol (UDP), IP, and Novell Internet Packet Exchange (IPX).

SNMPv2c includes improvements in performance, confidentiality, and manager-to-manager communications over SNMPv1, however it uses the simple-community based security scheme of SNMPv1.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to SNMP, click **Edit**.
3. Click **Edit SNMPv1/v2c Properties**.
4. Under GET Community Name, type a name.

GET returns the password for the SNMP GET requests to the printer. Applications obtaining information from the printer using SNMP, such as Xerox® CentreWare® Internet Services, use this password.

5. Under SET Community Name, type a name.

SET returns the password for the SNMP SET requests to the printer. Applications that set information on the printer using SNMP use this password.



CAUTION: Changes made to the GET or SET community names for this printer require corresponding changes to the GET or SET community names for applications using SNMP.

6. Under TRAP Community Name, type a name.

Note: Use the Default TRAP Community Name to specify the default community name for all traps the printer generates. Individual Trap Community Names specified for each trap destination address can override the community name. Each Trap Community Name must be unique.

7. Click **Save** to apply the new settings or **Undo** to retain the previous settings.

Configuring SNMPv3

SNMPv3 is the current standard version of SNMP defined by the Internet Engineering Task Force (IETF). It provides three important security features:

- Message integrity to ensure that a packet has not been tampered with in transit
- Authentication to verify that the message is from a valid source
- Encryption of packets to prevent unauthorized access

Editing SNMPv3 Properties

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to SNMP, click **Edit**.
3. Click **Edit SNMPv3 Properties**.
4. To create the administrator account, under Administrator Account, select **Account Enabled**.
5. Type and confirm the Authentication Password. The Authentication Password is used to generate a key used for authentication.
6. Type and confirm the Privacy Password. The Privacy Password is used for encryption of SNMPv3 data. The passphrase used to encrypt the data must match the passphrase on the Server.

Note: Ensure that the passwords are at least eight characters in length. You can include any characters except control characters.

7. To save the new password, click **Select to save new password**.
8. Under Print Drivers/Remote Clients Account, click **Account Enabled**. To reset the default password, click **Reset**. This account allows Xerox® clients and drivers limited access to objects on the printer.
9. Click **Save** to apply the new settings or **Undo** to retain the previous settings.

Configuring SNMP Advanced Settings

You can add, edit, or delete IP and IPX addresses for Network Management workstations that receive traps from the printer.

Configuring SNMP Advanced Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to SNMP, click **Edit**.
3. Click **Advanced Settings**.
4. To add an IP trap destination address, under Trap Destination Addresses, click **Add IP Address**.
5. To add an IPX trap destination address, under Trap Destination Addresses, click **Add IPX Address**.
6. To edit an address, next to the address click **Edit**.
7. To delete an address, select the check box next to the address and click **Delete**.

Adding or Editing an IP Trap Destination Address

1. On the Advanced Settings page, click **Add IP Address**, or select an existing address and click **Edit**.
2. Type the IP address of the host running the SNMP manager that receives traps.
3. Type the UDP Port Number. The default is 162 for traps.
4. Select the SNMP version based on what the system receiving traps supports.
5. Select the type of traps that the SNMP manager receives under Traps to be Received.
6. Click **Save** to apply the new settings or **Undo** to retain the previous settings.
7. Click **Cancel** to return to the previous page.

Adding or Editing an IPX Trap Destination Address

1. On the Advanced Settings page, click **Add IPX Address**, or select an existing address and click **Edit**.
2. Type the 8-digit hexadecimal number that identifies the IPX External Network host configured to receive the trap.
3. Type the 48-bit Physical MAC Address of the computer running the SMNP manager application receiving the trap.
4. Type the IPX Socket Number of the computer running the SNMP manager application configured to receive the packets. The default IPX Socket Number is 9010.
5. Select the SNMP Version.
6. Select the type of traps that the SNMP manager receives under Traps to be Received.
7. Click **Save** to apply the new settings or **Undo** to retain the previous settings.
8. Click **Cancel** to return to the previous page.

SSDP

Simple Service Discovery Protocol (SSDP) provides processes to allow network clients with little or no static configuration to discover network services. SSDP provides multicast discovery, server-based notification, and discovery routing options.

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to SSDP, click **Edit**.
3. For Protocol, select **Enabled**.
4. Under Cache Control, type a number from 1 through 43200.
5. Under Time to Live, type a number from 1 through 60.
6. Click **Save**.

WSD

Web Services for Devices (WSD) is technology from Microsoft that provides a standard method for discovering and using network connected devices. It is supported in Windows Vista, Windows Server 2008, and newer operating systems. WSD is one of several supported communication protocols.

Enabling WSD

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Protocol, next to WSD, click **Edit**.
3. Under WSD Services, select **Enabled**.
4. Click **Save**.

Security

4

This chapter includes:

• Setting Access Rights	72
• Configuring Authentication Settings	74
• Configuring Authorization Settings	84
• Secure HTTP (SSL)	92
• FIPS 140-2	93
• Stored Data Encryption	95
• IP Filtering.....	96
• Audit Log.....	98
• Installation Policies	101
• McAfee Embedded Control	102
• IPsec.....	105
• Security Certificates.....	110
• 802.1X.....	116
• System Timeout.....	118
• Overwriting Image Data.....	119
• PostScript Passwords.....	123
• USB Port Security.....	124
• Displaying or Hiding Network Settings	125
• Hiding User Names on the Control Panel	126
• Verifying the Software.....	127
• Restricting Print File Software Updates.....	128
• Specifying Email and Internet Fax Recipient Restrictions	129
• Disabling the System Administrator Password Reset.....	130

See also:

www.xerox.com/security

Setting Access Rights

You can control access to services and features by setting up authentication and authorization. Personalization allows the printer to retrieve user information to customize features.

Authentication

Authentication is the process of confirming your identity. When the system administrator enables authentication, the printer compares the information that you provide to another source of information, such as an LDAP directory. The information can be a user name and password, or the information stored on a magnetic, proximity, or smart card. If the information is valid, you are considered an authenticated user.

There are several ways to authenticate a user:

- **User Name / Password - Validate on the Device** enables local authentication. Users prove their identity by typing a user name and password at the control panel or in Xerox® CentreWare® Internet Services. The printer compares the user credentials to the information stored in the user database. If you have a limited number of users, or do not have access to an authentication server, use this authentication method.
- **User Name / Password - Validate on the Network** enables network authentication. Users prove their identity by typing a user name and password at the control panel or in Xerox® CentreWare® Internet Services. The printer compares the user credentials to the information stored on an authentication server.

Note: The printer can use one of the following authentication server types: Kerberos (Solaris or Windows), NDS, SMB (Windows 2000/2003), or LDAP.

- **Convenience Authentication** enables authentication for a proximity card reader. Users swipe a pre-programmed identification card at the control panel. To use this method, purchase and install a USB card reader and an authentication server that supports the Xerox® Convenience Authentication API.
- **Xerox Secure Access Unified ID System** enables authentication for the Xerox Secure Access Unified ID System. Users present a pre-programmed identification card to a card reader at the control panel. The printer compares the user credentials to the information stored on the Xerox® Secure Access server. To use this method, purchase and install the Xerox Secure Access Unified ID System.
- **Smart Cards** enables authentication for a smart card reader. Users insert a pre-programmed identification card in a carder reader at the control panel. To use this method, purchase and install a smart card reader system.

Authorization

Authorization is the function of specifying the features that users are allowed to access, and the process of approving or disapproving access. You can configure the printer to allow users to access the printer, but restrict access to certain features, tools, and services. For example, you can allow users to access copying but restrict access to scanning. You can also control access to features at specific times of the day. For example, you can restrict a group of users from printing during peak business hours.

There are two types of authorization:

- **Local Authorization** verifies user information on the printer to approve access.
- **Network Authorization** verifies user information stored externally in a network database, such as an LDAP directory, to approve access.

Personalization

Personalization is the process of customizing services for a specific user. The printer searches an LDAP directory for the home directory and email address of a user when using Scan to Home, or Email Scanning features.

Setting the Login Method

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **Login Methods**.
3. In the upper right-hand corner, click the pencil icon.
4. To set the authentication method for logging in to control panel, under Touch UI Method, select an option.
5. If you selected Convenience Authentication or Smart Cards as the authentication method, you can also allow users to log in at the control panel. This option is useful if a user loses their smart card, but must access the printer. Under Alternate authentication method on the machine's touch interface, select **User Name / Password Validated Remotely on the Network**.
6. To set the authentication method for logging in to Xerox® CentreWare® Internet Services, under Web UI Method, select an option.
7. To retrieve the home directory and email address of a user when using Scan to Home, or Email Scanning features, select **Personalize Touch UI**.
8. Click **Save**.

Configuring Authentication Settings

Configuring Local Authentication Settings

When you configure local authentication, users prove their identity by typing a user name and password at the control panel or in Xerox® CentreWare® Internet Services. The printer compares the user credentials to the information stored in the user database. If you have a limited number of users, or do not have access to an authentication server, use this authentication method.

To configure access rights using local authentication:

- Set the login method to **User Name / Password - Validate on the Device**. For details, see [Setting the Login Method](#) on page 73.
- Add user information to the user information database.
- If you enabled Personalization, configure LDAP server settings.
- Configure authorization settings. For details, see [Authorization](#) on page 84.

The Login Methods page in Xerox® CentreWare® Internet Services provides links to authentication and personalization configuration settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **Login Methods**.

User Database

The user database stores user credential information. The printer uses this information for local authentication and authorization, and for Xerox® Standard Accounting. When you configure local authentication, the printer checks the credentials that a user provides against the information in the user database. When you configure local authorization, the printer checks the user database to determine which features the user is allowed to access.

Note: User names and passwords stored in the user database are not transmitted over the network.

Adding User Information to the User Database

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. For Device User Database, click **Edit**.
3. Click **Add New User**.
4. Type a User Name and Friendly Name for the user.
5. Type a Password for the user, then retype it to verify.

Notes:

- The Password field only appears if the selected authentication method is local authentication.
 - If you have configured local authorization, you can add the user to a role.
6. To add the user to a role, select the check box next to the role:
 - **Accounting Administrator:** This role allows the user to access accounting settings and other services and settings that are locked.
 - **System Administrator:** This role allows the user to access all services and settings.

Note: If you have created any user roles, they also appear in the list.

7. Click **Save**.

Specifying Password Requirements

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. For Device User Database, click **Edit**.
3. Click **Password Settings**.
4. Specify the password Minimum Length and Maximum Length.
5. Select rules as desired:
 - **Cannot contain Friendly Name**
 - **Cannot contain User Name**
 - **Must contain at least one number**
6. Click **Save**.

Note: New password rules do not affect existing passwords.

Configuring Network Authentication Settings

When you configure network authentication, to prove their identity, users type their name and password in at the control panel or in Xerox® CentreWare® Internet Services. The printer compares the user credentials to the information stored on an authentication server.

Note: If two or more authentication servers are configured, then the IPP Authentication Policy window appears. The IPP Authentication Policy is used to determine which server to use for IPP Authentication.

To configure access rights using network authentication:

- Set the login method to **User Name / Password - Validate on the Network**. For details, see [Setting the Login Method](#) on page 73.
- Provide information about your authentication server and configure authentication server settings.
- If you enabled Personalization, configure LDAP server settings.
- Configure authorization settings. For details, see [Authorization](#) on page 84.

The Login Methods page in Xerox® CentreWare® Internet Services provides links to authentication and personalization configuration settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **Login Methods**.

Configuring Authentication Server Settings for Kerberos

1. On the Login Methods page, for Authentication Servers, click **Edit**.
2. For Authentication Type, select **Kerberos**.
3. Click **Add New**.
4. For Server Information, in the Domain or Realm field, type the domain or realm for your authentication server.
5. Select the desired address type.
6. Type the appropriately formatted address and port numbers for both the primary and backup addresses.

Note: A backup address is optional.

7. To use an LDAP server for network authorization or personalization:
 - a. Click **Add LDAP Mapping**.
 - b. Select the LDAP server from the list and click **Add Mapping**, or click **Add New** to add an LDAP server.
8. Click **Save**.
9. To specify server settings for an alternate authentication server, click **Add New**.
10. To copy the settings from another server, select a server from the list, then click **Copy From**.
11. To update the settings, click **Edit**.

Configuring Authentication Server Settings for NDS

1. On the Login Methods page, next to Authentication Servers, click **Edit**.
2. Under Authentication Type, select **NDS (Novell)**.
Note: If you do not see this authentication type, ensure that the NetWare protocol has been enabled under **Connectivity > Setup > NetWare > Edit**.
3. Click **Add New**.
4. Under Default Tree/Context, in the Tree and Context fields, type the details.
5. Click **Save Server**.
6. To specify server settings for an alternate authentication server, click **Add New**.
7. To copy the settings from another server, select a server from the list and click **Copy From**.
8. Click **Edit** to update the settings.

Configuring Authentication Server Settings for SMB

1. On the Login Methods page, next to Authentication Servers, click **Edit**.
2. Under Authentication Type, select **SMB (Windows NT 4)** or **SMB (Windows 2000/2003)**.
3. Click **Add New**.
4. Under Domain, type the domain name of your authentication server.
5. Select the address type.
6. Type the appropriately formatted address and port number.
7. Click **Save**.
8. To specify server settings for an alternate authentication server, click **Add New**.
9. To copy the settings from another server, select a server from the list and click **Copy From**.
10. Click **Edit** to update the settings.

Configuring Authentication Server Settings for LDAP

The printer uses the primary LDAP server for authentication, authorization, and personalization. The primary LDAP server is the server that appears at the top of the LDAP server list on the LDAP Server page in Xerox® CentreWare® Internet Services. If you already have configured LDAP server settings, the printer uses this server automatically when you select LDAP as the network authentication or authorization method. The printer only uses alternate LDAP servers for authorization and personalization when primary LDAP server communication fails.

1. On the Login Methods page, next to Authentication Servers, click **Edit**.
2. Under Authentication Type, select **LDAP**.
3. Click **Add New**.
4. Configure LDAP server settings, then click **Apply**.

Configuring Xerox Secure Access Unified ID System Authentication Settings

When Xerox® Secure Access authentication is configured, users swipe a pre-programmed identification card at the control panel. The printer compares the user credentials to the information stored on the Xerox® Secure Access server. To use Xerox® Secure Access, purchase and install the Xerox Secure Access Unified ID System.

To configure access rights using Xerox Secure Access Unified ID System authentication:

- Install the Xerox® Secure Access authentication server software and configure it with user accounts. For details, see the Xerox Secure Access Unified ID System documentation.
- Enable the Authentication and Accounting Configuration Web service. For details, see [HTTP](#) on page 41.
- Format and configure identification cards.
- Connect your card reader to the USB Port.
- Set the login method to **Xerox Secure Access - Unified ID System**. For details, see [Setting the Login Method](#) on page 73.
- Configure Xerox® Secure Access Setup settings.
- Enable the Xerox® Secure Access Web service. For details, see [HTTP](#) on page 41.
- If you enabled Personalization, configure LDAP server settings. For details, see [LDAP server settings](#) on page 49.
- Configure authorization settings. For details, see [Authorization](#) on page 84.

The Login Methods page in Xerox® CentreWare® Internet Services provides links to authentication and personalization configuration settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **Login Methods**.

Configuring Xerox Secure Access

1. On the Login Methods page, next to Xerox® Secure Access Setup, click **Edit**.
2. Configure the remote server. For details, see the instructions provided with your server hardware. Once the server is configured, it communicates with the printer and automatically completes the configuration process.
3. To configure communication manually, personalize instructional windows, and review accounting options, click **Manually Configure**.
4. To return to the Login Methods page, click **Pending Remote Server Setup**.
5. To configure any settings that are marked in red text as **Required; Not Configured**, in the table at the bottom of the page, click **Edit**.

Manually Configuring Xerox Secure Access Settings

If you are using Xerox® Secure Access for authentication, you can manually configure remote server communication, personalize instructional windows, or review accounting options.

Before you begin:

Configure the Xerox® Secure Access authentication server.

1. On the Login Methods page, next to Xerox® Secure Access Setup, click **Edit**.
2. Click **Manually Configure**.
3. Under Server Communication, select the address type and port number.
4. Type the appropriately formatted address and port number.
5. In the Path field, type the following HTTP path: **public/dce/xeroxvalidation/convauth**.
6. Under Embedded, select **Enabled**.
7. Under Device Log-In Methods, select an option:
 - **Xerox Secure Access Device Only** allows users to access the printer only using the card reader.
 - **Xerox Secure Access Device + alternate onscreen authentication method** allows users to access the printer by logging in at the control panel.
8. When Network Accounting is configured, the printer can obtain user accounting information from the authentication server. To reduce the number of screens that appear when a user logs in at the control panel, select **Automatically apply Accounting Codes from the server**.
 If you want users to provide an accounting code at the control panel, select **User must manually enter accounting codes at the device**.
9. To create login instructions for users, under Device Instructional Blocking Window, type text in the fields.
 - a. In the Window Title field, type text to appear as a title at the top of the touch screen.
 - b. In the Instructional Text field, type instructions that appear below the title.

Note: If the Title and Prompt are configured on the Xerox Partner authentication server, then any instructional text that you type is ignored.
10. Click **Save**.

Configuring Convenience Authentication Settings

When Convenience Authentication is enabled, users swipe a pre-programmed identification card through a proximity card reader at the control panel. To use this method, purchase and install a USB card reader and an authentication server that supports the Xerox® Convenience Authentication API.

The Login Methods page in Xerox® CentreWare® Internet Services provides links to authentication and personalization configuration settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **Login Methods**.

To configure access rights using Convenience Authentication:

- Format and configure identification cards.
- Connect your card reader to the USB Port.
- Enable the Xerox® Secure Access Web service.
- Set the login method to **Convenience Authentication**. For details, see [Setting the Login Method](#) on page 73.
- To provide information about your authentication server, next to Convenience Authentication Setup, under Action, click **Edit**.
- To enable the Xerox® Secure Access Web service, next to Web Service Enablement, under Action, click **Edit**.
- To configure card reader policies, next to Card Reader Setup, click **Edit**.
- To customize the title and instruction text that appears on the blocking screen, next to Customized Blocking Screen, click **Edit**.
- If you selected an alternate login method that requires a network authentication server, provide information about your server. Next to Authentication Servers, under Action, click **Edit**.
- To provide information about your LDAP server for personalization, next to LDAP Servers, under Action, click **Edit**.
- Configure authorization settings. For details, see [Authorization](#) on page 84.

Configuring an Authentication Server for Convenience Authentication

1. On the Login Methods page, next to Convenience Authentication Setup, click **Edit**.
2. Under Server Communication, select an address type. Type the appropriately formatted address or host name of your server and change the default port number as needed.
3. Under Path, type the path of the authentication Web service on your server.
4. When Network Accounting is configured, the printer can obtain user accounting information from the authentication server. To reduce the number of screens that appear when a user logs in at the control panel, select **Automatically apply Accounting Codes from the server**.
If you want users to provide an accounting code at the control panel, select **User must manually enter accounting codes at the device**.
5. Click **Save**.

Configuring Smart Card Authentication Settings

When Smart Card authentication is configured, users swipe a pre-programmed identification card at the control panel. Purchase and install a Smart Card reading system before configuring Smart Card authentication.

To configure access rights using Smart Card authentication:

- Provide information about your domain controller servers and configure Domain Controller and NTP settings.
- Set the login method to **Smart Cards**. For details, see [Setting the Login Method](#) on page 73.
- If you want to validate certificates, configure Certificate Validation options and provide information about your OCSP server.
- If needed, configure Smart Card Inactivity Timer settings.
- If needed, specify the method the printer uses to acquire the email address of a user by configuring email Smart Card Policies.
- If you want a custom image to appear at the control panel, import your image.
- If you enabled Personalization, configure LDAP server settings.
- Configure authorization settings. For details, see [Authorization](#) on page 84.

The Login Methods page in Xerox® CentreWare® Internet Services provides links to authentication and personalization configuration settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **Login Methods**.

Setting Up Authentication for a Smart Card System

Domain Controller

1. On the Login Methods page, next to Domain Controllers, click **Edit**. The domain controller server must validate the domain certificate on the smart card of the user before the user can access the printer.
2. Click **Add Domain Controller**.
3. If you are using a Windows-based domain controller, under Domain Controller Type, select **Windows-Based Domain Controller**.
4. Type the domain controller server address information.
5. Click **Save** to apply the new settings or **Cancel** to return to the previous screen.
6. To change the search priority of the domain controller, click **Change Domain Priority**.
 - a. To change the priority of the server, select a server in the list and click the arrows.
 - b. Click **Close**.
7. To configure NTP settings, next to Network Time Protocol, click **Edit**. Synchronize the domain controller time with the time set on the printer.

Note: Xerox recommends that you enable NTP to ensure time synchronization.

8. To return to the Login Methods page, click **Close**.

To associate an LDAP server with your Domain Controller for authorization or personalization, under LDAP Server Mapping, click **Add LDAP Mapping**.

Configuring OCSP Validation Server Settings

If you have an OCSP server, or an OCSP certificate validation service, you can configure the printer to validate certificates installed on the domain controller.

Before you begin:

Add a domain controller.

1. On the Login Methods page, next to Certificate Validation, click **Edit**.
2. Select a validation method and click **Next**.
3. On the Required Settings page, type the URL of the OCSP server.
4. To ensure that the printer can communicate with the OCSP server and the domain controller, configure your proxy server settings as needed.
5. For each domain controller listed, under Domain Controller Certificate, select the corresponding domain controller certificate from the menu. If there are no certificates installed, click **Install Missing Certificate**.
6. Click **Save**.

Setting the Inactive Time Limit

1. On the Login Methods page, next to Smart Card Inactivity Timer, click **Edit**.
2. Specify the maximum amount of time before a user is logged out automatically. Type the time in minutes.
3. Click **Save**.

Specifying the Method the Printer Uses to Acquire Email Address of Users

1. On the Login Methods page, next to Acquired Logged-in User's Email Address, click **Edit**.
2. Under Acquire logged-in user's email address from, select an option:
 - **Auto** instructs the printer to attempt to acquire the email address of the user from the Smart Card. If an email address is not associated with the Smart Card, the printer searches the Network Address Book. If an email address is not found, the printer uses the email address specified in the From Field. Edit From Field settings on the Required Settings tab of the Email Setup page.
 - **Only Smart Card** instructs the printer to acquire the email address of the user from the Smart Card.
 - **Only Network Address Book (LDAP)** instructs the printer to search the Network Address Book to acquire the email address of the user.
3. To configure LDAP server settings, under Server Configuration, next to Network Address Book (LDAP), click **Edit**.
4. To enable or disable Personalization, under Feature Enablement, next to Acquire Email from Network Address Book, click **Enable Personalization** or **Disable Personalization**.
5. Click **Save**.

Configuring Authorization Settings

Setting the Authorization Method

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. To edit the User Permissions Method, for Touch and Web User Interfaces, click **Edit**.
4. For User Permissions Method, select an option.
5. Click **Save**.

Configuring Local Authorization Settings

When you configure local authorization, the printer references the user database for authorization information for the authenticated user.

To configure local authorization:

- Add user information to the user information database.
- Configure User Permissions.

The User Permissions page in Xerox® CentreWare® Internet Services provides links to authorization configuration settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.

Configuring Network Authorization Settings

When you configure network authorization, the printer references an authorization server for authorization information for the authenticated user.

To configure network authorization:

- Provide information about your authorization server and configure authorization server settings.
- Configure User Permissions.

The User Permissions page in Xerox® CentreWare® Internet Services provides links to authorization configuration settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.

Configuring Network Authorization Server Settings

1. On the User Permissions page, under Action, next to LDAP Server or SMB Server, click **Edit**.
2. If you are using an LDAP server for authorization, configure LDAP server settings as needed. For details, see [LDAP](#) on page 49.

Note: The printer uses the primary LDAP server for authentication, authorization, and personalization. The primary LDAP server is the server that appears at the top of the LDAP server list on the LDAP Server page in Xerox® CentreWare® Internet Services. If you already have configured LDAP server settings, the printer uses this server automatically when you select LDAP as the network authentication or authorization method. The printer only uses alternate LDAP servers for authorization and personalization when primary LDAP server communication fails.

3. If you are using an SMB server for authorization:
 - a. Under Configuration, type the Default Domain.
 - b. Select the address type.
 - c. Type the appropriately formatted IP address.
 - d. Under Login Credentials to Access SMB Server, select an option:
 - **None** does not require the printer to provide the server a user name or password.
 - **Logged-in User** instructs the printer to log in to the repository using the credentials of the logged-in user.
 - **System** uses the information provided in the Login Name and Password Fields to access the server.
 - e. If you select System, type the Login Name and Password used to access the server. Type the password, then type the password again to verify.
 - f. Enable **Select to save new password** to update the password for an existing Login Name.
 - g. Click **Save**.

User Permissions

You can control access to service and tools, and printing times and methods for a group of users.

You can set print permissions to:

- Restrict 1-sided printing, requiring users to print 2-sided.
- Restrict a Job Type, such as Secure Print.
- Restrict access to specific paper trays.
- Specify the software applications from which users are allowed to print.
- Restrict printing, and restrict 1-sided printing from specific software applications.

Services and Tools permissions are rules that allow you to control access to features or configuration settings for a group of users.

You can configure Services and Tools to:

- Restrict access to specific services, such as Copy, Email, or Fax.
- Restrict access to settings managed on the Tools menu at the control panel.
- Restrict access to settings managed on the Properties tab in Xerox® CentreWare® Internet Services.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

User Roles

A role is a set of permissions associated with a group of users. To edit permissions for a group of users, you edit permissions for a role.

There are two types of roles:

- The **Non-Logged-In Users Role** applies to any user who accesses the printer, but is not authenticated. This role also applies to anyone who sends a job that is not associated with a user name or job owner. Examples are a job sent using LPR, or a job sent from a mainframe application.
- **Logged-In Users Roles** are roles that you create. These roles apply to authenticated users only. You can assign specific users or user groups to the role, or you can create a role that applies to all authenticated users.

Editing Print Permissions for the Non-Logged-In Users Role

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. Under Action, next to User Permission Roles, click **Edit**.
4. Click the **Non-Logged-In Users** tab.
5. Under Actions, click **Edit**.
6. Click the **Print** tab.
7. To edit print permissions, next to a print setting that you want to restrict, click **Edit**.

Setting 1-Sided Print Permissions

1. On the 1-Sided Printing page, under Role State, select **Not Allowed** to require users to print 2-sided.
2. Click **Save**.

Setting Job Type Print Permissions

1. On the Job Types page, under Presets, select one of the following options:
 - **Allow all Job Types** allows users to print any job type.
 - **Only Allow Secure Print** ensures that users only send secure print jobs.
 - **Custom** allows you to select the job types that users are allowed to send.
2. If you selected Custom, under Role State, next to each job type, select **Not Allowed** to restrict users from using the job type.
3. Click the **Lock** icon to lock all job types or click the **Unlock** icon to unlock all job types.
4. Click **Save**.

Setting Paper Tray Print Permissions

1. To restrict users from using a paper tray, under Role State, next to the paper tray, select **Not Allowed**.
2. To lock all paper trays, click the Lock icon. To unlock all paper trays, click the Unlock icon.
3. Click **Apply**.

Setting Application Print Permissions

1. On the Applications page, click **Add New Application**.
2. From the Application List, select an application.
Note: To add an application to the list, submit a print job from that application to the printer.
3. To restrict users from using the printing method, for Role State, next to a permission type, select **Not Allowed**.
4. Click **Apply**.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Managing the List of Applications

Application Manager allows you to associate Application IDs with an Application Group. Application Group Names for common application types appear in the table at the bottom of the Application Manager page. The associated Application IDs appear next to each of the Application Group Names. An Application ID identifies the application from which the job was sent. To control print permissions for an application, the Application ID of the application must be associated with an Application Group Name. If you send a job from an application that is not in the default list, a new Application ID appears in the Custom Application ID list.

1. On the Applications page, click **Application Manager**.
2. To associate a custom Application ID with an existing Application Group, under Actions, click **Merge With**.
 - a. Under Merge With the Application Group, select an application from the menu.
 - b. Click **Save**.
3. To create a new Application Group, under Actions, click **Make This A Group**.
 - a. Under Application Group Name, type a name for the group.
 - b. Click **Save**.
4. To delete a custom Application ID, under Actions, click **Delete**.
5. To delete or disassociate a custom Application ID from an Application Group Name, under Actions, click **Manage** next to an Application Group Name.
 - a. Click **Un-Merge** to disassociate the Application ID, or click **Delete** to delete the Application ID.
 - b. Click **Close**.
6. To create a custom Application ID, click **Add Manually**.
 - a. Under Application ID, type an Application ID.
 - b. Click **Save**.
7. Click **Close** to return to the Applications page.

Editing Services and Tools Permissions for the Non-Logged-In Users Role

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. Under Action, next to User Permission Roles, click **Edit**.
4. Click the **Non-Logged-In Users** tab.
5. For Actions, click **Edit**.
6. Click the **Services and Tools** tab.
7. For Presets, select an option.
8. If you select Custom, under Role State, for each service or tool in the list, select **Allowed** or **Not Allowed**.
9. To hide a service icon on the printer touch screen, select **Not Allowed**.
10. Click **Apply**.

Creating a New Role

To edit permissions for a specific group of users, first create a role.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. For User Permission Roles, click **Edit**.
4. Click the **Logged-In Users** tab.
5. To create a new role, click **Make Your Own Permission Roles**.
6. For New Permission Profile, type a name and description for the role.
7. To configure access for users to services, click **View Quick Setup Options**, then select options.

Note: If you do not select an option, print permissions are set to Allowed. The default permissions for a new role are the same as the Non-Logged-In user role.

8. Click **Create**.
9. To assign users to the role, or to configure permissions for the role, click either the **Print** link or the **Services and Tools** link.
10. To save, click **Apply**.

Assigning Users to a Role for Local Authorization

Once you configure local authorization, add user information to the user database, and create a user-defined permission role, you can assign users to the role.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. For User Permission Roles, click **Edit**.
4. Click the **Logged-In Users** tab.
5. To add users to a user-defined permission role, for the desired role, click **Edit User Mappings**.
6. For Methods, select an option.
 - **Select Individual Users:** This option allows you to select the users that you want to assign to the role.
 - **All Logged-in Users:** This option assigns all users to the role. To remove individual users from this list, select **Exceptions**, then select the users to remove.
7. To create a user entry and add it to the role, click **Add New User**.
8. Click **Apply**.

Assigning User Groups to a Role for Network Authorization

Once you configure network authorization, you can assign LDAP or SMB groups of users to roles.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. Under Action, next to User Permission Roles, click **Edit**.
4. Click the **Logged-In Users** tab.
5. Next to a role, click **Edit User Mappings**.
6. Under Methods, select an option:
 - **Assign Groups** allows you to select the user groups that you want to assign to the role.
 - **All Logged-in Users** assigns all user groups to the role.

To select specific user groups to remove from the role, select **All Logged-in Users** and **Exceptions**. All other user groups are assigned to the role.

7. If you chose Select Individual Users, or Exceptions, select user groups.
 - a. If you know the name of the group you want to add, under Assign Groups, type the group name and click **Search for Groups**.

Note: If LDAP or SMB server settings are not configured, you cannot search for and add groups.
 - b. To add a group to the role, select the group from the list and click **Add**. To add all groups from the list to the role, click **Add All**.

Groups assigned to the role appear in the Users in Assigned Groups list.
 - c. To remove a group, select the group in the Users in Assigned Groups list and click **Remove**. To remove all groups from the list, click **Remove All**.
8. Click **Apply**.

Editing a Logged-In User Role

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. Under Action, next to User Permission Roles, click **Edit**.
4. Click the **Logged-In Users** tab.
5. Next to a role, click **Edit User Mappings**.

Note: You cannot edit permissions for the System Administrator or Accounting Administrator roles. Users assigned to the System Administrator role can access all features of the printer. Users assigned to the Accounting Administrator role can access accounting features only.

6. Assign users to the role, or to configure permissions for the role, click either the **Print** tab or **Services and Tools** tab.
7. To save, click **Apply**.

For details, see [Editing Print Permissions for the Non-Logged-In Users Role](#) on page 86 and [Editing Services and Tools Permissions for the Non-Logged-In Users Role](#) on page 88.

Note: For each user permission type, you cannot restrict access for logged-in users and allow access for non-logged-in users. To restrict access for non-logged-in users, next to a permission setting, click the **Auto Correct** link.

Specifying Job Override Policies

Job Override Policies determine what happens when a user without appropriate permissions sends a 1-sided print job to the printer.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. For Action, next to Job Override Policies, click **Edit**.
4. For 1-Sided Printing, select **Print Job 2-Sided**, or **Delete Job**. If an unauthorized user sends a 1-sided job, the job prints 2-sides or is deleted.
5. Click **Save**.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Troubleshooting Conflicting Permissions

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting**.
2. Click **User Permissions**.
3. Under Action, next to User Permission Roles, click **Edit**.
4. Click **Troubleshooting**.
5. To see a summary of permissions for a user, on the Permission Role Summaries tab, next to a user name click **Permissions Summary**.

Temporarily Disabling Print Permissions for all Users

1. On the Troubleshooting page, click the **Permission Enablement** tab.
2. To disable print restrictions for all users, next to Print, under Actions, select **Disable**.
3. Click **Apply**.

Secure HTTP (SSL)

To establish an HTTP Secure (HTTPS) connection to the printer, you can use SSL to encrypt data sent over HTTP. Features that require HTTPS use SSL automatically. You can also use SSL encryption for protocols such as LDAP and SMTP.

Notes:

- SSL encryption is protocol-independent. You can turn on SSL for protocols or scan destinations as needed.
- When the printer uses HTTPS, all pages in Xerox® CentreWare® Internet Services contain https:// in the URL.

Using SSL for all HTTP Communication

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Protocol, next to HTTP, click **Edit**.
3. Click the **HTTP** tab.
4. For Force Traffic over SSL, select **Yes**. Change the default port number as needed.
 - a. From the Choose Device Certificate menu, select the Device Certificate to use for SSL.
 - b. To view the selected certificate details, or to save the certificate to your computer, click **View/Save**.
 - c. If you are using the Xerox® Default Device Certificate, you can install the Generic Xerox® Trusted CA Certificate in your Web browser. Installing the Generic Xerox® Trusted CA Certificate ensures that your browser trusts the printer. To download the certificate, click **Download the Generic Xerox® Trusted CA Certificate**.
5. Click **Save**.

FIPS 140-2

If FIPS 140-2 encryption is required, all computers, servers, browser software, security certificates, and applications must comply with the standard or operate in FIPS-compliant mode. Transmitted and stored data must be encrypted as specified in United States Federal Information Processing Standard (FIPS) 140-2 (Level 1). You can enable the printer to check that the current configuration ensures the specified encryption.

Enabling FIPS 140 Mode can prevent the printer from communicating with network devices that communicate using protocols that do not use FIPS-compliant encryption algorithms. To allow non-FIPS compliant protocols or features when FIPS 140 mode is enabled, acknowledge the notification of non-compliance during the validation process.

When non-FIPS compliant protocols are enabled after FIPS mode is enabled, a message appears indicating the protocols use non-FIPS compliant encryption algorithms. Examples of non-FIPS compliant protocols include SNMPv3 or NetWare.

When you enable FIPS-140 mode, the printer validates the current configuration by performing the following checks:

- Validates certificates for features where the printer is the server in the client-server relationship. An SSL certificate for HTTPS is an example.
- Validates certificates for features where the printer is the client in the client-server relationship. CA certificates for LDAP, Xerox Extensible Interface Platform, and Smart eSolutions are examples.
- Validates certificates that are installed on the printer, but not used. Certificates for HTTPS, LDAP, or SNMPv3 are examples.
- Checks features and protocols for non-compliant encryption algorithms. For example, NetWare and SNMPv3 use encryption algorithms that are not FIPS-compliant.

When validation is complete, information and links appear in a table at the bottom of the page.

- Click the appropriate link to disable a non-compliant feature, or protocol.
- Click the appropriate link to replace any non-compliant certificates.
- Click the appropriate link to acknowledge that you allow the printer to use non-compliant features and protocols.

Enabling FIPS 140 Mode and Checking for Compliance

1. In Xerox® CentreWare® Internet Services, click **Properties > Security > Encryption**.
2. Click **FIPS 140-2**.
3. Click **Enable**.
4. Click **Run Configuration Check and Apply**.

A pass or fail message appears:

- If the configuration check passes, click **Reboot Machine** to save and restart the printer.
- If the configuration check fails, the reasons for the failed test list in a table at the bottom of the page. For each reason, a link is provided. Click the appropriate link to disable the protocol, replace the certificate, or allow the printer to use the non-compliant protocol.

Note: When FIPS 140 Mode is enabled, only FIPS-compliant certificates can be installed on the printer.

Stored Data Encryption

You can encrypt user data on the printer hard drive to prevent unauthorized access to data stored on the drive.

Enabling Encryption of Stored Data

1. In Xerox® CentreWare® Internet Services, click **Properties > Security > Encryption**.
2. Click **User Data Encryption**.
3. Under User Data Encryption Enablement select **Enabled**.
4. Click **Apply** to save the new settings or **Undo** to retain the previous settings.



CAUTION: The printer restarts. This interrupts or deletes current jobs. Xerox® recommends that you back up jobs and folders before enabling User Data Encryption.

IP Filtering

You can prevent unauthorized network access by creating an IP Filter to block or allow data sent from particular IP addresses.

Creating or Editing an IP Filter Rule

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **IP Filtering**.
3. Click **Add IP Filter**.
4. Under Define Protocol, select the protocol.
5. Under Action, select how you want the filter to manage the incoming packet:
 - If you want the printer to allow the packet access, select **Accept**.
 - If you want the printer to reject the packet and send an ICMP message back to the source host, select **Reject**.
 - If you want the printer to ignore the packet, select **Drop**.
6. Type the Source IP Address.
7. Type a number from 0 through 32 for the Source IP Mask that uses this rule. The range of 0–32 corresponds to the 32-bit binary number comprising IP addresses. For example:
 - The number 8 represents a Class A address with a mask of 255.0.0.0.
 - The number 16 represents a Class B address with a mask of 255.255.0.0.
 - The number 24 represents a Class C address with a mask of 255.255.255.0.
8. If you selected TCP or UDP, type the Destination Port the rule will manage. If the incoming packet is not sent to this port, the rule is ignored.
9. If you selected ICMP, type the ICMP Message Type that the rule is going to manage.
10. To specify the order that actions are performed, under Precedence Order, select an option.
Actions are performed in the order defined in the rule list. To arrange rule execution order, go to the IP Filtering page.
11. Click **Save**.

Editing an IP Filter Rule

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **IP Filtering**.
3. For to the IP filter rule you want to edit, click **Edit**.
4. Make the desired changes to the settings.
5. Click **Save**.

Arranging the Execution Order of IP Filter Rules

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **IP Filtering**.
3. Click an IP filter rule.
4. Next to Move Up/Down, click the appropriate arrow.

Audit Log

The Audit Log feature records events that occur on the printer. You can then download the log as a tab-delimited text file to review for potential problems or security issues.

Enabling Audit Log

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Audit Log**.
3. For Device Audit Log, click **Enabled**.
4. Click **Apply**.

Note: When McAfee is enabled, this option is unavailable.

Enabling Automatic Log Transfer

The system administrator can use Secure FTP to send the device audit log file to a server. You can transfer the audit log on demand or schedule it as a daily service.

Note: Secure FTP applies to IPv4 only.

To enable automatic log transfer:

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Audit Log**.
3. For Automatic Log Transfer, click **Enabled**.
4. For Schedule Automatic Log Transfer, click **Enabled**.
5. To establish an automatic daily log transfer time, enter a time in 24-hour format.
6. For Automatic Log Transfer Server, select an option, then enter the repository server IP address or name.
7. For Path, enter the complete path name.
8. For Login Name, enter the login credentials.
9. For Password, enter then reenter the password credentials.
10. Click **Apply**.

Enabling Protocol Logs

Protocol logs provide information about connection-specific secure protocols, such as HTTPS, IPsec, SSH, and TLS. Each enabled protocol generates a unique protocol log that is populated with information. If a protocol is not enabled, the corresponding protocol log still appears but is not populated with information. Protocol log functionality complies with Common Criteria requirements.

Note: If you enable or disable the protocol log feature, reboot the device.

To enable protocol logs:

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Audit Log**.
3. For Protocol Log, click **Enabled**.

Note: The protocol logs download in a .zip file archive that contains either one or five text files. If the protocol log feature is enabled, the protocol log .zip file archive contains five text files. The .zip file name format appears as **serialnumber_year-month-date-timezone_offset-time_auditfile.zip**.

Saving an Audit Log

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Audit Log**.
3. Click **Export Audit Log**.
4. Right-click the **Download Log** link, then save the compressed **auditfile.txt.gz** file to your computer.
5. Extract the **Auditfile.txt** file, then open it in a spreadsheet application that can read a tab-delimited text file.

Saving an Audit Log to a USB Flash Drive

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Security Settings > Audit Log**.
3. Touch **Download Log**.
4. Insert your USB Flash drive into the front USB port. The log file downloads automatically.
5. When the download completes, click **Close**.

Interpreting the Audit Log

The Audit Log is formatted into ten columns:

- **Index:** Column 1 lists a unique value that identifies the event.
- **Date:** Column 2 lists the date that the event happened in mm/dd/yy format.
- **Time:** Column 3 lists the time that the event happened in hh:mm:ss format.
- **Event ID:** Column 4 lists the type of event. The number corresponds to a unique description.
- **Event Description:** Column 5 lists an abbreviated description of the type of event.

Notes:

- One audit log entry is recorded for each network destination within a Workflow Scanning scan job.
- For server fax jobs, one audit log entry is recorded for each server fax job, regardless of the number of destinations.
- For LAN fax jobs, one audit log entry is recorded for each LAN fax job.
- For email jobs, one audit log entry is recorded for each SMTP recipient within the job.
- **Other Event Details:** Columns 6–10 list other information about the event, such as:
 - **Identity:** User Name, Job Name, Computer Name, Printer Name, Folder Name, or Accounting Account ID display when Network Accounting is enabled.

Note: Authentication must be configured to record the user name in the Audit Log.

- **Completion Status**
- **Image Overwrite Status:** The status of overwrites completed on each job. Immediate Image must be enabled.

See also:

[Audit Log Event Identification Numbers](#) on page 272

Installation Policies

For additional security, you can restrict installation or upgrades.

Note: To enable software upgrades and installation of files, log in as a system administrator.

To manage installation policies:

1. In Xerox® CentreWare® Internet Services, click **Properties > Security > Installation Policies**.
2. To allow users to modify a feature, select the feature.
3. Click **Apply**, then click **OK**.
4. To view details about the feature, click **Take me there**.
5. To view details on sending multiple configuration files, click **Fleet Management Tips**, then click **OK**.

McAfee Embedded Control

McAfee Embedded Control consists of two security features:

- Enhanced Security maintains the integrity of printer software by monitoring system files and alerting you if an unauthorized change is made to a system file.
- Integrity Control is a software option that combines enhanced security features with the ability to monitor and prevent unauthorized executable files from running. Enable this option by providing a feature installation key on the Feature Installation page. To get a feature installation key, contact your Xerox representative.

You can configure the printer to send email alerts when a security event occurs. Email alerts can be sent to you or to a centralized management application such as McAfee ePolicy Orchestrator (McAfee ePO), Xerox® CentreWare® Web, or Xerox® Device Manager. For details about McAfee ePO and McAfee Embedded Control, visit www.mcafee.com.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

To configure McAfee Embedded Control:

- Set the security level and configure alert options as needed. Xerox recommends that you keep the security level set to the default setting, Enhanced Security.
- Configure email alerts. For details, see [Email Alerts](#) on page 228.
- If you are managing your printers using McAfee ePO, provide information about your McAfee ePO server.
- Download an audit log as needed. To download and review security events recorded in the audit log, under Action, next to Export Audit Log, click **Export**.
- To test your alert configuration by generating a test security event, click **Test Feedback Methods**.

After you set the security level and configure alert options, the McAfee Embedded Control page in Xerox® CentreWare® Internet Services provides links to related configuration settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **McAfee Embedded Control**.

Setting the Security Level

Unless you have acquired McAfee Integrity Control, Xerox recommends that you keep the security level set to the default setting, Enhanced Security.

McAfee Embedded Control has three security levels:

- Enhanced Security
- Integrity Control
- Disabled

Note: Only set the security level if necessary. The printer comes standard with an Enhanced Security level, which is adequate in many cases.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **McAfee Embedded Control**.
3. To enable McAfee Embedded Control features, and configure Alert Feedback options, click **Edit**.
4. To set the Security Level, under Security Level, select **Enhanced Security** or **Integrity Control**. To turn off McAfee Embedded Control security features, select **Disable McAfee Embedded Control**. Xerox recommends that you do not disable this feature.
5. If you selected Enhanced Security as the security level, click **Save**.
6. If you selected Integrity Control as the security level, click **Next**, enter the software feature installation key, then click **Apply**.

Note: When you change the security level setting, the printer restarts. The process takes several minutes.

Setting the Alert Options

You can configure the printer to alert you when a security event occurs.

To set the alert options:

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **McAfee Embedded Control**.
3. To configure Alert Feedback options, click **Edit**.
4. To configure the printer to send email alerts:
 - a. Under Locally on the Device, click **Email Alerts**, then **Save**.
 - b. Next to E-mail Alerts, under Action, click **Edit**.
 - c. Under Recipient Group Addresses, enter valid email addresses for each applicable group 1, 2, or 3.
 - d. For each group with email addresses, select **Enable Group**.
 - e. Under Recipient Group Preferences, for McAfee Embedded Control, select each group that you want to receive alerts: **Group 1**, **Group 2** and **Group 3**.
 - f. Click **Apply**.
 - g. At the prompt, click **OK**.
5. Configure your alert feedback method.
 - To configure the printer to send alerts to McAfee ePolicy Orchestrator Server, under McAfee Remote Solutions, select **McAfee's ePolicy Orchestrator Server**.
 - If you use Xerox® CentreWare® Web to manage your printers, configure security alerts in Xerox® CentreWare® Web.
 - If Xerox manages your printers, use Xerox® Device Manager to send security alerts from registered printers.

Note: When McAfee Embedded Control features are enabled, the printer also records security events in the audit log.

IPsec

Internet Protocol Security (IPsec) is a group of protocols used to secure Internet Protocol (IP) communications by authenticating and encrypting each IP data packet. It allows you to control IP communication by creating protocol groups, policies, and actions.

You can control IP communication on the printer for the following:

- DHCP v4/v6 (TCP and UDP)
- DNS (TCP and UDP)
- FTP (TCP)
- HTTP (Scan Out, TCP port 80)
- HTTPS (Scan Out, TCP port 443)
- HTTPS (Web Server, TCP port 443)
- ICMP v4/v6
- IPP (TCP port 631)
- LPR Print (TCP port 515)
- Port 9100 Print (TCP port 9100)
- SMTP (TCP/UDP port 25)
- SNMP (TCP/UDP port 161)
- SNMP Traps (TCP/UDP port 162)
- WS-Discovery (UDP port 3702)
- Up to 10 additional services

Enabling IPsec

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **IPsec**.
3. Under Enablement, select **Enabled**.
4. Click **Apply** to save the new settings or **Undo** to retain the previous settings.

Disabling IPsec at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Security Settings > IPsec**.
3. Touch **Disable IPsec**.

Note: IPsec can be enabled in Xerox® CentreWare® Internet Services only.

Managing Actions

Use actions to more specifically manage how IPsec controls dependent protocols.

Managing Protocol Groups

Protocol Groups are logical groupings of selected protocols based on service type, service name, port number, and device type. Create a Protocol Group to apply specific security policies for selected protocols.

Creating a New Protocol Group

1. Click **Protocol Groups** at the top of the IPsec page.
2. Click **Add New Protocol Group**.
3. Type a Name and a Description for the group.
4. Under Service Name, select the protocols that you want to add to the group.
5. To control a service that is not listed, under Custom Protocols type a name for the service and select the check box under Service Name.
6. To control a service that is not listed, under Custom Protocols type a name for the service and select the check box under Service Name.
7. Select **TCP** or **UDP** from the Protocol list.
8. Type the port number, and specify if the printer is the server or client.
9. Click **Save** to apply the new settings or **Undo** to retain the previous settings. Click **Cancel** to return to the previous page.

Editing or Deleting a Protocol Group

To edit or delete a protocol group, select the protocol group from the list, and click **Edit** or **Delete**.

Creating a New Action

1. Click **Actions** at the top of the IPsec page.
2. Click **Add New Action**.
3. On the Step 1 of 2 page, under IP Action Details, type in the Name. This field is required.
4. In the Description field, type a description for the action, if desired.
5. Under Keying Method, select **Manual Keying** or **Internet Key Exchange (IKE)**.
Note: Select Manual Keying if client devices are not configured for or do not support IKE.
6. If you selected IKE, under Pre-shared Key Passphrase, type the passphrase, then click **Next**.

Configuring Manual Keying Settings

Manual Keying is used when client systems either do not support IKE or are not configured for IKE.

1. For IPsec Mode, select **Transport Mode** or **Tunnel Mode**.
Transport mode only encrypts the IP payload, whereas Tunnel mode encrypts the IP header and the IP payload. Tunnel mode provides protection for an entire IP packet by treating it as an Authentication Header (AH), or Encapsulating Security Payload (ESP).
2. If you selected Tunnel Mode, under Enable Security End Point Address, select the address type. Options are **Disabled**, **IPv4 Address**, or **IPv6 Address**.
3. Under IPsec Security, select **ESP**, **AH**, or **BOTH**.
4. In the Security Parameter Index: IN field, type a 32-bit number larger than 256 that identifies the inbound Security Association (SA).
5. In the Security Parameter Index: OUT field, type a 32-bit number larger than 256 that identifies the outbound Security Association (SA).
6. If you selected ESP under IPsec security, under Hash, select an option.
7. Under Enter Keys as, select **ASCII format** or **Hexadecimal number**.
8. For Hash Key: IN and Hash Key: OUT, type a 20-character ASCII key or 40-character Hexadecimal key.
9. If you selected ESP or BOTH for the IPsec Security type, under Encryption, select an option.
Note: If you are configuring an IPsec security policy to communicate with a Linux computer, and you selected BOTH for the security type, select 3DES encryption. If you select AES encryption, the data transfer rate is reduced.
10. For Encryption Key: IN and Encryption Key: OUT, type a 24-character ASCII key or 48-character Hexadecimal key.
11. Click **Save**.

Configuring Internet Key Exchange Settings

IKE is a keying protocol that allows automatic negotiation and authentication, anti-replay services, and CA support. It can also change encryption keys during an IPsec session. IKE is used as part of virtual private networking.

IKE Phase 1 authenticates the IPsec peers and sets up a secure channel between the peers to enable IKE exchanges. IKE Phase 2 negotiates IPsec SAs to set up the IPsec tunnel.

1. Under IKE Phase 1, in the Key Lifetime field, type the length of time until the key expires in **Seconds**, **Minutes**, or **Hours**. When a key reaches this lifetime, the SA is renegotiated and the key is regenerated or refreshed.
2. Select the DH Group from the following options:
 - **Group 2** provides a 1024-bit Modular Exponential (MODP) keying strength.
 - **Group 14** provides a 2048-bit MODP keying strength.
3. Under IKE Phase 2, select the IPsec Mode. Options are **Transport Mode** or **Tunnel Mode**.

Note: Transport mode only encrypts the IP payload, whereas Tunnel mode encrypts the IP header and the IP payload. Tunnel mode provides protection for an entire IP packet by treating it as an Authentication Header (AH), or Encapsulating Security Payload (ESP).

4. If you selected Tunnel Mode, under Enable Security End Point Address, select the address type. Options are **Disabled**, **IPv4 Address**, or **IPv6 Address**.
5. Under IPsec Security, select **ESP**, **AH**, or **BOTH**.
6. Type the Key Lifetime, and select **Seconds**, **Minutes**, or **Hours**.
7. Under Perfect Forward Secrecy (PFS), select **None**, **Group 2**, or **Group 14**.

Note: PFS is disabled by default. PFS allows faster IPsec setup, but is less secure.

8. Under Hash, select from the following:
 - **SHA1**
 - **None**
9. If you selected ESP or BOTH for the IPsec Security type, select one or more of the following Encryption types:

Note: If the IPsec Security type is set to AH, the Encryption type options do not appear.

- **AES**
 - **3DES**
 - **Null**
10. Click **Save** to apply the new settings or **Undo** to retain the previous settings.

Editing or Deleting an Action

To edit or delete an action, select the action from the list, then click **Edit** or **Delete**.

Managing Host Groups

Host groups are groupings of computers, servers, or other devices that you want to control using security policies.

Creating a New Host Group

1. Click **Host Groups** at the top of the IPsec page.
2. Click **Add New Host Group**.
3. Type a Name and a Description for the group.
4. Under Address List, select **IPv4** or **IPv6**.
5. Select an Address Type. Options are **Specific**, **All**, or **Subnet**.
6. Type the appropriately formatted IP address.
7. To continue to add addresses to the group, click **Add**.
8. To delete addresses, next to any address, click **Delete**.
9. Click **Save** to apply the new settings or **Undo** to retain the previous settings.

Editing or Deleting a Host Group

To edit or delete a host group, select the host group from the list, and click **Edit** or **Delete**.

Managing Security Policies

IPsec security policies are sets of conditions, configuration options, and security settings that enable two systems to agree on how to secure traffic between them. You can have multiple policies active at the same time, however, the scope and policy list order determines the overall policy behavior.

Defining a Security Policy

1. Click **Security Policies** at the top of the IPsec page.
2. Under Define Policy, select a Host Group from the menu.
3. Select a Protocol Group from the menu.
4. Select an Action from the menu.
5. Click **Add Policy**.

Prioritizing a Security Policy

To prioritize policies, under Saved Policies, select the policy you want to move, then click the **Promote** or **Demote** buttons.

Editing or Deleting a Security Policy

To delete a policy, under Saved Policies, select the policy and click **Delete**.

Security Certificates

A digital certificate is a file that contains data used to verify the identity of the client or server in a network transaction. A certificate also contains a public key used to create and verify digital signatures. One device proves its identity to another by presenting a certificate trusted by the other device. Or, the device can present a certificate signed by a trusted third party and a digital signature proving its ownership of the certificate.

A digital certificate includes the following data:

- Information about the owner of the certificate
- The certificate serial number and expiration date
- The name and digital signature of the certificate authority (CA) that issued the certificate
- A public key
- A purpose defining how the certificate and public key can be used

There are three types of certificates:

- A Device Certificate is a certificate for which the printer has a private key. The purpose specified in the certificate allows it to be used to prove identity.
- A CA Certificate is a certificate with authority to sign other certificates.
- A Trusted Certificate is a self-signed certificate from another device that you want to trust.

Installing Certificates

To ensure that the printer can communicate with other devices over a secure trusted connection, both devices must have specific certificates installed.

For protocols such as HTTPS, the printer is the server, and must prove its identity to the client Web browser. For protocols such as 802.1X, the printer is the client, and must prove its identity to the authentication server, typically a RADIUS server.

For features that use these protocols, perform the following tasks:

- Install a device certificate on the printer.
Note: When the printer uses HTTPS, a Xerox® Device Certificate is created and installed on the printer automatically.
- Install a copy of the CA certificate that was used to sign the device certificate of the printer on the other device.

Protocols such as LDAP and IPsec require both devices to prove their identity to each other.

For features that use these protocols, perform the tasks listed under one of the following options:

To install certificates, option 1:

- Install a device certificate on the printer.
- Install a copy of the CA certificate that was used to sign the device certificate of the printer on the other device.
- Install a copy of the CA certificate that was used to sign the certificate of the other device on the printer.

To install certificates, option 2:

If the other device is using a self-signed certificate, install a copy of the trusted certificate of the other device on the printer.

Creating and Installing a Xerox® Device Certificate

If you do not have a server functioning as a certificate authority, install a Xerox® Device Certificate on the printer. When you create a Xerox® Device Certificate the printer generates a certificate, signs it, and creates a public key used in SSL encryption. After you install a Xerox® Device Certificate on the printer, install the Generic Xerox® Trusted CA Certificate in any device that communicates with the printer. Examples of other devices include client Web browsers for HTTPS or a RADIUS authentication server for 802.1X. Installing the Generic Xerox® Trusted CA Certificate ensures that users can access the printer using Xerox® CentreWare® Internet Services, and certificate warning messages do not appear.

Note: Creating a Xerox® Device Certificate is less secure than creating a certificate signed by a trusted certificate authority.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Certificates**.
3. Click **Security Certificates**.
4. Click the **Xerox Device Certificate** tab.
5. Select **Create New Xerox Device Certificate**.
6. Complete the form with the requested information.
7. Click **Finish**.

Installing the Generic Xerox® Trusted CA Certificate

If the printer uses the Xerox® Device Certificate, and a user attempts to access the printer using Xerox® CentreWare® Internet Services, an error message can appear in their Web browser. To ensure that error messages do not appear, install the Generic Xerox® Trusted CA Certificate in the Web browsers of all users.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Certificates**.
3. Click **Security Certificates**.
4. To save the file to your computer, click **Download the Generic Xerox Trusted CA Certificate**.
5. Install the file in your Web browser certificate store location. For details, see your Web browser help.

Note: You can also download the Generic Xerox® Trusted CA Certificate from the HTTP page at **Properties > Connectivity > Protocols > HTTP**.

Creating a Certificate Signing Request

If you do not install a Xerox Device Certificate, you can install a CA-signed device certificate. Create a Certificate Signing Request (CSR), and send it to a CA or a local server functioning as a CA to sign the CSR. An example of a server functioning as a certificate authority is Windows Server 2008 running Certificate Services. When the CA returns the signed certificate, install it on the printer.

Creating a Certificate Signing Request

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Certificates**.
3. Click **Security Certificates**.
4. Click the **CA-Signed Device Certificate(s)** tab.
5. Select **Create Certificate Signing Request (CSR)**.
6. Complete the form with your 2-Letter Country Code, State/Province Name, Locality Name, Organization Name, Organization Unit, and Email Address.
7. Select **Subject Alternative Name** if applicable, and type the MS Universal Principal Name.

Note: The Subject Alternative Name is only required when using 802.1X EAP -TLS for Windows clients or servers.

8. Click **Finish**.

Uploading a CA-Signed Device Certificate

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Certificates**.
3. Click **Security Certificates**.
4. Click the **CA-Signed Device Certificate(s)** tab.
5. Select **Install Certificate**.
6. Click **Browse** or **Choose File**, then navigate to the signed certificate in **.pem** or **PKCS#12** format.
7. Click **Open** or **Choose**.
8. Click **Next**.
9. If the certificate is password protected, type the password, then retype it to verify.
10. To help identify the certificate in the future, type a **Friendly Name**.
11. Click **Next**.

Note: The signed certificate can meet either one of the following requirements. The signed certificate can match a pending CSR created by the printer. The signed certificate can be a PKCS#12 certificate generated by a Certificate Authority.

Installing Root Certificates

You can install the certificates for the root certificate authority and any intermediate certificate authorities for your company. You can install the self-signed certificates from any other devices on your network.

Supported certificate encodings and typical file extensions include:

- Distinguished Encoding Rules (.cer, .crt, .der)
- Privacy Enhanced Mode/Base64 (.pem)
- PKCS#7 (.p7b)
- PKCS#12 (.pfx, .p12)

Note: To import a CA-Signed Device Certificate, use the PKCS#12 format.

To install a root certificate:

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Certificates**.
3. Click **Security Certificates**.
4. Click the **Root/Intermediate Trusted Certificate(s)** tab.
5. Click **Install Certificate**.
6. Click **Browse** or **Choose File**, then navigate to a signed certificate file.
7. Click **Open** or **Choose**.
8. Click **Next**.
9. To help identify the certificate in the future, type a **Friendly Name**.
10. Click **Next**.

The digital certificate appears in the list of Installed certificates.

Installing Domain Controller Certificates

You can install the self-signed certificates from any domain controllers on your network.

Supported certificate encodings and typical file extensions include:

- Distinguished Encoding Rules (.cer, .crt, .der)
- Privacy Enhanced Mode/Base64 (.pem)
- PKCS#7 (.p7b)
- PKCS#12 (.pfx, .p12)

Note: To import a CA-Signed Device Certificate, use the PKCS#12 format.

To install a domain controller certificate:

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Certificates**.
3. Click **Security Certificates**.
4. Click the **Domain Controller Certificate(s)** tab.
5. Click **Install Certificate**.
6. Click **Browse** or **Choose File**, then navigate to a signed certificate file.
7. Click **Open** or **Choose**.
8. Click **Next**.
9. To help identify the certificate in the future, type a **Friendly Name**.
10. Click **Next**.

The digital certificate appears in the list of Installed certificates.

Viewing, Saving, or Deleting a Certificate

1. On the Security Certificates page, click a certificate type tab.
2. To view or save a certificate, for Action, click **View/Export**.
Certificate details appear on the View/Save Certificate page.
 - a. To save the certificate file to your computer, click **Export (Base-64 encoded-PEM)**.
 - b. To return to the Security Certificates page, click **Close**.
3. To delete a certificate, next to the certificate name, select the check box, then click **Delete Selected**.

Note: You cannot delete the Default Xerox Device Certificate.

4. To delete all certificates except for the Default Xerox® Device Certificate, click **Reset to Machine/Device Factory Defaults**.

Specifying the Minimum Certificate Key Length

You can specify the minimum encryption key length required for certificates. If a user attempts to upload a certificate that contains a key that does not meet this requirement, a message appears. The message alerts the user that the certificate they are attempting to upload does not meet the key length requirement.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Certificates > Certificate Key Length**.
3. Under Minimum Encryption Key Length, select **1024-bit minimum**, **2048-bit minimum**, or **No Minimum**.
4. Click **Apply**.

802.1X

802.1X is an Institute for Electrical and Electronics Engineers (IEEE) standard that defines a method for port-based network access control or authentication. In an 802.1X secured network, the printer must be authenticated by a central authority, typically a RADIUS server, before it can access the physical network.

You can enable and configure the printer to be used in an 802.1X secured network from the printer control panel or in Xerox® CentreWare® Internet Services.

Before you begin:

- Ensure that your 802.1X authentication server and authentication switch are available on the network.
- Determine the supported authentication method.
- Create a user name and password on your authentication server.

Note: This procedure causes the printer to restart and be unavailable over the network for several minutes.

Enabling and Configuring 802.1X in Xerox® CentreWare® Internet Services

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. Under Network, next to Wired Connection, click **Edit**.
3. To configure 802.1X settings, next to 802.1X, click **Edit**.
4. Under Protocol, select **Enable 802.1X**.
5. Under Authentication Method, select the method used on your network.

Note: When the printer is in FIPS 140 mode, EAP-TLS authentication is required.

6. Under Server Validation - Validate server using, select the root certificate that you want to use to validate the authentication server. If you do not want to validate a certificate, select **No Validation**.

Notes:

- You can require the printer to validate certificates used to encrypt 802.1X only if you selected PEAPv0/EAP-MS-CHAPv2 or EAP-TLS as the authentication method.
- TLS authentication and server verification both require X.509 certificates. To use these features, install the necessary certificates on the Security Certificates page before configuring 802.1X.
- The Default Xerox® Device Certificate cannot be used with EAP-TLS in Windows environments. It can be used in FreeRADIUS server environments.

7. To view or save a certificate, select the certificate from the menu, then click **View/Save**.
Certificate details appear on the View/Save Device Certificate page.
 - a. To save the certificate file to your computer, at the bottom of the page, click **Export (Base-64 encoded - PEM)**.
 - b. Click **Close** to return to the previous page.
8. If you selected EAP-TLS as the authentication method, you can allow the printer to encrypt 802.1X communication. Under Device Certificate (TLS) - Authentication Certificate, select the certificate that you want to use.
9. To view or save a certificate, select the certificate from the menu, then click **View/Save**.
Certificate details appear on the View/Save Device Certificate page.
 - a. To save the certificate file to your computer, at the bottom of the page, click **Export (Base-64 encoded - PEM)**.
 - b. Click **Close** to return to the previous page.
10. Under User Name, type the user name for the authentication switch and server.
11. Under Password, type and confirm a password.
12. To save the new password, click **Select to save new password**. A password is not required for EAP-TLS authentication.
13. Click **Save**.

Enabling and Configuring 802.1X at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Network Settings > Advanced Settings**.
3. Touch **802.1X**.
4. Touch **Enabled**.
5. To select the authentication method used on your network, click the menu.

Notes:

- When the printer is in FIPS 140 mode, EAP-TLS authentication is required.
 - To configure 802.1X settings for EAP-TLS, use Xerox® CentreWare® Internet Services.
6. Touch **Username**.
 7. To type the user name and server that your authentication switch requires, use the touch screen keyboard. Touch **OK**.
 8. Touch **Password**, then to type the password, use the touch screen keyboard. Touch **OK**.
 9. Touch **Finish**.

System Timeout

You can specify how long the printer waits to log out an inactive user.

Setting System Timeout Values

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **System Timeout**.
3. For Touch User Interface System Timeout, type the time that the printer waits before it logs a user out of the touch screen.
4. To select the Web User Interface System Timeout settings, for Days, Hours, and Minutes, type a value or use the arrows to select a value.
5. To configure the printer to display a warning message before it logs a user out of the touch screen, for Enable Warning Screen, select the check box.
6. Click **Apply**.

Setting the System Timeout Values at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > Timers > System Timeout**.
3. To specify the time the printer waits to log out an inactive user at the control panel, for Timeout (Mins) and Timeout (Secs), touch the arrows, then select values.
4. To instruct the printer to display a warning message before it logs a user out of the touch screen, under Warning Screen, touch **Enabled**.
5. Touch **OK**.

Overwriting Image Data

Image data is any in-process or temporary user data on the hard drive, such as current jobs, queued jobs, temporary files, saved jobs, and saved folders. To ensure that image data on the printer hard drive cannot be accessed, you can delete and overwrite image data.

Standard Image Overwrite deletes all image data from the printer memory and hard drive, except:

- Jobs and folders stored in the Reprint Saved Jobs feature
- Jobs stored in the Scan to Mailbox feature
- Fax Dial Directories
- Fax Mailbox contents

Note: Standard image overwrite takes approximately 20 minutes to complete.

Full Image Overwrite deletes all image data from the printer memory and hard drive, including:

- Jobs and folders stored in the Reprint Saved Jobs feature
- Jobs stored in the Scan to Mailbox feature
- Fax Dial Directories
- Fax Mailbox contents

Note: Full image overwrite takes approximately 60 minutes to complete.

Immediate Job Overwrite prompts the printer to overwrite each job immediately after it finishes processing.

Manually Deleting Image Data

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Image Overwrite Security**.
3. Click the **Disk Overwrite** tab.
4. Click **Overwrite Now**.
5. To print a confirmation report after the printer overwrites data, for Confirmation Report, select **On**. To print a report only if an error occurs, select **Errors only**.
6. To start a Standard disk overwrite:
 - a. Click **Start Disk Overwrite Now**.
 - b. Click **OK** to acknowledge the warning message.

Note: Standard image overwrite takes approximately 20 minutes to complete.

7. To start a Full disk overwrite:
 - a. Click **Advanced Settings**.
 - b. Select **Full**.
 - c. Click **Start Disk Overwrite Now**.
 - d. Click **OK** to acknowledge the warning message.

Note: Full image overwrite takes approximately 60 minutes to complete.

Manually Deleting Image Data at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Security Settings > Image Overwrite Security**.
3. Touch **Disk Overwrite Now**.
4. To change the overwrite mode, touch **Overwrite Mode**, then touch an option.
5. To set the printer to print a confirmation report after it overwrites data, touch **Confirmation Report**, then select an option.
6. Touch **Overwrite Now**.

Note: If the number of files to delete is large, the printer can be offline for up to 60 minutes during the deletion process.

7. To acknowledge the message and start the process, touch **Overwrite Now**.

Scheduling Routine Deletion of Image Data

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Image Overwrite Security**.
3. Click the **Disk Overwrite** tab.
4. Click the **Scheduled** tab.
5. On the Scheduled tab, select **Enabled**.
6. Under Frequency, select how often the printer overwrites data.
7. To set the time when the printer overwrites data, under Time, type the hour and minute, and select **AM** or **PM**.
8. If you selected Weekly for Frequency, under Day of the Week, select the day when the printer overwrites data. If you selected Monthly for Frequency, under Day of the Month, select the date when the printer overwrites data.
9. To print a confirmation report after the printer overwrites data, under Confirmation Report for Schedule Overwrites, select **On**. To print a report only if an error occurs, select **Errors only**.
10. Under Overwrite Mode, select an option:
 - **Standard** Image Overwrite deletes all image data from the printer memory and hard drive, except:
 - Jobs and folders stored in the Reprint Saved Jobs feature
 - Jobs stored in the Scan to Mailbox feature
 - Fax Dial Directories
 - Fax Mailbox contents
 - **Full** Image Overwrite deletes all image data from the printer memory and hard drive.
11. Click **Apply**.

Scheduling Routine Deletion of Image Data at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Security Settings > Image Overwrite Security**.
3. Touch **Disk Overwrite**.
4. To specify how often the printer overwrites data, touch **Never**, **Daily**, **Weekly**, or **Monthly**.
5. Touch **Day of Month**, **Day of Week**, or **Overwrite Time**, then touch the arrows.
6. To change the overwrite mode, touch **Overwrite Mode**, then touch an option.
7. To set the printer to print a confirmation report after it overwrites data, touch **Confirmation Report**, then select an option.
8. Touch **OK**.

Immediate Job Overwrite

Immediate Job Overwrite prompts the printer to overwrite each job immediately after it finishes processing.

Enabling Immediate Image Overwrite

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Image Overwrite Security**.
3. Click the **Immediate Image Overwrite** tab.
4. On the Immediate Image Overwrite tab, under Enablement, select **Enabled**.
5. Click **Apply**.

Enabling Immediate Image Overwrite at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Security Settings > Image Overwrite Security**.
3. Touch **Job Overwrite**.
4. Touch **Enable**.
5. Touch **OK**.

PostScript Passwords

The PostScript language includes commands that allow PostScript print jobs to change the printer configuration. By default, PostScript jobs can use these commands, and a password is not required. To ensure that unauthorized changes are not made, you can require PostScript jobs to include a password.

You can enable the following passwords:

- **Run Start Job:** This password controls the execution of the Sys/Start file.
- **System Parameters Password:** This password controls the execution of PostScript programs that modify PostScript system parameters.
- **Start Job Password:** This password is used with the Startjob and Exitserver operators to restrict PostScript jobs from running unencapsulated. This prevents unencapsulated jobs from changing default printer settings.

For details, see the Help in Xerox® CentreWare® Internet Services.

Enabling or Creating PostScript Passwords

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **PostScript Passwords**.
3. For Startup Mode, to enable the Run Start job password, select **Enabled**.
4. For System Parameters Password, type a password.
5. Retype the password to verify.
6. For Job Start Password, type a password.
7. Retype the password to verify.
8. Click **Apply**.

USB Port Security

You can prevent unauthorized access to the printer through USB ports by disabling the ports.

Enabling or Disabling USB Ports

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **USB Port Security**.
3. To enable a USB port, next to a port, select **Enabled**. To disable the ports, clear the check box.
4. Click **Apply**.

Notes:

- If USB ports are disabled, you cannot use a USB card reader for authentication, update the software, or print from a USB Flash drive.
- If your printer model has a cover for the USB port on the control panel, you can install or remove the cover. You can find the installation instructions and the necessary part in the compartment inside of Tray 1.
- Only Type A ports can be enabled or disabled. These settings do not affect Type B ports.

Enabling or Disabling all USB Ports at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Security Settings > USB Port Security**.
3. To enable or disable the USB ports, touch **Enabled** or **Disabled**.
4. Touch **OK**.

Displaying or Hiding Network Settings

You can show or hide the IPv4 address or host name of the printer on the control panel touch screen.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Display Network Settings**.
3. Select **Show IPv4 Address** or **Show Host Name**. To hide network information, select **Hide Network Information**.
4. Click **Apply**.

Hiding User Names on the Control Panel

You can hide the user name for the logged in user to prevent it from displaying on the control panel.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security > Certificates**.
2. Click **Hide User Name**.
3. To hide the user name, for Hide User Name, click **Yes**.
4. Click **Apply**.

Verifying the Software

You can test the printer software to confirm that it is operating correctly. The test checks software files to confirm that they are not corrupt. If the printer software appears to be functioning improperly, a Xerox representative can ask you to perform this test.

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Click **Software Verification Test**.
3. To begin the test, click **Start test**.
4. To interrupt and cancel the test, click **Cancel**.

Notes:

- You can continue to use the printer while the test is running.
- If the test fails, software files are corrupt. Xerox recommends that you reinstall the software. Contact a Xerox representative for help.

Restricting Print File Software Updates

You can restrict users from installing optional software features by sending a print file. This option restricts users from updating the software.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Feature Installation**.
3. To restrict users from installing features using the **.csv** file print method, under Allow Print File Updates, select **Disable**.
4. Click **Apply**.

Specifying Email and Internet Fax Recipient Restrictions

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Security Settings > Valid Recipients**.
3. To allow users to send an email or Internet fax to addresses in the address book only, touch **Limit to Address Book Entries**.
4. Touch **Save**.

Disabling the System Administrator Password Reset

1. In Xerox® CentreWare® Internet Services, click **Properties > Security**.
2. Under Password Policies, click **Admin Password**.
3. Click the **Reset Policy** tab.
4. Under Password Reset Policy, click **Disable Password Reset**.
5. Click **Apply**.



CAUTION: If you disable the password reset feature, and forget the administrator password, you must schedule and pay for a Xerox representative to visit your company and reset the password.

Printing

5

This chapter includes:

• Paper Management	132
• Saving and Reprinting Jobs	134
• Printing Jobs from Xerox® CentreWare® Internet Services	137
• Configuring General Print Settings	138
• Printing an Error Sheet	139
• Managing Banner Page Printing Options	140
• Configuring Secure Print Settings	142
• Hold All Jobs	143
• UNIX, Linux, and AS/400 Printing	144
• Print from USB	147
• Print from Mailbox.....	148
• AirPrint.....	149
• Mopria	150
• Allowing Users to Interrupt Active Print Jobs.....	151
• Specifying Output Settings	152

Paper Management

Setting Default Paper Type and Color

You can specify the default settings for paper type and color.

Note: After you set the initial default settings, changes made on this tab do not affect the paper type and color.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup > Paper Management**.
2. Under Paper Type and Paper Color, select the default paper type and color.
3. Click **Apply**.

Enabling Required Paper Policies

You can enable or disable the nearest match and paper size replacement.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup > Paper Management**.
2. Click the **Required Paper Policies** tab.
3. For Nearest Match, select **Enabled**.
4. For Replace 8.5 x 14", select **Enabled**.
5. For Jobs Held for Required Paper, select an option.
6. Click **Apply**.

Setting Paper Size Preference

Use Paper Size preference to control how paper sizes appear on the screen in inches or millimeters. The selected preference appears first on the Paper Size screen. This setting also affects the custom size units for the paper tray.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup > Paper Management**.
2. Click the **Paper Size Preference** tab.
3. Select an option:
 - **Inches** sets the paper size preference to inches.
 - **Metric** sets the paper size preference to millimeters.
4. Click **Apply**.

Setting Paper Size Preferences at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > Paper Management > Paper Size Preference**.
3. Select an option.
 - **Inches**: Sets the paper size preference to inches.
 - **Metric**: Sets the paper size preference to millimeters.
4. Touch **OK**.

Selecting Paper Tray Settings

For each paper tray, you can view or configure the mode, priority, and auto-select settings.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup > Paper Management**.
2. Click **Tray Content & Settings**.
3. To edit a specific paper tray, click **Edit** on that row.
4. Under Edit Tray, select an option:
 - **Fully Adjustable** prompts you to confirm the type of paper loaded in the tray.
 - **Dedicated** assumes that the paper you loaded in the tray is the type specified under Paper Types.
 - If you selected Dedicated, to edit the paper size, type, and color for this tray, click the Pencil icon.
 - Select the desired options.
 - Click **Save**.
5. Under Priority, set the priority for each tray.
For example, the printer uses paper from the Priority 1 tray first. If that tray is empty, the printer then prints using paper from the Priority 2 tray.
6. To have the print driver select the tray, set the tray used as the paper source to Auto Selection Enabled.
7. Click **Save**.

Selecting Tray 1 Settings

You can dedicate tray 1 to print only envelopes, print any acceptable paper except envelopes, or print all paper acceptable for your printer.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > Paper Management > Tray 1 Usage**.
3. Select an option.
4. Touch **OK**.

Saving and Reprinting Jobs

The Reprint Saved Jobs feature allows you to save your print job on the printer so that you can print it at any time.

Enabling the Reprint Saved Jobs Feature

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Print From**.
2. Click **Reprint Saved Jobs > Enablement**.
3. Under Enablement, select **Enabled**.
4. Click **Apply** to save the new settings or **Undo** to retain the previous settings.

Create and Manage Saved Jobs Folders

By default, if Reprint Saved Jobs is enabled, jobs are saved in the Default Public Folder. You can create folders to organize saved jobs.

Managing certain folder types requires that you log in as the creator of the folder or that you have administrator-level permissions. You can delete, rename, or change the permissions for a folder. If you want to limit access to the saved jobs, assign a password to a folder.

Creating a Folder

1. In Xerox® CentreWare® Internet Services, click **Jobs > Saved Jobs**.
2. Click **Create New Folder**.
3. Type a name in the field provided.
4. Under Folder Permissions, select the folder type.
5. Click **Apply**.

Managing a Folder

1. Click **Manage Folders**.
2. Click the pencil icon.
3. If allowed, you can rename the folder and change folder permissions.
4. Click **Apply**.

Deleting a Folder

1. Click **Manage Folders**.
The list of existing folders appears.
2. Select the folder you want to delete.
The Delete Folder button activates.
3. Click **Delete Folder**.
A warning message appears informing you that the delete is permanent.
4. Click **OK** to delete or **Cancel** to exit.

Saving and Printing Jobs

Saving a Job from Your Computer

1. With your file open, click the **File** menu in the application, then click **Print**.
2. From the application Print window, select your printer from the Printer Name menu.
3. Click **Properties** to access the print settings for the job.
4. On the Printing Options tab, click the **Job Type** menu, then select **Saved Job**.
5. Type a Job Name for the job or, to use the document file name being submitted, select **Use Document Name**.
6. From the Save To menu, select the destination folder. Select **Default Public Folder** or type a name for a new folder.
7. To save the job to the printer and print it immediately, click **Save and Print**.
8. To save your job as a secure job, select **Private**, type and retype a 4–10 digit passcode, then click **OK**.

Backing up Saved Jobs

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Print From**.
2. Click **Reprint Saved Jobs > Backup Jobs**.
3. Under Settings, select **FTP** as the protocol.
4. Select the address type and Port for the FTP server to use to back up jobs. Options are **IPv4 Address**, **IPv6 Address**, or **Host Name**.
5. Type the appropriately formatted address in the IP Address and Port field. The default port number is 21.
6. Type the path to the file repository in the Document Path field.
7. Type the filename for the backup file in the File Name field. This name is appended to the end of the document path.
8. Type the login name for the FTP server in the Login Name field.
9. Type and retype the Password.
10. Enable **Select to Save New Password**.
11. Click **Start** to begin the backup or **Undo** to retain the previous settings.

Restoring Saved Jobs from an FTP Repository

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Print From**.
2. Click **Reprint Saved Jobs > Restore Jobs**.
3. Under Settings, select **FTP** as the protocol.
4. Select the address type and Port for the FTP server where the saved jobs are stored. Options are **IPv4 Address**, **IPv6 Address**, or **Host Name**.
5. Type the appropriately formatted address in the IP Address: Port field. The default port number is **21**.
6. Type the path to the file repository in the Document Path field.
7. Type the name for the backup file that you want to restore In the File Name field. This name is appended to the end of the document path.
8. Type the login name of the FTP server In the Login Name field.
9. Type and retype a Password.
10. Enable **Select to Save New Password**.
11. Click **Start** to begin restoring Saved Jobs or **Undo** to retain the previous settings.



CAUTION: When you restore backed-up jobs, existing stored jobs are overwritten, and the Default Public Folder is emptied.

Printing Jobs from Xerox® CentreWare® Internet Services

You can print **.pdf**, **.ps**, **.pcl**, and **.xps** files from Xerox® CentreWare® Internet Services.

1. In Xerox® CentreWare® Internet Services, click **Print**.
The Job Submission page appears.
2. Type the name of the file in the File Name field, or click **Browse** to select the file from a local network or remote location.
3. Under Printing, select the desired options for the job.
4. Click **Submit Job** to print the document.

Note: To ensure that the job was sent to the queue, wait for the job submission confirmation message to appear before you close this page.

Configuring General Print Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Printing > General**.
3. To print a Configuration Report when the printer is turned on, for Configuration Report, select **Print at Power on**.
4. To restrict printing of the Configuration Report and Information Pages to the system administrator, for Configuration/Information Pages Report, select **Restrict to System Administrator**.
5. To erase all print jobs from the print queue at power on, select **Delete All print jobs at Power On**.
6. For Held Job Policy, select the desired options.
 - a. To require active jobs to print in the order received after a held job, for Allow Print Around, select **No**.
 - b. To enable the user to print active jobs before a held job prints, for Allow Print Around on Held Jobs, select **Yes**.
 - c. To allow a job to print to an alternate paper source, for Allow Print on Alternate Paper When Job is Held, select **Yes**.
7. To set the amount of time that the printer holds print jobs before it deletes them, for Delete Held Jobs After, select options.
8. For Banner Sheet, select the desired options.
 - a. To print a banner page with each print job, for Print Banner Sheet, select Yes. To disable this option, select **No**.
 - b. To allow the print driver to override the setting for banner pages, for Allow the Print Driver to Override, select **Yes**.
 - c. To select the text that appears on the banner pages, for Banner Sheet Identification, click the arrow, then select an option.
9. To print an error sheet when a print job fails, for Print Error Sheets, select **Enable**.
10. For Defaults and Policies, for each setting, select the desired options.
11. Click **Apply**.

Printing an Error Sheet

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Printing > General**.
3. To print an error sheet when a print job fails, under Print Error Sheets, select **Enable**.
4. Click **Apply**.

Managing Banner Page Printing Options

You can set the printer to print a banner page with each print job. The banner page contains information identifying the user and job name. You can set this option in the print driver, in Xerox® CentreWare® Internet Services, or at the control panel.

Note: Enable Banner page printing in the print driver and at the control panel or in Xerox® CentreWare® Internet Services or a banner page does not print.

Enabling Banner Page Printing in Xerox® CentreWare® Internet Services

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Printing > General**.
3. Under Print Banner Sheets, select **Yes** to allow banner pages to print or **No** to disable this option.
4. Under Allow the Print Driver to Override, select **Yes** to allow the print driver settings for banner page printing to override the setting selected on this page.
5. Under Banner Sheet Identification, select the information that prints on the banner page.
6. Click **Apply** to save the new settings or **Undo** to retain the previous settings.

Enabling Banner Page Printing at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings**.
3. Touch **Job Sheets > Banner Pages**.
4. For Print Banner Pages, touch **Yes**.
5. To allow users to turn banner page printing on or off in the print driver, for Allow the Print Driver to Override, touch **Yes**.
6. For Banner Page Identification, select the information that prints on the banner page.
7. Touch **OK**.

Enabling Banner Page Printing in the Print Driver

1. With your file open, click the **File** menu in the application, then click **Print**.
2. From the application Print window, select your printer from the Printer Name menu.
3. Click **Properties** to access the print settings for the job.
4. Click the **Advanced** tab.
5. Click to expand the Paper/Output option.
6. Click **Banner Sheets**, then click the down arrow and select **Enabled** or **Disabled**.
7. Click **OK**.

Note: If banner page printing is disabled in Xerox® CentreWare® Internet Services or at the control panel, setting the print driver to print banner pages is ignored.

Configuring Secure Print Settings

You can configure Secure Print settings to specify how the printer behaves when a user sends a Secure Print job to the printer.

Configuring Secure Print Device Policies

1. To access the Secure Print page, click **Properties > Services > Printing > Secure Print**, or click **Security > Secure Print**.
2. Click the **Device Policies** tab.
3. To reveal or hide the characters with asterisks in job names, on the Device Policies tab, for Conceal Job names, select the desired option.

Note: When you send a Secure Print job to the printer, the job name appears in the list of jobs on the control panel touch screen by default. The characters in the job name appear as asterisks.

4. For Release Policies for Secure Print Jobs Requiring Passcode When the User is Already Logged In, select an option.
 - **Release Jobs Without Prompting for Passcode:** This option allows users who are logged in to release a Secure Print job without typing a passcode.
 - **Prompt for Passcode Before Releasing Jobs:** This option requires users who are logged in to type a passcode to release the job.
5. Click **Apply**.

Configuring Secure Print Driver Defaults

1. On the Secure Print page, click the **Print Driver Defaults** tab.
2. On the Print Driver Defaults tab, for Method, select a method to use to release a Secure Print job.
 - **User ID:** This option requires users to log in at the control panel to release their Secure Print jobs.
 - **Passcode:** This option requires users to type a passcode to release a Secure Print job at the control panel.
3. To specify the length of the Secure Print passcode, type a number from 4 through 10.
4. Click **Apply**.

Hold All Jobs

You can enable and configure the Hold All Jobs feature to require users to release print jobs manually at the control panel.

Configuring the Hold all Jobs Feature

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Printing > Hold All Jobs**.
3. For Enablement, select an option:
 - **Hold all Jobs in a Private Queue:** The printer holds sent jobs in a locked folder. Users must log in at the control panel to view, print, and delete jobs.
 - **Hold all Jobs in a Public Queue:** The printer holds sent jobs in an unlocked folder. Users are not required to log in at the control panel unless accessing a Secure Print job.
4. For Unidentified Job Policies, select an option.

Note: Unidentified jobs are jobs that are not associated with a user name. Unidentified jobs originate from a computer that does not require a user to log in. Examples include jobs sent from a DOS or UNIX window using LPR, Port 9100, or from the Jobs tab in Xerox® CentreWare® Internet Services.

- **Hold Jobs; All Users can Manage Jobs:** All users can view, print, and delete unidentified jobs. Users must enter a passcode to release Secure print jobs.
 - **Hold Jobs; Only Administrators can Manage Jobs:** Only system administrators can view, print, and delete unidentified jobs. System administrators must enter a passcode to release Secure Print jobs.
 - **Delete Jobs Immediately:** All unidentified jobs are deleted and are not printed. Deleted jobs appear in a list at the control panel in the Completed Jobs queue.
 - **Print Jobs Immediately:** All unidentified jobs are printed immediately except for unidentified Secure Print jobs. Users must enter a passcode to release Secure Print jobs.
5. For Release Job Policy After Log On, select an option.
 6. Click **Apply**.

UNIX, Linux, and AS/400 Printing

UNIX-based printing uses LPD/LPR port 515 or lp to port 9100 to provide printer spooling and network print server functionality. Xerox® printers can communicate using either protocol.

Xerox® Printer Manager

Xerox® Printer Manager is an application that allows you to manage and print to multiple printers in UNIX and Linux environments.

Xerox® Printer Manager allows you to:

- Configure and check the status of network connected printers.
- Set up a printer on your network as well as monitor the operation of the printer once installed.
- Perform maintenance checks and view supplies status at any time.
- Provide a common look and feel across the many different suppliers of UNIX and Linux operating systems.

Installing Xerox® Printer Manager

Before you begin:

Ensure that you have root or superuser privileges to install Xerox® Printer Manager.

1. Download the appropriate package for your operating system. To locate drivers for your printer, see www.xerox.com/office/drivers. The available files are:
 - Xeroxv5Pkg-AIXpowerpc-x.xx.xxx.xxxx.rpm for the IBM PowerPC family.
 - Xeroxv5Pkg-HPUXia64-x.xx.xxx.xxxx.depot.gz to support HP Itanium workstations.
 - Xeroxv5Pkg-Linux686-x.xx.xxx.xxxx.rpm to support RPM-based 32-bit Linux environments.
 - Xeroxv5Pkg-Linux686-x.xx.xxx.xxxx.deb to support Debian-based 32-bit Linux environments.
 - Xeroxv5Pkg-Linuxx86_64-x.xx.xxx.xxxx.rpm to support RPM-based 64-bit Linux environments.
 - Xeroxv5Pkg-Linuxx86_64-x.xx.xxx.xxxx.deb to support Debian-based 64-bit Linux environments.
 - Xeroxv5Pkg-SunOSi386-x.xx.xxx.xxxx.pkg.gz for Sun Solaris x86 systems.
 - Xeroxv5Pkg-SunOSSparc-x.xx.xxx.xxxx.pkg.gz for Sun Solaris SPARC systems.
2. To install the custom driver, log in as root then type the following command:
 - AIX: **rpm -U Xeroxv5Pkg-AIXpowerpc-x.xx.xxx.xxxx.rpm**
 - HPUX: **swinstall -s Xeroxv5Pkg-HPUXia64-x.xx.xxx.xxxx.depot.gz ***
 - Linux (RPM based): **rpm -U Xeroxv5Pkg-Linux686-x.xx.xxx.xxxx.rpm**
 - Linux (Debian based): **dpkg -i Xeroxv5Pkg-Linux686-x.xx.xxx.xxxx.deb**
 - Solaris (x86 based): **pkgadd -d Xeroxv5Pkg-SunOSi386-x.xx.xxx.xxxx.pkg**
 - Solaris (SPARC based): **pkgadd -d Xeroxv5Pkg-SunOSSparc-x.xx.xxx.xxxx.pkg**

The installation creates a Xerox directory in /opt/Xerox/prtsys.

Launching Xerox® Printer Manager

To launch Xerox® Printer Manager from a terminal window prompt as root, type **xeroxprtmgr**, then press **Enter** or **Return**.

Printing from a Linux Workstation

To print from a Linux workstation, install either a Xerox® print driver for Linux or a CUPS print driver. You do not need both drivers.

Xerox recommends that you install one of the full-featured custom print drivers for Linux. To locate drivers for your printer, see www.xerox.com/office/drivers.

If you use CUPS, ensure that CUPS is installed and running on your workstation. The instructions for installing and building CUPS are contained in the *CUPS Software Administrators Manual*, written and copyrighted by Easy Software Products. For complete information on CUPS printing capabilities, refer to the *CUPS Software Users Manual* available from www.cups.org/documentation.php.

Installing the PPD on the Workstation

1. Download the Xerox® PPD for CUPS from the Drivers and Downloads page on the Xerox® Support website.
2. Copy the PPD into the CUPS ppd/Xerox folder on your workstation. If you are unsure of the location of the folder, use the Find command to locate the PPD files.
3. Follow the instructions that are included with the PPD.

Adding the Printer

1. Verify that the CUPS daemon is running.
2. Open a Web browser and type **http://localhost:631/admin**, then click **Enter** or **Return**.
3. For User ID, type **root**. For password, type the root password.
4. Click **Add Printer** and follow the onscreen prompts to add the printer to the CUPS printer list.

Printing with CUPS

CUPS supports the use of both the System V (lp) and Berkeley (lpr) printing commands.

1. To print to a specific printer in System V, type: **lp -dprinter filename**, then click **Enter**.
2. To print to a specific printer in Berkeley, type: **lpr -Pprinter filename**, then click **Enter**.

AS/400

Xerox provides Work Station Customization Object (WSCO) files to support AS/400 or Iseries, V5R2 or later systems. The WSCO file provides printer-specific PCL codes. The host print transform uses these codes to select the correct tray, 2-sided printing option, font size and type, and orientation. The XTOOLSxxxx library provides a source WSCO for each supported Xerox® printer. You only download and install the library once.

Notes:

- The host print transform only works on AFPDS and SCS files. Convert IPDS formatted printer files to AFPDS files to use the WSCO for printing.
- You must have IOSYSCFG permissions to create a device description or a remote queue.
- For details on AS/400, refer to the *IBM AS/400 Printing V, (Red Book)*, available on the IBM website.

Installing the WSCO and Setting up Print Queues

For detailed instructions on installing the library and setting up print queues, refer to the installation instructions that are included with the library.

Print from USB

This feature allows you to print a file that is stored on a USB Flash Drive from the USB port on the printer control panel.

Before you begin:

Enable USB ports. For details, see [USB Port Security](#) on page 124.

Enabling Print from USB

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Print From > Print from USB**.
3. Under Print from USB, select **Enabled**.
4. Click **Apply**.

Print from Mailbox

Print from mailbox allows you to print a file that is stored in a folder on the printer hard drive.

Enabling Print From Mailbox

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Print From > Print From Mailbox**.
3. Under Scan to Mailbox, select **Enabled**.
4. Under Print From Mailbox, select **Enabled**.
5. Click **Apply**.

Note: For instructions on using this feature, see the *User Guide* for your printer model.

AirPrint

AirPrint is a software feature that allows you to print from wired or wireless Apple iOS-based mobile devices and Mac OS-based devices without the need to install a print driver. AirPrint-enabled printers allow you to print or fax directly from a Mac, an iPhone, iPad, or iPod touch.



Notes:

- AirPrint and all of its required protocols are enabled by default.
 - Not all iOS applications support printing using AirPrint.
 - Wireless devices must join the same wireless network as the printer. A system administrator can connect the printer by its wired network interface.
 - The device that submits the AirPrint job must be on the same subnet as the printer. To allow devices to print from different subnets, configure your network to pass multicast DNS traffic across subnets.
 - AirPrint-enabled printers work with all models of iPad, iPhone (3GS or later), and iPod touch (3rd generation or later), running the latest version of iOS.
 - The Mac OS device must be Mac OS 10.7 or later.
1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
 2. For Mobile Workflows, for AirPrint, click **Edit**.
 3. Configure HTTP, IPP, and Multicast DNS Registration as required. To configure a protocol, click **Edit**.
 4. For AirPrint Enablement, click **On**.
 5. Click **Save**.

Mopria

Mopria is a software feature that enables users to print from mobile devices without requiring a print driver. You can use Mopria to print from your mobile device to Mopria-enabled printers.

To configure Mopria:

1. In Xerox® CentreWare® Internet Services, click **Properties > Connectivity > Setup**.
2. For Mobile Workflows, to configure Mopria discovery, click **Edit**.
3. To configure HTTP, IPP, or Multicast DNS Registration as needed, for each protocol click **Edit**.
4. For Mopria Discovery, click **On**.
5. To configure your Device Name, click **Edit**.
6. Click **Save**.

Allowing Users to Interrupt Active Print Jobs

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > Interrupt Printing Enablement**.
3. Touch **Enable**.
4. Touch **OK**.

Specifying Output Settings

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings**.
3. Touch **Output**.
4. Make the desired changes to the features, then touch **OK**.
 - **Contention Management:** This option prioritizes copy and print jobs.
 - **Priority:** This option specifies the relative priority of the copy or print jobs. The lower the number, the higher the priority.
 - **First In/First Out:** This option schedules jobs to print based on their entry into the Job Queue.
 - **Output Location:** This option specifies the output location for jobs when a finisher is not available.
 - **Within Job Offsetting:** This option instructs the printer to separate print sets within an overall job. If you select **Disable**, the printer stacks all printed sets together.
 - **Staple Productivity Mode:** This option specifies where the printer applies staples to a print job.
 - **Out of Staples Options:** This option specifies how the printer handles a print job that requires staples when the printer has run out of staples.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type. Some options are available only if a finisher is installed.

Copying

6

This chapter includes:

- [Setting Copy Presets](#) 154
- [Specifying ID Card Copy Settings](#) 158
- [Specifying Output Settings](#) 159

Setting Copy Presets

This section includes:

• Specifying Default Copy Settings	154
• Specifying Feature Defaults for Copying at the Control Panel	155
• Setting the Presets Screen for Copying Settings	155
• Setting Edge Erase Presets	156
• Setting Image Shift Presets	156
• Setting Reduce/Enlarge Presets	157
• Setting the Reading Order Options	157
• Disabling Automatic Image Rotation	157

Specifying Default Copy Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Copy > Setup**.
3. For color printers, do the following:
 - To require users to select the output color at the control panel, under Color Presets Screen, select **On**. This setting allows you to conserve supplies. For example, when Auto Detect is on, the printer detects color in an original document that is almost entirely black and white. This setting prevents you from accidentally copying in color when you intend to copy in black and white.
 - Under Output Color, select the color mode that the printer uses for copies. If you select Single Color, under Single Color, select the color.
 - For 2-Sided Copying, select an option.
 - To rotate the second side, select **Rotate Side 2**.
4. For monotone printers, for Toner Saver, select an option.
5. Click **Apply**.

Specifying Feature Defaults for Copying at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Copy Service**.
3. Touch **Feature Defaults**.
4. Make the desired changes to the settings on the following tabs:
 - **Copy**: Reduce/Enlarge settings, Paper Supply, 2-Sided Copying, and Finishing settings.
 - **Image Quality**: Original Type, Image Options, and Image Enhancement settings.
 - **Layout Adjustment**: Original Orientation, Edge Erase, Original Size, and Image Shift.
 - **Output Format**: Specify settings for Annotations.
 - **Job Assembly**: Select settings for Build Job and Quantity.
5. Touch the check mark box.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Setting the Presets Screen for Copying Settings

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Copy Service**.
3. Touch **Toner Saver**.
4. Select an option.
5. Touch **OK**.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Setting Edge Erase Presets

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Copy Service**.
3. Touch **Edge Erase Presets**.

To create an Edge Erase Preset:

1. Touch **Presets**, then from the list of presets, touch **Available**.
2. At the bottom of the window, touch **Name**, then to enter the name of the new preset, use the touch screen keyboard.
3. Touch **OK**.

To edit an existing preset:

1. Touch **Presets**, then touch the desired preset.
2. Touch **Side 1**, then to change the amount to erase from each edge, touch the arrows.
3. Touch **Side 2**, then to change the amount to erase from each edge, touch the arrows , or touch **Mirror Side 1**.
4. To change the preset name, touch the name field, type the new name, then touch **OK**.
5. Touch **OK**.

Setting Image Shift Presets

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Copy Service**.
3. Touch **Image Shift Presets**.
4. Touch **Presets**, then touch the desired preset.
5. For side 1, to change the amount of Up/Down and Left/Right shift, touch the arrows.
6. For side 2, to change the amount of Up/Down and Left/Right shift, touch the arrows, or touch **Mirror Side 1**.
7. To change the preset name, touch the name field, type the new name, then touch **OK**.
8. Touch **OK**.

Setting Reduce/Enlarge Presets

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Copy Service**.
3. Touch **Reduce/Enlarge Presets**.
4. To change a proportional preset:
 - a. Touch **Proportional %**.
 - b. Touch the desired preset.
 - c. To type the percentage, use the touch-screen keypad, or touch + or -.
 - d. Touch **OK**.
5. To change a preset that uses an independent percentage for the width and length of the image:
 - a. Touch **Independent %**.
 - b. Touch the desired preset.
 - c. To type the scale percentage, use the touch-screen keypad, or touch + or -.
 - d. Touch **OK**.

Setting the Reading Order Options

You can change the order that pages are scanned in books, which impacts Book Copy and Book Fax features. You can also change the order that pages are printed, which impacts the Page Layout and Booklet Creation features.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Copy Service**.
3. Touch **Reading Order Options**.
4. For Scan Order or Print Order, touch an option.
5. If you selected Show Reading Order, for Default Reading Order, touch **Left to Right** or **Right to Left**.
6. Touch **OK**.

Disabling Automatic Image Rotation

When you have Auto Reduce/Enlarge or Auto Paper selected, the printer automatically rotates the image as needed. You can disable image rotation when either Auto Reduce/Enlarge or Auto Paper is selected.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings**.
3. Touch **Copy Service**.
4. Touch **Auto Image Rotation**.
5. For Auto Reduce/Enlarge or Auto Paper, select **Disable Rotation**.
6. Touch **OK**.

Specifying ID Card Copy Settings

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > ID Card Copy Service**.

To set ID card copy defaults:

1. Touch **Defaults**.
2. Do one or more of the following:
 - To set the quantity of copies to print by default, for Quantity, enter a number.
 - For Common Features, touch **Edit**.
 - For Front Side Features, touch **Edit**.
 - For Back Side Features, touch **Back Side**.
3. Touch **Done**.

Reduce/Enlarge Presets allow you configure how the printer handles image size. Both presets apply independently of the other.

To set the Reduce/Enlarge Presets:

1. Touch **Reduce/Enlarge Presets**.
2. Touch an option.
 - **Proportional %** reduces or enlarges the image proportionally.
 - **Independent %** allows you to reduce or enlarge the width and length of the image by different percentages.
3. Touch **Close**.

Specifying Output Settings

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings**.
3. Touch **Output**.
4. Make the desired changes to the features, then touch **OK**.
 - **Contention Management:** Prioritizes copy and print jobs.
 - **Priority:** Specifies the relative priority of the copy or print jobs. The lower the number, the higher the priority.
 - **First In/First Out:** Schedules jobs to print based on their entry into the Job Queue.
 - **Output Location:** Specifies the location for jobs.
 - **Within Job Offsetting:** Instructs the printer to separate print sets within an overall job. If you select **Disable**, the printer stacks all printed sets together.
 - **Out of Staples Options:** Specifies how the printer handles a print job that requires staples when the printer has run out of staples.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type. Some options are available only if a finisher is installed.

Scanning

7

This chapter includes:

- [Scanning to a Folder on the Printer.....](#) 162
- [Scanning to an Email Address.....](#) 166
- [Workflow Scanning.....](#) 171
- [Scan to USB.....](#) 181
- [Scanning to a User Home Folder](#) 182
- [Configuring the Printer for the Xerox Scan Utility.....](#) 184
- [Configuring Scan To Destination](#) 185

Scanning to a Folder on the Printer

The Scan to Mailbox feature allows users to scan files to mailboxes, which are folders created on the printer hard drive. These files can then be retrieved through Xerox® CentreWare® Internet Services. This feature provides network scanning capability without the need to configure a separate server and is supported in Workflow Scanning. For details, see [Workflow Scanning](#) on page 171.

For instructions on using this feature, see the *User Guide* for your printer model.

Enabling or Disabling Scan to Mailbox

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan to Mailbox > Enablement**.
3. Under Scan to Mailbox, select **Enabled**.

Note: When you enable Scan to Mailbox, folders appear as templates in the list of Workflow Scanning templates at the control panel.

4. To set the default view to show folders on the Scan tab in Xerox® CentreWare® Internet Services, select **On Scan tab, view Mailboxes by default**.
5. Click **Apply** to save the new settings or **Undo** to retain the previous settings.

Setting Scan Policies

Scan policies allow you to manage how users are allowed to scan files, create folders, and assign passwords to their folders on the printer.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan to Mailbox > Scan Policies**.
3. Under Scan Policies, select or clear:
 - **Allow scanning to Default Public Folder** allows users to scan files to the Default Public Folder without requiring a password.
 - **Require per job password for public folders** requires users to type a password for every job they scan to the public folder.
 - **Allow additional folders to be created** allows users to create additional public or private folders on the printer. If **Require password when creating additional folders** is disabled, assigning a password to the folder is optional and creates a public folder. If **Allow additional folders to be created** is disabled, the **Create Folder** button does not display on the Scan tab.
 - **Require password when creating additional folders** requires users to type a new password every time they create a folder. This feature only allows users to create private folders.
 - **Prompt for password when scanning to private folder** requires users to type the password at the control panel every time they scan a job to a private folder.
 - **Allow access to job log data file** allows users to print a job log containing details for any scanned image. Third-party applications can be used to search, file, and distribute jobs based on job log information.
4. Under Password Management, type a minimum and maximum password length, and select any password policies that you want to apply.
5. Click **Apply**.

Managing Folders and Scanned Files

Creating a Folder

By default, all users are allowed to scan to the Default Public Folder. If this option has been enabled in Scan Policies, users can create and edit additional folders.

To create a folder:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. Under Display, select **Mailboxes**.
3. Under Scan to Mailbox, click **Create Folder**.
4. Type a unique name for the folder.
Type and retype a password as needed.
5. Click **Apply**.

Editing a Folder

To edit a folder:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. For Display, select **Mailboxes**.
3. Select the folder that you want to edit. If the folder is private, type the password, then click **OK**.
4. To change the folder password, click **Modify Folder**.
5. To edit the default scan settings for the folder, click **Personalize Settings > Edit**. For details, see the Help in Xerox® CentreWare® Internet Services.

Deleting Scanned Files

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan to Mailbox > Files**.
3. To immediately remove files from the server, select an option:
 - **Delete all files now** to delete all files on the server.
 - **Delete all files older than** to delete files older than a specified number of days. Type how many days old files must be for deletion.
4. Click **Delete Files**.
5. Under Schedule Clean Up of Folder Files, specify the files that you want to delete. Type how many days old files must be for deletion.
6. Next to Cleanup time, select:
 - **Hourly** to have files deleted at the beginning of every hour.
 - **Daily** and specify the time of day for the delete process to run.
7. Click **Apply**.

Note: You can also delete scanned files from the Scan tab.

Deleting Scan Folders

You can modify or delete scan folders from two locations in Xerox® CentreWare® Internet Services. Deleting folders from either location deletes them from the printer.

To delete folders from the Properties tab:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan to Mailbox > Folders**.
3. To delete a folder, select the folder, then click **Delete Folder**.

To delete folders from the Scan tab:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. For Display, click **Mailboxes**, then select the folder that you want to delete. If the folder is private, type the password, then click **OK**.
3. Click **Modify Folder**, then click **Delete Folder**. If the folder is private, in the Old Password field, type the password again, then click **Delete Folder**.

Managing Folder Passwords

You can modify folder passwords from two locations in Xerox® CentreWare® Internet Services. Modifying passwords from either location changes them on the printer.

To modify folder passwords from the Properties tab:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan to Mailbox > Folders**.
3. Under Created Folder Operations, select the folder from the menu.
4. Under Created Folder Operations, type a new password for **Change Folder Password**.
5. Retype the password for Confirm Folder Password, then click **Save Password**.

To modify folder passwords from the Scan tab:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. Select **Mailboxes**, then select the folder you want to modify.
3. Click **Modify Folder**.
4. Under Folder Operations, type a new password for **Change Folder Password**.
5. Retype the password for Confirm Folder Password, then click **Save Password**.

Monitoring Capacity

Capacity is the total space available for all mailboxes.

Note: If the available space is less than 100 MB or the current percentage used is above 99%, your system requires cleanup to remove old, unneeded mailboxes and files.

To view the current capacity usage:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan to Mailbox > Capacity**.
 - **Capacity:** The total amount of space available on the printer for scanned images.
 - **Used:** The space currently used to hold scanned images.
 - **Available:** The space left for scanned images.
 - **Percentage Used:** The amount of space used by scanned images as a percentage of the total space.

Scanning to an Email Address

The email feature allows you to scan a document and send it to an email address as an attachment.

Before you begin:

- Configure SMTP settings. Note the IP Address or host name of your SMTP server. For details, see [Configure SMTP Server Settings](#) on page 64.
- Create an email account for the printer. The printer uses this address as the default text in the From: field of the email.

For instructions on using this feature, see the *User Guide* for your printer model.

Email

Configure email settings on the Email Setup page in Xerox® CentreWare® Internet Services. Email settings apply to other services that use SMTP.

Accessing the Email Setup Page

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Email > Setup**.

Editing User Policy Settings

1. On the Email Setup page, click the **Security** tab.
2. To edit User Policies, under User Policies, click **Edit**.
3. To restrict authenticated users from sending emails to others, next to Only send to Self, select **On**. This setting disables the New Recipient and Address Book buttons, preventing users from adding additional recipients.
4. To require users to select email addresses from an address book, next to Restrict Manual Entry of Email Address, select **On**.
5. To clear the To, CC, and BCC fields after a user presses the Start button on the control panel, next to Clear To:, Cc:, and Bcc: fields after selecting the Start button, select **On**.

Configuring Required Settings

1. On the Email Setup page, click the **Required Settings** tab.
2. To configure SMTP settings, next to SMTP, click **Edit**. For details, see [SMTP](#) on page 64.
3. To configure From Field settings, next to the From Field, under Action, click **Edit**.

Configuring From Field Settings

1. For Default From Address, type the email address you want sent from the printer.
2. To always use the default email address, for Always use Default From Address, select **Yes**.
3. Select the LDAP search result conditions in which authenticated users are allowed to edit the From field.
4. To allow users to edit the from field without authentication, next to Edit "From:" Field when Authentication is not Required, select **Yes**.
5. To use sender's name with the email address, select **Add sender's name to email address**.
6. Click **Save**.

Configuring General Email Settings

1. On the Email Setup page, click the **General** tab.
2. For Subject, type the text that you want to appear in the subject line of emails sent from the printer.
3. Next to Message body, type the text that you want to appear in the body of emails.
4. To include the user name or email address in the body of emails, under User, select **User Name** or **Email Address**.
5. To include attachment information in the message body, select **Number of Images**, or **Attachment File Type**.
6. To include information about the printer in the body, under Multifunction Device System, select the information that you want to include.
7. Next to Signature, type the information that appears at the end of the email message.
8. Next to Confirmation Sheet, select an option:
 - **Errors Only** instructs the printer to print a confirmation sheet only when a transmission error occurs. The confirmation sheet lists error information and indicates that the job has reached the SMTP server. The confirmation sheet does not indicate that the email message was delivered.
 - **On** instructs the printer to print a confirmation sheet.
 - **Off** instructs the printer not to print a confirmation sheet. You can find status about a job in the job log. To see the job log, at the control panel, press **Job Status > Completed Jobs**.
9. To add the email address of the sender to the To field in email, next to Auto Add Me, select **Enabled**.
10. Click **Apply**.

Configuring General Email Settings

1. On the Email Setup page, click the **General** tab.
2. For Subject, type the text that you want to appear in the subject line of emails sent from the printer.
3. Next to Message body, type the text that you want to appear in the body of emails.
4. To include the user name or email address in the body of emails, for User, select **User Name, Email Address**, or both.
5. To include attachment information in the message body, select **Number of Images, Attachment File Type**, or both.
6. To include information about the printer in the body, for Multifunction Device System, select the information that you want to include.
7. For Signature, type the information that appears at the end of the email message.
8. For Confirmation Sheet, select an option:
 - **Errors Only:** This option instructs the printer to print a confirmation sheet only when a transmission error occurs. The confirmation sheet lists error information and indicates that the job has reached the SMTP server. The confirmation sheet does not indicate that the email message was delivered.
 - **On:** This option instructs the printer to print a confirmation sheet.
 - **Off:** This option instructs the printer not to print a confirmation sheet. You can find status about a job in the job log. To see the job log, at the control panel, press **Job Status > Completed Jobs**.
9. To add the email address of the sender to the To field in email, for Auto Add Me, select **Enabled**.
10. Click **Apply**.

Configuring Address Book Settings

1. On the Email Setup page, click the **Address Books** tab.
2. To configure the Address Book settings stored in the printer, on the Address Books tab, next to Device Address Book, under Action, click **Edit**.
3. To use a Network Address book, configure LDAP server settings. Next to Network Address Book (LDAP), under Action, click **Edit**.
4. If you configured Address Book settings stored in the printer, under Policies, Use Device Address Book, to allow users to access the book, select **Yes**. To restrict users from accessing the address book, select **No**.
5. If you configured a Network Address Book, under Policies, under Use Network Address Book (LDAP) to allow users to access this address book, select **Yes**. To restrict users from accessing the address book, select **No**.
6. To set the default address book that users see at the control panel, under Default Address Book View, select an address book.
7. Click **Apply**.

Note: For details, see [Address Books](#) on page 239.

Configuring Default Email Settings

1. On the Email Setup page, click the **Defaults** tab.
2. To edit default Scan to Email settings, under Scan to Email, click **Edit**.
3. To edit default Image Options, Image Enhancement, Resolution, and Quality/File Size settings, under Advanced Settings, click **Edit**.
4. To edit default Original Orientation, Original Size, and Edge Erase settings, under Layout Adjustment, click **Edit**.
5. To edit default File Format and Filename Extension settings, under Email Options, click **Edit**.
6. To create a custom email attachment file name, under Email Options, next to Custom Email Attachment Name, click **Edit**.

Note: For details, see the Help in Xerox® CentreWare® Internet Services.

Setting File Compression Options

1. On the Email Setup page, click the **Compression** tab.
2. Select **.tiff**, **.pdf**, and **.xps** compression settings as needed. For details, see the Help in Xerox® CentreWare® Internet Services.
3. Click **Apply**.

Configuring Email Security Settings

Configuring Encryption and Signing Settings

1. On the Email Setup page, click the **Security** tab.
2. To edit encryption and signing settings, on the Security tab, under Encryption/Signing, click **Edit**.

Configuring Email Signing Settings

Before you begin:

- Configure Smart Card Authentication. For details see [Configuring Smart Card Authentication](#) on page 81.
 - Ensure that signing certificates are installed on all Smart Cards.
1. On the Email Encryption/Signing page, click the **Signing** tab.
 2. To enable Email Signing, on the Signing tab, under Email Signing Enablement, select an option:
 - **Always On; Not editable by user** restricts users from turning Email Signing off at the control panel.
 - **Editable by user** allows users to turn on or off Email Signing at the control panel.
 3. If you select Editable by user, select the default setting for users at the control panel. Under Email Signing Default, select **On** or **Off**.
 4. Under Signing Hash, select a method.
 5. Click **Apply**.

Configuring Email Encryption Settings

Before you begin:

- If you want to use the public keys stored on smart cards to encrypt email messages, configure Smart Card Authentication.
- If you want to use the public keys stored in an address book, configure a Network Address Book or the Device Address Book.

Notes:

- If you only configure Smart Card Authentication, users can send encrypted emails to themselves only.
 - To store public keys in the Device Address Book, configure the Import Using Email feature, and select **Import encryption certificate from signed emails**.
1. Click the **Encryption** tab.
 2. To enable Email Encryption, on the Encryption tab, under Email Encryption Enablement, select an option:
 - **Always On; Not editable by user** restricts users from turning off Email Encryption at the control panel.
 - **Editable by user** allows users to turn Email Encryption on or off at the control panel.If you select Editable by user, select the default setting for users at the control panel. Under Email Encryption Default, select **On** or **Off**.
 3. Under Encryption Algorithm, select an encryption method.
 4. Click **Apply**.

Editing Domain and Email Filter Settings

1. On the Email Setup page, click the **Security** tab.
2. To edit domain filter and email filter settings, under Network Policies, click **Edit**.
3. To enable a domain filter list, under Domain Filter settings, select **Allow Domains** or **Block Domains**.
4. Under New Domain, type the domain you want to add to the list and click **Add**.
5. To remove a domain from the list, select a domain, and click **Remove**.
6. To allow LDAP email address searches without the @ symbol, under **Allow LDAP Email Address without the @ Requirement**, select **On**.

Notes:

- Ensure that your mail server supports this requirement.
- If you select **On** under **Allow LDAP Email Address without the @ Requirement**, the number of items returned by an LDAP search can increase.

Workflow Scanning

Workflow Scanning allows you to scan an original document, distribute, and archive the scanned image file. The Workflow Scanning feature simplifies the task of scanning many multi-page documents and saving the scanned image files in one or more file locations.

To specify how and where scanned images are stored, create a template. You can create, manage, and store multiple templates in a template pool repository on a network server. For instructions on using this feature, see the *User Guide* for your printer model.

Enabling Workflow Scanning

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Scanning Web Services**.
3. For Scan Template Management, click **Settings**.
The HTTP page opens.
4. On the HTTP page, enable **Scan Template Management**.
5. Click **Save**.

Configuring File Repository Settings

A file repository is a network location where scanned images are stored. Configure the file repository settings before you create a template.

Your printer supports the following transfer protocols:

- FTP
- SFTP
- SMB
- HTTP/HTTPS

Note: HTTP/HTTPS scans to a Web server using a CGI script.

FTP or SFTP

Before you begin:

- Ensure that FTP or SFTP services are running on the server or computer being used to store scanned image files. Note the IP address or host name.
- Create a user account and password with read and write access for the printer to use to access the repository folder. Note the user name and password.
- Create a folder within the FTP or SFTP root. Note the directory path, user name, and password. This folder is your file repository.
- Test the connection. Log in to the file repository from a computer with the user name and password. Create a folder in the directory, then delete it. If you cannot create and delete the folder, check the user account access rights.

To configure file repository settings for FTP or SFTP:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > File Repository Setup**.
3. Click **Add New**.
4. In the Friendly Name field, type a name for the repository.
5. For Default Repository Protocol, click the arrow, then select FTP or SFTP.
6. Select the address type. Options for FTP include **IPv4**, **IPv6**, or **Host Name**. Options for SFTP include **IPv4**, or **Host Name**.
7. Type the appropriately formatted address and port number of your server.
8. For Default Repository Document Path, type the directory path of the folder beginning at the root of FTP or SFTP services. For example, //directoryname/foldername.
9. If you want the printer to create .XSM subfolders for single page format files, select **Sub-folder (.XSM) for 1 File Per Page, File Format jobs**.
10. For Default Repository Login Credentials, select an option:
 - **Authenticated User and Domain:** This option instructs the printer to use the user name and domain of the logged-in user when it accesses the repository.
 - **Logged-in User:** This option instructs the printer to log in to the repository with the credentials of the logged-in user.
 - **Prompt at User Interface:** This option instructs the printer to prompt users at the control panel for the repository credentials.
 - **Stored in Template:** This option instructs the printer to use specific credentials when it accesses the repository.
11. For Login Name and Password, type the credentials.
12. To update an existing password, select **Select to save new password**.
13. Click **Save**.

SMB

Before you begin:

- Ensure that SMB services are running on the server or computer where you want to store scanned image files. Note the IP address or host name.
- On the SMB server, create a shared folder. This folder is your file repository. Note the directory path, Share Name of the folder, and the Computer Name or Server Name.
- Create a user account and password with read and write access for the printer to use to access the repository folder. Note the user name and password.
- Test the connection by logging in to the file repository from a computer with the user name and password. Create a folder in the directory, then delete it. If you cannot do this test, check the user account access rights.

To configure file repository settings for SMB:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > File Repository Setup**.
3. Click **Add New**.
4. In the Friendly Name field, type a name for the repository.
5. For Default Repository Protocol, click the arrow, then select **SMB**.
6. Select the address type. Options are **IPv4** or **Host Name**.
7. Type the appropriately formatted address and port number of your server.
8. In the Share field, type the share name.
9. For Default Repository Document Path, type the directory path of the folder starting at the root of the shared folder. For example, if you have a folder named scans in the shared folder, type **\scans**.
10. If you want the printer to create .XSM subfolders for single page format files, select **Sub-folder (.XSM) for 1 File Per Page, File Format jobs**.
11. For Default Repository Login Credentials, select an option:
 - **Authenticated User and Domain:** This option instructs the printer to use the user name and domain of the logged-in user when it accesses the repository.
 - **Logged-in User:** This option instructs the printer to log in to the repository with the credentials of the logged-in user.
 - **Prompt at User Interface:** This option instructs the printer to prompt users at the control panel for the repository credentials.
 - **Stored in Template:** This option instructs the printer to use specific credentials when it accesses the repository.
12. For Login Name and Password, type the credentials.
13. To update an existing password, select **Select to save new password**.
14. Click **Save**.

HTTP/HTTPS

Before you begin:

- Enable HTTP or Secure HTTP (SSL). Ensure that a certificate is installed on the printer if you are using SSL.
- Configure your Web server, and ensure that HTTP/HTTPS services are running. POST requests and scanned data are sent to the server and processed by a CGI script. Note the IP address or host name of the Web server.
- Create a user account and password for the printer on the Web server. Note the user name and password.
 - Create a /home directory for the printer.
 - Create a /bin directory in the home directory.
 - Copy an executable CGI script into the /bin directory. You can create your own script, or download a sample script. For details, see [CGI Scripts](#) on page 174. Note the path to the script. The script can be defined with script_name.extension or by path/script_name.extension.
- Create a folder with read and write permissions on the Web server, or alternate server. Note the directory path, user name, and password. This folder is your file repository.
- Test the connection by logging in to the home directory of the printer on the Web server. Send a POST request and file to the Web server. Check to see if the file is in the repository.

CGI Scripts

A CGI (Common Gateway Interface) script is a program on a Web server that is executed when the server receives a request from a browser. A CGI script is required to allow files to be transferred to your HTTP server from your printer.

When a document is scanned, the printer logs in to the Web server, sends a POST request along with the scanned file, then logs out. The CGI script handles the remaining details of file transfer.

To download a sample CGI script:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > File Repository Setup**.
3. Click **Add New**.
4. Select **HTTP** or **HTTPS** from the Protocol menu.
5. Under Script path and filename, click **Get Example Scripts**.
6. Select a script language supported by your Web server. Right-click and save the appropriate **.zip** or **.tgz** file to your computer.
7. Extract the downloaded file to the root of the Web services home directory.

Configuring File Repository Settings for HTTP/HTTPS

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > File Repository Setup**.
3. Click **Add New**.
4. In the Friendly Name field, type a name for the repository.
5. From the Protocol menu, select **HTTP** or **HTTPS**.
6. Select an address type. Options are **IPv4 Address**, **IPv6 Address**, or **Host Name**.
7. Type the appropriately formatted address and port number of your server.
8. To validate the SSL certificate used for HTTPS, select **Validate Repository SSL Certificate**.
9. To verify that a digital certificate is installed on the printer, for HTTPS, click **View Trusted SSL Certificates**.
10. In the Script path and filename field, type the path to the CGI script starting at the root. For example: /directoryname/foldername. To download working example scripts, click **Get Example Scripts**.
11. In the Document Path field, type the directory path of the folder. For Web server directories, type the path starting at root. For example, //directoryname/foldername.
12. If you want the printer to create .XSM subfolders for single page format files, select **Sub-folder (.XSM) for 1 File Per Page, File Format jobs**.
13. For Default Repository Login Credentials, select an option:
 - **Authenticated User and Domain:** This option instructs the printer to use the user name and domain of the logged-in user when it accesses the repository.
 - **Logged-in User:** This option instructs the printer to log in to the repository with the credentials of the logged-in user.
 - **Prompt at User Interface:** This option instructs the printer to prompt users at the control panel for the repository credentials.
 - **System:** This option instructs the printer to use specific credentials when it accesses the repository. If you select **System**, type the credentials in the User Name and Password fields. To update an existing password, select **Select to save new password**.
 - **None** instructs the printer to access the repository without providing credentials.
14. For Login Name and Password, type the credentials.
15. To update an existing password, select **Select to save new password**.
16. Click **Save**.

Configuring the Default Template

Before you can use the Workflow scanning feature, create and edit a template. A template contains scan settings, and at least one destination for the scanned image files.

Configure the default template before you create a template. After the default template is configured, all new templates created inherit the default template settings and can then be edited as required.

The default template cannot be deleted.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Default Template**.
3. Under Destination Services, select:
 - **File** to add File Destinations.
 - **Fax** to add Fax Destinations.
4. Add File Destinations, Fax Destinations, Document Management Fields, and configure other scanning options.

Adding a File Destination

1. For File Destinations, click **Add**.
2. From the menu, select the required **Filing Policy**.
3. Click **Save**.

Adding a Fax Destination

1. For Fax Destinations, click **Add**.
2. Type a fax number in the Add Fax Number field, then click **Add**.
3. For Delivery, select **Delayed Send**, then type a time if you want to send the fax at a specific time.
4. Click **Apply** to save the new settings or **Cancel** to return to the previous screen.

Configuring Other Default Template Scanning Options

1. Click **Edit** to edit the following settings. For details, see the Xerox® CentreWare® Internet Services Help.
 - Workflow Tags
 - Workflow Scanning
 - Advanced Settings
 - Layout Adjustment
 - Filing Options
 - Job Assembly
 - Filename Extension
 - Report Options
 - Scan to Image Settings
 - Compression Settings
2. To restore the Default Template to its original settings, click **Apply Factory Default Settings**. This action deletes any custom settings applied to the Default Template.

Configuring Workflow Scanning General Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > General Settings**.
3. For Confirmation Sheet, select when you want a confirmation sheet to print.
 - **Errors Only:** This option instructs the printer to print a confirmation sheet only when a workflow scanning job generates an error.
 - **On:** This option instructs the printer to print a confirmation sheet.
 - **Off:** This option instructs the printer not to print a confirmation sheet. You can find status about a job in the job log. To see the job log, at the control panel, press **Job Status > Completed Job Queue**.
4. To allow users to add file destinations to templates manually, for Allow Manual Entry of File Destinations, select **Enabled**.
5. To configure the printer to refresh templates automatically, for Enable Automatic Refresh, select **Enabled**. For Daily Start Time, select the time that templates update. The list of templates appears on the control panel. To update the template list immediately, click **Refresh Template List Now**.
6. To configure user or domain names to appear in the job log, for Optional Information, select **User Name**. If you added Document Management Fields to a template, the job log is filed with scanned image files.
7. Click **Apply**.

See also:

[Updating the List of Templates at the Control Panel](#) on page 179

Configuring Single-Touch Service

You can customize the naming convention of files generated during Workflow Scanning. For example, you can:

- Assign file names in a numbered sequence.
- Select standard options or add custom text.
- Add advanced features such as including the date and time in the name.

To customize file names:

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Single-Touch Service**.
3. Click **Create**.
4. Type a name and description for the service.
5. Click **Create**.

Notes:

- After you create a service, you can edit the description but not the name of the service.
- You can create up to 10 services.
- The service does not appear on the control panel touch screen until you design your service and select a scan template for your service.

Configuring Custom File Naming

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Custom File Naming**.
3. For File Naming, select one of the following:
 - **Auto:** Type a prefix for the scanned image file name.
 - **Custom Naming:** For Display, select the elements that you want to use to build the file name. As you select display elements, they appear in the Position field. The display elements are:
 - **Date**
 - **Time**
 - **Job ID**
 - **User ID**
 - **Custom Text:** Type any custom text that you that want to appear in the file name. For example, select the first Custom Text field and then type an underscore (_). The underscore appears in the Position field. You can include up to four Custom Text strings in the file name.
 - **Position:** Click an element in the Position field. Use the Arrow buttons to move the element into the correct position for the file name. The file name that generates uses all of the elements in the Position field, in order, from top to bottom.
 - **Advanced:** To create the file name, type a string with variables. For details, see the Help in Xerox® CentreWare® Internet Services.
4. Click **Apply**.

Setting Template Display Settings for the Control Panel

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Display Settings**.
3. To specify the template that appears at the top of the list, for Templates, select the template, then click **Promote**.
4. To prevent users from using the Default Workflow Scanning template, for Default Template Display, select **Hide Default Template in the Templates list**.
5. To require users to select a template before they press the Start button, for Device Template Selection, select **User must select a template before pressing Start**.
6. Click **Apply**.

Enabling Remote Scanning using TWAIN

Enable Remote Start to allow users to scan images into a TWAIN-compliant application using the TWAIN driver.

Before you begin, enable the Scan Extension Web service. For details, see [HTTP - Web Services](#) on page 42.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Remote Start (TWAIN)**.
3. Under Start Job via Remote Program, click **On**.
4. Click **Apply**.

Configuring a Validation Server

Scan metadata entered at the printer control panel can be verified against a list of valid values by a validation server.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Validation Servers**.
3. Click **Add**.
4. Select **HTTP** or **HTTPS**.
5. Under Protocol, select the address type. Options are **IPv4**, **IPv6**, or **Host Name**.
6. Type the appropriately formatted address and port number in the IP Address: Port field. The default port number is 80 for HTTP and 443 for HTTPS.
7. In the Path field, type the path on the server.

Note: The format for a directory path for FTP is /directory/directory, while the format for a directory path for SMB is \directory\directory.

8. Type a Response Timeout between **5–100** seconds.
9. Click **Apply** to save the new settings or **Cancel** to return to the previous screen.

Configuring Template Pool Repository Settings

You can store Workflow Scanning templates on your network in a template pool repository. Workflow Scanning templates contain details about scan jobs that can be saved and reused for other scan jobs.

If you use a scanning management application, such as SMARTsend or ScanFlowStore, provide information about the server that hosts the templates on this page.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Advanced > Template Pool Setup**.
3. Under Settings, select the desired protocol from the menu.
4. Type the required information for the protocol. Follow the same steps used for setting up a file repository for the protocol.

Notes:

- For details, view the online help in Xerox® CentreWare® Internet Services for the selected protocol.
 - The format for a directory path for FTP is /directory/directory, while the format for a directory path for SMB is \directory\directory.
5. Click **Apply** to save the new settings or **Undo** to retain the previous settings.
Click **Default All** to reset settings to default values.

Configuring Unspecified Defaults

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Advanced > Unspecified Defaults**.
3. For Advanced Settings, select a scanning resolution.
4. For Filing Options, select a TIFF Rotation Method.
5. For Template Distribution Repositories, select a Login Source.
6. Click **Apply**.

Scan to USB

You can insert a USB Flash Drive into the printer, scan a document, and store the scanned file on the USB drive.

Before you begin:

Enable USB ports. For details, see [USB Port Security](#) on page 124.

Enabling Scan to USB

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan to USB > General**.
3. Under Enablement, select **Enabled**.
4. Click **Apply** to save the new settings or **Undo** to retain the previous settings.

Scanning to a User Home Folder

Use the Scan to Home feature to scan to their home folder, as defined in your LDAP directory, or to a shared network folder.

Before you begin:

Configure authentication. For details, see [Configuring Authentication Settings](#) on page 74.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan to Home > General**.
3. Under Status, click **Enabled**.
4. Type a Friendly Name. Friendly Name is the default description of the template that appears when you select the template from the list of templates at the control panel.
5. Type a Template Name. Template Name is the name of the template that appears in the list of templates at the control panel. If you leave this field blank, the template default name is @S2HOME.
6. Select how to scan:
 - To scan to the home folder defined in an LDAP directory, select **LDAP Query**.
 - To scan to a shared network folder, select **No LDAP Query**, then type the complete network path of the external server. For example, type **\\servername\foldername**.
7. To create a subdirectory in the network home path, type a network path in the Subdirectory field. For example, type **\\servername\foldername\subdirectoryfoldername** to scan to **\\servername\foldername\subdirectoryfoldername**.
8. To store scanned images in folders named according to each user on your network home path, for example **\\servername\foldername\username**, select **Append User Name to Path**. The user name is the name used when logging in at the control panel.
9. If you want to create individual folders for each user, select **Automatically Create User Name directory if one does not exist**.
10. If you created a subdirectory, specify your existing directory structure. Under Directory Structure, select an option.
11. If you want the printer to create .XSM subfolders for single page format files, select **Sub-folder (.XSM) for 1 File Per Page, File Format jobs**.
12. If network authentication is configured to use a Kerberos server, and you want to modify the Kerberos settings, click the link. Kerberos Tickets let you use the SMB protocol without selecting login credentials.

13. Under Login Credentials to Access the Destination, select an option:
 - **Authenticated User and Domain** instructs the printer to use the user name and domain of the logged-in user when accessing the repository.
 - **Logged-in User** instructs the printer to log in to the repository using the credentials of the logged-in user.
 - **Prompt at User Interface** instructs the printer to prompt users at the control panel for the repository credentials.
 - **System** instructs the printer to use specific credentials when accessing the repository. If you select System, type the credentials in the User Name and Password fields. To update an existing password, select **Select to save new password**.
14. To save a copy of the job log in the scan repository, under Report Options, under Save Job Log (.XST) in Repository, select **Enable**.
15. Click **Apply**.

Configuring the Printer for the Xerox Scan Utility

The Xerox® Scan Utility allows you to scan directly to your computer and helps you manage and distribute scanned image files. Before you can scan, create a template in the utility. The template is saved on the printer. The Xerox® Scan Utility installs when you install scan drivers.

Notes:

- Before scanning using the Xerox® Scan Utility, ensure that Secure HTTP (SSL) is enabled, and a certificate is installed on the printer.
- Ensure SMB is enabled on your computer. SMB is not enabled by default on Macintosh computers.
- You cannot delete templates created in the Xerox® Scan Utility from the printer control panel or from Xerox® CentreWare® Internet Services. Templates must be deleted in the Xerox® Scan Utility by the user who created them.
- The Xerox® Scan Utility is available for Macintosh computers only.

Configuring Scan To Destination

The Scan To Destination feature allows you to associate scan destinations with address book contacts. Users can select these contacts when scanning using the Scan To feature.

Before You Begin

- Add at least one contact to the Device Address Book.
- Add scan destinations to address book contacts.

For details, see [Address Books](#) on page 239.

Configuring Default Scan Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan To > Setup**.
3. Edit settings as needed. For details, see the Help in Xerox® CentreWare® Internet Services.

Configuring Default Scan Settings for Address Book

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan To > Setup**.
3. Click **Address Book**.
 - To configure the Device Address Book settings stored in the printer, click **Edit**.
 - To configure your favorite contacts to appear in the Address Book when you enter a Scan To function, select **View Favorites on Scan To Service Entry**.
 - To reset the printer to factory settings, click **Apply Factory Settings**.
4. Click **Apply**.

Configuring Default Scan Settings for Security

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Scan To > Setup**.
3. Click **Security**.
4. To configure security settings, click **Edit**.

Faxing

8

This chapter includes:

- Fax Overview 188
- Fax..... 189
- Internet Fax 204
- LAN Fax 208

Fax Overview

You can send a fax in one of four ways:

- **Fax**, or embedded fax, scans the document and sends it directly to a fax machine.
- **Server Fax** scans the document and sends it to a fax server, which transmits the document to a fax machine.
- **Internet Fax** scans the document and emails it to a recipient.
- **LAN Fax** sends the current print job as a fax. For details, see the print driver software.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type. For details, contact your Xerox representative.

Fax

This section includes:

• Configuring Required Fax Settings at the Control Panel	189
• Configuring Embedded Fax Settings	190
• Fax Security	190
• Setting Fax Defaults	191
• Setting Fax Feature Defaults	193
• Fax Forwarding	194
• Fax Mailboxes	196
• Fax Reports	197

When you send a fax from the printer control panel, the document is scanned and transmitted to a fax machine using a dedicated telephone line. To use the embedded fax feature, ensure that your printer has access to a functioning telephone line with a telephone number assigned to it.

Notes:

- Not all printer models can send faxes. Some printers require an optional fax hardware kit.
- Not all printer models have multiple fax lines.

Configuring Required Fax Settings at the Control Panel

Before you can send a fax at the control panel:

- Set the fax country.
- Configure the embedded fax settings.

Setting the Fax Country at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service > Fax Country Setting**.
3. Select your country from the list.
4. Touch **OK**.

Configuring Embedded Fax Settings

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service**.
3. Touch **Line 1 Setup** or **Line 2 Setup**.
4. Touch **Fax Number**, use the touch screen keypad to type the fax number, then touch **OK**.
5. Touch **Line Name**, use the touch screen keypad to type a Line Name for the printer, then touch **OK**.
6. Under Options, select fax send and receive options.
7. If allowed, for Dial Type, select your dialing method. If you have a tone line, select **Tone**. If you have a 10-pulse-per-second line, select **Pulse**. If in doubt, touch **Tone**.
8. Touch **OK**.

Notes:

- At least one fax line must be configured.
- Most countries use tone dialing.
- The Pulse/Tone feature is not available in some countries.

Fax Security

When the Fax Secure Receive feature is enabled, users must type a fax passcode to release a fax. Fax passcodes are also used to secure fax mailboxes. You can specify the required fax passcode length.

Notes:

- Existing passcodes are not changed.
- If you edit an existing passcode after changing the passcode length requirement, the new password must meet the current length requirement.

Configuring Fax Passcode Length

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Fax > Setup > Security**.
2. To configure fax passcode options, next to Fax Passcode Length, click **Edit**.
3. To set the passcode length, use the arrows.
4. Click **Save**.

Configuring Fax Passcode Length at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service**.
3. Touch **Fax Passcode Length**.
4. To set the passcode length, touch the arrows.
5. Touch **OK**.

Setting Fax Defaults

Setting Ring Volume

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. **Touch Service Settings > Fax Service > Fax Volume.**
3. For Incoming Ring Volume, touch the desired selection.
4. For Outgoing Ring Volume, touch the desired selection.
5. Touch **OK**.

Setting Incoming Fax Defaults

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service.**
3. Touch **Incoming Fax Defaults** to open the Incoming Fax Defaults window.

Enabling Auto Answer Delay

1. On the Incoming Fax Defaults window, touch **Automatic Answer Delay**.
2. To set the answer delay, touch the arrows.
3. Touch **OK**.

Selecting Default Paper Settings

1. On the Incoming Fax Defaults window, touch **Paper Settings**.
2. To direct the printer to print faxes on the paper size that most closely matches the attributes of the incoming fax, touch **Automatic**. If the exact paper size is not available, the printer prints to the next best match and scales the fax to fit if needed.
3. To specify exact paper attributes for incoming faxes, touch **Manual**. If the specified paper size is not available, incoming faxes are held until resources are available.
4. Touch **OK**.

Enabling or Disabling the Secure Fax Feature

To secure fax transmissions, enable the Secure Fax feature.

When Secure Fax is enabled, a password is required before a fax can be printed or deleted.

1. On the Incoming Fax Defaults screen, touch **Secure Receive Settings**.
2. For Secure Receive, to turn on Secure Receive, touch **Passcode Protect**.

Note: Depending on when the device was manufactured, the default administrator password may be the device serial number or **1111**.

3. To change the passcode, use the touch screen keypad to type the new passcode.
4. To allow guest users to turn on or off this feature, under Permission Policy, touch **Allow User to Manage**.

Note: Guest users cannot change the passcode.

5. Touch **OK**.

Setting Default Output Options at the Control Panel

1. On the Incoming Fax Defaults screen, touch **Default Output Options**.
2. To staple documents, for staple, touch **Enable**.
3. To punch holes in documents, for Hole Punch, touch **Enable**.
4. To set faxes to print on both sides of the page, for 2-Sided, touch **Enable**.
5. Touch **OK**.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type. Some options are available only if a finisher is installed.

Disabling Advanced Capabilities

If your printer is not communicating successfully with older fax machines, disable the advanced document transmission speed and resolution capabilities.

1. On the Incoming Fax Defaults screen, touch **Advanced Capabilities**.
2. Touch **Disable**.
3. Touch **OK**.

Setting Outgoing Fax Defaults

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service**.
3. Touch **Outgoing Fax Defaults**.

Setting Automatic Redial

1. On the Outgoing Fax Defaults screen, touch **Automatic Redial Setup**.
2. Use the arrows to set:
 - **Redial Time Interval:** This option sets the time interval before the fax system redials after a failed transmission. The range is 1–25 minutes.
 - **Automatic Redial Attempts:** This option sets the number of attempts the fax system makes before it rejects the job. The range is 0–14.
3. Touch **OK**.

Send Header Text

1. On the Outgoing Fax Defaults screen, touch **Send Header Text**.
2. To type up to 30 characters of text to include in the header for the fax, use the touch-screen keyboard.
3. Touch **OK**.

Automatic Resend

1. On the Outgoing Fax Defaults screen, touch **Automatic Resend**.
2. To set the number of resend attempts the printer makes, for Set Number of Resends, touch the arrows, then select a number between **0–5**.
3. From the list of options, select the condition that prompts the printer to resend jobs automatically.
4. Touch **OK**.

Batch Send

The Batch Send feature allows you to send multiple fax jobs to a single destination during a single fax transmission session. This feature reduces the connection time and cost of call connection that occurs when the faxes are sent independently.

1. On the Outgoing Fax Defaults screen, touch **Batch Send**.
2. To enable Batch Send, touch **Enabled**.
3. Touch **OK**.

Setting Fax Feature Defaults

The printer uses the default fax feature settings on all embedded fax jobs unless you change them for an individual job. You can modify the default fax feature settings.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service**.
3. Touch **Feature Defaults**.
4. Make the desired changes to the settings on the following tabs:
 - **Fax:** Configures 1-sided or 2-sided scanning, text and photo, the default scan resolution, and original size settings.
 - **Image Quality:** Configures image options and image enhancement settings.
 - **Layout Adjustment:** Configures the reduce/split and book faxing settings.
 - **Fax Options:** Configures the confirm report, starting rate, cover sheet, send header text and delay send settings.
 - **Job Assembly:** Configures the build job settings.
5. Touch the check mark box.

Fax Forwarding

You can configure the printer to forward incoming faxes to email or file destinations by creating a Fax Forward Rule. For different situations, you can configure up to five rules, and apply them to the available fax lines.

Note: After you configure the fax forwarding rule, apply the rule to a fax line.

Editing a Fax Forwarding Rule

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Fax > Setup > Forwarding**.
2. On the Forwarding page, for the desired rule, click **Edit**.
3. To base the new rule on an existing rule, for Based on Rule, select a rule from the menu.
4. For Rule Name, type a name for the rule.
5. Select a File Format Type from the menu.
6. For Print Local Copy, to print all incoming faxes, select **Always**. To print a copy only if the forwarded fax transmission fails, select **On Error Only**.
7. Add an email address or file destination to the rule.
8. Click **Save**.

Adding Email Addresses to the Rule

1. On the Forwarding page, next to the desired rule, click **Edit**.
2. To forward to an email address, select **Email**.
3. In the Address fields, type the email addresses of the recipients.
4. Type the From Address, From Name, and Subject.
5. To customize the name of the attachment, click **Customize**.
 - a. Under Display, select the check boxes next to Date or Time to add the date or time to the file name.
 - b. To customize the file name, type the new name in Custom Text, then click **Add**.
 - c. Under Position, select an item, and click the arrows to arrange the items as you want them to appear in the file name.
 - d. Click **Save**.
6. Type the Message text for the body of the email.
7. Type the Signature text for the email message.
8. Click **Save**.

Adding File Destinations to the Rule

1. On the Forwarding page, next to the desired rule, click **Edit**.
2. To forward to a file location, select **SMB Protocol**.
3. Select **IPv4 Address** or **Host Name**, then type the address or host name.
4. Type the following information:
 - a. In the Share field, type the share name.
 - b. In the Document Path field, type the directory path of the folder.
 - c. Type a Login Name for the printer to use to access the shared folder.
 - d. Enter the computer login password for the printer to use to access the shared folder, then confirm it.
5. To update an existing password, type the new password, then click **Select**.
6. To customize the name of the file, click **Customize**.
 - a. Under Display, select the check boxes next to Date or Time to add the date or time to the file name.
 - b. To customize the file name, type the new name in Custom Text, then click **Add**.
 - c. Under Position, select an item, and click the arrows to arrange the items as you want them to appear in the file name.
7. To receive email notifications of forwarded faxes, select Email Notification, then enter your email address.
8. To send an email confirmation when file transfer is complete, select **Email Notification (without Attachment)**, and type the email address in the Notification Address field.
9. Click **Save**.

Applying a Fax Forwarding Rule

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Fax > Setup > Forwarding**.
2. On the Forwarding page, for the desired rule, click **Edit**.
3. To apply a rule, select **Apply to Fax Line 1** or **Apply to Fax Line 2**.
4. To save, click **Apply**.

Disabling Fax Forwarding

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Fax > Setup**.
2. Click **Forwarding**.
3. To disable fax forwarding for a line, next to No Fax Forwarding, select **Apply to Fax Line 1** or **Apply to Fax Line 2**.
4. To save, click **Apply**.

Fax Mailboxes

You can store faxes locally in the printer or on a remote fax machine. You can use Remote Polling to print or access a stored fax. There are 200 available fax mailboxes.

Editing a Fax Mailbox

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service**.
3. Touch **Mailbox Setup**.
4. Touch a mailbox from the list.
 - To edit a name to a mailbox, touch **Friendly Name**, use the touch screen keyboard to type a name for the mailbox up to **30** characters, then touch **OK**.
 - To assign a passcode to the mailbox, touch **Passcode & Notification**, then **Passcode Protect**. To type a 4-digit passcode, use the numeric keypad, then touch **OK**.
- Note:** The passcode is required when users store faxes to the mailbox or print faxes from the mailbox.
 - To notify users of mailbox status changes, touch **Passcode & Notification**, then for Mailbox Notification, touch **Enabled**.
 - To reset and delete mailbox contents, touch **Reset Mailbox & Cont**, then touch **Reset**.
 - To print mailbox content, touch **Print Mailbox List**.
5. Touch **Close**.

Deleting a Fax Mailbox

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service**.
3. Touch **Mailbox Setup**.
4. Touch the assigned mailbox that you want to delete, then touch **Reset Mailbox & Contents**.



CAUTION: If you touch **Reset Mailbox**, the mailbox and all documents that it contains are permanently deleted.

5. On the Delete Mailbox confirmation screen, to delete the mailbox touch **Reset**, or to exit touch **Cancel**.
6. Touch **Close**.

Fax Reports

You can configure three different reports:

- Activity Report
- Confirmation Report
- Broadcast and Multipoll Report

Setting Up Fax Reports

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service**.
3. Touch **Setup Fax Reports**.
4. Touch **Fax Activity Report**, then touch an option:
 - **Auto Print**: This option always prints an activity report.
 - **Off**: This option never prints an activity report.
5. Touch **OK**.
6. Touch **Confirmation Report**, then Under Report Options, touch an option:
 - **Print On Error**: Prints a confirmation report only when a fax transmission error occurs.
 - **Always Print**: Prints a confirmation report every time.
 - **Off**: This option never prints confirmation report.
7. Under Print Options, touch a thumbnail printing option:
 - **Reduced Image**: This option prints a smaller thumbnail image of the first page of the fax on the confirmation report.
 - **Cropped Image**: This option prints a larger thumbnail image of the first page of the fax on the confirmation report.
 - **No Image**: This option disables printing a thumbnail image of the first page of the fax on the confirmation report.
8. Touch **OK**.
9. Touch **Broadcast & Multipoll Report**, then touch an option:
 - **Print On Error**: Prints a confirmation report only when a fax transmission error occurs.
 - **Always Print**: Prints a confirmation report every time.
 - **Off**: This option never prints confirmation report.
10. Touch **OK**.
11. Touch **Close**.

Printing a Fax Report

You can print the following fax reports from the printer control panel:

- Activity Report
- Protocol Report
- Fax Address Book Report
- Options Report
- Pending Jobs Report

To print a fax report:

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Fax Service**.
3. Touch **Print Fax Reports**.
4. Touch the desired report, then touch **Print**.
5. Touch **Close**.

Deleting Sent Fax Jobs from Memory

1. At the printer control panel, press the **Job Status** button.
2. Touch the down arrow, then touch **Scan and Fax Sent Jobs**.
3. Touch the pending fax in the list.
4. Touch **Delete**.

Server Fax

Server fax allows you to send a fax over a network to a fax server. The fax server then sends the fax to a fax machine over a phone line.

Before you can send a server fax, configure a fax filing repository, or filing location. The fax server retrieves the documents from the filing location and transmits them over the telephone network. You can also print a transmission report.

Note: Not all printer models support this feature.

Configuring a Server Fax Filing Repository

Before you can send a server fax, configure fax repository settings. Once configured, the printer transfers faxed images to the repository. The fax server then sends the fax to its destination over the phone line.

You can set up a repository that uses one of the following protocols:

- FTP
- SFTP
- SMB
- HTTP/HTTPS: A Web server using a CGI script.
- SMTP: A mail server.
- NetWare

Configuring a Fax Repository Using FTP or SFTP

Before you begin:

- Ensure that FTP or SFTP services are running on the server or computer where images faxed by the printer are stored. Note the IP address or host name.
 - Create a user account and password for the printer. When the server fax feature is used, the printer logs in using the account, transfers the file to the server or computer and logs out. Note the user account and password.
 - Create a directory within the FTP or SFTP root to be used as a fax repository. Note the directory path.
1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
 2. Click **Server Fax > Fax Repository Setup**.
 3. Select the address type. Options for FTP include **IPv4**, **IPv6**, or **Host Name**. Options for SFTP include **IPv4**, or **Host Name**.
 4. In the Repository Server field, type the appropriately formatted address and port number for the FTP or SFTP location.
 5. In the Document Path field, type the directory path of the folder beginning at the root of FTP or SFTP services. For example, //directoryname/foldername.
 6. Under Login Credentials to Access the Destination, select an option:
 - **Authenticated User and Domain** instructs the printer to use the user name and domain of the logged-in user when accessing the repository.
 - **Logged-in User** instructs the printer to log in to the repository using the credentials of the logged-in user.
 - **System** instructs the printer to use specific credentials when accessing the repository. If you select System, type the credentials in the User Name and Password fields. To update an existing password, select **Select to save new password**.
 7. Click **Apply**.

Configuring a Fax Repository Using SMB

Before you begin:

- Create a shared folder to be used as a fax repository. Note the share name of the folder and the computer name or server name.
 - Create a user account and password for the printer with full access rights to the fax repository. Note the user account and password.
1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
 2. Click **Server Fax > Fax Repository Setup**.
 3. From the Protocol menu, select **SMB**.
 4. Select the address type. Options are **IPv4** or **Host Name**.
 5. Type the appropriately formatted address in the Repository Server field for the server where the file repository is located.
 6. In the Share field, type the share name.
 7. In the Document Path field, type the directory path of the folder starting at the root of the shared folder. For example, if you have a folder named scans in the shared folder, type **\scans**.
 8. Under Login Credentials to Access the Destination, select an option:
 - **Authenticated User and Domain** instructs the printer to use the user name and domain of the logged-in user when accessing the repository.
 - **Logged-in User** instructs the printer to log in to the repository using the credentials of the logged-in user.
 - **System** instructs the printer to use specific credentials when accessing the repository. If you select System, type the credentials in the User Name and Password fields. To update an existing password, select **Select to save new password**.
 9. Click **Apply**.

Configuring a Fax Repository Using HTTP/HTTPS

Before you begin:

- Ensure that Web services are installed on the server where you want to store scanned images. Examples of Web servers include Microsoft Internet Information Services (IIS) and Apache. Note the IP address or host name of the server.
 - For HTTPS, ensure that your Web server is installed with a secure certificate.
 - Create a user account and password for the printer. When a document is scanned, the printer logs in using the account, transfers the file to the server or workstation and logs out. Note the user account and password details.
 - Create a directory on the HTTP/HTTPS server to use as a scan filing location. Note the directory path.
 - Note any script that is required to be run.
1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
 2. Click **Server Fax > Fax Repository Setup**.
 3. From the Protocol menu, select **HTTP** or **HTTPS**.
 4. Select the address type. Options are **IPv4 Address**, **IPv6 Address**, or **Host Name**.
 5. Type the appropriately formatted address and port number of your server.
 6. To verify that a digital certificate is installed on the printer, for HTTPS, click **View Trusted SSL Certificates**.
 7. To validate the SSL certificate used for HTTPS, select **Validate Repository SSL Certificate**.
 8. In the Script path and filename field, type the path to the CGI script starting at the root. For example, `//directoryname/foldername`.
 9. In the Document Path field, type the directory path of the folder.
 10. Under Login Credentials to Access the Destination, select an option:
 - **Authenticated User and Domain** instructs the printer to use the user name and domain of the logged-in user when accessing the repository.
 - **Logged-in User** instructs the printer to log in to the repository using the credentials of the logged-in user.
 - **System** instructs the printer to use specific credentials when accessing the repository. If you select System, type the credentials in the User Name and Password fields. To update an existing password, select **Select to save new password**.
 - **None** instructs the printer to access the repository without providing credentials.
 11. Click **Apply**.

Configuring a Fax Repository Using SMTP

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Server Fax > Fax Repository Setup**.
3. Select **SMTP** from the Protocol menu.
4. Type the domain name of your SMTP server in the **Domain Name** field.
5. In the Default "From:" Address field, type the address you want to display automatically on the fax.
6. To enable email security, select **Enable**.
7. Click **Apply** to save the new settings or **Undo** to retain the previous settings.

Configuring a Fax Repository Using Netware

Before you begin:

Enable and configure Netware settings. For details, see [NetWare](#) on page 55.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Server Fax > Fax Repository Setup**.
3. From the Protocol menu, select **NetWare**.
4. Type the Repository Server, Server Volume, NDS Tree, NDS Context, and Document Path.
5. Under Login Credentials to Access the Destination, select an option:
 - **Authenticated User and Domain** instructs the printer to use the user name and domain of the logged-in user when accessing the repository.
 - **Logged-in User** instructs the printer to log in to the repository using the credentials of the logged-in user.
 - **System** instructs the printer to use specific credentials when accessing the repository. If you select System, type the credentials in the User Name and Password fields. To update an existing password, select **Select to save new password**.
6. Click **Apply**.

Configuring Server Fax General Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Server Fax > Defaults and Policies**.
3. For General, click **Edit**.
4. For Save Job Log in Repository, select the options to include on the Job Log. The printer adds the selected fields to the job log saved on the server.
5. To print a confirmation sheet after every server fax job, under Confirmation Sheet, select **On**. The confirmation sheet specifies the success or failure of the server fax job. If the fax is successful, the location of the document on the fax server is also specified. **Errors Only** instructs the printer to print a confirmation sheet only when a transmission error occurs. The confirmation sheet lists error information and indicates that the job has reached the SMTP server. The confirmation sheet does not indicate that the email message was delivered.
6. Click **Save**.

Configuring Server Fax Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Server Fax > Defaults and Policies**.
3. For Server Fax, click **Edit**.
4. Select the desired options.
5. Click **Save**.

Configuring Server Fax Image-Quality Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Server Fax > Defaults and Policies**.
3. For Image Quality, click **Edit**.
4. Select the desired options.
5. Click **Save**.

Configuring Layout Adjustment Settings

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Server Fax > Defaults and Policies**.
3. For Layout Adjustment, click **Edit**.
4. Select the desired options.
5. Click **Save**.

Configuring Server Fax Filing Options

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Server Fax > Defaults and Policies**.
3. For Filing Options, click **Edit**.
4. To set the time of day a fax is sent, next to Delay Start, click **Specific Time**.
5. Click **Save**.

Internet Fax

Internet fax allows you to scan documents at the control panel, send them to destination email addresses, or receive and print emails with attachments. You can also print a transmission report. A telephone line connection is not required.

Accessing the Internet Fax Setup Page

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Internet Fax > Setup**.

Configuring Required Settings

1. On the Internet Fax Setup page, click the **Required Settings** tab.
2. To configure SMTP settings, next to SMTP, click **Edit**. For details, see [SMTP](#) on page 64.
3. To configure POP3 settings, next to POP3, click **Edit**. For details, see [POP3](#) on page 58.

Configuring General Internet Fax Settings

1. On the Internet Fax Setup page, click the **General** tab.
2. To print a report after all recipients receive the fax, next to acknowledgment report, select **Print Report**.
Note: The report can be delayed depending on the response time of the recipient.
3. To print an activity report after 50 jobs have been processed, next to Activity Report, select **Enable**. An activity report lists Internet fax jobs and the current delivery status of each job. To print an activity report, click **Print Activity Report**.
4. To set the time that the printer waits for a delivery confirmation from recipients, type the time in hours next to Delivery Confirmation Timeout.
5. For Subject, type the text that you want to appear in the subject line of emails sent from the printer.
6. Next to Message body, type the text that you want to appear in the body of emails.
7. To include the user name or email address in the body of emails, under User, select **User Name** or **Email Address**.
8. To include attachment information in the message body, select **Number of Images**, or **Attachment File Type**.
9. To include information about the printer in the body, under Multifunction Device System, select the information that you want to include.
10. Next to Signature, type the information that appears at the end of the email message.

11. Next to Confirmation Sheet, select an option:
 - **Errors Only** instructs the printer to print a confirmation sheet only when a transmission error occurs. The confirmation sheet lists error information and indicates that the job has reached the SMTP server. The confirmation sheet does not indicate that the email message was delivered.
 - **On** instructs the printer to print a confirmation sheet.
 - **Off** instructs the printer not to print a confirmation sheet. You can find status about a job in the job log. To see the job log, at the control panel, press **Job Status > Completed Jobs**.
12. Click **Apply**.

Configuring Internet Fax Receive Settings

1. On the Internet Fax Setup page, click the **Receive Settings** tab.
2. To print email messages without attachments, on the Receive Settings Tab, under Filter Options, select **Accept Email with no attachment**.
3. Under Accept the following attachments, select what types of attachments can be received.
4. Under Finishing Options, click the drop-down menu and select the desired settings for **Stapling** and **2-Sided Printing**.
5. To send a Mail Delivery Notification (MDN) email to the requester when the fax job completes, under Receipt Options, select **Send confirmation reply when requested**.
6. To print a cover sheet containing the email message of the requester before printing the fax job, select **Print cover sheet with incoming Email messages**.
7. Click **Apply**.

Configuring Address Book Settings

1. On the Internet Fax Setup page, click the **Address Books** tab.
2. To configure the Address Book settings stored in the printer, on the Address Books tab, next to Device Address Book, under Action, click **Edit**.
3. To use a Network Address book, configure LDAP server settings. Next to Network Address Book (LDAP), under Action, click **Edit**.
4. If you configured Address Book settings stored in the printer, under Policies, Use Device Address Book, to allow users to access the book, select **Yes**. To restrict users from accessing the address book, select **No**.
5. If you configured a Network Address Book, under Policies, under Use Network Address Book (LDAP) to allow users to access this address book, select **Yes**. To restrict users from accessing the address book, select **No**.
6. To set the default address book that users see at the control panel, under Default Address Book View, select an address book.
7. To allow users to create or edit contacts in the Device Address Book from the printer control panel, select **All Users**.
8. Click **Apply**.

Note: If the Network Address Book does not appear, on the LDAP Server configuration page, ensure that Internet fax is not set to No Mappings Available. This setting prevents the Network Address Book from displaying on the Internet fax page. If your LDAP server does not contain a unique Internet fax address field, it can be set to match the heading for email address.

Configuring Default Internet Fax Settings

1. On the Internet Fax Setup page, click the **Defaults** tab.
2. To edit default Internet fax settings, under Internet Fax, click **Edit**.
3. To edit default Image Options, Image Enhancement, Resolution, and Quality/File Size settings, under Advanced Settings, click **Edit**.
4. To edit default Original Orientation, and Original Size settings, under Layout Adjustment, click **Edit**.
5. To edit default File Format and Filename Extension settings, under Internet Fax Options, click **Edit**.

Note: For details, see the Help in Xerox® CentreWare® Internet Services.

Setting File Compression Options

1. On the Internet Fax Setup page, click the **Compression** tab.
2. Select TIFF and PDF settings as needed. For details, see the Help in Xerox® CentreWare® Internet Services.
3. Click **Apply**.

Editing Internet Fax Network Policies

1. On the Internet Fax Setup page, click the **Security** tab.
2. To set the user policies for Internet fax, next to Access Control for Internet Fax Service, click **Edit**.
3. To set domain filter and email filter settings, under Network Policies, click **Edit**.
4. To enable a domain filter list, under Domain Filter settings, select **Allow Domains** or **Block Domains**.
5. Under New Domain, type the domain you want to add to the list and click **Add**.
6. To remove a domain from the list, select a domain, and click **Remove**.
7. To allow LDAP email address searches without the @ symbol, under **Allow LDAP Email Address without the @ Requirement**, select **On**.

Note: If you select **On** under **Allow LDAP Email Address without the @ Requirement**, the number of items returned by an LDAP search can increase.

LAN Fax

Local Area Network (LAN) Fax allows you to send faxes using the print driver on your computer to a fax machine over a telephone line.

For details about using or configuring LAN Fax, see the print driver software help.

Note: Not all printer models support this feature. Some printers require an optional fax hardware kit.

Accounting

9

This chapter includes:

- [Xerox Standard Accounting](#) 210
- [Network Accounting](#) 218
- [Accounting Using an Auxiliary Access Device](#) 223
- [Enabling Accounting in Print Drivers](#) 225
- [Printing a Copy Activity Report.....](#) 226

Xerox Standard Accounting

Xerox® Standard Accounting tracks the numbers of copy, print, scan, and fax jobs for each user. You can set limits to restrict the total number of jobs by type that a user can produce. You can generate reports listing usage data for individual users and groups.

When Xerox® Standard Accounting is enabled, users must log in to the printer before they can access services. Before they can print documents from their computer to the printer, they must provide their account details in the print driver.

Notes:

- If Xerox® Standard Accounting is enabled, you cannot enable other accounting modes.
- Install device drivers and enable accounting in those drivers for all user computers.

You can create a maximum of:

- 2499 unique Xerox® Standard Accounting user IDs
- 500 General Accounts
- 499 Group Accounts

All user IDs must be assigned to one or more group accounts. Xerox® Standard Accounting settings and account data are stored in the printer. Xerox recommends that you use the Cloning feature to back up settings. If Xerox® Standard Accounting settings are lost or deleted, you can restore them using the cloning backup file. For details, see [Cloning](#) on page 238.

Enabling Xerox Standard Accounting

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
2. Click the pencil icon.
3. For Accounting Method, select **Xerox Standard Accounting**.
4. Click **Save**.

Setting Service Tracking Options

1. On the Accounting page, for Action, next to Service Tracking, click **Edit**.
2. For Presets, select an option:
 - **Disable tracking for all services:** This option turns off tracking.
 - **Enable tracking for all services:** This option instructs the printer to track Copies, Prints, Scans, and Faxes.
 - **Custom:** This option allows you to enable tracking for specific services.
3. Click **Save**.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

General and Group Accounts

You can create a group account to track and limit the number of copies, prints, scans, and faxes for a group of users. The number of copies, prints, scans, and faxes of each user are tracked against the user account and the group account. You can limit the usage for each user.

You can create a general account to track the total usage for a group of users. The number of copies, prints, scans, and faxes of each user are not tracked against the user account. The usage is only tracked against the general account. You cannot specify usage limits for a general account.

If a user is associated with a group account and a general account, they can access the printer using the accounting code for either account. Individual copies, prints, scans, and faxes, are tracked against the user and group accounts if the user accesses the printer using the group account. If the user accesses the printer using a general account, the usage is only tracked against the general account and not the user account.

Creating an Account

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
2. For Group and General Accounts, under Action, click **Edit**.
3. Click the **Group Accounts** tab or the **General Accounts** tab.
4. Type a unique Account ID number and a unique Account Name for the new group.
5. Click **Add Account**.

Editing, Viewing, or Deleting an Account

1. On the Group and General Accounts page, click **Group Accounts** or **General Accounts**.
2. To edit the account name, or assign users to an account, under Actions, click **Edit**.
 - a. To assign users to the account, select the check box next to a user ID.
 - b. To edit the Account Name, under Account Name, type a new name.
 - c. Click **Save**.
3. To view usage details for an account, under Actions, click **View Usage**.
4. To delete an account, in the table at the bottom of the page, select the check box next to the account and click **Delete Selected**.

Adding a User and Setting Usage Limits

Before you can associate users with an accounting group, add or import user information to the user database. To edit the user database, see [Configuring Authentication Settings](#) on page 74.

To add a user and set usage limits for the user:

1. On the Accounting page, next to Users and Limits, click **Edit**.
2. Click **Add New User**.
3. For Display Name, type a name for the user. This name is associated with the user in the user database.
4. Type a unique user name for the new user. To log in at the control panel, the user types this name.
5. For Black Impressions, next to Prints or Copies, type the maximum number of impressions or sent images allowed for the user.
6. For Scanned Images, type the maximum number of impressions or sent images allowed for the user.
7. For Fax Images, next to Sent or Black Faxed Impressions, type the maximum number of impressions or sent images allowed for the user.
8. To reset limits, next to an impression or image type, click **Reset**.
9. To reset all limits, click **Reset All**.
10. Click **Apply**.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Managing User Information

You can import or export user information and accounting data as a **.csv** file. For details, see Xerox® CentreWare® Internet Services help.

Importing User Information

1. On the Accounting page, next to Users and Limits, click **Edit**.
2. From the Management Actions menu, select **Import**.
3. Under File, click **Browse** or **Choose File**, select your **.csv** file, and click **Open** or **Choose**.
4. Under Delimiting Character, select an option.
5. Under Language, select the language of the text in your **.csv** file.
6. Under When importing your File, select an option:
 - **Append to existing** adds user information from the **.csv** file to the existing user information stored in the database.
 - **Overwrite existing data** replaces all user information in the database with user information from your **.csv** file.
7. Click **Next**.
8. Under required Fields, under Imported Heading, select the column heading from your **.csv** file containing information to use for User Name and Display Name.
 - a. To build User Name and Display Name from First Name and Last Name, under First Name and Last Name, select a column heading.
 - b. Under User Name and Display Name, select **Build from First and Last Name**.
9. If you created your **.csv** file by exporting from a non-Xerox® printer, the **.csv** file format can contain unwanted characters. To remove unwanted characters from all fields, select **Remove Unwanted Characters**.
 - a. Under Leading Characters, Body Characters, and Trailing Characters, select an option.
 - b. If you selected Custom String, type the string of characters that you want to remove from each field.
10. Under Limits, select an option:
 - **Quick Setup for All Users** allows you to set a default limit for all services for all users. Under Default for All Services, type the limit.
 - **Manual Setup for All Users** allows you to set the limit for each service and impression type. Under User Limits, type the limit.
 - **Import Existing Limits from File** allows you to import limits from your **.csv** file. Under Imported heading, select the column heading from your **.csv** file to use for the limit for each service and impression type.

Note: Limits must be in the range of 0–16,000,000. If you do not assign a limit, the limit is set to 16,000,000.

11. Under Accounts, under Group Accounts, select the default group to which you want to add imported users:
 - **Use System Default** adds all users to the current system default group.
 - **Assign New Account** allows you to create an account and add all users to the account. Under Group Account ID, type a unique Account ID number and a unique Account Name for the new group. Select **Make this the new system default group** account as needed.
 - **Import Existing Accounts from File** allows you to import accounts from your **.csv** file. Under Imported heading, select the column heading from your **.csv** file to use for the Group Account ID and Group Account Name.

Notes:

- Combine Account ID and Account Name in a single column. Use a colon (:) to separate Account Name and Account ID. For example, **123:account_A**.
 - You can associate a user with multiple accounts. Separate the account names using a # symbol. For example, **111:account_A#222:account_B**. The first account is the default user account. To associate a user with multiple accounts, but use the default system account, type the # symbol, then type the account names. For example, **#222:account_B**.
12. Under General Accounts, select an option:
 - **No General Accounts** does not add users to a General Account.
 - **Import Existing Accounts from File** allows you to import accounts from your **.csv** file. Under Imported heading, select the column heading from your **.csv** file to use for the General Account ID and General Account Name.

Notes:

- Combine Account ID and Account Name in a single column. Use a colon (:) to separate Account Name and Account ID. For example, **123:account_A**.
 - You can associate a user with multiple accounts. Separate the account names using a # symbol. For example, **111:account_A#222:account_B**.
13. Click **Import**.

Downloading a Sample File

You can download a sample file to see how to format your **.csv** file for import.

1. On the Accounting page, next to Users and Limits, click **Edit**.
2. From the Management Actions menu, select **Download Sample**.
3. Under Delimiting Character, select an option.
4. Under Language, select the language of the text in your **.csv** file.
5. Click **Generate**.

Exporting User Information

1. On the Accounting page, next to Users and Limits, click **Edit**.
2. From the Management Actions menu, select **Export**.
3. Under Delimiting Character, select an option.
4. Under Language, select the language of the text in your **.csv** file.
5. Click **Export**.

Assigning Users to an Account

1. On the Accounting page, next to Users and Limits, click **Edit**.
2. Select the check box next to the User ID of the user that you want to add to an account.
3. Under Action, click **Access, Limits, & Accounts**.
4. Click the **Group Accounts** tab or the **General Accounts** tab.
5. Select the check box next to the User ID of the user that you want to add to an account.
6. Click **Apply**.

Usage Limits

The system administrator can set individual usage limits on access to printer features. Once a user reaches the established limit for a printer feature, the printer rejects access to the feature. The system administrator can reset the usage limit on each printer feature.

If the user reaches a feature limit during a print job, the printer generates an error report and deletes the job. If any sheets of paper remain in the paper path, the printer completes the print job. Once the system administrator resets the usage limit, the printer subtracts any excess impressions from the new usage limit.

The following details describe common usage limits and types for monochrome printers.

- The maximum number of impressions or images sent is 16,000,000.
- Cover sheets, banner pages, fax acknowledgment reports, and scan confirmation reports count as impressions.
- Black Impression Prints includes all black and white print jobs and received server fax documents.
- Black Impression Copies includes all black and white copies.
- Scanned Images includes documents sent over the network, including network scans, scans to email, server faxes, and Internet faxes.
- Fax Images Sent includes faxed documents. The total number of documents is the number of faxed documents, including cover sheets, multiplied by the number of destinations. Documents sent that use the server fax feature are not included.
- Black Fax Impressions includes received fax documents that are printed. Documents sent that use the server fax feature are not included.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Downloading a Usage Report

The usage report lists the number of impressions recorded for each user and each account. You can download a usage report as a **.csv** file.

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
2. Click **Report and Reset**.
3. To export user ID information in the report, for Show User ID in Report, select **Yes**.
4. Click **Download Report**.

Resetting Usage Limits

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
2. Click **Report and Reset**.
3. Click **Resets**.
4. To reset all usage data to zero, click **Reset Usage Data**.
5. Click **OK** to acknowledge the warning message.

Configuring Validation Policies and Print Job Exceptions

Unidentified jobs are jobs that are not associated with a user name. Unidentified jobs originate from a computer that does not require a user to log in. Examples are a job sent from a DOS or UNIX window using LPR, Port 9100, or from the Jobs tab in Xerox® CentreWare® Internet Services. Unidentified print jobs can originate from IPP clients, including mobile clients that support AirPrint and Mopria. You can set validation policies and configure print job exceptions for unidentified print jobs.

Validating Accounting Codes

To set the printer to validate the accounting code for all jobs:

1. Ensure Xerox Standard Accounting is enabled. For details, see [Enabling Xerox Standard Accounting](#) on page 210.
2. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
3. To configure Validation Policies and Print Job Exceptions, under Action, for Validation Policies/Print Job Exceptions, click **Edit**.
4. For Validate Accounting Code, select **Yes**.
5. Click **Save**.

To configure validation options for unidentified print jobs:

1. Ensure Xerox Standard Accounting is enabled. For details, see [Enabling Xerox Standard Accounting](#) on page 210.
2. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
3. On the Accounting page, for Action, next to Validation Policies/Print Job Exceptions, click **Edit**.
4. For Validate Accounting Code, select **Yes with Exceptions**.
5. To allow the printer to print unidentified print jobs from any computer, for Exceptions for Jobs Not Containing an Accounting Code, select **Guest Mode**.
6. To allow IPP print jobs, for Exceptions for Jobs Not Containing an Accounting Code, select **IPP Exception Mode**. Select an option.
 - **Track IPP jobs with invalid accounting codes against the IPP Exception User and Account IDs:** Use this option to allow print jobs with invalid accounting codes from IPP sources. This configuration prevents rejection of jobs from IPP clients such as AirPrint and Mopria.
 - **Reject IPP jobs with invalid accounting codes:** Use this option to reject print jobs with invalid accounting codes.

Note: Apple iOS7 and iOS8 clients send an unalterable accounting user ID value of **mobile**. To allow jobs from iOS7 and iOS8 clients, select **Track IPP jobs with invalid accounting codes against the IPP Exception User and Account IDs**.
7. To allow unidentified print jobs from specific sources only, for Exceptions for Jobs Not Containing an Accounting Code, select **Designated Source Mode**. The printer deletes invalid unidentified print jobs.
 - a. To specify the computers or other sources that are allowed to send unidentified print jobs in Designated Source Mode, click **Add Device**.
 - b. Select IPv4 Address or Host Name.
 - c. Type the address of the source that is allowed to send unidentified print jobs.
 - d. For User ID, select the information that the printer uses for the User ID. If you selected Custom, type the User ID.
 - e. Click **Save**.
8. Click **Save**.

Network Accounting

Network Accounting allows you to manage printer usage with detailed cost analysis capabilities. Print, scan, fax, and copy jobs are tracked at the printer and stored in a job log. All jobs require authentication of User ID and Account ID, which are logged with the job details in the job log. Users are prompted for accounting information when submitting jobs to the printer.

You can compile the accounting server job log information and format it into reports.

Before you begin:

- Install and configure Xerox® certified network accounting software on your network. Refer to the manufacturer instructions for help.
- Test communication between the accounting server and the printer. Open a Web browser, type the IP Address of the printer in the address bar, then press **Enter**. The printer Xerox® CentreWare® Internet Services home page appears.
- To track print and LAN Fax jobs, install print drivers on all user computers.

Enabling Network Accounting

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
2. Click the pencil icon.
3. For Current Accounting Method, select **Network Accounting**.
4. Click **Save**.

Setting Network Accounting Workflow Options

1. On the Accounting page, under Action, next to Accounting Workflow, click **Edit**.
2. Under Accounting Workflow, next to each Job Type, select an option:
 - **Pre-Authorization and Capture Usage** requires a job limits server to approve each job that a user attempts to send or print. The job limits server approves a job based on the credentials of the user and the configured job attributes.
 - **Capture Usage** only tracks usage.
3. If you selected Capture Usage, click **Save**.
4. If you selected Pre-Authorization and Capture Usage for Print Jobs, under Pre-Authorization Communication Error Notification, select an option:
 - **None** instructs the printer not to notify users if pre-authorization fails.
 - **Print Error Sheet** instructs the printer to print an error sheet if pre-authorization fails.
 - **Touch User Interface** instructs the printer to display a message on the control panel touch screen if pre-authorization fails.
5. If you selected Pre-Authorization and Capture Usage for any Job Types, click **Next** and configure Job Limit server settings.
6. Under Server URL, type the URL of your job limits server.
7. Under Timeout, type the time in seconds that the printer waits for the job limits server to respond to job approval requests before it disconnects.
8. Click **Save**.

Configuring Job Limits Server Settings

1. On the Accounting page, under Action, next to Job Limits Server (Pre-Authorization), click **Edit**.
2. Under Server URL, type the URL of your job limits server.
3. Under Timeout, type the time in seconds that the printer waits for the job limits server to respond to job approval requests before it disconnects.
4. Click **Save**.

Configuring User Prompts

An accounting prompt is the text that prompts users to enter accounting information at the control panel. You can enable up to two prompts, as your validation server requires. For example, if your company uses a unique numeric identifier for each department, you can use that number as the accounting code. Then, you can customize the prompt text to ask users for a Department ID Code, rather than a User ID or Account ID. You can customize accounting prompts.

Notes:

- Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.
 - When prompts are turned off, jobs that do not contain an accounting ID are tracked with a generic code.
1. On the Accounting page, for Action, next to User Accounting Prompts, click **Edit**.
 2. To display prompt 1 or 2, for Display Prompt, select **Yes**. To hide prompts, select **No**.
 3. For Label and Default Value, type the text that you want to appear at the control panel.
 4. To hide text that users type at the control panel, for Mask Entries, select **Yes**. Asterisks * replace any characters that users type in the field.
 5. To check that accounting credentials entered at the control panel conform to the format specified by your validation server, for Validation, select **Enabled**.
 6. For Prompt Options, under Presets, select an option, or select **Prompt** or **No Prompt** for each service as needed.

Disabling the Job Limits Web Service

If your accounting solution provider recommends disabling the Job Limits Web service, or if your job limits server only requires client-based calls, disable the service.

1. On the Accounting page, for Action, next to Job Limits Web Service, click **Edit**.
2. For Authentication and Accounting, next to Job Limits, clear the check box.
3. Click **Save**.

Configuring Validation Policies and Print Job Exceptions

Unidentified jobs are jobs that are not associated with a user name. Unidentified jobs originate from a computer that does not require a user to log in. Examples are a job sent from a DOS or UNIX window using LPR, Port 9100, or from the Jobs tab in Xerox® CentreWare® Internet Services. Unidentified print jobs can originate from IPP clients, including mobile clients that support AirPrint and Mopria. You can set validation policies and configure print job exceptions for unidentified print jobs.

Validating Accounting Codes

To set the printer to validate the accounting code for all jobs:

1. Ensure Network Accounting is enabled. For details, see [Enabling Network Accounting](#) on page 218.
2. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
3. On the Accounting Methods page, for Action, next to Validation Policies/Print Job Exceptions, click **Edit**.
4. For Enablement, select **Enabled**.
5. For Validate Accounting Code, select **Yes**.
6. Click **Save**.

To configure validation options for unidentified print jobs:

1. Ensure Network Accounting is enabled. For details, see [Enabling Network Accounting](#) on page 218.
2. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
3. On the Accounting Methods page, for Action, next to Validation Policies/Print Job Exceptions, click **Edit**.
4. For Enablement, select **Enabled**.
5. For Validate Accounting Code, select **Yes with Exceptions**.
6. To allow the printer to print unidentified print jobs from any computer, for Exceptions for Jobs Not Containing an Accounting Code, select **Guest Mode**.
7. To allow IPP print jobs, for Exceptions for Jobs Not Containing an Accounting Code, select **IPP Exception Mode**. Select an option.
 - **Track IPP jobs with invalid accounting codes against the IPP Exception User and Account IDs:** Use this option to allow print jobs with invalid accounting codes from IPP sources. This configuration prevents rejection of jobs from IPP clients such as AirPrint and Mopria.
 - **Reject IPP jobs with invalid accounting codes:** Use this option to reject print jobs with invalid accounting codes.

Note: Apple iOS7 and iOS8 clients send an unalterable accounting user ID value of **mobile**. To allow jobs from iOS7 and iOS8 clients, select **Track IPP jobs with invalid accounting codes against the IPP Exception User and Account IDs**.

8. To allow unidentified print jobs from specific sources only, for Exceptions for Jobs Not Containing an Accounting Code, select **Designated Source Mode**. The printer deletes invalid unidentified print jobs.

Note: The printer deletes invalid unidentified print jobs.

- a. To specify the computers or other sources that are allowed to send unidentified print jobs in Designated Source Mode, click **Add Device**.
 - b. Select IPv4 Address or Host Name.
 - c. Type the address of the source that is allowed to send unidentified print jobs.
 - d. For User ID, select the information that the printer uses for the User ID. If you selected Custom, type the User ID.
 - e. Click **Save**.
9. Click **Save**.

Accounting Using an Auxiliary Access Device

You can configure the printer to use an auxiliary access device for accounting.

Before you begin, purchase and install the Auxiliary Interface Kit. An Auxiliary Interface Kit, or a Foreign Device Interface Kit, is a third-party access and accounting device. These kits, such as a coin operated printer accessory or a card reader, can be attached to the printer. Installation instructions are included with the Foreign Device Interface Kit.

Enabling Accounting Using an Auxiliary Access Device

1. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
2. Click **Edit**.
3. For Accounting Method, select **Auxiliary Access Device**.
4. Click **Save**.

Displaying Your Company Logo on the Blocking Screen

You can customize the blocking screen to display your company logo. The blocking screen appears on the printer touch screen when card reader authentication or an auxiliary accounting device is configured. The screen displays a message when a user attempts to access a restricted feature, reminding users to swipe an identification card to access the feature.

Displaying Your Company Logo on the Blocking Screen

1. On the Accounting Methods page, for Import Customer Logo, click **Import**.
2. Click **Browse** or **Choose File**.
3. Select a **.png** file that is not larger than 300 x 200 pixels, then click **Open**.
4. Click **Import**.
5. Click **Reboot Device**.

Setting the Auxiliary Access Device Type

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Accounting Settings > Accounting Mode**.
3. Touch **Auxiliary Access > Auxiliary Device Type**.
4. Touch your auxiliary access device type.
5. Touch **OK**.

Selecting Services to Restrict or Track

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Accounting Settings > Accounting Mode**.
3. Touch **Auxiliary Access > Service Access and Accounting**.
4. To track usage of the copy and printing services, under Select the services you want to track usage, select an option.
5. To restrict particular services, under Select the services you want to restrict, select an option.
6. Touch **OK**.

Setting the Job Timeout

1. Touch **OK**.
2. In Xerox® CentreWare® Internet Services, click **Properties > Login/Permissions/Accounting > Accounting Methods**.
3. Click **Edit**.
4. For Accounting Method, select **Auxiliary Access Device**.
5. Click **Save**.
6. For Configuration Settings, click **Job Timeout**.
7. For Settings, click **Enable**.
8. To specify the amount of time that the printer waits before it deletes a job, for Job Timeout, enter the time in seconds. The printer only deletes held print jobs or jobs that are waiting for payment.
9. Click **Save**.

Enabling Accounting in Print Drivers

Enabling Accounting in a Windows Print Driver

1. From the Start menu, select **Printers and Faxes**.
2. Right-click the printer in the list, then select **Properties > Configuration > Accounting**.
3. From the Accounting System menu, select **Xerox Standard Accounting or Auditron**, or **Xerox Network Accounting**.
4. To prompt users to type their User ID and Account ID each time they print, select **Always Prompt**. If you do not want users to log in, select **Do Not Prompt** and type the user information in the Default User ID and Default Account ID fields. Select **Mask User ID** and **Mask Account ID** to show characters as asterisks when an ID is entered.
5. Select **Remember Last Entered Codes** to show the last entered code when a user is prompted for their Account ID.
6. If you are using Xerox Standard Accounting with an external accounting device, select **Auxiliary Accounting Interface**.
7. To specify the default User ID and Account ID, type them in the Default User ID and Default Account ID fields, then select the default account type.
8. Click **OK**.
9. Click **OK** to exit.

Enabling Accounting in an Apple Macintosh Print Driver

Users must select this preset each time they print or send a LAN fax using the print driver.

1. Open a document and select **File**, then select **Print**.
2. Select the Xerox® printer.
3. From the menu, select **Accounting**.
4. For Accounting System, select **Xerox Standard Accounting**, **Auditron**, or **Xerox Network Accounting**.
5. If you want users to type their User ID and Account ID every time they print, select **Prompt for Every Job**.
6. To show characters as asterisks when the user types an ID, select **Mask User ID** and **Mask Account ID**.
7. To specify the default User ID and Account ID, type them in the Default User ID and Default Account ID fields, then select the default account type.
8. To use Xerox Standard Accounting with an external accounting device, select **Auxiliary Accounting Interface**.
9. To save your settings, click the **Presets** menu, then select **Save As**.
10. Type a name for the preset.
11. Click **OK**.

Printing a Copy Activity Report

The copy activity report is a usage report that prints after each copy session. The report lists details about the job and the number of copies made during the session.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Accounting Settings > Copy Activity Report**.
3. Touch **Enabled**.
4. Touch **OK**.

Administrator Tools

10

This chapter includes:

• Monitoring Alerts and Status	228
• Energy Saving Settings	230
• Remote Control Panel	232
• Entry Screen Defaults	233
• Smart eSolutions and Billing Information.....	234
• Billing Impression Mode	237
• Cloning	238
• Address Books	239
• Font Management Utility	245
• Network Logs	246
• Customizing Printer Contact Information	247
• Display Device Information	248
• Xerox Online Support	249
• Restarting the Printer in Xerox® CentreWare® Internet Services.....	250
• Restarting the Printer at the Control Panel	251
• Taking the Printer Offline	252
• Erase Customer Data	253
• Resetting the User Interface to Factory Default Settings.....	254
• Updating the Printer Software	255
• Adjusting Color, Image, and Text Detection Settings	257

Monitoring Alerts and Status

The Description and Alerts page displays printer information, such as printer name and location, as well as a list of any current alerts. You can view alert information, such as the status code, description of the issue, and the suggested skill level required to resolve the problem.

To view alerts:

1. In Xerox® CentreWare® Internet Services, click **Status > Description & Alerts**.
The Description and Alerts page appears.
2. To update the page, click **Refresh**.

Alert Notification

There are several ways to set the printer to send out notifications when alerts occur. Possible alert types include low supply status, paper supply status, and paper jams.

Email Alerts

You can define groups to receive email notifications when selected status alerts occur on the printer.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Alert Notification > Email Alerts**.
3. Under Recipient Group Addresses, select which group you want to enable and type up to five email addresses to receive selected alerts.
4. Under Recipient Group Preferences, for the group you created, select the type of alerts that cause email notifications to occur. You can set up to three separate groups to receive any combination of email alerts.
5. To view definitions of the alert types, click **(Glossary)** under Status Codes in the Recipient Group Preferences area.
6. In **"Reply to:" Email Address**, type the email address of the administrator or user designated to receive any replies sent by Alert Notification group members.
7. Type a number between **0–60** minutes for **Set jam timer for release of status to selected groups** to specify how long the printer waits after a jam is detected before it sends an email status message. The default time is 0 minutes.
8. Click **Apply** to save the new settings or **Undo** to retain the previous settings.

Local UI Alerts

You can specify when you want the printer to display a warning on the control panel.

Setting Scan Disk Memory Warning

You can specify when you want the printer to display a warning on the control panel if the printer scan disk memory is low. Low memory can cause the printer to slow down or lose jobs.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Alert Notification > Local UI Alerts**.
3. For Scan Disk Memory Warning, select the estimated number of scanned pages that the printer can hold in scan memory before a warning appears.

Note: The higher the number of pages that you select, the more frequently warnings appear.

Setting Low Supply Warning

You can set the printer to display a warning on the control panel when supplies reach a low level.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Alert Notification > Local UI Alerts**.
3. For Scan Disk Memory Warning, select the estimated number of scanned pages that the printer can hold in scan memory before a warning appears.
4. To display low supply warnings on the control panel, select **Display Low Supply Warnings on the device's touch screen**.
5. Click **Apply**.

Configuring Low Supply Warning

To set when the printer displays low supply warnings:

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Alert Notification > Low Supply Warning**.
3. From the menu for each supply, select when you want the printer to display an alert in the printer status region. The range is 0–20 days.
4. Click **Apply**.

Notes:

- You can view the status on the Description & Alerts page under Status.
- To view current supplies status, click **Status > Supplies**.

Energy Saving Settings

Setting Energy Saver Mode

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup > Energy Saver**.
2. For Exit Sleep Mode Strategy, select an option:
 - **Intelligent Ready:** The printer wakes and sleeps based on previous usage.
 - **Job Activated:** The printer wakes when it detects activity.
 - To set the delay before the printer enters Low-Power mode, for Ready Mode, enter the minutes.
 - To set the delay before the printer enters Sleep mode, for Low Power Mode, enter the minutes
 - Click **Apply**.
 - **Scheduled:** The printer wakes and sleeps according to a schedule that you specify. To specify the schedule:
 - To allow the printer to wake when it senses activity on a specific day of the week, for Schedule Based on, select **Activity**.
 - To wake the printer at a specific time for any day of the week, for Schedule Based On, select **Time**. To set the time that the printer wakes up, select a **Warm Up time**. To specify the time that the printer sleeps, select an **Energy Saver** time.
3. To allow the printer to poll Novell print queues, select **Resume Network Controller Briefly to Poll Novell Print Queues During Sleep Mode**. Type the time in seconds to define the interval that the printer uses to come out of sleep mode.
4. To allow the printer to broadcast SAP during sleep mode, select **Resume Network Controller Briefly to Broadcast Service Advertising Protocol (SAP) During Sleep Mode**. Type the time in seconds to define the interval that the printer uses to come out of sleep mode.
5. Click **Apply**.

Configuring Energy Saver Settings at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > General > Energy Saver**.

Note: If this feature does not appear, log in as a system administrator. For details, see [Logging In as the System Administrator at the Control Panel](#) on page 21.

3. On the Energy Saver screen, select an option:
 - **Intelligent Ready:** The printer wakes and sleeps based on previous usage.
 - **Job Activated:** The printer wakes when it detects activity. To change the default Low-Power and Sleep timeout periods, touch **Energy Saver Timers**.
 - To set the delay before the printer enters Low-Power mode, touch the Minutes field, then to set the number, touch the arrows.
 - To set the delay before the printer enters Sleep mode, touch the Minutes field, then to set a number, touch the arrows.
 - Touch **OK**.
 - **Scheduled:** The printer wakes and sleeps according to a schedule that you specify. To specify the schedule, touch **Scheduled Settings**.
 - Touch a day of the week in the list.
 - To allow the printer to wake when it senses activity on that day, touch **Activity**.
 - To wake the printer at a specific time, touch **Time**. To set the time that the printer wakes up on the specified day, touch **Warm Up Time**, then to select the time, touch the arrows. Touch **OK**. To specify the time that the printer sleeps on the specified day, touch **Energy Saver Time**, then to select the time, touch the arrows. Touch **OK**.
 - Touch **OK**.
4. Touch **OK**.

Remote Control Panel

The Remote Control Panel allows you to access the control panel of the printer from a Web browser.

To enable the Remote Control Panel feature:

1. In Xerox® CentreWare® Internet Services, click **Support** > **Remote Control Panel**.
2. For Configuration, click **Edit**.
3. For Enablement, select **Enable**, then select an option:
 - **For Admin only:** This option allows system administrators to access the Remote Control Panel.
 - **For Admin and Diagnostics Users only:** This option allows system administrators and Xerox representatives to access the Remote Control Panel.
 - **For All Users:** This option allows all users to access the Remote Control Panel.
4. Click **Save**.

To restrict other users from accessing the control panel while you are connected, select **Block Local Control Panel**. A message appears if a user attempts to access the control panel.

To access the control panel remotely, click **Open Remote Control Panel**.

Entry Screen Defaults

Use this page to set the default screens that appear on the touch screen when you press buttons on the printer control panel.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Entry Screen Defaults**.
3. Under Services, select the default screen that appears when you press the **Services** button on the control panel.
4. Under Job Status, select the default screen that appears when you press the **Job Status** button on the control panel.
5. Under Default Walk-Up Screen, select the screen that appears when you walk up to the printer.
6. Under Default Screen when Originals are Detected, select the screen that appears when you load original documents.
7. Click **Apply**.

Smart eSolutions and Billing Information

Smart eSolutions

Smart eSolutions is a suite of features that simplifies printer ownership and administration. It provides free services to enable administration of metered billing and supplies replenishment plans for printers on a network.

Before you can use Smart eSolutions, register the printer for Smart eSolutions. There are three ways to register the printer for Smart eSolutions:

- **Automatic registration** is available as a standard feature on many printer models.
- **Xerox® Device Agent-Lite** is an option for small and medium-sized businesses. To download the client, see www.xerox.com/smartesolutions.
- **Xerox® CentreWare® Web** is a browser-based software tool that installs, configures, manages, monitors, and reports on all network printers and multifunction printers, regardless of manufacturer. Xerox® CentreWare® Web is suited for large enterprise businesses. For details, see www.xerox.com/centrewareweb.

Note: Smart eSolutions is not available in all countries. See your Xerox representative for details.

Before You Begin

- If your network uses an HTTP proxy server, provide information about your proxy server on the HTTP Proxy Server page.
- Ensure that the printer recognizes your DNS server. For details, see [DNS](#) on page 44.

Enabling Smart eSolutions

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Smart eSolutions Setup**.
3. Under Enrollment, select **Enrolled**.
4. Under Daily Transmission Time, type the time of day that you want the printer to perform its daily communication with Xerox.
5. Click **Apply**.
6. If your network uses an HTTP proxy server, provide information about your proxy server on the HTTP Proxy Server page. Next to HTTP Proxy Server, click **Configure**.
 - a. On the Proxy Server page, under HTTP Proxy Server, select **Enabled**.
 - b. Select the Proxy Server address type. Options are **IPv4 Address**, **IPv6 Address**, or **Host Name**.
 - c. Type the appropriately formatted address or host name of your server and change the default port number as needed.
 - d. Click **Save**.
7. To verify communication with the Xerox® server, on the Smart eSolutions Setup page, click **Test Communication Now**. Under Communication Setup, a status message appears indicating if your printer is able to communicate with Xerox.

MeterAssistant

MeterAssistant automatically submits meter reads to Xerox from network printers. This process eliminates the need to collect and report meter read information manually.

To view the last transmission of Billing Meter information for your printer:

1. In Xerox® CentreWare® Internet Services, click **Status > SMart eSolutions**.
2. Click **MeterAssistant®**.

The number of impressions is listed in the table.

Note: If the count is zero, no data has been transmitted to Xerox®.

3. Click **Edit** to enable Meter email alerts.

For details on setting up alerts, see [Setting up Alert Notification](#) on page 228.

SuppliesAssistant

SuppliesAssistant monitors the remaining life of the toner or ink, and other printer consumables. When Smart eSolutions is configured to communicate with Xerox, SuppliesAssistant also monitors the usage of consumables. The data reported to Xerox is used to replenish supplies.

1. In Xerox® CentreWare® Internet Services, click **Status > SMart eSolutions**.
2. Click **SuppliesAssistant**. The supply list appears with the current % Life Remaining of each supply item.

Note: If the % Life Remaining is unknown, no data has been transmitted to Xerox.

Maintenance Assistant

Maintenance Assistant provides options for troubleshooting your printer. You can send detailed diagnostic information to Xerox®, start online troubleshooting sessions with Xerox®, and download usage information to your computer in **.csv** format.

1. In Xerox® CentreWare® Internet Services, click **Status > SMart eSolutions**.
2. Click **Maintenance Assistant**.
3. Click one of the following:
 - **Send Diagnostic Information to Xerox**
 - **Start an Online Troubleshooting Session at www.xerox.com**
 - **Download file to your computer:** Right-click and download the **UsageLog.csv** file to your computer.

View Usage and Billing Information

Usage Counters

The Usage Counters page displays the total number of pages printed or generated by the printer. You can see usage amounts for impressions made, sheets, images used, and images printed, copied, and faxed.

1. In Xerox® CentreWare® Internet Services, click **Status > Usage Counters**.
2. To update the page, click **Refresh**.
3. To download the list, click **Download File to Your Computer**, then right-click on the link.

Billing Information

The Billing Information page displays current readings for printer counters that are used for billing. You can view the number of impressions made in color or black and white, as well as the total number of impressions. The impression counts shown are used for billing.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

1. In Xerox® CentreWare® Internet Services, click **Status > Billing Information**.
The list of pages printed or created by the printer appears.
2. To update the page, click **Refresh**.

Billing Impression Mode

The Billing Impression Mode defines how the printer tracks impressions made on large-size paper, such as A3 or tabloid size paper.

There are two modes:

- A3 Impressions counts all impressions equally.
- A4 Impressions counts large impressions as their A4 equivalent.

A Xerox representative sets the Billing Impression Mode for your printer.

To change the Billing Impression Mode:

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Billing Impression Mode**.

Note: A personal identification number (PIN) is required to change the billing impression mode. To obtain a PIN, contact your Xerox representative and provide the sequence and serial number information that appears on the Billing Impression Mode page.

3. For PIN, type the number that you obtained from your Xerox representative.
4. Click **Apply**.

Cloning

Cloning allows you to save your current printer settings to a file to use as a backup and restore file for your printer. You can also use a clone file to copy your printer settings to other printers.

- To view all installation policies, click **Security Installation Policy**.
- To restrict installation to administrators, click **Restrict Installation**, then click **OK**.

Notes:

- If you are using a clone file to copy your printer settings to another printer, ensure that both printers are the same model and have the same version of software installed.
- If FIPS 140-2 mode is enabled, you cannot install a clone file.

To determine the software version:

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Configuration Report**.
3. To verify the software installed on your printer, scroll down to **Software Versions**.

Creating a Clone File

1. In Xerox® CentreWare® Internet Services, click **Properties > Cloning**.
2. For Create Clone File, select the features that you want to clone to other printers. All features are selected by default.
3. To view the specific settings that can be cloned for individual features, next to the feature, click **Details**.
4. Click **Clone**.
5. For Cloning Instructions, to download the clone file, right-click **Cloning.dlm** to download the clone file.
6. Click **Save Link As**, then select a name and the location to save the file. The default name for the file is **Cloning.dlm**. If you rename the file, use **.dlm** as the file extension.
7. Click **Save**.

Installing a Clone File

1. In Xerox® CentreWare® Internet Services, click **Properties > Cloning**.
2. Under Install Clone File, click **Browse** or **Choose File**.
3. Browse to the clone file to use, then click **Open**.
4. Click **Install**.
5. Click **OK**.

Address Books

This section includes:

- [Device Address Book](#) 239
- [Network Address Book](#) 244
- [LAN Fax Address Book](#) 244

An address book is a list of individual contacts, each associated with an email address, fax number, or scan destination. You can configure the printer to use a Network Address Book or the Device Address Book for email or Internet fax. The Network Address Book looks up addresses from an LDAP directory. If you do not have an LDAP server, you can use the Device Address Book. If you configure both address books, users are presented with a choice to use either address book at the control panel.

Device Address Book

Email addresses are stored in the Device Address Book. An Internet fax address is the email address assigned to an Internet fax machine or service.

Manually Editing the Address Book

You can use contacts, groups, or Favorites to edit and organize the address book manually.

Viewing Contacts

A contact is a user with an associated email address, fax number, or scan destination. Contacts can be added to groups or marked as a Favorite.

To view a contact, click the **Address** tab, then do one of the following:

- To view all contacts in the address book, under Address Book, select **All Contacts**.
- To view a specific type of contact, under Email, Fax, or Scan To Destination, select **Contacts**.
- To view specific contact information, select the contact from the list.

Adding a Contact

1. In Xerox® CentreWare® Internet Services, click **Address Book**.
2. Click **Add**.

Note: If the Add button is unavailable, the address book has reached its limit. The Device Address Book can contain up to 5000 contacts.

3. Type the contact information:
 - a. To associate a scan destination with this contact, under Scan To Destination, click the **Plus** button. For details, see the Help in Xerox® CentreWare® Internet Services. For details about configuring the Scan To Destination feature, see [Configuring Scan To Destination](#) on page 185.
 - b. To mark a contact as a Favorite for email, fax, or scan to destination, when adding or editing the contact, click the star next to that field. If you click the star next to Display Name, the contact becomes a Global Favorite.
4. Click **Save**, or select **Add Another Contact**, then click **Save & Add Another**.

Managing Groups

Groups allow you to send a file to multiple address book contacts at the same time. Unknown Groups are unrecognized groups that were created in an address book that you imported from another printer. You can convert unknown groups to a fax group, then add or remove contacts from the group as needed.

1. In Xerox® CentreWare® Internet Services, click **Address Book**.
2. Under Fax, select **Groups**, then click **Add Group**.
3. In Group Name, type a name for the group.
4. To make this group a favorite, next to Add Fax Favorite, click the star.
5. To add a contact to the group, from the list of available contacts on the left, select the contact. Contacts in the group appear in the Group Members list to the right. To add all available contacts, click **Add All**.
6. To remove a contact from the group, from the Group Members list on the right, select the contact. To remove all contacts, click **Delete All**.
7. Click **Save**.

Converting an Unknown Group

1. On the Address Book tab, select **Unknown Groups**.
2. Select the group from the list, then click **Edit Group**.
3. Under Group Location, select a group type.

Managing Favorites

You can mark contacts that you frequently use as favorites. A star next to a contact in the list indicates a Favorite. You can mark a favorite as a Global Favorite for all services or as a Favorite for email, fax, or scan to destinations.

To manage favorites:

1. In Xerox® CentreWare® Internet Services, click **Address Book**.
2. To edit a contact marked as a Favorite, select the contact from the Favorite list for that section, then click **Edit Favorite**.
3. To clear a contact marked as a Favorite, select the contact from the Favorite list for that section, click **Delete Favorite**, then click **OK**.
4. Click **Save**.

Importing Addresses Using Email

The Import Using Email feature adds email addresses to the Device Address Book from emails sent to the printer. Use this feature to populate the address book without manually typing address information. You can allow users to send encrypted email by storing encryption certificates from received signed email.

Note: Xerox recommends that you disable the Import Using Email feature after the Device Address Book is populated sufficiently. When this feature is enabled, the Device Address Book can fill quickly. For example, if you send an email message to the printer containing 30 recipient addresses in the CC field, and you allow the printer to add addresses in the CC field, all 30 addresses are added to the address book.

Before You Begin

Configure the POP3 settings. For details, see [POP3](#) on page 58.

Configuring Import Using Email

1. In Xerox® CentreWare® Internet Services, click **Address Book**.
2. Under Management, select **Import Using Email**.
3. Under Enablement, select **On**.
4. To allow the printer to add the email addresses of all senders to the Device Address Book, under Email Type, select **All Emails**. To add email addresses contained in emails sent with a digital signature only, select **Only Signed Emails**.
5. To save digital certificates sent with signed email messages, select **Import encryption certificate from signed emails**.
6. To add email addresses to the Device Address Book from the From, To, and CC fields, under Add all recipients contained in the following email fields, select one or more fields.
7. Click **Apply**.

Importing Device Address Book from File

You can import address book contacts from a **.csv** file.

Notes:

- The printer recognizes the second row in the **.csv** file as the first address book entry. The first row contains headings for the information in each column.
 - To view an example of the appropriate format for the **.csv** file, download a sample file.
1. In Xerox® CentreWare® Internet Services, click **Address Book**.
 2. Under Management, select **Import from File**.
 3. Under Select an Address Book file to import, click **Browse** or **Choose File**, select your **.csv** file, then click **Open** or **Choose**.
 4. Under Record Delimiter, select an option.
 5. Some printer manufacturers allow you to export address book contacts to a **.csv** file, but contact information is enclosed in brackets. To remove brackets when importing this type of **.csv** file, select **Remove brackets from the beginning and end of text fields**.
 6. Select an option:
 - **Add new contacts to existing Device Address Book** adds user information from the **.csv** file to the existing user information stored in the database.
 - **Replace existing Device Address Book with new contacts** replaces all user information in the database with user information from your **.csv** file.
 7. Click **Upload File**.
 8. Click **Import**.
 9. To upload a different address book file or revise the settings, click **Change File/Options**.
 10. If the current address book fields match exactly the imported file fields, the headings do not appear. To see the mapped fields, click **Show Headings List**.
 11. If the current address book fields do not match exactly the imported file fields, the headings appear. The unmapped fields are highlighted. To assign a mapping to the field, select a heading from the list.
 12. Click **Import Address Book**.

Editing the Device Address Book as a .csv File

To manage many addresses, you can create and edit a list in a spreadsheet application. You can save the list as a **.csv** file and upload it to the printer.

Downloading a Sample .csv File

To back up your current address book, you can export the address book as a **.csv** file. To view an example of the appropriate format for the **.csv** file, download a sample file. You can also use the sample file as template, replacing the existing values with your own information.

1. In Xerox® CentreWare® Internet Services, click **Address Book**.
2. Under Management, select **Download Sample**.
3. Under Delimiter, select an option.
4. Select **Export in Legacy Mode** as needed. Legacy Mode omits favorites, groups, fax, and Scan To Destination contact information. Display Name is changed to Friendly Name, allowing you to import the file directly to an older Xerox® printer without mapping address book fields.
5. To exclude Email, Scan to Destination, Fax, or Internet Fax, clear the option.
6. Click **Download**.

Exporting an Address Book File

To back up your current address book, or to import it to another machine, you can export your current address book contacts as a **.csv** file.

1. In Xerox® CentreWare® Internet Services, click **Address Book**.
2. Under Management, select **Export**.
3. Under Delimiter, select an option.
4. Select **Export in Legacy Mode** as needed. Legacy Mode omits favorites, groups, fax, and Scan To Destination contact information. Display Name is changed to Friendly Name, allowing you to import the file directly to an older Xerox® printer without mapping address book fields.
5. Click **Export**.

Configuring Device Address Book Security Settings

You can allow users to edit the Device Address Book, or restrict editing to system administrators only.

1. In Xerox® CentreWare® Internet Services, click **Address Book**.
2. To set user permissions to view and manage the address book, from the Management list, select **Security: User Permissions**.
3. Select one of the following:
 - **System Administrators Only** to require users to log in as an administrator to edit the address book.
 - **Open to All Users** to allow anyone to edit the address book.
4. Click **Save**.

Network Address Book

The Network Address Book looks up addresses from an LDAP directory. If you do not have an LDAP server, you can use the Device Address Book.

Configuring the Network Address Book for Email

Before you begin, configure LDAP server settings. For details, see [LDAP](#) on page 49.

1. In Xerox® CentreWare® Internet Services click **Properties > Services > Email > Setup > Address Books**.
2. Under Policies, under Use Network Address Book (LDAP) to allow users to access this address book, select **Yes**.
3. To set the default address book that users see at the control panel, under Default Address Book View, select an address book.
4. To save, click **Apply**.

Configuring the Network Address Book for Internet Fax

Before you begin, configure LDAP server settings. For details, see [LDAP](#) on page 49.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Internet Fax > Setup > Address Books**.
2. Under Policies, under Use Network Address Book (LDAP) to allow users to access this address book, select **Yes**.
3. To set the default address book that users see at the control panel, under Default Address Book View, select an address book.
4. To save, click **Apply**.

LAN Fax Address Book

The LAN Fax feature has a separate directory for storing and managing addresses. For details about using or configuring the LAN Fax address book, see the driver help.

Font Management Utility

The Xerox® Font Management Utility is a utility that allows you to manage fonts for one or more printers on your network. You can use the font management utility to download your company branded fonts or unicode fonts to support multiple languages on your printer. You can add, delete, or export fonts. You can select printers in the utility printer list that you want to display.

To download Xerox® Font Management Utility, go to www.xerox.com/office/WC3655drivers.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Network Logs

Log files are text files of recent printer activity that are created and stored in the printer. Log files are used to monitor network activity or troubleshoot network problems. A Xerox customer support representative can interpret the encrypted format log files.

Downloading a Network Log

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Network Logs**.
3. For Information Level, select an option.
4. For Additional Content, select the log types that you want to download.
5. Click **Save**.
6. Click **Start Download**.
7. After the information processes, click **Download File Now** and save the files to your computer.
8. To send files to Xerox for diagnostic purposes, click **Send**. To include NVM data with network log push, select the check box, then click **Send**.

Downloading a Network Log to a USB Flash Drive

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Network Settings > Network Logs**.
3. Insert a USB Flash drive in to the USB port on the back of the printer, then touch **Download Log File**.



CAUTION: Do not remove the USB flash drive until the download completes. If you remove the USB flash drive while the download is in progress, the USB flash drive can become damaged.

When the download completes, a confirmation message appears.

4. Remove the USB Flash drive, then touch **Close**.

Customizing Printer Contact Information

The support page in Xerox® CentreWare® Internet Services displays contact information for service and supplies as well as contact information for your system administrator. You can customize this information to display your company details for printer users.

To add your own custom information:

1. In Xerox® CentreWare® Internet Services, click **Support**.
2. Click **Edit Settings**.
3. Update the fields with your information, then click **Apply**.

Display Device Information

You can specify the details, such as device model, IPv4 address, host name, contact name, or HTTP address, to appear on the control panel.

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup > Display Device Information**.
2. To display the required device information, under Information Field, select an option.
3. Click **Apply**.

Xerox Online Support

Xerox Online Support allows you to access and print help, maintenance, and troubleshooting information by touching an icon on the control panel touch screen.

Before you begin:

If your network uses a proxy server, configure the Proxy Server settings of the printer to ensure that the printer can connect to the Internet.

Enabling Xerox Online Support

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Service Registration**.
3. Under Enabled, select the check box next to Xerox Online Support.
4. Click **Apply**.

Restarting the Printer in Xerox® CentreWare® Internet Services

1. In Xerox® CentreWare® Internet Services, click **Status > Description & Alerts**.
2. At the bottom of the page, click **Reboot Machine**, then click **OK**.

Notes:

- If your printer is locked, type the system administrator user name and password to access the Properties tab. The administrator user name is **admin**. Depending on when the device was manufactured, the default administrator password may be the device serial number or **1111**.
- This procedure causes the printer to restart and be unavailable over the network for several minutes.

Restarting the Printer at the Control Panel

Using Software Resets to restart the printer is faster and wastes fewer consumables than powering the printer on and off. Restarting the printer can take up to five minutes during which time Xerox® CentreWare® Internet Services is not available.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Troubleshooting**.
3. Touch **Resets**.
4. Touch **Software Resets**.
5. For Reset Options, select the type of reset that you want.
 - **All Software**
 - **Network Software**
 - **Copy Software**
6. Touch **Reset**.

Taking the Printer Offline

To prevent the printer from either sending or receiving jobs over the network at any given time, you can take the printer offline. Taking the printer offline allows you to perform printer maintenance without jobs being sent to the printer. When the printer is offline, any services, such as Workflow Scanning, are unavailable.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Network Settings**.
3. Touch **Online/Offline**.
4. Touch **Online** or **Offline**.
5. Touch **Close**.
6. Press the **Log In/Out** button, then touch **Logout** to exit the Tools pathway.

Note: When you are finished, ensure that you put the printer back online to allow jobs to process.

Erase Customer Data

You can use the Erase Customer Data feature to prepare a printer for removal from the network. This feature clears all customer-specific information including jobs, configurations, and settings from the printer. Printer-specific values, such as total images and supply counters, are not cleared.

Note: When the Erase Customer Data process begins, the printer is unavailable for use.



CAUTION: The erase process permanently removes all jobs, customer configurations, and data.

To erase customer data:

1. To configure the printer to print a status report after it completes the erase process, load paper in the printer.
2. To prevent customer data from reaching the printer, disconnect the printer from the network. If required, disconnect the Ethernet cable.
3. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
4. Touch **Device Settings > General > Erase Customer Data**.
5. Touch **Erase Customer Data > Erase All Customer Data**.
6. Touch **Confirm**.



CAUTION: Do not power off the printer during the erase process. This can cause damage to the printer.

Notes:

- The erase customer data process reboots the printer and displays messages. The printer does not require your attention during the process.
 - The erase process can take up to 50 minutes to complete. When the process completes, a report prints.
7. Turn off the printer and disconnect the power cord and other cables from the back of the printer.
 8. The printer is ready to be moved.

Resetting the User Interface to Factory Default Settings

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings > Reset UI to Factory Settings**.
3. Touch **Restart**.



CAUTION: If you reset the user interface to factory default settings, all current user interface settings are lost.

Updating the Printer Software

You can update your printer when Xerox releases a new version of printer software or firmware.

To restrict software upgrades to administrators only:

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup > Software Upgrade**.
2. To restrict software upgrades, click **Restrict Upgrade**, then click **OK**.

To view all installation policies, click **Security Installation Policy**.

Before you begin:

- Determine the current software version of your printer.
- Download the latest software update file in **.dlm** format from the Xerox Support website at www.xerox.com/office/WC3655support.

To determine the software version:

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Configuration Report**.
3. To verify the software installed on your printer, scroll down to **Software Versions**.

Enabling Upgrades

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup > Software Upgrade**.
2. To allow users to upgrade software, click **Allow Upgrade**. If **Restrict Upgrade** appears, upgrades are enabled already.

Manually Updating the Software Using a USB Flash Drive

1. Create a directory folder on your USB Flash Drive called **UPGRADE**.
2. Copy the software **.dlm** file to this directory.
3. Insert the USB Flash Drive into the USB host port of the printer.
The software upgrade process begins.
4. When the software update completes, the printer restarts.

Software Upgrade

You can configure the printer to connect routinely to an FTP directory on your network to update printer software automatically. First, manually download the latest software file and copy it to the location on the FTP server. The printer retains all configured network settings and installed options after the software upgrade processes.

- To view all installation policies, click **Security Installation Policy**.
- To restrict software upgrades, click **Restrict Upgrade**, then click **OK**.

To upgrade the printer software manually:

1. Under Manual Upgrade, to locate and select the software upgrade file in **.dlm** format, click **Browse** or **Choose File**.
2. Click **Open** or **Choose File**.
3. Click **Install Software**.

Notes:

- Software installation begins several minutes after you submit the software to the printer.
 - Once installation begins, Xerox® CentreWare® Internet Services is disabled.
 - You can monitor the installation progress from the printer control panel.
4. Click **OK**.

To verify that the software has updated, check the configuration report.

To upgrade the printer software automatically, click **Auto**.

Adjusting Color, Image, and Text Detection Settings

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Device Settings**.
3. Touch **Input**.
4. Adjust how the printer detects color, images, and text in original documents.
 - **Auto Color Detection:** This option allows you to customize the bias based on the type of originals being scanned and the output required.
 - **Scan from Document Glass:** This option selects the bias toward color or monochrome when scanning using the document glass.
 - **Scan from Document Feeder:** This option selects the bias toward color or monochrome for the document feeder.
 - **Photo/Text Settings:** This option selects the bias toward photo or text quality based on which quality is more important.
5. Touch **OK**.

Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Customization and Expansion

11

This chapter includes:

- Xerox Extensible Interface Platform 260
- Auxiliary Interface Kit 261
- Driver Download Link 262
- Displaying or Hiding ConnectKey Apps..... 263
- Creating a Custom Single-Touch Scan Service..... 264
- Weblet Management..... 268
- Configuring Weblet Settings..... 269

Xerox Extensible Interface Platform

The Xerox Extensible Interface Platform® allows independent software vendors and partners to develop personalized and customized document management solutions. These solutions can be integrated and accessed directly from the printer control panel. These solutions can leverage existing printer infrastructure and databases. Examples of applications include ScanFlow Store, Scan to PC Desktop, Equitrac Office, and others. For more information on Xerox Extensible Interface Platform® applications for your printer, contact your Xerox representative or see www.office.xerox.com/eip/enus.html on the Xerox website.

Note: The printer contains a third-party font package, Liberation fonts. For details and license, see <https://fedorahosted.org/liberation-fonts/>. These fonts are licensed under GNU General Public License. This font is used only with the Xerox Extensible Interface Platform® Second-Generation browser. For details, contact your Xerox representative.

Configuring Extensible Services

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Extensible Service Setup > Settings**.
3. Ensure that the Extensible Service Registration Web service is enabled.
 - a. To ensure that the Extensible Service Registration service is configured, for Extensible Service Registration, click **Edit**.
 - b. Change settings as needed, then touch **Save**.
4. For Enable Extensible Services, if your Xerox Extensible Interface Platform application requires the user password, select **Export password to Extensible Services**.
5. Under Browser Settings, select **Enable the Extensible Services Browser**.
6. To check the certificates on the remote server, select **Verify server certificates**.
7. Configure Proxy Server settings as needed.
 - a. For Proxy Server, select **Proxy** from the list.
 - b. To configure HTTP proxy server settings, under HTTP, for Enabled, click **Edit**.
 - c. To use the same proxy server for HTTPS, select **Use settings for all protocols**.
 - d. To use a separate proxy server for Xerox Extensible Interface Platform® applications that use HTTPS, under HTTPS, select **Enabled**. Select the Address Type. Options are **IPv4 Address**, **IPv6 Address**, or **Host Name**. Type the address name or host name.
 - e. For Bypass Proxy Rules, type the required values and separate them with commas.
8. Click **Apply**.

Auxiliary Interface Kit

An Auxiliary Interface Kit, or a Foreign Device Interface Kit, is a third-party access and accounting device. These kits, such as a coin operated printer accessory or a card reader, can be attached to the printer. Installation instructions are included with the Foreign Device Interface Kit.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Accounting Settings**.
3. Touch **Accounting Mode > Auxiliary Access**.
4. Touch **Auxiliary Device Type**, then select your device type.
5. Touch **OK**.

See also:

[Accounting](#) on page 209

[Local Authentication](#) on page 74

Driver Download Link

The driver installation link appears on the Xerox® CentreWare® Internet Services Welcome, Print, and Support pages. This link goes to the default driver and downloads page for your printer on the Xerox Support website. You can hide or customize this link to go to a location on your network where you post driver installation files for users.

Customizing or Hiding the Driver Download Link

1. In Xerox® CentreWare® Internet Services, click **Properties > General Setup**.
2. Click **Configure Driver Links**.
3. Under Display Option, select **Hide Link** to hide the link.
4. Under Software Links, select **Custom Link** and type a link to direct users to the location for drivers on your network.
5. Click **Apply** to save the new settings or **Undo** to retain the previous settings.

Displaying or Hiding ConnectKey Apps

You can show or hide ConnectKey Apps on the control panel touch screen.

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Display**.
2. Click **Show/Hide**.
3. To select individual services to appear on the touch screen, for Displayed, select the services that you want to appear. To hide a ConnectKey App, clear the selection.
4. Click **Apply**.

Creating a Custom Single-Touch Scan Service

You can create a custom scan service and associate the service with a scan template. You can also customize the icons and text that appears on the printer touch screen.

Notes:

- After you create a service, you can edit the description but not the name of the service.
- You can create up to 10 services.
- The service does not appear on the control panel touch screen until you design your service and select a scan template for your service.

Creating a Custom Single-Touch Scan Service Overview

- Create the service.
- Customize the appearance of your service.
- Associate a scan template with your service.
- Lock or hide the service on the control panel as needed.
- Set the service as the default screen that appears on the touch screen as needed.

Creating a Single-Touch Scan Service

1. In Xerox® CentreWare® Internet Services, click **Properties > Services**.
2. Click **Workflow Scanning > Single-Touch Service**.
3. Click **Create**.
4. Type a name and description for the service.
5. Click **Create**.

Customizing the Appearance of Your Service

1. For Color Scheme, select a color.
2. To replace the default header logo image, for Header Logo, click **Browse** or **Choose File**.
 - a. Select your 96 x 96 pixel **.png** file.
 - b. Click **Open** or **Choose**.
3. For Service Display Name, type the text that you want to appear in the header.
4. For Instructional Text, type instructions for users.
5. Line breaks are supported. For example, type:
 Load documents and press Start.
 File original documents in the file cabinet in Room 423.
 Scanned files are sent to the following destinations:
 ServerA:\business_records
 ServerB:\scan_archives
6. Click **Apply**.
7. To see how the service looks on the printer touch screen, click **Preview**. On the Configure Your Service page, under Action, next to Design your Service, click **Edit**.
8. For Color Scheme, select a color.
9. On the Design Your Service page, do the following as needed:
 - To specify the image settings that are available to users, click the **Additional Features** tab.
 - To specify the custom icon image files that you want to appear on the Service Home page, click the **Services Home Presentation** tab.

Specifying the Image Settings Available to Users

1. On the Design Your Service page, click the **Additional Features** tab.
2. To allow users to use the Build Job option, select **Display Build Job**.
 - a. To turn on Build Job by default, select **On by default**.
Note: This setting overrides the default setting specified in the scan template that you associate with the service.
 - b. Under Feature Label/Instructional Text, type instructions for users.
3. To allow users to configure Output Color, 2-Sided Scanning, Original Type, or File Name settings, select **Display Image Settings**.
Note: The scan template specifies the default image settings associated with the service.
4. Click **Apply**. To see how the service looks on the printer touch screen, click **Preview**.
Note: Not all options listed are supported on all printers. Some options apply only to a specific printer model, configuration, operating system, or driver type.

Specifying the Custom Icon Image Files that Appear on the Service Home Page

You can specify the icon image files that you want to represent the service on the Service Home page. To ensure that your icon displays consistently when other services are added or removed from the Services Home screen, create icon files at three sizes.

1. On the Design Your Service page, click the **Services Home Presentation** tab.
2. Under Logo 1, click **Browse** or **Choose File**.
 - a. Select a 128 x 128 pixel **.png** file that represents the service when 4 or fewer services are displayed on the touch screen.
 - b. Click **Open** or **Choose**.
3. Under Logo 2, click **Browse** or **Choose File**.
 - a. Select a 96 x 96 pixel **.png** file that represents the service when 5–8 services are displayed on the touch screen.
 - b. Click **Open** or **Choose**.
4. Under Logo 3, click **Browse** or **Choose File**.
 - a. Select a 48 x 48 pixel **.png** file that represents the service when 9 or more services are displayed on the touch screen.
 - b. Click **Open** or **Choose**.
5. Click **Apply**.

Managing Scan Templates

A template contains scan settings and at least one destination for the scanned image files. You can associate a scan template with your service or use the default template.

Note: If you select Default Template, configure the default template and add at least one file destination to the template.

To view a scan template:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. For Display, select **Templates**.
3. To view a template, for Templates, click a template.

To create a scan template:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. For Display, select **Templates**.
3. To create a template, click **Create New Template**.

To delete a scan template:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. For Display, select **Templates**.
3. To view a template, for Templates, click a template.
4. To delete the currently selected template, at the top of the page, click **Delete**.

To copy a scan template:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. For Display, select **Templates**.
3. To view a template, for Templates, click a template.
4. To copy the template that is currently selected:
 - a. Click **Copy**.
 - b. Type the **Template Name**, **Description**, and **Owner** details, as needed.
 - c. Click **Add**.

To edit a scan template:

1. In Xerox® CentreWare® Internet Services, click **Scan**.
2. For Display, select **Templates**.
3. To view or edit settings for a template, for Templates, click a template.
4. To edit the template:
 - To change the settings for a field, for the desired field, select the setting, then click **Edit**. Configure the settings as needed, then click **Apply** or **Save**.
 - To add settings to a field, for the desired field, click **Add**. Configure the settings as needed, then click **Apply** or **Save**.
 - To delete a setting from a field, select the setting, click **Delete**, then click **OK**.

Locking or Hiding Your Service from Appearing on the Control Panel

To lock or hide the service from appearing on the control panel, configure Services and Tools user permissions for the role of non-logged-in users. On the Configure Your Service page, under Action, next to Define Service Access Permissions, click **Edit**. For details, see User Permissions.

Weblet Management

Weblets are small HTML and JavaScript-based applications that you can install on the printer to customize the touch-screen. You can download weblets from the [Xerox Home Page](#).

Installing a Weblet

1. In Xerox® CentreWare® Internet Services, click **Properties > Services > Custom Services > Weblet Management**.
2. Click **Choose File** or **Browse**, navigate to a **.weblet** file, then click **Choose** or **Open**.
3. Click **Install Weblet**.

Enabling Weblet Installation at the Control Panel

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Weblet Settings**.
3. Touch **Weblet Install Policy**.
4. Touch **Allow Installation**.
5. Touch **OK**.

Installing a Weblet at the Control Panel

Before you begin, save the **.weblet** file to a USB Flash drive.

1. At the printer control panel, press the **Machine Status** button, then touch the **Tools** tab.
2. Touch **Service Settings > Weblet Settings**.
3. Touch **Weblet Management**.
4. Touch **Install from USB**.
5. Insert the USB Flash drive. Follow the instructions on the touch screen.
6. Browse to the appropriate file folder on the USB Flash drive, then touch the **.weblet** file you want to install.

Configuring Weblet Settings

To configure settings for a specific weblet, next to the weblet name, under Action, click **Edit**.

Audit Log Event Identification Numbers



This appendix includes:

- [Audit Log Event Identification Numbers 272](#)

Audit Log Event Identification Numbers

Event Identification Number	Description
1	System startup
2	System shutdown
3	Manual On-Demand Image Overwrite (ODIO) Standard started
4	Manual ODIO Standard (complete)
5	Print job
6	Network scan job
7	Server fax job
8	Internet fax job
9	Email job
10	Audit Log disabled
11	Audit Log enabled
12	Copy job
13	Embedded fax
14	LAN Fax job
15	Data encryption enabled
16	Manual ODIO Full (start)
17	Manual ODIO Full (complete)
18	Data encryption disabled
20	Scan to Mailbox job
21	Delete File/Dir
23	Scan to Home
24	Scan to Home job
26	PagePack login
27	PostScript passwords
29	Network user login
30	System admin login
31	User login
32	Service login diagnostics
33	Audit Log download
34	IIO feature status
35	System admin pin changed
36	Audit Log file saved

Event Identification Number	Description
37	SSL
38	X509 certificate
39	IPsec (enable/disable/configure)
40	SNMPv3
41	IP Filtering rules
42	Network Authentication (enable/disable/configure)
43	Device clock
44	Software upgrade
45	Cloning
46	Scan metadata validation
47	Xerox® Secure Authentication (enable/disable/configure)
48	Service login copy mode
49	Smartcard access
50	Process terminated
51	ODIO scheduled
53	CPSR backup
54	CPSR restore
55	System Administrator Tools admin access
57	Session Timer log out
58	Session Timer interval change
59	Feature Access Control (configure)
60	Device clock NTP (enable/disable)
61	Grant/revoke admin rights
62	Smartcard (enable/disable/configure)
63	IPv6 (enable/disable/configure)
64	802.1X (enable/disable/configure)
65	Abnormal system termination
66	Local Authentication (enable/disable)
67	Web User Interface Authentication (Enable Network or Local)
68	FIPS 140 mode (enable/disable/configure)
69	Xerox® Secure Access login
70	Print from USB (enable/disable)
71	USB port (enable/disable)
72	Scan to USB (enable/disable)
73	System log download
74	Scan to USB job

Event Identification Number	Description
75	Remote UI feature
76	Remote UI session
77	Remote Scan feature (TWAIN Driver enable/disable)
78	Remote Scan job submitted
79	Scan to Web Service job completed (TWAIN driver remote scan job)
80	SMTP connection encryption
81	Email Domain Filtering rule
82	Software self test started
83	Software self test completed
84	McAfee Security state
85	McAfee Security event
87	McAfee Agent
88	Digital Certificate import failure
89	User name (add/delete)
90	User name password change
91	Embedded fax job Secure Print passcode
92	Scan to Mailbox folder password change
93	Embedded fax mailbox passcode
94	FTP/SFTP Filing passive mode
95	Embedded Fax Forwarding rule
96	Xerox Extensible Interface Platform® Weblets allow install
97	Xerox Extensible Interface Platform® Weblets install
98	Xerox Extensible Interface Platform® Weblets (enable/disable)
99	Network connectivity (enable/disable/configure)
100	Address Book permissions
101	Address Book export
102	SW upgrade (enable/disable)
103	Supplies Plan activation
104	Plan conversion
105	IPv4 (enable/disable/configure)
106	System Administrator password reset
107	Convenience Authentication login
108	Convenience Authentication (enable/disable/configure)
109	Embedded fax passcode length
110	Custom Authentication login
111	Custom Authentication (enable/disable/configure)

Event Identification Number	Description
112	Billing Impression mode
113	AirPrint (enable/disable/configure)
114	Device Cloning (enable/disable)
115	Save for reprint job
116	Web UI Access configure
117	System log push to Xerox
119	Scan to WebDAV job
120	Mopria Print (enable/disable)
121	Point-of-sale credit card API (enable/disable)
122	Point-of-sale data transfer
123	Near Field Communication (enable/disable)
124	Invalid login attempt lockout
125	Protocol audit log (enable/disable)
126	Display device information (configure)
127	Invalid login lockout expires
128	Erase customer data
129	Audit log SFTP schedule (configure)
130	Audit log SFTP transfer
131	Remote software download (enable/disable)

External Keyboard



This appendix includes:

- [External Keyboard Shortcuts](#) 278

You can connect the external keyboard directly to your device using the USB ports. Wi-Fi Direct keyboards are not supported.

Depending on the feature, you can use the external keyboard to navigate fields and manage input.

Note: These keys are not enabled on all screens.

Key	Action
Tab	Moves the cursor from one field to another in the address book
Esc	Cancels input
Enter	Submits input

External Keyboard Shortcuts

You can use shortcuts on the external keyboard instead of buttons on the control panel.

Control Panel Button	Keyboard Shortcut
Services Home	CTRL+8
Features/Services	CTRL+F1
Job Status	CTRL+F2
Machine Status	CTRL+F3
Start	CTRL+F4
Clear All	CTRL+F5
Log in/ log out	CTRL+F6
Power Saver	CTRL+F7
Interrupt	CTRL+F8
Stop	CTRL+F9
Help	CTRL+1
Language	CTRL+2