Device and Feature Guide

LCD screen

Power/Wake device/
Navigation key

External antenna port

External antenna port

microUSB charging port

AT&T Unite Express™

1) Activate Your Account

Online
① On a computer that is connected to the Internet, go to **att.com/gophone** in the device's browser and select **Activate your device**.

② Select **mobile hotspot** and follow the prompts to create an account.

By Phone
• Call **866-707-5550** to activate your account.

Your Account Passcode
• Your mobile hotspot will be assigned a wireless phone number.
• The **last four digits of your wireless number** will be your account passcode.
• You will need this passcode **to manage your account**.
• For security, we recommend that you change this to a secure passcode not related to the wireless number assigned to this device.

Note: To begin using service, please be sure to add sufficient money to cover the plan you selected. If you do not add money to your account within 26 days of activation, your account will be canceled.

Set Up Your Mobile Hotspot

① Insert the battery.

Gold contacts

Gold pins

② Install the back cover.

The battery is precharged. When you need to recharge it, connect the USB cable to the mobile hotspot and then plug into:

• A wall socket, using the wall charger (fastest option)
• The USB port on your laptop

Note: The mobile hotspot comes with a preinstalled SIM card.

2) Connect to the Internet

Turn on your mobile hotspot
① Press and hold the Power button for 2 seconds.

Note: The screen displays the hotspot's Wi-Fi network name and password.

On your laptop or other wireless device

② Open your Wi-Fi/network connection manager.
③ Find your mobile hotspot's Wi-Fi network name (ATT-WIFI-XXXX) and connect.
④ Enter your mobile hotspot's Wi-Fi password.
⑤ Launch your Internet browser.

Note: The screen goes dark to save power. Press and release the Power button to wake the screen.

LCD Display

Network indicator

Alert indicator

Signal strength

Number of connected devices

Messages

Battery

Wi-Fi network name and password

Navigation instruction

Press the Navigation key ⏻ to scroll through the screens.

Note: Check your Alerts and Messages for important service reminders and for passcode resets.

3) Manage Your Account

Check your balance, buy a data package, add money, and more
• Visit **att.com/myatt** or dial **866-707-5550**.
• For additional information visit **att.com/GoMobileData**.

Renew your plan
• Your plan automatically renews on your rate plan renewal date. To ensure continuous service, be sure to have enough money in your account to cover your rate plan charge.
• If you need more data before your rate plan renewal date, you can purchase a data package.

Add money to your account
• Auto Refill is an easy option that keeps your account active while keeping you in charge. You can use a credit or debit card and choose the amount you want to refill.
• Use a credit/debit card for a one-time refill.
• To load funds from a GoPhoneRefill Card, visit **att.com/mygophone** or call **800-901-9878**. Refill cards are available at retail locations nationwide.

View Device Information

View basic settings and alerts on the LCD screen, including the following:

- Wi-Fi name and password

- New messages

- Alerts

- Find hotspot's wireless number (About)

Press the Navigation button (⏻) to scroll through the screens.

Network Indicators

Your 4G LTE wireless device will display one of the following network indicators to let you know which of AT&T's wireless networks you are connected to.

4G LTE — Connected to AT&T's 4G LTE network.

**4G** — Conntected to AT&T's HSPA+network.

Limited 4G LTE availability in select markets. 4G speeds delivered by LTE, or HSPA+ with enhanced backhaul, where available. Compatible data plan required. LTE is a trademark of ETSI. Learn more at att.com/network.

A network indicator does not necessarily mean that you will experience any particular upload or download data speeds. Actual upload and download data speeds depend upon a variety of factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at wireless.att.com/learn/articlesresources/wireless-terms.jsp and from your AT&T Wireless Customer Agreement, Section 3.2 Where and How Does AT&T Service Work.

Advanced Settings — In Your Browser

Change advanced settings such as the Wi-Fi network name and password, the maximum number of devices, and more, via the AT&T Wi-Fi Manager web interface.

① Connect a Wi-Fi device to your mobile hotspot.

② Type **http://attwifimanager** in the connected device's browser.

③ Login is **attadmin**.

Menu →

Account information →

Data usage →

Advanced Connection Options

Guest Wi-Fi

You can give guests one-time access to your mobile hotspot by setting up a Guest Wi-Fi network:

① On your laptop (or other Wi-Fi device), type **http://attwifimanager** in the browser bar.

② Log in as administrator. Default login is **attadmin**.

③ Select **Wi-Fi** from the left-side menu.

④ Select **Options**.

⑤ Check the box next to Enable secondary Wi-Fi network.

The Submit button displays near the bottom of the screen after you make a selection.

⑥ Click **Submit**.

Wi-Fi Passwords

Hide password

① On your Wi-Fi device, type **http://attwifimanager** in the browser bar.

② Log in as administrator. Default login is **attadmin**.

③ Select **Wi-Fi** on the left-side menu.

④ Select **Options**.

⑤ In the Main section next to Broadband Network Name, click the radio button next to Hide.

⑥ Click **Submit**.

Change Wi-Fi network name and password

① On your Wi-Fi device, type **http://attwifimanager** in the browser bar.

② Log in as administrator. Default login is **attadmin**.

③ Select Wi-Fi on the left-side menu.

④ In the Wi-Fi Info section, click **Edit**.

⑤ In the Main section, type your new Wi-Fi network name and password.

⑥ Click **Submit**.

Advanced Connection Options (continued)

Block device access

To prevent a device from reconnecting to the mobile hotspot, add it to the hotspot's blocked list:

① On your laptop (or other Wi-Fi device), type **http://attwifimanager** in the browser.

② Log in as administrator. Default login is **attadmin**.

A list of devices connected to the main Wi-Fi and guest Wi-Fi networks displays on the home screen.

③ Click on the device you want to block.

④ Follow the displayed instructions to block the device.