SONY

User guide

Bluetooth® Music Receiver
BM10

Contents

Accessory overview

| 1. Stereo connectors (Left/ Right)	Insert stereo cables to connect the device to a stereo.
2. Micro USB port	Insert charger cable to power on the device.
3. Notification light	Flashing blue light indicates the device is visible to other Bluetooth® devices or is being reconnected.
	Stable blue light indicates the device is connected to your phone.
	Stable white light indicates the device is ready for reconnection.
4. Pair/Connect button	Long press to enter pairing mode and make the device visible to other Bluetooth® devices.
	Press to disconnect from the currently connected phone.
	Press to reconnect to the most recently connected phone.

3

Basics

To power on the music receiver

1 Plug one end of the charger cable into the charger.
2 Plug the other end of the cable into the Micro USB port of the music receiver. A white notification light illuminates briefly to indicate that the device is powered on.

! The music receiver only works when connected to a power source.

To connect the music receiver to a stereo

1 Plug one end of the stereo cable into the relevant stereo connectors (Left/Right) on your music receiver.
2 Plug the other end of the cable into the stereo.

Pairing and connecting

Before you can use your music receiver to play music through a stereo system, you need to first pair the music receiver with your phone. You can pair the devices manually, or you can use NFC. Once paired, the music receiver automatically establishes a connection to your phone.

The internal memory of your music receiver can save and remember up to eight pairings with other phones at any given time.

To manually pair the music receiver with your phone

1. Make sure your phone has the Bluetooth® function turned on.
2. **Music Receiver:** If you are pairing the music receiver with a phone for the first time, the music receiver enters pairing mode automatically. If not, press and hold the Pair/Connect button until the notification light flashes blue.
3. **Phone:** Scan for Bluetooth® devices, then select **BM10** in the available devices list.
4. Follow the pairing instructions that appear on your phone. If a PIN code is required, enter "0000".

To pair the music receiver with a phone using NFC

1. Make sure that the phone has the NFC function turned on and that the screen is active and unlocked.
2. Place the phone over the music receiver so that the NFC detection area of each device touches the other.

Disconnecting and reconnecting

There are three ways to disconnect your phone from or reconnect it with the music receiver:

- Deselect or select **BM10** in the list of paired Bluetooth® devices in your phone.
- Place your phone over the music receiver so that the NFC detection area of each device touches the other.
- Press the Pair/Connect button.

Smart Connect

You can use the Smart Connect application on your phone to automatically stream music to the music receiver when the phone is connected with the receiver.

Setting up such an action in the Smart Connect application is known as creating an event. For example, you could create an event that sets the music player to stream music to the music receiver every day at a certain time, for example, while you are taking a tea or coffee break.

Before you can create music events in Smart Connect, you must install the Smart Connect application on your phone.

To install the Smart Connect application on your phone

1 From the main application menu of your phone, find and tap **Play Store** to open the **Google Play™** application.
2 Tap the search icon at the top right corner and enter "Smart Connect" in the search field, then tap the search icon again.
3 Tap **Smart Connect**.
4 Tap **Download**, then tap **Accept & Download**.
5 Follow the instructions that appear on the screen of your phone to install the application.

To create a Smart Connect event

1 Start the Smart Connection application. If you are opening Smart Connect for the first time, tap **OK** to close the introduction screen.
2 Tap +.
3 Give the event a name, then tap **Create**.
4 Under **WHEN**, add either the accessory or a time interval, or both.
5 Under **DO THIS**, add what you want to happen in your phone.
6 Under **AT THE END**, add what you want to happen when you disconnect the accessory or when the time interval comes to an end. If both these conditions are set, the actions start either when you disconnect the accessory, or when the time interval comes to an end.
7 To save the event, press ↩.

! To add a Bluetooth® accessory, you have to first pair it with your phone.

Legal information

Music ReceiverBM10

This User guide is published by Sony Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide.
All rights reserved.
©Sony Mobile Communications AB, 2013
Publication number: 1277-5974.1
All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners. Any rights not expressly granted herein are reserved. All other trademarks are property of their respective owners.
Visit *www.sonymobile.com* for more information.
All illustrations are for illustration only and may not accurately depict the actual accessory.

Declaration of Conformity forBM10

We, **Sony Mobile Communications AB** of

Nya Vattentornet

SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony type RD-0030

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards **EN 300 328:V1.7.1, EN 301 489-3:V1.4.1, EN 301 489-7:V1.3.1, EN 301 489-17:V2.1.1 and EN 60 950-1:2006 +A11:2009+A1:2010** following the provisions of, Radio Equipment and Telecommunication Terminal Equipment directive **1999/5/EC**.

Lund, July 2013

CE 0682

Anders Grynge
Director, Head of Global Type Approval

We fulfil the requirements of the R&TTE Directive (1999/5/EC).

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
Any change or modification not expressly approved by Sony may void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Statement

This device complies with RSS-210 of Industry Canada.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Avis d'industrie Canada

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et, and (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux. Le gain maximal d'antenne permis pour les dispositifs utilisant les bandes 5250-5350 MHz et 5470-5725 MHz doit se conformer à la limite de p.i.r.e. Le gain maximal d'antenne permis (pour les dispositifs utilisant la bande 5725-5825 MHz) doit se conformer à la limite de p.i.r.e. spécifiée pour l'exploitation point à point et non point à point, selon le cas. De plus, les utilisateurs devraient aussi être avisés que les utilisateurs de radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) pour les bandes 5 250-5 350 MHz et 5 650-5 850 MHz et que ces radars pourraient causer du brouillage et/ou des dommages aux dispositifs LAN-EL.