User's Guide

**Smart Watch**

Model: TIGER smartWATCH

1.1: Feature

· 1.22-inch IPS TFT touch screen
· 240x204pixels display resolution
· Bluetooth 4.0LE and 3.0 compatible
· Built-in heart rate sensor, monitor your heart rate instantly
· Smart Wake-up, you can simply raise your arm or shake your arm to wake up the device
· Synchronize phonebook, make and receive phone calls through your Smartphone via Bluetooth
· Receive and display notifications from your Smartphone instantly
· Built-in pedometer, measures your steps, calculates distance and calories etc
· Built-in sleep monitor, sedentary reminder..etc
· Remote control music playback, remote capture photo on your Smartphone via Bluetooth
· Anti-theft function, watch will alert you if your Smartphone is more than 10meters away
· Built-in 300mAh Li-poly battery, up to 7 days standby time
· Magnetic PO-GO Pin charge design
· Built-in loudspeaker and Microphone
· Waterproof
· Fully compatible with iOS7 or above and Android 4.2 or above
· Different design styles for your different occasions and preferences

1.2: Button and Function

1. MIC
2. Screen
3. Power Button
    A- Short press to return to active mode
    B- Hold 3 sec. to turn off
    C- Hold 10 sec. to RESET
4. Speaker
5. Heart Rate Sensor
6. POGO-Pin
7. Charger
8. Micro-USB Port(only use for charging)

1.3: How to charge Smart watch?
· If you use a Power Adaptor (Not included), Power Adaptor current is: 5V, 500mA.
· It takes 3-hours to fully charge the smart watch, please follow steps below to charge.

1.4: Motion

Flip to mute incoming call and alarm	Smart-Wake up	Shake once to go to Main Menu	Shake once to answer incoming call

1.5: How to use?

1.6: Bluetooth

1.6.1: For phone calls: how to connect to Android Smartphone / iPhone?

|	
Step 1: Turn on Bluetooth on Smartphone Step 2: Go to Shortcut interface to open Bluetooth	
Step 3: On Smart Watch, Search New Device	
Step 4: On Smart Watch, find your Smartphone and connect	
Step 5: Connected	

Using the Smart Watch App

The Smart Watch app allows you sync your activity, sleep and Heart Rate data with your smart phone or tablet, and manage which notifications get sent to your watch.   Please follow the steps below to begin using the app.

Mobile Device Requirements
The Smart Watch is compatible with most Android 4.3 and above phones and IOS7 support Bluetooth.

Smartphone: How to connect to Smartphone for notification?

Step 1: Scan QR code to install android app

Step 1: Scan QR code to install IOS app

Personal data & Target	Sporty record the same day	Sporty data / History	Setting (Bluetooth connection etc)

Note:
- Make sure your smart phone is choosing of "Visible to all nearby Bluetooth device".
- Accessibility setting: show applications
- If you switch off your Smart Watch and switch on again, Smart watch will automatically pair with your Smartphone after the 1st time paring is successful.
- Smart watch will auto-sync the date and time to smart phone.

Bluetooth connection step1

Turn on Bluetooth from smart phone, pls ensure your bluetooth is open and can be searched, Connection build from smart watch, if the bluetooth connection is done, there are blue bluetooth icon was show on the screen.


1.7: Watch Background

· Available with 3 different watch Background, Choose from Setting -à Display

Male	Female	Sports

1.8: Main Menu

Shortcut	Pedometer	Heart Rate	Dialer
Contacts	Call Histories	Notification	Settings
Others			

1.8.1: Smart wake-up	Setting A:　go to Shortcut interface and tap Smart wake-up.	
	Setting B:　Or go to choose directly from: Settingsà Motionà Smart wake-up"à ON	
	(**Attention!!** Keep Smart Wake-Up on will reduce battery life)	
1.8.2: Mute	Enable mute to keep the device silence.	

1.8.3: Clock	Touch and hold until you see OK to select 5 different clock faces	
1.8.4: Pedometer		
	· Tap ▤ to set goal, steps, height and weight.	
	· Tap ▤ to check the history, it saves 20 records	

1.8.5: Heart Rate	 · Please wear the watch on your wrist before start to measure your heart rate · It is strongly suggested to measure 2 times at least to ensure the accuracy, · Tap ☰ to check the history, it saves 20 records · Tap ☰ to set "repeat" as dynamic- measuring, it will keep measuring your heart rate. return to main menu for multi-tasking · No history can be saved under dynamic- measuring
1.8.6: Dialer Contacts Call Records	 · It sync your phonebook, you can make and receive phone calls, it also shows your incoming and outgoing records · Slide up and down to increase or decrease the volume.

- (For iPhone): choose to answer the incoming call via your Smartphone or Smart watch.

- (For Android Smartphone): tap to answer the incoming call via your Smartphone or Smart watch, speaker=smartphone, bluetooth= smartwatch..

1.8.7: Notification	 - It shows all your instant message such as What'sApp, facebook, pop-up news..etc

	· Notification will be dismissed when it is read · Please delete your notification on your Smartphone to avoid multiple sync to your Smartwatch
1.8.8: Others	 · Sleep monitor: monitor your sleep quality, it saves 20 records · Sedentary Reminder: it reminds you if you sit too long · Message: This shows SMS received on your Android Smartphone · Alarm: set your alarm · BT Music: remote control and play track-list on your Smartphone · Remote capture: easily switch on camera on your Smartphone to take photo A: This shows how to control your Android Smartphone B: This shows how to control your iPhone
1.8.9: Settings	BT settings, Clock, Sound, Volume, Display, Motion, International, Apps, Reset, About

1.9: Trouble sheet

If watch crashed?	· Long press 10 seconds to switch on
Exit to safe mode?	· Long press 10 seconds to switch off then switch on
Can not switch on?	· Charge the smart watch · Long press 10 seconds to switch off then switch on
Automatically shut down?	· Charge the smart watch.
No caller ID or name can be displayed?	· Make sure sync your phonebook to your Smart watch. If Bluetooth is disconnected, try to sync the phonebook again when is connected.
Sound quality is not good when make phone calls	· Try to keep the distance between Smartphone and Smartwatch as short as possible. · Keep check your smartphone signal is strong, adjust the position accordingly if it shows weak signal.
Watch can't charge	· Please ensure POGO-PIN on both Smart watch and charger are clean.

1.10: Use & Care

To care for your Smart watch, please observe the following:

·   Liquids: Don't expose your product to water, rain, extreme humidity, sweat, or other liquids.
·   Drying: Don't try to dry your product using a microwave oven, conventional oven, or dryer.
·   Extreme heat or cold: Avoid temperatures below -10°C (14°F) or above 60°C (140°F).
·   For battery powered accessories, do not recharge your accessory in temperatures below 0°C (32°F) or above 45°C (113°F).
·   Dust and dirt: Don't expose your product to dust, dirt, sand, food, or similar materials.
·   Cleaning: To clean your product, use only a dry soft cloth. Don't use alcohol or other cleaning solutions
·   To help protect your product, always make sure that all connector and compartment covers are closed and secure, and avoid carrying it with hard objects such as keys or coins.

FCC Caution：

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

FCCID:2AKSW-SMARTWATCH