V380 Pro

AI Intelligent Camera Manual

Before use

Insert the memory card to the device.

*This product is not equipped with memory card, please buy it on your own;
*Please do not hot plug in the memory card.

Download APP

Mobile phone scan the QR code to download "V380 Pro" APP. Android phone can download "V380 Pro" in Google play and iphone can download "V380 Pro" in the App Store.

Start and set the device

Please initialize the device when first used.

After the device is energized, it will wait for 15 seconds to start the device successfully, and long press the Reset button for 7 seconds.When you hear "restore factory settings" the voice prompt,the device reset successfully.

Reset button

Tip：The location of this Reset button is for reference only, specifically based on the equipment on your hand.

1,When you hear "Waiting for WiFi smartlink configuration" ,please read WiFi smartlink configuration.

2,When you hear "Access-Point established" , please read AP quick configuration or AP hotspot configuration.

Configure network

In order to be able to monitor remotely, devices need to be connected to the Internet.

Mode1:WiFi smartlink configuration

1,When you hear "Waiting for WiFi smartlink configuration" ；

2,Open the APP, Click [+], And click [next] in the interface;

Device List

3,Click [Waiting for WiFi smartlink configuration];

When you hear one of the following voice prompts,please tap she arrow to continue.

- "Access-Point established"
- "Waiting for WiFi smartlink configuration"
- "WiFi connected"

4,Input the name and password of the router, next step;

Please input the router password.

bingo

Please input password

show password

5, After the configuration is completed, the device list will display the device.

Mode2: AP fast configuration

1,When you hear "Access-Point established" ；

2,Open the APP, Click [+], And click [next] in the interface;

Device List

3,Click [Access-Point established];

When you hear one of the following voice prompts,please tap she arrow to continue.

- "Access-Point established"
- "Waiting for WiFi smartlink configuration"

Android	iOS

Android

Add a camera

MV32588236

4,APP automatically detects the device. Please click on the device.

bingo
●●●●●●●●

5, Select the router and fill in the password;

* not support 5GWiFi temporarily

iOS

Next step

4,Click [Next step];

WLAN
WLAN+
Available WLAN List
MV32588236
Connected (not available to the Internet)

5, enter [settings], select WLAN, connect device hotspots (MV+ID), and return to APP.

6, Select the route and fill in the password (only for iOS system);

*not support 5GWiFi temporarily

Laohua 10
Haoya
bingo
NV-Y-F
ADAO888

bingo
Please input password of bingo and start setting.
Input password
Cancle   Start

5, After the configuration is completed, the device list will display the device.configuration.

Mode3:AP hotspot configuration

1,When you hear "Access-Point established" ；

2,Open the mobile phone WiFi list, connect "MV****" WiFi, such as: MV32588236;

WLAN+
Improving the network intelligent connection experience
open
Available WLAN List
MV32588236
Connected (not available to the Internet)

3, Open APP, drop-down search, you can search out the device;

Device List

4,The LAN monitoring can be carried out;

32588236
ID:32588236

5, After the configuration is completed, the device list will display the device.

LAN Online

If remote monitoring is required, please do the following:

①Click［Settings ］；

②Click［Change the device network］；

Set
Device information
Change the device network

③Click [CHANGE TO WIFI STATION MODE];

CONFIRM
CHANGE TO WIFI STATION MODE

④Select the route and fill the password;

Please input password
Display password

⑤The camera voice prompts "WiFi connected" to complete the configuration.

Preview

The device is connected to the Internet, and users can configure and monitor devices on the APP.

Arm/Disarm
Device network station
Alarm picture

Cloud Storage Service
Settings
Delete device
Share device

Click ▶ to enter preview interface
*APP pop-up set password prompt, please go to setup.

Viewing:32588236

Image setting
Lamp control setting
Replay

Preview mode
Voice intercom

Cloud storage service

Using the cloud storage service, an alarm is generated when the camera screen changes, that is, the generated video is uploaded to the cloud space for storage. Even if the camera is taken away by the thief or the TF is damaged, the user can log in to the account to query the dynamic video file.

Buy package

①Click [Cloud Storage Service];
*Please login with an account

LAN Online

②Click [BUY A NEW PACKAGE];

BUY A NEW PACKAGE

①Select a package to purchase;
(Support Paypal payment)

My cloud storage package

7 day cloud storage service(month package) ￥10.00   Buy
Record alarm video without AI analysis and notification service.

Bind to service

④Bind the cloud package to the device;

Do you like to subscribe?
The function of the package can be used only after subscription.

yes   no

③Binding is completed, The device has enabled cloud storage recording;

Cloud storage service
Message notification

Unlock service

①Click [unzip service];

Cloud storage service
Message notification

②Get the verification code to unbind by phone or email.

Cloud video search

Unbind the service
Please input code   VERIFICATION CODE

CANCEL   CONFIRM

Alarm setting

Motion detection.When an abnormal condition is detected, the device alarms and pushes the alarm information to the apps of users.

①Click [Settings ⚙];

LAN Online

②Click [Device alarm setting];
③After opening alarm switch, we can set the alarm schedule alarm area, and alarm sound.

Alarm on/off
Alarm schedule
Alarm area
Alarm sound

Replay

*The recording of memory card and cloud storage are on this interface.

1,Click the button ▶ in the device list to enter the real-time monitoring interface;

LAN Online

2,Click [Replay ⏺];

Snapshot Monitor Replay Mode Installat.. Full view

3,You can select the TF card or cloud storage video and select the date for playback.

SD card   Cloud Storage   Return
2018-07-12 ›   Timeline ›
10:10   10:20   10:30

Mobile tracking

Mobile tracking, when the person moves, the camera automatically captures the person's movement track for tracking shooting.

1,Click the button ▶ in the device list to enter the real-time monitoring interface;

LAN Online

2,Click on "Preset Tracking" ;

Snapshot Record Replay Preset tracki..

3,Click "Mobile Tracking" .

Mobile tracking set
Guard position Setting Preset position
Mobile tracki..   Mobile tracking

Snapshot Record Replay Preset tracki..

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled enviroment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

.