



HYPE™
Bluetooth Speaker Pod
Operation Manual HY-177-BLK

Thank you for purchasing the Bluetooth Stereo Speaker Pod. Please read all instructions carefully before using and retain this manual for future use and reference.

PACKAGE CONTENTS

- Bluetooth Stereo Speaker Pod
- USB Charging Cable
- Operation Manual
- Optional Auxiliary Cable

KEY FEATURES

- Stereo sound quality
- Compatible with Bluetooth-enabled devices

SAFETY INSTRUCTIONS

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not puncture or harm the exterior surface of the product in any way.



Keep the unit free from dust, lint, etc.

Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device.

This product is not a toy. Keep out of reach of children.


Do not use the headset at excessive levels as this may damage hearing.

Do not expose batteries, battery pack, or batteries to installed to excessive heat, such as direct sunlight, or open flame.




FEATURES

1. Vol + : Press and Hold
- Next Track: Quick Press
2. MODE: Play/Pause/Answer/End Call: Quick Press
3. Vol - : Press and Hold
- Previous Track: Quick Press
4. LED Light
5. Power Off/On
6. 3.5mm Stereo Input
7. Micro USB Charging Port
8. Microphone




PAIRING THE SPEAKER TO A BLUETOOTH ENABLED PHONE

1. Make sure the Bluetooth Speaker is turned off.
2. Keep your Bluetooth Speaker Pod and mobile phone within 3 feet of each other during the pairing process.
3. Slide the Power Off/On switch to the On position. The LED light will flash blue 6 times quickly to indicate the Speaker Pod is in pairing mode.
4. Quick press the MODE button. The LED will flash blue and red alternately to indicate the Speaker Pod is in pairing mode.



NOTE: To enter pairing mode, you must turn the speaker on, then quick press the MODE button after the blue light flashes 6 times quickly.

5. Make sure Bluetooth is enabled on your mobile phone. If you are unsure how to do this, please refer to the user manual of your mobile device, or contact the manufacturer of your mobile phone.
6. Using your mobile device, search for Bluetooth devices within range. Select "HY-177-BLK" from the list.
7. If prompted for a PIN code, enter "0000" from your mobile device and select "OK" to complete pairing. Depending on which model you have, it may not be necessary to enter a PIN and your Speaker Pod and your mobile phone will pair automatically.
8. Your mobile phone will confirm that the pairing was completed, and prompt you to accept the connection. Please respond "Yes" or "OK" to complete pairing. If the pairing was successful, the Speaker Pod's indicator light will flash blue every few seconds.
9. When attempting to reconnect the speaker to your mobile phone, you may see the message below, and your mobile phone will prompt you to accept the connection request from the HY-177-BLK speaker and ask you if you would like this option shown to you again.



To have your Speaker Pod pair automatically to this device when in pairing mode and in range, you can select "Don't ask this again."

NOTE: The screenshot above is typical of many Bluetooth-enabled phones in the market today, and is used to assist in the explanation of the pairing process. Your mobile phone's interface and interaction with the Bluetooth Speaker Pod may differ slightly from the illustration above.

USING YOUR BLUETOOTH SPEAKER

Powering your Speaker On/Off

- To turn your speaker on, slide the On/Off switch to the On position. The LED light will flash blue 6 times quickly, then once every few seconds.
- To turn your speaker off, slide the On/Off switch to the Off position. The LED light will turn red, and the speaker will power itself off.

Answering/Ending a Call

- To answer a call, quick press the MODE button.
- To end a call, quick press the MODE button again.

Adjusting Volume

- Press and hold the Vol+ and Vol - button to adjust volume during a call or while music is playing.

NOTE: You may also adjust the volume from your mobile phone's volume controls.

Making a Call

- Dial the number from your mobile device and press the Send or Call button. The call will automatically transfer to your speaker.



Redialing the Last Number

- Quick press the MODE button twice. The last number dialed from your mobile device will be dialed.

Rejecting Calls

- To reject an incoming call, press and hold the MODE button for 3 seconds. The call will disconnect from your mobile device.

STEREO BLUETOOTH


This speaker allows you to listen to and control the music on your Bluetooth-enabled mobile phone, computer, or mp3 player in full stereo. It supports the following profiles:

- A2DP: Advanced Audio Distribution Profile
- AVRCP: Audio/Video Remote Control
- HSP: Headset Profile
- HFP: Hands-Free Profile

To use the speaker to listen/control music, your Bluetooth-enabled device must support the A2DP and AVRCP profiles. Please refer to the user guide of your Bluetooth-enabled device for more information.

PLAYING MUSIC

To enjoy wireless music on your Bluetooth Speaker Pod, make sure you are connected to a Bluetooth-enabled media device. Once connected, you can press PLAY on your Bluetooth device or you can press the MODE button on the HY-177-BLK Bluetooth Speaker Pod. Once playback has begun, you can control the music or answer phone calls from the control buttons on the



Play/Pause

- Press the MODE button to pause the music. To resume music playback, press the MODE button again.

Skipping Tracks*

- (*Not available on all phones)
- Press the Vol - once to skip to the previous track.
- Press the Vol + once to skip to the next track.

USING AS A WIRED SPEAKER

The HY-177-BLK can be used as a wired speaker by using the optional auxiliary cable. This cable is included with your speaker.

1. Plug one side of the auxiliary cord into the headphone jack of your device.
2. Plug the other end of the auxiliary cable into the 3.5mm AUX jack on the speaker.
3. Using your media device's music controls, you can control music and adjust volume.

NOTE: When connected via AUX cable to your speaker, only the Vol + and Vol - buttons work on the speaker. To skip to the previous or next track, you will need to use the controls of your audio device.

In order for Bluetooth devices to communicate with one another properly, they must utilize the same Bluetooth profile. To determine the profiles supported by your device, please refer to the device's user guide.

Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth-enabled devices and/or the functionality of such features may be limited with certain devices.

Speaker. Please note, not all mobile phones support the control of music using Bluetooth.

NOTE: Most media-enabled smart phones will display "connected to phone audio and media" when connecting to the Bluetooth Speaker Pod. This means you can make phone calls and enjoy your music.

TROUBLESHOOTING

Please refer to the below frequently asked questions to see if these basic troubleshooting tips help solve your problems.

- I can pair the Bluetooth Speaker with my Bluetooth device, but I cannot hear any music.

Make sure your device supports the A2DP profile

- I cannot get the Bluetooth Speaker into pairing mode.

Make sure the Bluetooth Speaker is turned off before beginning the pairing process. Slide the power switch to the On position and wait for the LED light to flash blue six times quickly. Quickly press the MODE button after this, and the LED light will alternately flash red and blue.

- My mobile phone is not able to pair with the Bluetooth Speaker Pod.

Make sure that you fully charged the speaker before use. Keep your Bluetooth speaker and mobile phone within 3 feet of each other during the pairing process. Check that your phone's Bluetooth is enabled. Try repeating the pairing process.

MAINTENANCE

Power this product off when not in use.

DO NOT expose this product to water or liquid.

DO NOT use abrasive cleaning solvents to clean this speaker. Clean with a dry cloth if necessary.

If you are not using the speaker for a long period of time, store in a dry, safe location. Charge the speaker every 2 months when in storage to maintain battery life.

WARRANTY INFORMATION

The condition of this warranty and our responsibilities under this warranty are as follows:

Supplier's warranty is non-transferable. And this warranty is limited to the original purchaser only.

- * You must be able to prove the date of original purchase of the unit with a dated receipt.
- * The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
- * The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.
- * Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorates and other accessories.
- * A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.

* Modification and repair of the unit should be done by authorized and qualified service personnel, Center or returned to the manufacturer.

* This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations. We offer a warranty on our products in accordance with the following conditions:

- 1) Hype™ products are covered by a 12 month warranty. We will resolve damages or defects on Hype™ products free of charge within 12 months of the purchase date under the following warranty conditions. For any damage or defect determined later than 12 months after the purchase date, proof of a manufacturing fault must be submitted for repair under warranty.
- 2) The warranty does not cover batteries and other parts, which are considered consumables, parts that break easily such as glass or plastic or defects based

on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and workmanship provided these have a negligible effect on the product's fitness for use, in the event of damage caused by chemical or electrochemical effects, by water or generally from abnormal conditions.

- 3) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or to replace them with working parts free of charge. Hype™ reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. Requests cannot be made for repairs to be carried out on site. Parts that have been replaced or exchanged become our property.
- 4) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for our product.
- 5) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.
- 6) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory legal liability. We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to usage restrictions, data loss, and loss of earnings or interruption to business

Asserting a warranty claim:

- 1) To make use of the warranty service for hardware issues, you must contact the Hype™ Service Center by email at support@dgiusa.com
- 2) Hype™ will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to Hype™.

IMPORTANT: Hype™ will only accept parcels that have an RMA number.

Please observe the following when sending the product:

- 1) Send the product suitably packaged with carriage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc.) unless the Hype™ Service Center specifies otherwise.
- 2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.
- 3) You must enclose a copy of the sales slip as proof of purchase.
- 4) Once Hype™ has received the product, it will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender with carriage and insurance paid.

Service outside of warranty

Hype™ can refuse any service claim made that is not covered by the warranty.

If Hype™ agrees to provide a service outside the warranty, the customer will be invoiced for all repair and transport costs. Hype™ will not accept any packages that have not first been approved by Hype™ by means of an RMA (Return Material Authorization).

FCC STATEMENT

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

Re-orient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment.

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment and invalidate the warranty claim.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure requirement.

The device can be used in portable exposure condition without RF striction.