

# AIRTAME

How to use, Safety, Regulatory  
and Warranty information



For more information visit  
[airtame.com/support](https://airtame.com/support)

## WHAT'S IN THE BOX?

### AIRTAME:

The AIRTAME Dongle plugs into the HDMI port on your TV

### Micro USB Cable:


To provide power for AIRTAME you need to connect the Micro USB cable between AIRTAME and the AC Adapter

### HDMI Extension Cord:


The HDMI extender can be used if AIRTAME not fit behind the TV because of limited space.

### Power supply:

The provided power supply should be used to power AIRTAME



Micro USB cable



HDMI extension cable

AC power adapter



EU power adapter



UK power adapter



# SET UP PROCESS

More help can be found at:  
[setup.airtame.com](http://setup.airtame.com)



## Step 1

Plug AIRTAME into an HDMI port in the back of your TV. Take the included USB cable and plug the smaller end into AIRTAME and the other end into the included power adapter. Power it up.



## Step 2

On your TV, select the HDMI input source you just plugged AIRTAME in to. You should see an AIRTAME setup screen now.



## Step 3

Go to [setup.airtame.com](http://setup.airtame.com) from your browser on your phone, tablet or computer - and follow further instructions.

# SAFETY PRECAUTIONS

AIRTAME has been designed with high attention to the safety for the user. However if used improperly, AIRTAME have the potential for causing fire, electrical shock or personal injury. To avoid any accident please pay attention to these guidelines:

- Use only the power supply and Micro USB cable provided by AIRTAME. Using other cables and power supplies can potentially damage or influence the functionalities during use.
- AIRTAME generates heat during use that increases the temperature of the outside of AIRTAME. It should be powered off and cooled before removing from your monitor.
- Stop use of AIRTAME immediately if the device functions in an abnormal manner, produces unusual sounds or smell and/or becomes too hot to touch.
- Do not expose AIRTAME including the Micro USB cable, HDMI extender or power supply

to water or extreme conditions (moisture, heat, cold, dust) as it potentially could result in malfunction when exposed to such elements.

- Do not attempt to disassemble or repair AIRTAME yourself. Doing so voids the limited warranty and could harm you, your television, and/or the device.

- Be careful when using the Power supply and only use in combination with AIRTAME in dry locations to avoid the risk of electric shock.

## **LICENSE AGREEMENT**

Software license terms related to AIRTAME can be found at [airtame.com/support/license](http://airtame.com/support/license)  
When using AIRTAME you accept the agreement to those terms.

## **WARRANTY INFORMATION**

Warranty information applicable for your country can be found at [\*\*airtame.com/support/warranty\*\*](http://airtame.com/support/warranty)

# LEGAL NOTICES

Model AT-DG1

FCC ID: 2ADEFAT-DG1

IC: 12460A-ATDG1

## **Federal Communication Commissions Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IEEE 802.11b or 802.11g operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.

Wireless Radio Use: This device is restricted to indoor use when operating in the 5.15 to 5.25 GHz frequency band.



## **IMPORTANT NOTE:**

### **FCC Radiation Exposure Statement:**

To satisfy FCC and IC exposure requirements, a separation distance of at least 20 cm should be maintained between the antenna of this device and persons during device operation. Operations at closer than this distance are not recommended. The antenna used for this transmitter must not be co-located in conjunction with any other antenna or transmitter.

### **Note to US model owner:**

To comply with US FCC regulation, the country selection function has been completely removed from all US models.

The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination. The firmware setting is not accessible by the end user.

## INDUSTRY CANADA (IC) NOTICES

### English

“Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.”

“This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.”

## **French**

“Conformément à la réglementation d’Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d’un type et d’un gain maximal (ou inférieur) approuvé pour l’émetteur par Industrie Canada.

Dans le but de réduire les risques de brouillage radioélectrique à l’intention des autres utilisateurs, il faut choisir le type d’antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l’intensité nécessaire à l’établissement d’une communication satisfaisante.”

“Le présent appareil est conforme aux CNR d’Industrie Canada applicables aux appareils radio exempts de licence.

L’exploitation est autorisée aux deux conditions suivantes : (1) l’appareil ne doit pas produire de brouillage, et (2) l’utilisateur de l’appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d’en compromettre le fonctionnement.”

# EUROPEAN UNION



AIRTAME ApS declares that this equipment is in compliance with the essential requirements and other provisions of Directive 1999/5/EC.

The full Declaration of Conformity can be found at [airtame.com/support/cemarking](http://airtame.com/support/cemarking)



Waste management of AIRTAME follows the WEEE Directive 2012/19/EU and the RoHS recast Directive 2011/65/EU. More information can be found at [airtame.com/support/waste](http://airtame.com/support/waste)

AIRTAME was designed by:  
AIRTAME ApS, Vestergade  
20C 2nd, Copenhagen K 1456,  
Denmark.

[airtame.com](http://airtame.com)