

Getting Started

Using Your Headphones


Turning on Your Headphones

Press the power button to turn on the headphones. A white light will appear for 2 seconds, and then will blink to indicate the headphones are on.

To turn off the headphones, press the power button.

When there is no audio for 45 seconds, the headphone power automatically shuts off.

The power button turns red to indicate low power and the need to charge the headphones.



Battery Power Indicators		
	Black	Power Off
	White	Power On
	Blinking	Power On - Battery OK
	Blinking	Power On - Battery Low
	Red	Need to Charge

Getting Started


Using Your Headphones

Charging Your Headphones

Headphones should be fully charged before they are first used.

To charge the headphones, connect the micro USB cable to the headphone USB port. You can use an AC adapter with a USB jack, for example the one that comes with your iPhone. Please note Alpine headphones do not include an AC adapter.


The power button stays red while charging. The power button light changes to white when the headphones are fully charged, which takes about 4 hours.



Getting Started

Using Your Headphones

Using the Audio Cable Remote Control



Adjusting Volume

- ① To increase volume, push the top button on the remote control.
- ③ To decrease volume, push the lower button.

Play /Pause

- ② To play or pause the music, press the middle button.

Next Track

- ② To skip to the next track, rapidly press the middle button twice.

Previous Track

- ② To go back to the previous track, quickly press the middle button three times.

Fast Forward

- ② To fast forward, quickly press the middle button twice and hold.

Rewind

- ② To Rewind, quickly press the middle button three times and hold.

Answer/End Phone Call

- ② To answer or end a phone call, press the middle button.


The remote control and microphone attached to the audio cable are intended for use only with Apple products.

Getting Started

Using Your Headphones

Folding Your Headphones

Your headphones can be folded flat to make them easier to pack. Carefully turn the right earcup inward, to the left, and turn the left earcup inward, to the right, until each is at a 90-degree angle to the headband.



Technical Specifications

Impedance	$30 \pm 20\% \Omega$ at 1kHz
Frequency response	15Hz - 24,000Hz
Sound pressure level	107dB \pm 3dB at 1kHz max
Total harmonic distortion	<0.1 % at 1mW/1kHz

NOTE: Specifications and design are subject to change without notice.

Limited Warranty

This warranty, effective 1 year from original purchase date, covers product defects in materials or workmanship. This warranty covers only the original product purchaser or person who received the product as a gift, and only residents of the United States, Puerto Rico or Canada.

This warranty does not cover normal wear and tear, loss or theft; damage occurring during product shipment for repair, or damage caused by negligence, improper operation or failure to follow instructions in the owner's manual or if caused by act of God or other acts of nature; service performed by an unauthorized person, company or association; any product with serial number defaced, altered or removed; any product not distributed by Alpine in the United States, Puerto Rico, or Canada, or not purchased from an Authorized Alpine dealer.

How to obtain warranty service

- 1) You are responsible for sending the product to Alpine Customer Service (USA), Inc. for repair, and for paying initial shipping charges. If warranty covers repairs, Alpine will either repair or replace the product with a new or reconditioned one without charge, and will pay return shipping charges.
- 2) Provide a detailed description of the problem(s) requiring service.
- 3) Supply proof of product purchase.
- 4) Package the product securely to avoid damage during shipment.

ANY IMPLIED WARRANTIES INCLUDING FITNESS FOR USE AND MERCHANTABILITY ARE LIMITED IN DURATION TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE. NO PERSON IS AUTHORIZED TO ASSUME FOR ALPINE ANY OTHER LIABILITY IN CONNECTION WITH SALE OF THE PRODUCT.

ALPINE EXPRESSLY DISCLAIMS LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES CAUSED BY THE PRODUCT. "INCIDENTAL DAMAGES" REFERS TO EXPENSES OF TRANSPORTING THE PRODUCT TO THE ALPINE SERVICE CENTER, LOSS OF THE ORIGINAL PURCHASER'S TIME AND LOSS OF USE OF THE PRODUCT. "CONSEQUENTIAL DAMAGES" REFERS TO COST OF REPAIRING OR REPLACING OTHER PROPERTY DAMAGED WHEN THIS PRODUCT DOES NOT WORK PROPERLY. REMEDIES PROVIDED UNDER THIS WARRANTY ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS.

Limited Warranty

This warranty gives you specific legal rights. You may have additional rights that vary according to state or country. Should the product require service, please call Alpine Tech Support to verify issue. Once verified, send to Alpine Customer Service (USA), Inc. at 2012 Abalone Ave., Unit D, Torrance, CA 90501.

CUSTOMER SERVICE	1-800-421-2284, ext. 860304
TECH SUPPORT	1-800-TECH-101 (1-800-832-4101)

or visit our website at <http://www.alpine-usa.com>.

ALPINE ELECTRONICS OF AMERICA INC.,
19145 Gramercy Place, Torrance, California 90501, U.S.A
Do not send products to this address.

©2014 Alpine Electronics of America, Inc. All rights reserved.

“Made for iPod” and “Made for iPhone” mean that an electronic accessory has been designed to connect specifically to iPod or iPhone respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance. iPhone, iPod and iPod nano are trademarks of Apple Inc., registered in the U.S. and other countries.

Made for
iPhone 5s, iPhone 5c, iPhone 5, iPhone 4s, iPod with Video, iPod nano (6th and 7th generation)