

TROUBLESHOOTING

If you are unable to connect the speaker to your device, please try the following:

- Check to make sure the battery is not low, and/or plug the speaker into the wall via AC/DC adaptor directly.
- Turn the speaker off/on to reset it.
- Make sure Bluetooth is enabled on your mobile device.
- Attempt "PAIRING" again from beginning.

If your unable to hear any music:

- Press "Volume +" to increase volume on the speaker.
- Turn up the volume on your mobile/mp3 device.

If the sound is coming out distorted:

- Turn down the volume on the speaker or your mobile/mp3 device.

WARRANTY

The condition of this warranty and our responsibilities under this warranty are as follows:

Supplier's warranty is non-transferable. And this warranty is limited to the original purchaser only.

- * You must be able to prove the date of original purchase of the unit with a dated receipt.
- * The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
- * The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.
- * Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorates and other accessories.
- * A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.
- * Modification and repair of the unit should be done by authorized and qualified service personnel, Center or returned to the manufacturer.
- * This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations. We offer a warranty on our products in accordance with the following conditions:

- 1) Hype™ products are covered by a 12 month warranty. We will resolve damages or defects on Hype™ products free of charge within 12 months of the purchase date under the following warranty conditions. For any damage or defect determined later than 12 months after the purchase date, proof of a manufacturing fault must be submitted for repair under warranty.
- 2) The warranty does not cover batteries and other parts, which are considered consumables, parts that break easily such as glass or plastic or defects based on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and workmanship provided these have a negligible effect on the product's fitness for use, in the event of damage caused by chemical or electrochemical effects, by water or generally from abnormal conditions.
- 3) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or to replace them with working parts free of charge. Hype™ reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. Requests cannot be made for repairs to be carried out on site. Parts that have been replaced or exchanged become our property.
- 4) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for our product.
- 5) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.
- 6) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory legal liability. We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to usage restrictions, data loss, and loss of earnings or interruption to business.

Asserting a warranty claim:

- 1) To make use of the warranty service for hardware issues, you must contact the Hype™ Service Center by e-mail at support@dgusa.com
- 2) Hype™ will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to Hype™.

IMPORTANT: Hype™ will only accept parcels that have an RMA number.

Please observe the following when sending the product:

- 1) Send the product suitably packaged with carriage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc.) unless the Hype™ Service Center specifies otherwise.
- 2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.
- 3) You must enclose a copy of the sales slip as proof of purchase.
- 4) Once Hype™ has received the product, it will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender with carriage and insurance paid.

Service outside of warranty

Hype™ can refuse any service claim made that is not covered by the warranty. If Hype™ agrees to provide a service outside the warranty, the customer will be invoiced for all repair and transport costs. Hype™ will not accept any packages that have not first been approved by Hype™ by means of an RMA (Return Material Authorization).



Wireless Bluetooth Speaker

ES-13003BT (HY-333)

SAFETY INFORMATION

Read these instructions thoroughly and store for future reference.

Do not use this device near water.

Clean only with a slightly damp cloth.

Do not block any ventilation openings.

Install in accordance with the manufacturer's instructions.

Do not install or operate near any heat sources such as radiators, stoves, or an open flame.




Unplug this device when not in use or during lightning storms.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FEATURES



1. Speakers
2. Play/Pause
3. Previous Track / Volume -
4. Next Track / Volume +
5. Bluetooth LED Indicator
6. One-touch Answer
7. Battery Compartment
8. AUX-IN
9. DC-IN
10. Power On/Off

OPERATION

This unit is designed for use with the included AC/DC adaptor. 6 AA batteries (not included) are also required for backup power supply.

BATTERY INSTALLATION

1. Open the battery door.
2. Insert 6 AA batteries (not included) into the compartment according to polarity.

NOTE: With the volume turned 2/3 of the way up, the speaker has up to 4 hours of continuous play time.

WARNING

Batteries should be inserted according to the correct polarity.

If the unit is not in use for a long period of time, remove the batteries.

Do not mix old and new batteries.

An old or leaking battery may damage the unit. Remove if seen.

Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.

AC/DC ADAPTER

1. Plug one end of the AC/DC adaptor into the input jack located on the back of the speaker.
2. Connect the AC plug of the AC adaptor to AC 100-240V power source.
3. Unplug the AC adaptor and disconnect the DC jack if the unit is not being used for a long period of time.

SPECIFICATIONS

RMS Output: 2x1.7W

Range: Up to 33ft (10m)

Speaker Impedance: 4 Ohm (5W x 2)

AC/DC Power: 100-240V ~50-60Hz

AC/DC Output: 5V, 1200 mA

Power: 6 AA Batteries (not included)

PACKAGE CONTENTS

- HY-333 Speaker
- AC/DC Adaptor
- User Manual

PAIRING

1. Slide the Power On/Off button at the back of the unit into the ON position. The LED Power Indicator Light will turn on.

2. When the speaker is powered on, the Bluetooth Indicator Light will turn on and the unit will enter Bluetooth pairing mode automatically and the light will flash blue.

3. Turn on your mobile device to start pairing with the speaker. Ensure Bluetooth is enabled on your device. Search the HY-333 speaker from your Bluetooth settings on your mobile device. When searching is complete, the Bluetooth Indicator Light will stop flashing and remain lit.

PLAYBACK CONTROL

- Press "◀" button to skip to the previous track.
- Press "▶" button to skip to the next track.
- Long press "-" / "+" to adjust volume.
- During playback, press "⏸" to pause or resume play.

NOTE: Previous Track, Next Track or Play/Pause buttons may not work with all mobile devices after pairing. To adjust if not working, adjust directly from your mobile device.

ANSWERING CALLS

The built-in microphone enables hands-free call answering. Press the "☎" button to answer/end a call.

NOTE: If a password is required for pairing, please enter "0000" from your mobile device. Before pairing to Bluetooth, make sure the AUX-IN cable is not connected to your device or the HY-333 speaker.

AUX-IN

1. Connect the audio source to the 3.5mm stereo connection at the back of your speaker. The Bluetooth Indicator Light will flash.
2. Connect the other end of the audio cable to your mp3 player.
3. Control volume using the "Volume +/-" buttons.

NOTE: Previous Track, Next Track, and Play/Pause may not work with all external audio devices.