



Excellence in Compliance Testing

---

## **Certification Exhibit**

**FCC ID: U4A-SCYPROX3**

**IC: 6982A-SCYPROX3**

**FCC Rule Part: 15.209**

**IC Radio Standards Specification: RSS-210**

**ACS Report Number: 10-0443.W06.11.A**

Manufacturer: Assa Abloy


Model: S1-PA/PK, S2-PA/PK,

TCIP1-M802/M803, TCWI1-M802/M803

## **Manual(s)**

**SARGENT®**

**ASSA ABLOY**



**v.s1**

**Profile**  
**PoE Mortise Lock**  
**Installation Instructions**

A7764B

01/11

# Table of Contents

<b>1</b>	<b>Warning</b> .....	<b>2</b>
<b>2</b>	<b>General Description</b> .....	<b>3</b>
<b>3</b>	<b>Hardware Specifications</b> .....	<b>3</b>
<b>4</b>	<b>Electronic Specifications</b> .....	<b>3</b>
<b>5</b>	<b>Installation Wiring Overview</b> .....	<b>3</b>
<b>6</b>	<b>Installation Wiring</b> .....	<b>4</b>
<b>7</b>	<b>Parts Breakdown</b> .....	<b>8</b>
<b>8</b>	<b>Lock Installation</b> .....	<b>10</b>
<b>9</b>	<b>Operational Check</b> .....	<b>17</b>

## **1** Warning

Changes or modifications to this unit not expressly approved by ASSA ABLOY Inc. could void the user's authority to operate the equipment.

### FCC:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### Industry Canada:

The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

This Class A digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Cet appareillage numérique de la classe A répond à toutes les exigences de l'interférence canadienne causant des règlements d'équipement. L'opération est sujette aux deux conditions suivantes: (1) ce dispositif peut ne pas causer l'interférence nocive, et (2) ce dispositif doit accepter n'importe quelle interférence reçue, y compris l'interférence qui peut causer l'opération peu désirée.



Warning SARGENT Mfg. Co. v.S Series locksets utilizing a door position switch (DPS) are not rated for, or intended for use in life safety applications.

## 2 General Description

The SARGENT Profile Series v.S1 Mortise Lock is available with either an HID® 125 kHz prox or 13.56 MHz iCLASS® technology reader. It utilizes existing infrastructure and IEEE 802.3af PoE (Power over Ethernet) technology as a proven alternative to traditional access control installations. The v.S1 is a self-contained microprocessor-controlled access control product with non-volatile memory. It uses the existing network cable to communicate with access control systems. The v.S1 lock holds a total of 2400 unique users per lock.

Using PoE technology coupled with approved third party software, this v.S1 online lock offers a complete, integrated access control system.

The Profile Series v.S1 Mortise lock may be used for both indoor and exterior applications. A weather-protective gasket is recommended for exterior applications.

*HID and iCLASS are registered trademarks of HID Global Corporation.*


## 3 Hardware Specifications

- Complete lockset with on-board memory
- Available with or without keypad
- ADA compliant
- Latch: One-piece stainless steel, 3/4" projection
- Deadbolt: One-piece hardened stainless steel
- Guardbolt: Stainless steel, non-handed
- Case - 12 gauge, heavy duty, wrought steel
- Inside lever retracts latch and deadbolt
- UL Listed (3 hr.)
- Handing (RH/LH/RHR/LHR) can be specified but is easily field-reversible without disassembling the lock body
- Locks furnished for 1-3/4" doors. Can be furnished for other door sizes upon request. Consult factory.
- Wire from EAC Panel to door must be shielded with drain terminated at EAC Panel controller

## 4 Electronic Specifications

- 2400 users per lock; 10,000 event audit trail
- Multiple time zone and holiday access scheduling
- Centralized lock management
- Real time door status monitoring
- First-In unlock configuration, either by time or by user (selectable)
- Lock down capable
- Input Power: PoE Class 2 Device, as defined by IEEE 802.3af
- Supports HID® 125 kHz prox or 13.56 MHz iCLASS® credentials (26 - 39 bit); supports CSN reads for other common 13.56 MHz cards, including MiFare, DesFire, and Felica


## 5 Installation Wiring Overview



## 6 Installation Wiring

- A** PoE frame harness assembly (From McKinney)
- B** PoE data hinge (Patent Pending) (From McKinney)
- C** PoE door harness\* (From McKinney)
- D** DPS: Door Position Switch (cylindrical and exits only)
- E** Profile Series v.S1 Online P1 PoE lock


\* Order of installation may vary.  
Refer to appropriate sections for instructions.



### Notes:

- Connectors go on only one way. They cannot be placed in an incorrect position.
- Do not force and do not offset connectors.
- Be sure they are completely seated (flush).


## A Frame Harness Installation



### Cut end / ceiling-side PoE harness:

Suggested installation of components and wire harness supplied by McKinney:

#### TIA-568-B Standard Wiring



Pair Number	Wire	PIN
1	White/Blue	5
	Blue	4
2	White/Orange	1
	Orange	2
3	White/Green	3
	Green	6
4	White/Brown	7
	Brown	8

Do not confuse pair numbers with pin numbers. A pair number is used for reference only (e.g.: 10Base-T Ethernet uses pairs 2 & 3). The pin numbers indicate actual physical locations on the plug and jack.


### Hinge side of PoE harness:

1. Feed cut end of harness into hole on hinge-side through single access hole.
2. Push one of the connectors back through hole and feed into separate access hole.

Each of the hinge-side harness connectors should end up threaded through a different access hole and matched to the same size pin connector from the door harness:

- 4-pin male Molex connector.
- 6-pin male Molex connector with ground wire.

## B PoE Data Hinge



### Hinge-side harness connectors:

- 4-pin male molex connector
- 6-pin male molex connector with ground wire

### Lock-side harness connectors:

- Ring terminal
- (2) 4-pin connectors
  - 4-pin Molex connector
  - 4-pin connector

### C Door Harness Installation

Order of installation may vary.  
Refer to appropriate sections for instructions.


1. Prop door open.
2. Tape the two lock-side 4-pin connectors to the ring terminal.
3. Using the ring terminal, carefully fish the assembly through the door channel to the lock.
4. Remove tape from ring terminal and door harness connectors.

Hinge-side harness connectors:


- 4-pin male Molex connector
- 6-pin male Molex connector with ground wire

Lock-side harness connectors:



- Ring terminal
- (2) 4-pin connectors:
  - 4-pin Molex connector
  - 4-pin connector



### PoE Lock



## D PoE Lock Wiring




Copyright © 2011, Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproductions in whole or in part without express written permission of Sargent Manufacturing Company is prohibited.

01/29/11



## 6 Parts Breakdown 125 kHz Prox and 13.56 MHz iCLASS



Copyright © 2011, Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproductions in whole or in part without express written permission of Sargent Manufacturing Company is prohibited.

## Parts Breakdown 125 kHz Prox and 13.56 MHz iCLASS, continued

ITEM	PART NO.	DESCRIPTION	QTY.
1	Outside Lever	Reference 8200 Catalog for available levers	1
2	Inside Lever	Reference 8200 Catalog for available levers	1
3	82-0493	O/S Escutcheon only with Cylinder	1
	82-0495	O/S Escutcheon only without Cylinder	1
4	82-0492	Inside Escutcheon only without Thumb Turn	1
	82-4571	Inside Escutcheon only with Thumb Turn	1
5	52-2431	125 kHz Prox Only Bezel Assembly (PA)	1
	52-2432	Keypad and 125kHz Prox Bezel Assembly (PK)	
		OR	
	52-4420	13.56 MHz iCLASS Only Bezel Assembly (S1-IA) 13.56 MHz reader assembly ships configured for PoE/Hardpower use.	
	52-4421	Keypad and 13.56 MHz Bezel Assembly (S1-IK) 13.56 mHz reader assembly ships configured for PoE/Hardpower use.	
6	52-4424	S1 Controller Assembly (Double Pulse)	1
7	52-3855	Battery Cover Assembly	1
8	01-1212	Security Screw	1
9	52-2427	Profile Screw Pack - Specify Finish (Includes: Fire Stop Plate, Trim Mounting Screws, Security Allen Wrench)	1
10	Consult Factory	Lever Handle Screw (Depends on Lever Style)	1
11	Consult Factory	Inside Adapter Assembly (Depends on Lever Style)	1
12	Consult Factory	Outside Adapter Assembly (Depends On Lever Style)	1
13	S1-82276-hand-finish	Lockbody with Dead Bolt with Cylinder	1
	S1-82277-hand-finish	Lockbody with Dead Bolt without Cylinder	
	S1-82278-hand-finish	Lockbody without Dead Bolt with Cylinder	
	S1-82279-hand-finish	Lockbody without Dead Bolt without Cylinder	
14	82-0084	Faceplate with Dead Bolt (shown)	1
	82-0081	Faceplate without Dead Bolt	1
15	77-4336	Mortise Screw Pack - Specify Finish (Includes: Wood and Metal Lock body Screws, Faceplate Screws, and Strike Screws)	1
16	Consult Factory	#43 Mortise Cylinder	1

Copyright © 2011, Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproductions in whole or in part without express written permission of Sargent Manufacturing Company is prohibited.

01/29/11

## 8 Lock Installation

### Step #1 – Door Preparation

#### A. Verify Hand and Bevel of Door

Stand on outside of locked door when determining door hand.





Fig. 1A

#### B. Door Preparation

Prior to installation, all holes must be free of burrs, debris and sharp edges.

Prepare door according to appropriate template (see website [www.intelligentopenings.com](http://www.intelligentopenings.com)):

- Manufacturer Door Template: 4533



\*Note: Raceway placement in document is approximate.

Fig. 1B

## Step #2 – How to Change Hand of Lockbody

### A. Reverse Lock Hand

Red surface of locking piece must face the outside/locked side of door. To rotate locking piece (Fig. 2A):

1. Position lock body with red surface of locking piece visible.
2. Insert blade type screwdriver into locking piece slot to rotate locking piece toward back of lock body.
3. Rotate the locking piece 180° until RED surface is on opposite side.

Note: Red indicates locked side (outside).  
Wire harness MUST exit through the inside/non-cylinder side of the lockbody.

### B. Retaining Ring

Make sure the plastic retaining ring is seated correctly (Fig. 2B):

1. The wires and the plastic retaining ring must be located on the non-cylinder side.
2. Orient the plastic retaining ring so that the word **Bottom** is located at the bottom of the cylinder hole.
3. Route the wires from the top of the cylinder hole into the slot on the top of the plastic retaining ring, NOT through the retaining ring.




Fig. 2A




Fig. 2B

Outside of Door

### C. Reverse Latch Hand

Beveled surface of latchbolt must face strike.

The deadlatch is self adjusting.

To change the hand of the latchbolt:

1. Insert the blade of a slotted screwdriver (>1/4") into the spade shape slot behind latch.
2. Rotate the screwdriver 90° to push latchbolt out until back of bolt clears lock case front.
3. Rotate latchbolt 180° until the latchbolt drops back into the lockbody.

Note: Latch cannot be unscrewed.




Fig. 2C

### Step #3 – Install Lockbody

1. Feed the wires first through the mortise pocket and out the inside prep, followed by the lockbody (Fig. 3A).  
 Note: Connectors and wires must be fed through non-cylinder side.
2. The wires from the lockbody exit the inside door prep through the mortise cutout.
3. Loosely secure the lockbody in the door with two #12 x 1-1/4" wood screws or #12-24 x 1/2" machine screws.

Note: Do not completely tighten at this time.




Fig. 3A

### Step #4 – Door Options

#### A. Fire Stop Plate (P/N 52-0033)

Fire-rated doors require a fire stop plate on the outside of the door (Fig. 4A).

1. Drill (2) 1/8" x 1-1/4" deep holes in the door if not already present.  
 Refer to template for fire-stop prep locations.
2. Attach with flap up and out using (2) #8 x 1/2" self-tapping screws for wood and metal doors.




Fig. 4A

Outside of Door

#### B. Weather Conduit (52-2847)

Install weather conduit on **NON FIRE-RATED** exterior doors only (Fig. 4B).

1. Carefully insert the weather conduit into the ribbon cable hole on the inside of the door.
2. Place the O-ring around the weather conduit on the outside and up against the door (Fig. 4C)




Fig.4B

Fig.4C

Outside of Door

## Step #5 – Install Gasket (for Exterior Doors)

1. Carefully remove the backing from the gasket.
2. Apply gasket to escutcheon:
  - Starting in one place, press the adhesive side of the gasket firmly against the escutcheon.
  - Work around the escutcheon, pressing the sticky side of the gasket firmly against the escutcheon edge.
  - The gasket should be aligned so that all edges of the escutcheon are covered.
3. Attach escutcheon to the door after the wires are connected.

Note: The 43 cylinder may be used with or without a gasket.

Gasket 82-0500




Fig. 5A




Fig. 5B

## Step #6 – Install Outside Escutcheon and Lever Assembly

- 1A. For fire rated doors, feed ribbon cable with connector and ground wire from outside of door through weatherseal gasket and fire stop plate (Fig. 6A).

Note: Install ribbon cable with cable exiting down

- 1B. For non-fire rated doors, feed ribbon cable with connector and ground wire from outside of door through weatherseal gasket (if used) and weather conduit (Fig. 6A).

Note: Install ribbon cable with cable exiting down

2. With outside lever horizontal, locate the outside escutcheon on the door, while directing the mounting posts through the door and lock body (Fig. 6B).  
Make sure the lever spindle is properly engaged in lock.
3. On the inside of the door, insert spindle into square hole of mortise lock.

4. Slide inside adapter and plate assembly over spindle and loosely secure with 2 through bolt screws (#8-32 x 5/8”).

Note: For 8276 and 8278, loosely thread cylinder through escutcheon and into the lock body before tightening the lock case screws and escutcheon through bolts.




Fig. 6B




Fig. 6A

Outside of Door

## ASSA ABLOY

### Step #7 – Escutcheon Wire Connections

Images are shown without gasket. If gasket is necessary, refer to Step #5.

Before the controller is attached to the door:

1. Attach the reader assembly ribbon cable into the back of the controller assembly (side that faces towards the door when mounted (Fig. 7C Detail).
2. Attach the antenna to the circuit board in the plastic housing under the controller assembly.

Note: The difference between the wiring for the iCLASS 13.56 MHz reader and the 125 kHz Prox is that the iCLASS wiring includes an antenna wire.

3. Attach the ground wire to the bottom of the controller assembly (E1, Fig. 7A).




Fig. 7A

### Step #8 – Additional Wiring Connections

Lock, DPS and raceway wire connections:

1. Connect the cable from the mortise lock to the bottom of the controller assembly (TB1, Fig. 8A).
2. Connect the AX/DPS connector to the 2-pin harness.
3. Push the two connectors from the raceway over the controller assembly, through the gap between the plastic controller assembly and the escutcheon, to the front of the circuit board.




Fig. 8A

## Step #9 – Circuit Board Wiring


Before installing escutcheon, route raceway cables and ground attach to front of circuit board.

Turn the controller assembly over:

1. Route the raceway connectors over the top of the controller assembly and plug into the front of the circuit board (side that faces out when mounted (J7, J4; Fig. 9A).
2. Route the 2 ground ring terminals, one from the lock and the other from the hinge wiring, over the top of the controller assembly and connect both to the top escutcheon screw.

Note: Connectors go on only one way.

Do not offset connectors and make sure they are completely seated.



Inside of Door

Fig. 9A

## Step #10 – Install Inside Escutcheon

1. Gently fold the excess ribbon connector and ground wire into the top hole, JST connectors and ground wire into offset middle hole, and mortise and AX/DPS wires into bottom hole, being careful not to pinch wires (Fig. 10A).
2. Insert (2) #8-32 x 1-1/4" screws through inside escutcheon and thread into outside escutcheon (Fig. 10B)

Straighten escutcheons and tighten securely.




Fig. 10A





Fig. 10B



### Step #11 – Install Inside Lever

1. Slide lever handle onto spindle until fully seated (Fig. 11A).
2. Tighten the set screw securely with 1/8" hex wrench.



### Step #12 – Install and Secure Cylinder

1. Slide cylinder through the spring and rosette/collar and screw into lockbody, rotating the cylinder clockwise (Fig. 12A).

Cylinder should be flush with rosette/collar.

Note: SARGENT logo must be horizontal and on the top of the cylinder (Fig. 12B).

2. Secure the cylinder by tightening cylinder clamp screw located above the deadbolt using #2 Phillips screwdriver (Fig. 12C).
3. Using the key, test cylinder functions:
  - 8278 Function: Key retracts latch-.
  - 8276 Function: Key retracts latch and projects and retracts deadbolt-.




Fig. 12B

Cylinder Clamp Screw




Fig. 12C





Fig. 12A

Outside of Door

## Step #13 – Attach Front Plate

Attach front plate with (2) flat head screws.



## 9 Operational Check

1A. For 8276- and 8278- function mortise locks with cylinders:

- Insert key into cylinder and rotate.  
There should be no friction against lock case, wire harness or any other obstructions.  
Refer to **Section 6, Step 8 Wiring** if harness friction exists).


- Check that the key retracts the latch:  
The key should rotate freely.

1B. For 8276- and 8277- function:

- Throw the deadbolt:  
Check that the key retracts both the deadbolt and the latch.
- Try the inside lever:  
Ensure it retracts latch and deadbolt (if provided).

2. Use a prox 125 kHz or 13.56 MHz iCLASS credential, or keypad PIN code set up with the **Network and Lock Configuration Tool** to unlock outside lever and retract latch.

Refer to **Network Lock and Configuration Tool** user manual (WFMN1D) for information on how to configure and program v.S1 locks.



**SARGENT®**

**ASSA ABLOY**

SARGENT Manufacturing  
100 Sargent Drive  
New Haven, CT 06511 USA  
800-810-WIRE (9473) • [www.sargentlock.com](http://www.sargentlock.com)

*Founded in the early 1800s, SARGENT® is a market leader in locksets, cylinders, door closers, exit devices, electro-mechanical products and access control systems for new construction, renovation, and replacement applications. The company's customer base includes commercial construction, institutional, and industrial markets.*

*Copyright © 2011, Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited.*

*ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience.*

A7764B-01/11