

KeyChain Remote Control



Summary

The Keychain Remote Control enables the users to turn the system on and off after exiting or before entering the home or to turn on the siren and to call the central monitoring station if there is an emergency.

Enrollment Guidelines

The remote control is an alkaline battery-powered, wireless touchpad designed to fit on a keychain, in a pocket or purse. It provides users a convenient option for the following system operations:

- Arm the system at Away mode
- Arm the system with no exit delay
- Disarm the system
- Trigger Panic alarms

Use the following guidelines to add the remote control to the system:

1. Enter the installer menu and select Sensor Learning.
2. Press any button on the remote control and hear the response, beep sound, from the main console.
3. Exit the programming menu and complete

the enrollment procedure.

Testing the KeyChain Remote Control

The following steps describe the guidelines for testing the remote control.

1. Disarm or Unlock button-The system is disarmed. Doors, Windows, and Motion sensors are disarmed.
2. Arm or Away button-The system is armed immediately. Doors, Windows, and Motion sensors are active.
3. Panic button-The system initiates a call to report and alarm is processed.

FCC Notes

ACES MODEL NO. KR-01 KEYCHAIN REMOTE CONTROL
FCC ID TTG05KR-01

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

WARNING

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice:

- (1) A Unshielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.
- (2) Use only shielded cables to connect I/O devices to this equipment.
- (3) Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.