

Safety

Before proceeding with the installation, please note the following safety warnings:

- Always follow the manufacturer's advice when using power tools and wear suitable protective equipment (e.g. safety goggles) when drilling holes, etc.
- Before drilling holes in walls, check for hidden electricity cables and water pipes. The use of a cable/pipe locator is advisable if in doubt.


1. Checking Pack Contents

- Chime
- Bell push
- CR2032 battery for bell push
- 2 x screws for push
- 2 x wall plugs
- Adhesive pad

You will need:

- 3 X LR14 C size 1.5V Alkaline batteries
- A #1 Philips-head screw driver
- A small flat bladed screwdriver
- A 1/4-in. (6 mm) drill bit


2. Installing Batteries



2

3. Change Tune or Program New Push

Press and release programming button, LED will illuminate, press push button to hear the tune. Press push button again to hear another tune.




Note: Pressing the program button for more than 15 sec will erase all memory. Follow step 3 to re-program.

3


4. Install Back Cover Using Screws or Adhesive Pad Provided

5. Volume Adjustment




Note: Before final installation adjust distance and position between push and chime to optimize the chime within your environment. Dense walls and metal can reduce range.

Wall Type	Range Reduction
Dry-lined partition wall	10-30%
Single-layer brick wall	20-40%
Double-layer brick wall	30-70%
Metal panel/radiator	90-100%



6. Strobe and Sound Selections

Light and sound selection (applicable to RCWL210A only).




6

7. Low Battery Indication

Tune + 2 beeps + 2 LED flashes = change batteries in chime.

Tune + 3 beeps + 3 LED flashes = change battery in push.



7

Specification	Chime	Bell Push
Operating Temperature	32°F to 104°F 0°C to +40°C	14°F to 104°F -10°C to +40°C
RF Frequency – US	345MHz	345MHz
Range (open field)	150 ft (50 m)	
Sound Level (typical)	82dBA @ 3 ft (1m)	
RF Power		<1mW
Battery Type	LR14 C size	CR2032
Battery Life (5 operations/day)	16 months	18 months
Water Proof		Pass UL1598 rain test
Tunes ♪ ♪♪ ♪♪♪ ♪♪♪♪	Ding Dong 4 notes Modern 8 notes Westminster Saxophone Sound	

Troubleshooting

Two 'beep' sounds are heard and LED flashes twice after the normal chime sound...
This indicates a low battery in the chime. Install new batteries, type LR14 C size alkaline batteries.

Three 'beep' sounds are heard and LED flashes three times after the normal chime sound...

This indicates a low battery in the bell push that activated the chime. Install a new battery, type CR2032.

When the bell push is operated, the red confidence light does not turn on, or is only on for a short time...

Low battery. Install a new battery, type CR2032.

The chime does not work...

- Check that the batteries are the correct type.
Only use alkaline batteries for chime.
- Check that the batteries are fitted correctly (no wrong polarity).
- Check that batteries are not loose.
- The chime could be out of range of the bell push. Try the chime in a different location.
- The chime might not have learned the identity of the bell push. Follow the programming procedure in step 3.

Note: Do not press program button for more than 15 seconds, this will delete all the memory! Repeat programming procedure in step 3 to restore operation.

Troubleshooting

The chime does not sound...

- Check the chime switch position.
- Check that the volume control is not at the minimum setting.

Chime does not play tune selected...

Chime might not have learned the tune selected. Follow programming sequence as in step 3.

The range is reduced...

- Metal structures, including uPVC door frames can reduce the range of the product. Avoid mounting the push or chime on or near metal structures.
- Other equipment can cause radio interference that affects your chime.
- Walls and ceilings will reduce the range.
- Weak batteries will reduce range. Replace every 12-18 months. In cold conditions, (below 41°F/5°C), batteries may need to be replaced more often.

Disposal & Recycling

Batteries and waste electrical products should not be disposed of with household waste. Please recycle where these facilities exist. Check with your local authority or retailer for recycling advice.

Guarantee

Honeywell guarantees this product for 1 year from the date of purchase. Proof of purchase is required; this does not affect your statutory rights. If you require further information about your product, call the Honeywell helpline at 1-800-468-1502.

Declaration

Honeywell hereby declares that this product complies with Part 15 of the FCC rules and Industrial Canada standards. This device operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution:

Changes or modification not expressly approved by the party responsible for regulatory compliance could void the user's authority to operate the equipment.

