

**ADEMCO LIMITED WARRANTY**

Alarm Device Manufacturing Company, a Division of Pittway Corporation, and its divisions, subsidiaries and affiliates ("Seller"), 165 Eileen Way, Syosset, New York 11791, warrants its products to be in conformance with its own plans and specifications and to be free from defects in materials and workmanship under normal use and service for 18 months from the date stamp control on the product or, for products not having an Ademco date stamp, for 12 months from date of original purchase unless the installation instructions or catalog sets forth a shorter period, in which case the shorter period shall apply. Seller's obligation shall be limited to repairing or replacing, at its option, free of charge for materials or labor, any product which is proved not in compliance with Seller's specifications or proves defective in materials or workmanship under normal use and service. Seller shall have no obligation under this Limited Warranty or otherwise if the product is altered or improperly repaired or serviced by anyone other than Ademco factory service. For warranty service, return product transportation prepaid, to Ademco Factory Service, 165 Eileen Way, Syosset, New York 11791.

THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. IN NO CASE SHALL SELLER BE LIABLE TO ANYONE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, OR UPON ANY OTHER BASIS OF LIABILITY WHATSOEVER, EVEN IF THE LOSS OR DAMAGE IS CAUSED BY THE SELLER'S OWN NEGLIGENCE OR FAULT.

Seller does not represent that the products it sells may not be compromised or circumvented; that the products will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; or that the products will in all cases provide adequate warning or protection. Customer understands that a properly installed and maintained alarm may only reduce the risk of a burglary, robbery, fire or other events occurring without providing an alarm, but it is not insurance or a guarantee that such will not occur or that there will be no personal injury or property loss as a result. CONSEQUENTLY, SELLER SHALL HAVE NO LIABILITY FOR ANY PERSONAL INJURY, PROPERTY DAMAGE OR OTHER LOSS BASED ON A CLAIM THE PRODUCT FAILED TO GIVE WARNING. HOWEVER, IF SELLER IS HELD LIABLE, WHETHER DIRECTLY OR INDIRECTLY, FOR ANY LOSS OR DAMAGE ARISING UNDER THIS LIMITED WARRANTY OR OTHERWISE, REGARDLESS OF CAUSE OR ORIGIN, SELLER'S MAXIMUM LIABILITY SHALL NOT IN ANY CASE EXCEED THE PURCHASE PRICE OF THE PRODUCT, WHICH SHALL BE THE COMPLETE AND EXCLUSIVE REMEDY AGAINST SELLER. This warranty replaces any previous warranties and is the only warranty made by Seller on this product. No increase or alteration, written or verbal, of the obligations of this Limited Warranty is authorized.

**FCC NOTICE**

FCC ID: CFS8DL5817CB-1

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

IC: 573F-5817CBI

**ADEMCO**

Honeywell International Inc.  
165 Eileen way, Syosset, New York 11791



K5623 8/00

**ADEMCO**

**5817CB**  
**WIRELESS**  
**COMMERCIAL TRANSMITTER**

**INSTALLATION INSTRUCTIONS****GENERAL INFORMATION**

The 5817CB Wireless Commercial Transmitter is a door- or window-mounted burglary transmitter. Upon activation, it emits an RF signal to a control panel that, in turn, sends a burglary or fire alarm to the central station. The 5817CB has *three* unique input loops (zones). The *first* loop (*primary loop*) is supervised and typically used for high-priority alarm reporting such as fire. It requires a 470K ohm end-of-line resistor to be placed across the sensor. The *second* loop is the built-in normally closed reed switch (used in conjunction with a magnet, as described below). The *third* loop is another normally closed burg loop. All three loops may be used. A fourth (automatically enrolled) loop contains two tamper switches to protect the 5817CB transmitter. A built-in cover tamper switch is activated when the cover is removed. A unit tamper switch is activated if the unit is separated from its mounting plate.

The 5817CB has its own unique serial number permanently assigned during manufacture. A control panel is required to "enroll" this transmitter serial number at some point prior to its usage in the alarm system. Refer to the control panel's installation instructions for further details. *For UL installations, a sensor and its wiring may not be more than 3 feet from the transmitter. Note:* During programming of the control panel, 5817CB transmitters are treated as "RF" (i.e., supervised RF) Type (*mandatory for UL installations*).

**Mounting**

*For proper orientation of the unit in relation to its wall mounting plate and the loop wiring, read all of this section before installing the unit. Before mounting the transmitter permanently, conduct Go/No Go tests (see control's instructions) to verify adequate signal strength and reorient or relocate the transmitter if necessary. When a satisfactory location is found, remove the battery and proceed with installation.*

The following mounting instructions assume that the unit will be mounted as shown in the diagrams. The unit may, however, be installed in *any* direction, as long as the relationship of the unit to its mounting plate is maintained.

The mounting plate, installed as described below, enables easy removal of the unit for servicing, should it become necessary.

- 1. Remove the transmitter's cover** by inserting the flat blade of a small screwdriver into the pry-off slot at the bottom end of the unit on the right side closest to the cover's decorative ribs and twisting.
- 2. Disengage the supplied mounting plate from the unit** by inserting the blade of a small screwdriver into the mounting plate release hole (see Diagram 2) and pushing the locking tab out (see Diagram 1). Slide the mounting plate downward along the case back. *Note:* For this application, the alignment guide strip along one edge of the mounting plate serves no function and may be broken away, if desired.
- 3. If concealed wiring is to be used**, feed the wires through the concealed wiring entry hole at one corner of the plate (*surface wiring is mentioned in Step 5 below*).
- 4. Install the mounting plate**, with its case-holding posts pointing up, in the location selected, as described in the control unit's installation instructions. Use the two flat-head screws supplied.
- 5. If surface wiring is to be used**, remove the knockout slot in the case back (located across from loop 3 terminal block). *Surface wiring* should enter through this knocked out space provided. Do not connect the wiring to the terminal block(s) yet.