




# Lyric Controller Quick User Guide



Ref: LCP500-L

These instructions provide a brief overview of common system functions. For more detailed information, please refer to the Controller's full User Guide, located online at:  
<http://www.honeywell.com/security/hsc/resources/literature/>

**IMPORTANT!**

If the Lyric Controller is beeping rapidly when you enter the premises, an alarm has occurred during your absence and an intruder may still be on the premises.

LEAVE IMMEDIATELY and CONTACT THE POLICE from a nearby safe location.

**IMPORTANT!**

**PROPER INTRUSION PROTECTION**

For proper intrusion coverage, sensors should be located at *every possible point of entry* to a home or commercial premises. This would include any skylights that may be present, and the upper windows in a multi-level building.

In addition, we recommend that radio backup be used in a security system so that alarm signals can still be sent to the Central Monitoring Station in the event that the Wi-Fi network connections or Internet connections are out of order (alarm signals from this control panel are normally sent over the Wi-Fi and Internet network).

**EARLY WARNING FIRE DETECTION**

Early warning fire detection is important in a home. Smoke and heat detectors have played a key role in reducing fire deaths in the United States. With regard to the number and placement of smoke/heat detectors, we subscribe to the recommendations contained in the National Fire Protection Association's National Fire Alarm Code (NFPA 72). These recommendations can be found in the separate Part 2 of this document package.

**IMPORTANT SECURITY NOTICE**




Key fobs are comparable to your house and car keys. If they are lost or stolen, another person can compromise your security system and may be able to enter your home. Immediately notify your Dealer/Installer of a lost or stolen key fob, so that it can be removed from your system.

## ARM THE SYSTEM


---

1  Press **Security** icon on **Home** screen.

---

2  *Select Select Select*  
**Arm Away** (when you're out)  
OR  
 **Arm Stay** (when you'll be home)  
OR  
 **Arm Custom** (bypass selected zones)

---

3  Enter user code.

---

4 **What Happens**

- System arms in selected mode
- Exit Delay countdown begins
- Keypad beeps begin, if enabled  
(*Silent Exit mutes countdown beeps*)

## DISARM THE SYSTEM

1




Press **Security *Armed*** icon.

2



Press **Disarm** icon.

3



Enter user code.

**What Happens**

- System Disarms
- Entry Delay beeps stop (if beeps enabled)

4

**Memory of Alarm**

If an alarm has occurred, zones with alarms remain displayed.  
Repeat Disarm sequence to clear display.

5

## BYPASS ZONES

NOTE: Bypassed zones are unprotected.

1




Press **Security** icon.

2



Press **Zones** icon.

3




Select zones to bypass from list.

4



Press **Bypass**.

5



Enter user code.

6



Bypassed zones appear in list with  icon.

7



(Away)



(Stay)



(Custom)

Arm system as usual.

## PANIC ALARMS

See your installer for the types of Panic alarms programmed for your system.

---

1



Press and hold **Panic** button for 3 seconds.

---

2



Fire  
OR



Police  
OR



Local  
Alarm

Press desired Panic icon within 5 seconds.

---


3




Alarm message is sent to your central station.

## ASSIGN USER CODES

1  Press **Tools** icon on Security screen.

2  Enter **Master User** code.


3  Press **Users** icon.

4 **Master** To assign a Master, Guest, or Duress code, press the desired option then press **Edit**.  
**Guest**  
**Duress** To assign a regular user code, press **Add New**.  
**Add New**

5 

Name User 3	03
User Code	Z-wave Lock Control No

 If desired, press **Name** to assign a personal name to this user. Follow the prompts.  
If desired, press **Z-Wave Lock Control** to set whether entering this code at the Z-Wave door lock will disarm the system. Follow the prompts.  
Press **User Code** to assign a 4-digit code to this user. Go to step 6.

6  Assign 4-digit code and **Save**.

## USE AUTOMATION DEVICES (Z-WAVE)

1



Press **Automation** icon.

2

Switches	Water Valves
Thermostats	
Locks	
Garages	

Select type of device.

3

Switch 01	>
Switch 02	^
Switch 03	v
	⊙

Select a specific device from the list.

4 **Select Desired Action**

Select the desired action for that device.  
Actions vary based on the device selected.



## ADD/REMOVE Z-WAVE DEVICES (Include/Exclude)

1



Press **Automation** icon.

2



Scroll down on device list, press **Tools**.

3



Press **Include** to add device.

OR



Press **Exclude** to remove device.

4

Follow the prompts and activate the device's Function button.  
**Note:** These steps can vary with each Z-Wave device.

Read the device's instructions and see **Working with Z-Wave Devices** in the User Guide.

## CONTROL SMART SCENES

Smart Scenes are created by using Total Connect. However, Smart Scenes can be manually started (Run) or placed on Hold using the Lyric Controller Smart Scenes menu.

Scenes - code - ALL - lists them - select desired then press run or hold

---


1



Press the **Smart Scenes** icon.

---

2



Enter Master User code.

---

3

All  
Triggered  
Anytime  
Scheduled

Press **All** to list all the Smart Scenes programmed in the system.

---

4

Select a Scene

Select the desired Smart Scene from the list.

---

5

**Run**  
OR  
**Hold**  
OR  
**Show**









To run the selected scene, press **Run**.

To suspend the selected scene, press **Hold**.

To remove the hold later, repeat these steps and press **Hold** again.

To view the Smart Scene settings, press **Show**.

## VIEW CAMERAS (if installed)

- 
- 1  Press **VIDEO** icon.
- 
- 2  System may scan for cameras.
- 
- 3  Select up to 4 cameras.
- 
- 4  Press **Display** to view video from available cameras.
- 
- 5  Press **Scan** to list newly-installed cameras.
- 
- 6  View one or more cameras at once.  
OR  

- 
- 7  Control features like Pan and Zoom from the panel.

## SETTINGS

1




Press **Settings** icon.

2



Adjust screen brightness and Voice/Chime volume.

3



Mute Voice and Chimes if desired.

4







Press **Clean** icon; use a damp, soft cloth while screen is disabled for 15 seconds.

## TEST THE SYSTEM (to be conducted weekly)

Disarm the system and close all protected windows and doors. The **Home** button should show green.

**NOTE:** No alarm messages are sent to your alarm monitoring company during these tests.

- 
- 1  Press Security icon on Home screen.
- 
- 2  Press **Tools** icon on Security screen.
- 
- 3  Enter the Master User code.
- 
- 4  Press **Advanced** icon, then select **Walk Test**.
- 
- 5 **Trigger Zones** Trigger (open and close) all zones. Listen for three beeps from the controller when each zone is triggered.
- 
- 6 **Exit Test mode** When testing is completed, press the **Home** button on the controller and enter the Master User Code if prompted.

### **SYSTEM COMPATIBILITY NOTICE**

Your Honeywell security system is designed for use with devices manufactured or approved by Honeywell for use with your security system. Your Honeywell security system is not designed for use with any device that may be attached to your security system's keypad or other communicating bus if Honeywell has not approved such device for use with your security system. Use of any such unauthorized device may cause damage or compromise the performance of your security system and affect the validity of your Honeywell limited warranty. When you purchase devices that have been manufactured or approved by Honeywell, you acquire the assurance that these devices have been thoroughly tested to ensure optimum performance when used with your Honeywell security system.

### **Lyric™ Lock**

Your system supports advanced features designed to keep it functioning optimally. These capabilities include: the ability to interact with Honeywell and your dealer's network for the setup and programming of its features, support for remote software updates and the ability (when enabled by your monitoring dealer) to enhance your security by preventing an unauthorized takeover of the system by another monitoring company. In the event that your dealer has enabled the feature to prevent an unauthorized takeover and you wish to authorize a new company to take over your system, you may request that Honeywell remotely disable this feature. Honeywell will require documentation that you have attempted to contact your existing security dealer and that they have failed to respond, or failed to agree to your request.

**SERVICING INFORMATION**

Your local authorized service representative is the person best qualified to service your Lyric system. Arranging some kind of regular service program with him is advisable.

Your local service representative is:

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Phone: \_\_\_\_\_



800-18080 4/15 Rev. A PART 1 BETA

## **Honeywell**

2 Corporate Center Drive, Suite 100  
P.O. Box 9040, Melville, NY 11747  
Copyright © 2015 Honeywell International Inc.  
[www.honeywell.com/security](http://www.honeywell.com/security)