



# 37" 2.1-CHANNEL SOUNDBAR

Model: BWA18SB001

## PRODUCT GUIDE

Ver.00 Rev.02/05/18

### SAFETY PRECAUTIONS

#### FCC Information

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### WARNING:

- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- The AC adapter is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the unit from the mains completely, the AC adapter should be disconnected from the mains socket outlet completely.
- The AC adapter of unit should not be obstructed OR should be easily accessed during intended use.

### LOCATION OF CONTROLS

#### Soundbar



- |                          |                               |
|--------------------------|-------------------------------|
| 1. I/O Standby/ON button | 10. BLUETOOTH LED Indicator   |
| 2. SOURCE button         | AUX IN LED Indicator          |
| 3. - VOLUME button       | DIGITAL IN                    |
| 4. + VOLUME button       | 1. OPTICAL IN LED indicator   |
| 5. OPTICAL IN Jack       | 2. COAXIAL IN LED indicator   |
| 6. LINE IN 3.5mm Jack    | will illuminate when selected |
| 7. AUX IN R / L Jack     | 3. LINE IN LED Indicator      |
| 8. COAXIAL IN Jack       | 11. Remote Sensor             |
| 9. DC IN Jack            |                               |

### SAFETY PRECAUTIONS

- Minimum 10 cm (4 inches) distances around the unit for sufficient ventilations.
- The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains, etc.
- No naked flame sources such as lighted candles should be placed on the unit.

#### On Safety

- Should any objects or liquids fall into the unit, disconnect the power supply and have the unit checked by qualified personnel before any further operation.
- The unit shall not be exposed to dripping or splashing and that no objects filled with liquid, such as vases, shall be placed on the unit.

#### On Use

Never use the unit where it would be subject to:

- Heat sources such as radiators or air ducts.
- Direct sunlight.

#### WARNING - DO NOT INGEST BATTERY. CHEMICAL BURN HAZARD.


- The remote control supplied with this product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

- 2 -

### LOCATION OF CONTROLS

#### Remote Control




- |                              |                          |
|------------------------------|--------------------------|
| 1. I/O button                | 6. OPTICAL button        |
| 2. AUX button                | 7. MUTE button           |
| 3. LINE IN button            | 8. BLUETOOTH (BT) button |
| 4. I/O / PAUSE / PLAY button | 9. COAXIAL button        |
| 5. PRESET EQ buttons         | 10. SOURCE button        |
| - STANDARD                   | 11. VOL - / + button     |
| - TALKS                      |                          |
| - MOVIE                      |                          |
| - MUSIC                      |                          |

### REMOTE CONTROL


#### Using the Remote Control

- Point the remote control at the REMOTE SENSOR located on the unit.
- When using this unit in very bright light, the infrared REMOTE SENSOR may not work properly.



#### To Change Remote Battery

1. Open the battery door.
2. Insert one CR2025 (3V) size battery.



#### Battery Replacement

When the battery becomes weak, the operating distance of the remote control will be greatly reduced and you will need to replace the battery. Note: If the remote control is not going to be used for a long time, remove the battery.

#### WARNING:

- Do not dispose of the battery in a fire or it may leak and/or explode.
- Batteries should not be exposed to excessive heat such as sunshine, fire or the like.

#### CAUTION:

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

- 3 -

### BASIC OPERATION

1. Press I/O button on the Soundbar or I/O button on the remote to turn on the unit.
2. Press SOURCE button on the Soundbar or remote to select AUX IN, OPTICAL IN, COAXIAL IN, LINE IN or Bluetooth source (input). The LEDs located on top of Soundbar will indicate the currently-selected source, for COAXIAL IN, the LED indicator will flash slowly when selected.
3. Press the preset EQ buttons on the remote control (STANDARD, TALKS, MOVIE and MUSIC) to obtain your desired sound effect.

Note: When mute is enabled, the 4 LED indicators will flash. Press the MUTE button on the remote control to disable the mute function and LED flashing stop.

### ACCESSORIES

Please locate the included accessories.


- Remote control with battery .....x 1
- AC power adapter .....x 1

## SYSTEM CONNECTIONS


### Hear Audio from a TV/Blu-ray Player/DVD Player or Set Top Box

A. Connect an Audio Cable (not included) from the AUX IN jacks to the AUDIO OUT jacks of your TV, Set-Top Box or Blu-ray/DVD Player.

Then press AUX button on the remote or SOURCE button on the Soundbar to select AUX IN mode.



The AUX IN LED indicator located on top of Soundbar will illuminate.



- 8 -

Ver.00 Rev.02/05/18

## PLAYBACK VIA BLUETOOTH® ENABLED DEVICES

Before Bluetooth pairing, you should turn on the Bluetooth function of your Bluetooth® enabled device (such as, mobile phone with Bluetooth function).

1. Press SOURCE button on the unit or **B** button on the remote control to select BT (Bluetooth) mode. The Bluetooth indicator light on the soundbar will blink.
2. On your device (mobile phone, MP3 player, etc.), select "ON70 Soundbar" from the list of available Bluetooth connections.

Note: If your Bluetooth device (such as, mobile phone) requires a password while pairing, please enter 4-digit number: 0000.

- If the Bluetooth pairing is successful, the Bluetooth indicator will illuminate.
- If the Bluetooth pairing is unsuccessful, the Bluetooth indicator will blink at slow speed. Please try again.

### To disconnect the currently paired device

1. On your currently paired and connected device, select "ON70 Soundbar" from the list and disconnect it. Or
2. Turn off the connected device.


- 12 -

Ver.00 Rev.02/05/18


## SYSTEM CONNECTIONS

B. Connect an Optical Cable (not included) from the OPTICAL IN jack to the OPTICAL OUT jack of your TV, Set-Top Box or Blu-ray/DVD Player.

Then press DIGITAL button once on the remote or SOURCE button on the Soundbar to select DIGITAL IN mode.



The OPTICAL IN / COAXIAL IN LED indicator located on top of Soundbar will illuminate.



- 9 -

Ver.00 Rev.02/05/18

## TROUBLESHOOTING

### The unit does not switch on.

- Make sure it is plugged in.
- Press STANDBY/ON button to turn on the Soundbar.

### I have no sound.

- Press the VOLUME **+** / **-** button on the top of the Soundbar or VOL **+** / **-** button on the remote.
- Ensure the source you've selected is outputting audio. If you're using "audio out" from your TV, ensure your TV is configured to output audio (see TV's menu settings).
- Ensure your AV connections are properly made (ensure you don't have any loose connections).
- Ensure you've selected the correct source (input) - the LEDs located on the top of the Soundbar will indicate the currently-selected source (input).
- Mute is activated (the 4 LEDs on top of the Soundbar flashes). Press the mute button on the remote control.
- Ensure the input source is selected PCM output on the setup menu of the input device.

### Cannot setup Bluetooth pairing

- Reset the bluetooth connection by turning off and on your connecting device, or this Soundbar, or select other SOURCE on this Soundbar then back to BT mode again.

### The remote control doesn't work

- If battery is weak, please replace the battery and ensure the new battery is installed correctly.
- Please ensure there is nothing blocking the remote sensor on the front of the Soundbar.



As concerns grow about the environmental impact of outdated electronic products, Venturer Electronics is committed to being a part of the solution. Free of charge, Venturer Electronics customers can return qualifying units to us for recycling. For more details, please visit our website at [www.venturer.com/recycle](http://www.venturer.com/recycle).

Specifications and external appearance are subject to change without notice.


- 13 -

Ver.00 Rev.02/05/18


## SYSTEM CONNECTIONS

C. Connect a COAXIAL Cable (not included) from the COAXIAL IN jack to the COAXIAL OUT jack of your TV, Set-Top Box or Blu-ray/DVD Player.

Then press DIGITAL button twice on the remote or SOURCE button on the Soundbar to select DIGITAL IN mode.



The OPTICAL IN / COAXIAL IN LED indicator located on top of Soundbar will flash slowly.



- 10 -

Ver.00 Rev.02/05/18

## LIMITED WARRANTY

VENTURER ELECTRONICS ("VENTURER") makes the following limited warranty. This limited warranty extend to the original consumer purchaser and is limited to non-commercial use of the product.

### Ninety (90) Day Parts & Labor Warranty

Venturer products purchased in the United States are warranted to be free from defects in materials or workmanship for a period of ninety (90) days from the date of their original retail purchase. If the unit fails to conform to this warranty, we will service the product using new or refurbished parts and products, at VENTURER's sole discretion. During a period of ninety (90) days from the effective warranty date, VENTURER will provide, when needed, service labor to repair a manufacturing defect at its designated Service Center. To obtain warranty service in the United States, you must first contact our Customer Support Center at [www.venturer.com](http://www.venturer.com). The determination of service will be made by VENTURER Customer Support. PLEASE DO NOT RETURN YOUR UNIT TO VENTURER WITHOUT PRIOR AUTHORIZATION. New or remanufactured replacements for defective parts or products will be used for repairs by VENTURER at its designated Service Center for ninety (90) days from the effective warranty date. Such replacement parts or products are warranted for an additional ninety (90) days from the date of repair or replacement. The Customer will be required to ship the unit to the Service Center indicated at the time Customer Support is contacted to make the necessary repairs. The customer is responsible for all transportation charges to the service facility.

### Packaging and Shipping Instruction

When you send the product to the VENTURER service facility you must use the original carton box and packing material or an equivalent as designated by VENTURER.

### Your Responsibility

- (1) You must retain the original sale receipt to provide proof of purchase.
- (2) These warranties are effective only if the product is purchased and operated in the U.S.A. or Canada.
- (3) Warranties extend only to defects in material or workmanship, and do not extend to any product or parts which have been lost or discarded, or damage to product or parts caused by misuse, accident, improper operation or maintenance, or use in violation of instructions provided with the product, or to product which has been altered or modified without authorization of VENTURER, or to products or parts thereof which have had the serial number removed or changed.

- 14 -


Ver.00 Rev.02/05/18

## SYSTEM CONNECTIONS


### Play other devices

D. Plug one end of a 3.5mm Audio Cable (not included) into the LINE IN jack and other end into your MP3 or other audio sources.

Then press LINE IN button once on the remote or SOURCE button on the Soundbar to select LINE IN mode.



The LINE IN LED indicator located on top of Soundbar will illuminate.



- 11 -

Ver.00 Rev.02/05/18

## LIMITED WARRANTY

### Out of Warranty

In the event your product requires repair after the limited warranty period has expired, please contact our Customer Support Center at [www.venturer.com](http://www.venturer.com). Important: You are responsible for any transportation, shipping or insurance relative to the return of product to our Product Returns Center.

All warranties implied by state law, including the implied warranties of merchantability and fitness for a particular purpose, are expressly limited to the duration of the limited warranties set forth above. With the exception of any warranties implied by state law as hereby limited, the foregoing warranty is exclusive and in lieu of all other warranties, guarantees, agreements and similar obligations of manufacturer or seller with respect to the repair or replacement of any parts. In no event shall VENTURER be liable for consequential or incidental damages. No person, agent, distributor, dealer or company is authorized to change, modify or extend the terms of these warranties in any manner whatsoever. The time within action must be commenced to enforce any obligation of VENTURER arising under the warranty or under any statute, or law of the United States or any state thereof, is hereby limited to ninety (90) days from the date of purchase. This limitation does not apply to implied warranties arising under state law. This warranty gives you specific legal rights and you may also have other rights, which may vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, when an action may be brought, or the exclusion or limitation of incidental or consequential damages, so the above provisions may not apply to you.

For more information on other products and services, please visit our website [www.venturer.com](http://www.venturer.com) or email address [support@1800customersupport.com](mailto:support@1800customersupport.com). Important: Also keep your "Bill of Sale" as proof of purchase.

Model no. .... Product name .....  
 Type of set ..... Serial no .....  
 Invoice no ..... Date purchased .....  
 Dealer name .....

FOR SERVICE AND REPAIR, PLEASE VISIT  
 Email address: [support@1800customersupport.com](mailto:support@1800customersupport.com)  
 Website: [www.venturer.com](http://www.venturer.com)

Printed in China

- 15 -

Ver.00 Rev.02/05/18