



World leader in metal detection for anti-shoplifting purposes

Alert Hyperguard

OEM Integration guide V1.0

Phone: +45 36 46 71 71

Fax: +45 36 46 71 74

Vester Voldgade 104 st, th

The logo for Alert Systems, featuring the word "alert" in blue and "Systems" in red.

Info@alertsysteams.dk

1552 Copenhagen V, Denmark

www.alerthyperguard.com

TABLE OF CONTENTS

1. FORWARD	3
2. FCC / IC	3
2.1 LABELING REQUIREMENTS	3
2.2 FEDERAL COMMUNICATIONS COMMISSION STATEMENT	3
2.3 INDUSTRY CANADA STATEMENT.....	4
3. MODULE HYPER ANTENNA 3.1 PCB	5
3.1 MECHANICAL DIMMENTIONS.....	5
4. HOW TO INTEGRATE THE MODULE INTO AN OEM ANTENNA.....	6
4.1 OEM EAS ANTENNA	6
4.2 OEM ANTENNA	6
4.3 EAS ANTENNA BOARD INTEGRATION KIT	7
4.4 COLOR CODE OF THE CAT5E CABLE	7

1. FORWARD

The purpose with this guide is to give instructions for integrating the module HYPER ANTENNA 3.1 into the antenna housing.

2. FCC / IC

2.1 Labeling requirements

The HYPER ANTENNA 3.1 module meets Part 15 of the FCC rules and regulations. Compliance with the labeling requirements, FCC notices is required.

In order to comply with FCC Certification requirements, the Original Equipment Manufacturer (OEM) must fulfill the following requirements.

- The system integrator must place an exterior label on the outside of the final product housing the HYPER ANTENNA 3.1 Module. The figure below shows the contents that must be included in this label.

The OEM must make sure that FCC / IC labeling requirements are met. This includes a clearly visible exterior label on the outside of the final product housing, that displays the contents shown in below:

Contains FCC ID: S8OHYPER1730
IC ID: 5849A-HGINT1730
M/N: HYPER ANTENNA 3.1

2.2 Federal Communications Commission Statement

Limited Modular Approval:

This module is approved only for installation in devices under control of the grantee and only for models indicated in this filing. The antenna(s) used for this module must not be co-located or operated in conjunction with any other antenna or transmitter. Separate approval is required for all other operating configurations, and different antenna configurations.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation of the device"

The S8OHYPER1730 module is approved only for installation into the antenna housing types:

Alert HyperGuard Antenna V2.0 12cm
HyperGuard Antenna V2.0 18cm
HyperGUARD V2.0 Pedestal P10.

WARNING!

The antenna(s) used for this module must not be co-located or operated in conjunction with any other antenna or transmitter. Separate approval is required for all other operating configurations, and different antenna configurations".

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

2.3 Industry Canada Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This radio transmitter (IC: 5849A-HGINT1730) has been approved by Industry Canada to operate with the antenna sizes listed below with the maximum permissible gain and required antenna impedance for each antenna size indicated. Antenna sizes not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio (IC: 5849A-HGINT1730) a été approuvé par Industrie Canada pour fonctionner avec les tailles d'antenne énumérées ci-dessous et ayant un gain admissible maximal et l'impédance requise pour chaque tailles d'antenne. Antenne tailles non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur

The 5849A-HGINT1730 module is approved only for installation into the antenna housing types:

Alert HyperGuard Antenna V2.0 12cm

Alert HyperGuard Antenna V2.0 18cm


HyperGUARD V2.0 Pedestal P10.

3. MODULE HYPER ANTENNA 3.1 PCB

Module HYPER ANTENNA 3.1 have the following FCC ID and IC ID numbers:

FCC ID: S8OHYPER1730

IC ID: 5849A-HGINT1730



Top side of Antenna board



Bottom side of antenna board



Label on antenna board


3.1 Mechanical dimmensions

Length: 140 mm / 5.51 in

Width: 80 mm / 3.15 in


Height: 18 mm / 0.71 in

Weight : 95 g / 0.63 oz



4. HOW TO INTEGRATE THE MODULE INTO AN OEM ANTENNA

4.1 OEM EAS antenna




Place the module at the bottom of the EAS antenna using the parts in the board installation kit.
It is very important that the board is placed in the centerline with RJ45 connectors pointing down.

Connect the 0 loop and ground to connector P5 as shown in the drawing.

Please note:

Special considerations due to the magnetic sensor on the module
If using metal screws for fixing the module, they shall be of non ferromagnetic materials like stainless steel

4.2 OEM antenna




Place the module at the bottom of the EAS antenna using the parts in the board installation kit.
It is very important that the board is placed in the centerline with RJ45 connectors pointing down.

Connect the 0 loop to connector P5 as shown in the drawing.
The ground wire shall not be connected

Please note:

Special considerations due to the magnetic sensor on the module
If using metal screws for fixing the module, they shall be of non ferromagnetic materials like stainless steel

4.3 EAS antenna board integration kit




The RF antenna board integration kit consists of

- 4 pcb spacers with adhesive
- 4 pcb stand offs
- Alcohol swab for cleaning metal surfaces where the spacers shall be placed
- an extension cable consisting of three wires.
Two wires to the zero loop
One wire to the ground (see drawing above)
- 2.5 m / CAT5e cable terminated in one end with RJ45 connector
- 2 x RJ45 connector

4.4 Color code of the CAT5e cable

Color code and the CAT5e cable

- Wiring: EIA/TIA-568B



Article number: 9001003151