
Tablet PC



User's Guide

Preface

©Copyright 2007

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Safety Notices

- (1) Please read these safety instructions carefully.
- (2) All precautions and warnings on the equipment should be carefully noted.
- (3) Please disconnect the computer from the AC outlet before cleaning.
- (4) Never pour any liquids into any openings or directly onto the computer unit. This could result in fire or electrical shock.
- (5) Ensure the voltage range of the power outlet is between 100V and 240V before connecting the computer unit. Exceeding the maximum rated voltage may cause damage to the AC adapter or to the computer. This could result in fire or electrical shock.
- (6) Do not leave this equipment in a non-temperature controlled environment; storage temperatures below 4°C (39°F) or above 35°C (95°F) may damage the unit.

! CAUTION *To reduce the risk of an electric shock, which could cause personal injury, please follow all safety notices. The symbols shown are used in your documentation and on your equipment to indicate safety hazards.*

! CAUTION *Lithium batteries can be dangerous. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.*

! CAUTION *Under no circumstances should the user attempt to disassemble the power supply. The power supply has no user-replaceable parts. Inside the power supply are hazardous voltages that can cause serious personal injury. A defective power supply must be returned to your dealer.*

Safety Notices for the Power Cord

This equipment has a 2 or 3-wire power cord. Replace the power cord if it becomes damaged. Contact your dealer for an exact replacement.

In the U.S.A. and Canada, the power cord must be a UL-listed detachable power cord (in Canada, CSA-certified).

2-wire cord	SPT-2 18AWG
-------------	-------------

3-wire cord	SVT or SJT, 18 AWG, 3-conductor
-------------	---------------------------------

Provided with a molded-on cord connector body at the other end. The cord length must not exceed 3 meters.

Outside the U.S.A. and Canada, the plug must be rated for 250 VAC, 2.5 amp minimum, and must display an international agency approval marking. The cord must be suitable for use in the end-user's country.

Consult your dealer or the local electrical authorities if you are unsure of the type of power cord to use in your country. Voltage changes occur automatically in the power supply.

Notice of EMC Compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced technician for help.

Use only shielded I/O cables to connect I/O devices to this equipment. You are cautioned the changes or modifications not expressly approved by the party responsible for compliance could void your authority to use the equipment.

This device complies with Part 15 of the FCC Rules.

Max. SAR Measurement (Body)(1g)

802.11b: 0.121 W/kg

802.11g: 0.132 W/kg

802.11n, 20MHz: 0.193 W/kg

802.11n, 40MHz: 0.140 W/kg

Operation is subject to the following two conditions: (1) this device will not cause harmful interference, and (2) this device must accept any interference it receive including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Radiation Exposure Statement

This Transmitter has been demonstrated co-location compliance requirements with (Bluetooth/Model No: GUBTCR42M). This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

- (1) This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with FCC RF exposure compliance requirements, avoid direct contact to the transmitting antenna during transmitting.
- (2) Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

Canadian EMI Compliance Statement

This Class B digital apparatus meets all requirements of the Canadian Interference - Causing Equipment Regulations.

European Union CE Marking Declaration

This product has been tested and found to comply with the EMC requirement subject to the EU directive for CE marking.

CE Declaration of Conformity

For the following equipment: Ultra Mobile PC

CE0984!

Is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (89/336/EEC), Low-voltage Directive (73/23/EEC) and the Amendment Directive (93/68/EEC), the procedures given in European Council Directive 99/5/EC and 89/336/EEC.

The equipment was passed. The test was performed according to the following European standards:

- EN 300 328 V.1.6.1 (2004)
- EN 301 489-1 V.1.4.1 (2002) / EN 301 489-17 V.1.2.1 (2002)
- EN 50371: 2002
- EN 60950-1: 2001

Regulatory statement (802.11 a/b/g)

European standards dictate maximum radiated transmit power of 100mW EIRP and frequency range 2.400-2.4835GHz; In France, the equipment must be restricted to the 2.4465-2.4835GHz frequency range and must be restricted to indoor use.

- Inside the buildings with a power (WORSE *) maximum of 100 MW on all the frequency band 2400-2483,5 MHz,
- Outside the buildings with a power (WORSE *) maximum of 100 MW on the part 2400-2454MHz and with a power (WORSE *) maximum of 10 MW on the part 2454-2483MHz

Laser Compliance Statement for CD-ROM, DVD-ROM, CD-RW and DVD/CD-RW Combo Drives



The CD-ROM, DVD-ROM, CD-RW and DVD/CD-RW Combo drive for this computer are laser products. The classification label of the drive is located on the bottom of the drive. Below is a sample of the classification label;

CLASS 1 LASER PRODUCT
LASER KLASSE 1
LOUKAN 1 LASERLAITE
APPAREIL A LASER DE CLASSE 1
KLASS 1 LASER APPARAT

The drive is certified in the USA to comply with the requirements of the Department of Health and Human Services 21 Code of Federal Regulations (DHHS 21 CFR) Subchapter J. for Class 1 laser products.

In other countries the drive is certified to comply with the requirements of EN60825.



WARNING:

Do not open the drive. There are no user-serviceable parts or components inside. Use of controls, adjustments and operation of procedures other than those specified, may result in hazardous exposure to radiation. Class I (1) laser products are not considered hazardous. The drive has an internal, Class I (1), 0.5-milliwatt, aluminum gallium-arsenide laser that operates at a wavelength of 760 to 810 nanometers. The design of the laser system and the drive ensures that there is no exposure to laser radiation above a Class I (1) level during normal operation, user maintenance or servicing.

Table of Content

CHAPTER 1: BEFORE YOU START	1
LET YOUR COMPUTER ACCLIMATIZE ITSELF	1
PLACEMENT OF YOUR COMPUTER	1
SUITABLE PLACE TO WORK	2
CHAPTER 2: INTRODUCTION	3
UNPACKING THE COMPUTER	3
FRONT VIEW	4
SIDE 1	7
SIDE 2	8
SIDE 3	9
BOTTOM VIEW	10
CHAPTER 3: GETTING STARTED	12
INSERTING THE BATTERY PACK	12
REMOVING THE BATTERY PACK	13
OPERATING ON BATTERY POWER	15
CHARGING THE BATTERY PACK	15
CHAPTER 4: USING THE COMPUTER	18
EXTERNAL CRT DISPLAY	18
THE COMPUTER'S LED BUTTON CONTROLS	18
PREPARING THE BATTERY PACK FOR USE	21
BATTERY STATUS	21
BATTERY LOW WARNING	22
CMOS BATTERY	22
ADJUSTING THE BRIGHTNESS	23
ADJUSTING THE VOLUME	23
BATTERY STATUS	23
TURN WIRELESS ON	23
ROTATE SCREEN	23
CONNECT DISPLAY	23
SYNC SETTING	23
TURN ON/OFF	24
CHAPTER 5: USING THE DOCKING STATION (OPTIONAL)	26

OPERATION.....	28
CHAPTER 6: UPGRADING YOUR SYSTEM	29
CHAPTER 7: TROUBLESHOOTING	32
A FREEZE ON THE SYSTEM DURING PROGRAM OPERATION	32
SYSTEM NOT RESUMING OPERATION	32
THE LCD SCREEN IS TOO DARK OR TOO BRIGHT	33
BEEPING SOUND.....	33
THE SYSTEM CAN NOT SHUTDOWN PROPERLY	33
WHAT ARE THE MAJOR STEPS TO FOLLOW WHEN THE SYSTEM DOES NOT TURN ON PROPERLY AFTER IT SHUTDOWN	33
HOW TO EXTEND BATTERY LIFE	33
WIRELESS LAN CONNECTION IS DISCONNECTED AFTER 2~3 MINUTES, AND THE CONNECTION IS NOT RECOVERED.....	34
THE COMPUTER IS UNABLE TO CONNECT TO THE INTERNET.....	34
THE WIRELESS LAN IS CONNECTED, BUT I CAN NOT CONNECT TO OR TO ANOTHER COMPUTER.....	34
THE SIGNAL STRENGTH IS EXCELLENT BUT CANNOT CONNECT TO THE NETWORK.	34
CONTACTING YOUR DEALER	35
WHAT STEPS SHOULD BE TAKEN WHEN WATER ACCIDENTALLY GET INSIDE THE TABLET PC	35
THE SYSTEM CAN'T RESUME OPERATION.....	36
RECOVERING YOUR SYSTEM	36
APPENDIX A: SPECIFICATION	38
CPU.....	38
CORE LOGIC	38
VGA.....	38
VIDEO.....	38
AUDIO.....	38
MEMORY	39
BIOS.....	39
MODULAR BATTERY BAY	39
MASS STORAGE	39
DISPLAY.....	39
CAMERA	39
BIOMETRIC.....	39

AUDIO.....	39
OTHER I/O DEVICES.....	40
I/O PORTS.....	40
DOCKING STATION	40
LED INDICATOR	40
ANTENNA	40
BUTTON DEFINITION	41
POWER SYSTEM.....	41
PHYSICAL DIMENSION.....	41
ACCESSORY KIT	41
OPTIONS.....	41
REGULATORY APPROVAL	42



Chapter I

Before You Start

This manual will help you get the most from your computer. If you are a less experienced user, you should read through the manual carefully before using your computer.

What to do Before You Work on your Computer

Let your Computer acclimatize itself

Rapid changes in temperature such as those from the cold outdoors to a warm office would not be suitable for your system.



Do not power up your system immediately if it has been exposed to hot or cold conditions. Instead, allow the system to adjust gradually to room temperature over a three to four hour period.

Placement of your Computer

Choose a suitable place for your system that's not too hot, too cold, too dark, or too bright. Glare can make it difficult to read the screen.

- Allow sufficient air circulation around the computer when you are working indoors

-
- Try to keep the system components from being destroyed if it is over heated
 - Do not block the ventilation opening
 - Do not place your computer in direct sunlight

Suitable place to work

Your computer will run well under most conditions but avoid extreme temperatures and humidity levels.

There are some things you can tolerate that the computer can't – things like static electricity, dust, water, steam and oil.



A lithium-ion battery pack is included for those who are frequent travelers. When you are running your computer on battery power for the first time, remove the battery from the package, install it into the system and recharge the battery to fully prepare for service.



Chapter 2

Introduction

Introducing your Computer

Your computer features the latest advances in portable computing technology. The computer modular design provides maximum expandability without compromising portability.



WARNING:

Please never try to disassemble the Tablet PC and we will not be responsible for any damage caused by this action.

Unpacking the Computer

The computer comes securely packaged in a shipping carton. Please contact your dealer if you find that anything is missing or damaged after examining the contents. The shipping carton should contain the following items:

- AC-DC Adapter 19V 65W
- Carry Bag
- 6 cells Li-Ion Battery
- Power Cord
- Quick Guide
- Touch Pen

■ Clean Cloth


Do not throw the packaging materials away. You may need them later if you have to ship the computer.




Because of customer requirement, some of the features mentioned in this manual might not be included on your computer or may differ slightly.

Getting to Know Your Computer

Front View





(1)



(2)



(3)

(1) **Battery Indicator**

Battery Indicator (Charging: Orange, Full w/ DC: Green, Full w/o DC: OFF)

(2) **Wireless Indicator**


WLAN ON: (blue color)

(3) **HDD Indicator**

HDD Accessing (Blinking: Green color)

(4) **Built-in Camera**

This is where the built-in camera located where you can use for any video conferencing application



(5) **Rotation Screen/Vista Flip 3D LED Button**

This button will let you execute the Rotation Screen and Vista Flip 3D application.



(6) **Mobility Center/Media Center LED Button**

This button will let you execute the Mobility Center and Media Center application.



(7) **Internet Explorer/Email LED Button**

This button will let you execute the Internet Explorer and Email (Outlook) application.



Please refer to Chapter 4 for more detailed description on these above buttons.



(8) **SAS LED Button**

The same function as you often use in an ordinary keyboard of "Ctrl-Alt-Del" to log off from your Tablet PC.

Side 1



(1) Finger Print Application

The Tablet PC is equipped with the finger print application for security reason.

(2) Ventilation Opening

Please don't block this opening that serve as cooling purpose for the system.

(3) DC IN Jack

Plug the AC adapter into this jack.


(4) PCMCIA or Express Card

This compartment contains the system PCMCIA or expresscard.

(5) Scroll Application


Use this dial jog to scroll up and down just like the way you use the application in scrolling up and down arrow key and Enter key of an ordinary keyboard.

Side 2



- (1) Power Slide Latch**
Slide this latch to power on the Tablet PC.
- (2) Wireless On/Off Switch**
Slide this latch to turn On/Off the wireless LAN.
- (3) Headphone Jack**
The stereo headphone jack (3.5-mm diameter) is where you connect the headphones or external speakers.
- (4) Microphone Jack**
You can also use this as an output source by connecting a speaker.
- (5) VGA Out Port**
Use this connect to connect an external monitor.

Side 3




(1) Pen Compartment

Secures the pen to the system.

(2) Battery Latch

Slide this latch to release the battery.

Bottom View



(1) Memory Slot Compartment

This serve as compartment for your system memory.

(2) MiniPCI-E Slot Compartment

This compartment is for your MiniPCI-E slot.

(3) Docking Port

Use this port to connect to the system docking station

(4) Battery Compartment

This serve as compartment for the battery.



Chapter 3

Getting Started

Setting Up the Computer

- Remove the computer from its package. Insert the battery pack into the computer so the pack can start charging.
- Connect the computer to an external power source. Turn on the computer.

Inserting and Removing the Battery Pack

Inserting the Battery Pack





Before inserting the battery, be sure the front side of the battery is facing the top side of the system as shown in the illustration.

- Turn over the computer and place it on a solid, flat surface.
- ❶ Align the battery into the battery compartment.
- With the three edge aligning to the three slot on the battery compartment.
- ❷ Push down the battery to completely attach into the compartment.



Removing the Battery Pack

- Slide the battery latch as shown in the illustration
- ❶ Lift up the battery from the compartment.
- ❷ Pull out the battery away from its compartment.



Connecting the Computer to an External Power Source

To connect the computer to an external AC power source using the AC adapter:

- Plug the AC adapter cable into the AC power connector on the computer.
- Plug one end of the power cord into an electrical outlet and the other end into the AC adapter.



WARNING:

To prevent damage to your computer, please do not use inferior extension cords. An AC adapter comes with your computer. Never use a different kind of adapter to power the computer or other electrical devices.

Whenever possible, keep the AC adapter plugged into the computer and an electrical outlet to recharge the battery.



WARNING:

Don't try to reset your computer while the hard disk is in use as it may result in the loss or destruction of your data.

Operating on Battery Power

Your computer comes with a rechargeable battery pack that lets you operate the computer without an external power source.

When the battery pack is fully charged, you can operate the computer for approximately 2.2 hours/26Wh pack under typical condition.

Charging the Battery Pack

The installed battery pack charges automatically whenever the computer is connected to the AC adapter and an external power source.

The first time you use the battery, be sure to fully discharge the battery and recharge it until it is fully charged.

Using the Stand

The Tablet PC also provides you with a simple stand that you can use on a trip.



Chapter 4

Using the Computer


Adjusting the Screen Display

External CRT Display

You can connect an external monitor through the VGA out port.

The Computer's LED Button Controls

The computer provides you with special hot keys to execute all the major functions that you like to run on your computer.



▶▶NOTE: Use finger tip to tap the  icon twice until an orange light will lit up all these four LED button. When all the LED buttons are lighten up, you can now use these buttons to execute some of the available function provided by this system.

(1) Rotation Screen/Vista Flip 3D LED Button

Use your fingertip to tap this LED button once to convert your screen display into landscape and portrait view.

Your screen display will start rotating at **90 degrees clockwise angle** until you prefer what angle that most suited for you to view.

You can also use the “**Rotate Screen**” function on the Mobility Center to execute this application.



Tap this button for 1 second will let you execute the Vista 3D Flip application.

(2) Mobility Center/Media Center LED Button

Use your fingertip to tap this LED button to display and execute all the major function on the “**Mobility Center**” windows application.



Tap this button for 1 second will let you execute the “Media Center” application.

(3) Internet Explorer/Email LED Button

Use your fingertip by tapping this LED button to execute the Internet Explorer application.




Tap this button for 1 second will let you execute the “Email (Outlook)” application.

(4) SAS LED Button

Use your fingertip by tapping this LED button once to exit your windows operating system.

All these functions are set as the default function when you are starting to operate this system. These functions can be modified by yourself according to your preference and convenient.

-
- From the “**Control Panel**” scroll down to locate the “**Tablet PC Settings**” icon.
 - Click on the “**Buttons**” tab.



You can now change the control keys by clicking on the “**Change**” tab.

The Battery Power System

Before using the computer on battery power for the first time, disconnect the power adapter and check the battery status icon on the Windows Toolbar to make sure the battery is fully charged.

Preparing the Battery Pack for Use

Before using the battery pack for the first time, the Smart Battery IC within the battery pack should be calibrated in order to get accurate reporting of the remaining battery life status.


To calibrate the battery pack, follow the instructions below:

- Turn the computer off. Connect the AC adapter and let the battery fully recharge. When the battery charge LED turns from orange to green, the battery is fully charged.
- Turn On the computer and let the battery run down until the battery is low-low and you hear continuous warning beeps. The system will automatically enter the Suspend mode. You can now connect the AC adapter.
- The battery pack is now properly calibrated.

In general, using the battery until the low battery warning indicator appears and fully recharging the battery each time (full discharge/charge cycle) will ensure the accuracy of the battery status gauge.

Automatic Battery Pack Charging Function

You can automatically charge the battery pack by using the AC Adapter.



The charge time is almost two hours when the computer power is turned off.

Battery Status

Windows Vista has an applet in the Control Panel that will display an icon in the Windows taskbar indicating when the computer is running on battery power or is attached to the AC adapter.


This applet also displays a meter that indicates how much charge is remaining in the battery.

Battery Low Warning

When the battery is in low status, its LED indicator will blink continuously and you will hear beeping sound.

CMOS Battery


There is a small built-in battery pack that supplies power to the system in order to maintain certain system information while the power is off. If the computer is left without a power source for long period of time, this battery will be exhausted and system information will be lost.



To avoid damage, only use replacement batteries recommended by System provider. To prevent the loss of data when the system loses power, do not remove the battery pack while the power is on.

Using the Mobility Center

Drag the “**Mobility Center**” located on the right side of the Tablet PC to display the “**Mobility Center**” window dialog box.



Some of the most popular functions can be accessed from this menu.

Adjusting the Brightness

The brightness can be adjusted using the selection provided by the Mobility Center.

Use can scroll to the right direction to increase your display brightness or scroll to the left direction to decrease the brightness.

Adjusting the Volume

The volume can be adjusted using the selection provided by the Mobility Center.

Use can scroll to the right direction to increase your system volume or scroll to the left direction to decrease the volume.

Battery Status

This function indicates the remaining power of your system if you are using the system on battery charge.

Turn Wireless On

This application lets you turn on the wireless application in your system.

Rotate Screen

As previously mentioned in rotating your screen display, this function is also use to rotate your screen the same as you are tapping the  resolution icon.

Connect Display

This function detects on the external display connected to your Tablet PC for dual screen display purposes.

Sync Setting

You can use Sync Center to keep your files and other information in sync between your computer and mobile devices, network folders, and compatible programs.


Turn On/Off

This function provides an excellent tool when you are giving a presentation.

Pen Calibration

If your cursor pointer does not function well, you can select the “**Calibrate**” function available in this system.

- From the “**Control Panel**” scroll down to locate the “**Tablet PC Settings**” icon.
- Click on the “**Calibrate**” tab.



This setting will enable you to adjust the screen orientation.




Use your pen to tap on the four corners that appears on the screen.

Chapter 5


Using the Docking Station (Optional)

Front View



1. Docking Station connector

Rear View




-
1. DC Jack
 2. VGA Port
 3. USB 2.0
 4. LAN RJ45

Side View



1. Audio Line Out
2. USB 2.0 Port

Connecting the Tablet PC to the Docking Station



-
- Align the Tablet PC with its edge aligning to the two edges on the docking station
 - Push back the Tablet PC with its connector directly connecting to the connector on the docking station.


Operation

When operating your Tablet PC with the docking station installed, the power is supplied by the docking station's power supply.

Chapter 6

Upgrading Your System


Upgrading the System Memory



Upgrading the MiniPCI Card



Upgrading Your Hard Disk Drive





Chapter 7

Troubleshooting

This chapter describes locating and solving problems that you may encounter while using your computer.

General Hardware Problems / Possible Cause and Solution

A few common hardware problems and suggested solutions are presented in the table below:

A freeze on the system during program operation

An error occur during program currently being used. Press the SAS key of your Tablet PC.

Solution: An error with the Windows OS. Reboot the system using the Power button.

System Not Resuming Operation

If the system will not resume operation after system operation has been suspended, check the following possible causes:

Solution: The battery may either be defective, or discharge to a critically low level. To correct this problem, connect an external power supply such as AC adapter.

The LCD screen is too dark or too bright

Solution: Adjust the LCD brightness. Press the Mobility Center button and click on Brightness Up or Brightness Down.

Beeping sound

Solution: Connect the computer to an external power source immediately.

The system can not shutdown properly

Solution: Press and hold the power button for 4~6 seconds until the system shutdown manually.

What are the major steps to follow when the system does not turn on properly after it shutdown

The system will turn after connecting the AC adapter, this indicates the battery is in low status.

Solution:

- Check if the LCD screen is accidentally press or the LCD toggle key.
- Remove the battery and connect the AC adapter to turn on and press on the Reset the button to turn on the system.

How to extend battery life

Solution:

- Adjust the display brightness to minimum level.
- Adjust the volume to minimum level.
- Disconnect all PC card not often used.
- Turn off the Bluetooth application
- Turn off the Wireless application

-
- Set the power scheme to “Power Saving” mode

Wireless LAN connection is disconnected after 2~3 minutes, and the connection is not recovered.

Solution: The reason may be caused by channel interference, change the channel of the AP and reconnect.

The computer is unable to connect to the Internet.

Solution: Account for Internet service provider (ISP) is not properly configured. Ask for your ISP assistance.

The Wireless LAN is connected, but I can not connect to or to another computer.

Solution:

- Check the device driver is properly installed.
- Check that the device driver is properly installed. If the driver is not properly installed, you will find a yellow exclamation mark on the network icon by clicking Start > Control Panel > System > Device Manager > Network Adapters.
If there is a yellow exclamation mark, please reinstall the device driver with the system software Media.

The signal strength is excellent but cannot connect to the network.

Solution: Check the TCP/IP properties are configured properly. When you connect to an AP, click the Wireless Network Connection icon on the taskbar and select the Support tab.

Contacting Your Dealer

If you still have a problem after reading the preceding section, the next step is to contact your dealer.

Your dealer can determine if the problem is something that requires the computer to be taken to the shop. Before you call your dealer, however, please have the following information available:

Solution:

- How is your computer configured? Your dealer needs to know what peripheral devices you are using.
- What messages, if any, are on the screen?
- What software were you running at the time?
- What have you done already to try to solve the problem? If you have overlooked a step, your dealer may be able to solve the problem over the phone.

What steps should be taken when water accidentally get inside the Tablet PC

Solution:

- At this time be sure not to power on the Tablet PC or else it will cause more serious damage to the computer
- Unplug the adapter and take out the battery. Disconnect as well if there are any external devices connected (like CD-ROM or flash drive)
- Pour out the water that got inside the computer and use a soft cloth to remove the stain to avoid any more damage
- Use the fan to dry the whole system and any peripheral then send it to the closest service center for experienced personnel to diagnose and repair. This will reduce the damage to the system
- As a special reminder, be sure not to put the computer

inside the carry bag that has stain in sending the computer for repair

The system can't resume operation

Solution:

- Malfunction of external memory or internal memory – an error will occur during saving into the system memory, it will not execute normal operation
- External peripheral connected to the system not compatible – such as external USB devices, compact flash, MMC, Smart Media are complicated devices will easily cause the computer to enter standby mode thus unable to resume operation
- Un-suitable program or driver – any un-suitable driver could cause any extension file like .dll, .sys and .exe would not allow the system to enter standby or hibernate mode
- Operating System loses effect – the power saving mode of Microsoft operating system adopt ACPI mode (advanced Configuration and Power Interface), the power scheme will be handle by the OS thus affecting the power saving mode of the system

Recovering your system

Solution: Press on the F11 key to recover.



To execute this operation, an external keyboard and mouse must be connected to your system.



Appendix A

Specification

CPU

- Core Duo (ULV)--9W
- 533 MHz FSB, 2M L2 Cache (U2500 (1.2G)
- Core 2 Duo (ULV)--10W
- 533 MHz FSB, 2M L2 Cache (U7500 (1.06G)
- Micro-FCBGA onboard
- Heat Sink with PWM FAN
- Maximum 1 FAN

Core Logic

- 945GM +ICH7-M

VGA

- GMA 950 Integrated

Video

- 945GM (Simultaneous and multi-monitor)

Audio

- High Definition Audio

Memory

- 2x SODIMM Slot, Double channel, DDR2 533/667
- 4GB Maximum (1GB default)

BIOS

- BIOS includes System & Video
- Boot from USB
- Plug & Play
- APM 1.2
- ACPI 2.0

Modular Battery Bay

- Re-chargeable Lithium Ion Battery Pack (Prismatic Cell) 3S2P -- 45W

Mass Storage

- 60GB 2.5" 9.5mm height 5400 RPM SATA Ultra DMA

Display

- 12.1" XGA TFT (1024*768)
- Brightness (cd/m²) : 220 nits (typ)
- Sun-Light readable LCD Option

Camera

- 1.3 M USB Camera Built in

Biometric

- Swipe type (Built in)

Audio

- Built in Stereo Speaker *2 (High quality) → 1.5W (Bose or JBL like)
- Internal Stereo Microphone(Digital Mic)

Other I/O Devices

- Intel® PRO/Wireless 3945 ABG Network Connection(Mini-PCle)
- 10/100/1000 Fast-Ethernet (RJ45) --- Giga Lan Upgrade
- USB Blue Tooth 2.0 Module build in
- Resistive touch screen w/o Plam rejection
- Digitizer
- TPM 1.2

I/O Ports

- 1 x DC-IN Jack
- 1 x Headphone Jack (3.5mm)
- 1x Stereo Mic Jack
- 2 x 4-pin USB 2.0 Port
- 1 x Cardbus PC Card or new card
- 1x D-Sub 15 Monitor out
- 1x LAN RJ45
- Detachable Simple Cradle Connector

Docking Station

- 1 x DC-IN Jack
- 3 x USB (4 Pin Type A)
- 1 x D-SUB 15
- 1x Audio out
- 1 x LAN RJ45 (W/ LED indicator)

LED Indicator

- Power On indicator (ON : Blue, Standby : Blinking)
- Battery Indicator (Charging : Orange, Full w/ DC : Green, Full w/o DC : OFF)
- HDD Accessing (Blinking in Green)
- Wireless Status (ON : Blue)

Antenna

- Bluetooth* 1

-
- Wireless* 2

Button Definition

- Slide SW for Power
- SAS (Cntl+Alt+Del)
- Internet Explorer
- Mobility Center
- Rotation
- Wireless On/OFF
- Scroll wheel + Enter

Power System

- AC 100~240Volt, 60-65W
- 3S2P -- 45W
- Smart Charger
- Support for ACPI 2.0

Physical Dimension

- About 310 * 250 mm, thickness = 21.8mm
- 3.3 Lbs --1.5kg
- VESA Mounting Hole (70*70 or 100*100)
- Pen holder

Accessory Kit

- Simple Stand (Use VESA Hole)
- AC-DC Adapter 65W
- Carry Bag
- Quick Guide (Other language Verison Provide by Customer)
- More in discussion

Options

- Small Cradle
- VESA Plate

Regulatory Approval

- CE, FCC, VCCI, BSMI, CCC
- UL, TUV, CB report, CCC
- Contact discharge 4kV, Air Discharge 8kV (15kV if possible)
- FCC ID, CE, TELEC, DGT, SRRC