




Spinbase Setup

1. Remove Spinbase from its box. Keep the packaging in case you need to return or exchange your unit.
2. Place Spinbase on a level surface. This is important for the performance of your turntable.
3. Plug Spinbase into a power outlet using the included power adapter.



Connecting a Turntable or Record Player to Spinbase

1. Place your turntable on top of Spinbase.
2. **If using a turntable with a magnetic cartridge (most common):** Connect your turntable to "MAGNETIC PHONO" on Spinbase with the RCA cable.
3. **If using a turntable with a ceramic cartridge, or a record player with a line output:** Connect it to the "LINE IN" on Spinbase. Flip the EQ switch to match your configuration.
4. **IMPORTANT:** For turntable connections, use the ground cable to prevent hum.



One Year Warranty

Andover warrants its products against manufacturing defects and workmanship to the initial purchaser for a period of one (1) years from the date of purchase. Andover will repair the unit as necessary to restore proper operation.

If you think you need warranty service, please contact us to obtain an RMA (Return Merchandise Authorizaiton) by emailing support@andoveraudio.com or calling 978.775.3670. For more information on returns and exchanges, please visit www.andoveraudio.com/pages/returns-and-exchanges.

1. BT frequency range: 2402-2480MHz

2. Temperature: 0°C to +45°C

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

