


SF180 FM transmitter for Ipod Shuffle

Quick Start guide

Caution and Notes before using

- Due to using FM frequency, there may be some additional noise.
- IPOD TM is a registered trademark of Apple® Computer Inc. , Apple® computer Inc. does not endorse, approved or Validate this product

Product Shape



How to play with SF180 FM transmitter and Ipod Shuffle

1. Plug your Ipod Shuffle into the USB connector of the SF180 FM transmitter
2. Connect the 3.5mm to the SF180 FM transmitter and the Ipod shuffle
3. Plug the SF180 FM transmitter into the car cigarette jack, you can adjust the position of the transmitter by moving it up or down.
4. The SF180 will illuminate green on top next to the 3.5mm connector.
5. Select and play the songs from ipod control
6. Set your desired FM frequency by switching Dip Switch 1 and 2.

7. * **Caution** : The method of switching Dip Switch refers to “How to tune in FM frequency of the FM transmitter
8. Set the FM channel of the FM radio to the same as the FM transmitter
9. Adjust the volume control of the FM radio to the desired listening level.
10. Switch off the FM transmitter by sliding TX to Charger position, it will charge the

Ipod shuffle or other items using USB bus power.

How to tune in FM frequency of the SF180 FM transmitter

Slide the TX for starting the FM transmitter or Charger for charging the Ipod shuffler.

Slide the FM selector to your desired FM station (88.1, 88.3, 88.5, 88.7, 107.1, 107.3, 107.5 or 107.7).

Slide Low/Hi to either Low or Hi depending on the FM station you selected.

Low corresponds with stations 88.1, 88.3, 88.5 and 88.7 and Hi corresponds with stations 107.1, 107.3, 107.5 and 107.7.

Federal Commnuations Commission

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - ◆ Reorient or relocate the receiving antenna.
 - ◆ Increase the distance between the equipment and receiver.

- ◆ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.