

FCC Part 15 C Notice

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

INDUSTRY CANADA NOTICE: CANADA ONLY.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

X09

Palm Sized High Performance Drone



INSTRUCTION BOOKLET

WARNING: Never leave product charging unattended for extended periods of time. Always disconnect X09 from charger immediately after the X09 is fully charged. Please refer to enclosed safety instructions.

PACKAGE CONTAINS:



X09



2.4G Wireless Controller



USB Charging Cord



Spare Parts



Instruction Booklet

Colors and styles may vary slightly.



Conforms to safety requirements of RSS210 and FCC.

©2018 Rooftop Brands™ All rights reserved
Tel: + (1) 949-566-9573 • www.propelrc.com

Made in China

v 1.0

TABLE OF CONTENTS

Features	2
Remote Control Battery Installation	2
Charging the X09	2
X09 Diagram, Remote Diagram	3
Preparing for Flight	4
Syncing Your X09	4
Flying Tips	4
Now You Are Ready To Fly!	5
Recognizing the Front and Rear of the X09	5
Automatically Take Off / Land	5
Understanding The Altitude Lock	5
Speed Setting Button	5
T (Training) Mode	5
Understanding Trim Adjustments.....	6
Forward / Backward Trim	6
Banking Left / Right Trim	6
3/4 Channel Select.....	7
4 Channel Flight Control	7
3 Channel Flight Control	8
Calibrating the X09	9
How To Do 360° Stunt Rolls	9
X09 Warning:.....	10
Battery Warnings, Care and Maintenance	10
Replacing the Propeller Blade	10
FCC Part 15 C Notice	11


Thank you for purchasing the 2.4 G Indoor /Outdoor X09. Please read this instruction booklet as it contains valuable information on how to properly fly and care for your X09.

FEATURES

- Air Pressure Sensor Locks Flight Altitude
- Built In 6 Axis Gyroscopic Chip Keeps the X09 Extremely Stable in All Conditions
- T (Training) Mode Helps Beginner Pilots Learn How to Fly
- Automatically Start and Lands with The Push of A Button
- 4 Different Speed Settings for Slow to High Speed Flying

REMOTE CONTROL BATTERY INSTALLATION

1. Unscrew and remove the battery cover from the back of the remote control.
2. Install 2 "AAA" alkaline batteries into the battery compartment as shown in the diagram A1.
3. Replace the battery cover and secure it.



CHARGING THE X09

1. Before playing, you need to charge the X09 battery first. Connect the USB charging cord to the charging socket on the battery side. (See diagram A)
2. Connect the X09 charging cord to your computer's USB port (see diagram B).

Caution: The USB plug fits the charging socket only in one way. Do not force it.


Caution: Only use this charging cord with a computer USB port! Do not attempt to use other USB charging devices.

3. The red LED on the USB plug lights up when charging is complete (See diagram C).



Note: If the red LED lights up, either the charging is complete or the USB plug is not properly connected.

4. The average charging time is approximately 35-40 minutes. The X09 operates for about 5 minutes per charge.


Low battery indication: the X09's LED lights will begin to flash to notify you that the battery is running low. 45 seconds after the LED lights start flashing your X09 will automatically land to the floor.



Battery Compartment
(2 "AAA" batteries not included)




C




D

X09 DIAGRAM



REMOTE DIAGRAM



WARNING

DO NOT FLY YOUR X09 IN FOUL WEATHER!



PREPARING FOR FLIGHT

- Verify that there are 2"AAA" batteries inside the remote control unit and the X09 has been fully charged.
- Make sure to be in a large space with an open radius of at least 50 feet.
- Make sure the empty space has no obstacles or rivers. Set your X09 on a clean flat surface before take-off.

DO NOT ATTEMPT TO FLY YOUR X09 IF THERE IS RAIN, SNOW, HEAVY WINDS, THUNDER OR LIGHTNING OUTDOORS. IT COULD DAMAGE YOUR PRODUCT AND POSSIBLY EVEN CAUSE BODILY HARM.

SYNCING YOUR X09

Important! When syncing your X09 copter with the controller always make sure that the copter is on a flat level surface. This insures that the 6-axis gyro is properly programmed to mimic your trim settings.

Your X09 utilizes an automatic 2.4G channel selection system that allows up to 8 people to fly side by side in the same wireless range.

For One-person Play:

1. Before starting, make sure that both your controller and X09 are powered off. Make sure that there are no other 2.4G devices in the area as well.
2. Connect the battery into your X09 and set it down on a flat level surface. The white and red LED indicators of the X09 should start flashing rapidly.
3. Turn ON your remote and you will hear 1 short beep, the white and red LED lights will start flashing slower. Push the throttle all the way up then pull it all the way down. You will hear 2 beeps and the LED lights will turn solid. Your X09 and remote should have successfully synced. Should this not happen, repeat all steps again.

For Multi-person Play:

4. Before starting, make sure that all X09s and Controllers are powered off. Make sure that there are no other 2.4G devices in the area as well.
5. Each person will have to sync their X09 individually at a different time to avoid interference. Follow steps 1 to 3 above, making sure to keep away from other people while also making sure that no one else is syncing at the same time.
6. After syncing one player's X09, it should be left ON until all players have synced their X09s.
7. Should there be a mistake/interference, all players must turn off their controllers and X09s and start the process all over again.

FLYING TIPS

- It is recommended that you operate the X09 in a wide space. The ideal space should have a 61 m/200 ft radius.
- Parental guidance or adult supervision is suggested at all times.
- If you are flying the X09 with others, make sure all spectators are behind you.
- For best performance, it is recommended that you operate the X09 in zero wind conditions. Wind can greatly affect the performance of the X09.


NOW YOU ARE READY TO FLY!

If you have successfully synced your X09 to your controller as explained on page 4 you are now ready to fly. Before beginning to fly your drone you should familiarize yourself with how to start and stop the rotors, how to use your take off and auto land feature and how the controls work. please carefully read and familiarize yourself with various control features explained in the next few pages. Once again as a beginner pilot you should learn how to control your drone in a large open field or park on a day with zero or very light wind. Do not try to fly your X09 too high until you become a more experienced pilot.

RECOGNIZING THE FRONT AND REAR OF THE X09

Even though the X09 has four rotors there is still a front or forward-facing direction and back or backwards-facing direction. The Front and forward-facing direction of the X09 is the side with two holes. The rear and back of the X09 is where the battery charging socket and the power ON/OFF is. The X09 when in flight will also help you keep aware of the orientation with lighted LED lights in the arms of the X09.

NOTE:The front of the copter displays WHITE LED light and the back of the copter displays RED LED light.




AUTOMATICALLY TAKE OFF / LAND

Make sure you have properly synced The X09.

- simply press the Auto Start/Land button, your X09 will automatically take off.
- To stop or land the X09 just Press the Auto Start/Land button again and the X09 will descend and land automatically.

Tips:You also can move the two control sticks simultaneously down to the inside corners, hold them till you hear a “beep” and the blades start spinning. Release the control sticks and push the throttle stick slowly to take off manually.



UNDERSTANDING THE ALTITUDE LOCK

The X09 has a unique Altitude Lock function. With the help of air pressure sensor you can control, your X09 more stable than ever. The sensor locks in the altitude of the copter while allowing the user to adjust the directional control without having to hold the throttle.

After starting the copter, fly upwards to a safe height. Once at a safe height, let go of the throttle control, your X09 should lock in the altitude and allow the user to focus on getting used to the directional controls.

NOTE:The altitude sensor does have some tolerance based on atmospheric conditions and could have a slight variation in altitude.

SPEED SETTING BUTTON

The X09 has 4 speed Modes; **T(Training)**, **1(SLOW)**, **2(MEDIUM)** and **3(HIGH)**. The Default setting when you first turn on your X09 is **1(SLOW)**. Short press speed button you can switch among the 3 speed settings.


T (Training)MODE

Simply press and hold the Speed Button, you will hear a long beep indicating you are in T Mode now. T mode allows you to learn how to operate your X09 at a very slow speed. Also there are maximum and minimum height limits set to avoid crashing to ceiling or floor in T mode. To exit T mode just press the speed setting button again.


UNDERSTANDING TRIM ADJUSTMENTS

Forward/Backward Trim


- If your X09 is moving forwards or backwards automatically, you may need to adjust the FORWARD/BACKWARD TRIM buttons.
- If your X09 flies forward, push and release the Backward TRIM button repeatedly until the moving stops and proper flight is maintained.
- If your X09 flies backwards, push and release the Forward TRIM button in the same manner until the problem is resolved.
- From time to time you may have to adjust the FORWARD/BACKWARD TRIM to ensure the X09 will hover in mid-air and respond accurately to your commands.



Forward/Backward Trim Controls




Push backward trim button




Push forward trim button

Banking Left/Right Trim


- If your X09 is not steadily hovering and is banking to the left or right automatically, you may need to adjust the BANKING TRIM buttons.
- If your X09 banks to the left, push and release the R Trim button repeatedly until the banking stops and proper flight is maintained.
- If your X09 banks to the right, push and release the L Trim button in the same manner until the problem is resolved.
- From time to time you may have to adjust the BANKING TRIM to ensure the X09 will and respond accurately to your commands.



Left/Right Banking Controls



Push the “ L ” trim button to increase left banking sensitivity



Push the “ R ” trim button to increase Right banking sensitivity

NOTE: The use of the Trim buttons are accompanied with a beep tone. A single long beep indicates the product is centre-trimmed. No beeping after press the trim button indicates the product is trimmed to the maximum on a particular side.

3/4 CHANNEL SELECT



X09 allows you to control your Quadcopter in 3 channel mode (beginner) or 4 channel mode (advanced flying). The X09 default setting is 4 channel mode.

To change to 3 channel mode:


PRESS the Throttle Control stick vertically down then release, you will hear 3 short beeps indicating the X09 now is set to 3CH mode.

To change back to 4 Channel mode:

PRESS the Throttle Control stick vertically down then release again, you will hear 4 short beeps indicating the X09 is now set to 4CH mode.



Move the Direction Control left and the X09 will bank to the left.




Move the Direction Control right and the X09 will bank to the right.

3 CHANNEL FLIGHT CONTROL

For beginner pilot, you may want to practice in 3 CHANNEL mode first. Press the direction control stick vertically down, you will hear a beep and now you are in 3 CHANNEL mode. Follow the below steps to start your flight practice. (Note: To switch back to 4 CHANNEL MODE, just press the Direction Control Stick again, you will also hear a beep too.)


4 CHANNEL FLIGHT CONTROL




Move the Throttle up to increase the speed of the motors and the X09 will rise up.




Move the Throttle down to decrease the speed of the motors and the X09 will descend.




Move the Throttle stick left and the X09 will rotate left.



Move the Throttle stick right and the X09 will rotate right.



Move the Direction Control up and the X09 will move forward.




Move the Direction Control down and the X09 will move backward.




Move the Throttle up to increase the speed of the motors and the X09 will rise up.




Move the Throttle down to decrease the speed of the motors and the X09 will descend.




Move the Throttle stick left and the X09 will rotate left.



Move the Throttle stick right and the X09 will rotate right.




Move the Direction Control up and the X09 will move forward.



Move the Direction Control down and the X09 will move backward.

CALIBRATING THE X09


If the X09 becomes unstable during the course of flying, you may need to calibrate the internal gyros. To do this place the X09 on a flat level surface. The LEDs on the X09 will flash quickly and then remain solid, this indicates your drone has been recalibrated (see diagram E).



E

HOW TO DO 360° STUNT ROLLS

1. In order to make your X09 do 360° rolls you must fully charge your battery.
Note: The X09 will not do 360° stunt rolls in Mode 1 or under low battery indication (The LED lights on the drone will be flashing).
2. Once you are ready to attempt a 360° roll, simply depress and let go of the "STUNT" button on the top right hand side of your controller (see Remote Diagram on page 3). You will hear beeping sounds, this means you are now in "STUNT MODE."
3. Now quickly move your right control stick in any of 4 directions; up, down, left or right. Your X09 copter will instantly roll in the associated direction. See diagram below.
Note: After performed the stunt roll, the beeping sounds will stop. Repeat step 2 to 3 if you wish to do it again.



F

G

X09 WARNING:

The X09 is designed for INDOOR and OUTDOOR use. The X09 blades revolve at high speeds and can cause damage to the user, spectators and animals. Stand away from the X09 to reduce the risk of getting into the flight path. Warn spectators that you will be flying your X09 so that they are aware of its position. Before flight, inspect the rotor blades to make certain that the blades are securely fastened to the X09.

WARNING!

- Choking/Cutting Hazard. Small Parts/Sharp Rotor Blades.
- Keep hands, hair and loose clothing away from the propeller when the power switch is turned to the ON position.
- Turn off the transmitter and X09 power switches when not in use.
- The included charger is built specifically for the X09 Li-Poly battery. Do not use it to charge any other battery.
- New alkaline batteries are recommended for maximum performance.
- Parental supervision recommended when flying X09.

BATTERY WARNINGS

RECHARGEABLE BATTERY:

This X09 uses a Li-Poly rechargeable battery. If battery no longer stays charged, dispose of battery properly according to local disposal requirements.

CONTROLLER BATTERIES:

Remote control requires 2 "AAA" batteries (not included). Please read the important battery safety warning below.

- Do not mix alkaline, standard (carbon-zinc) and rechargeable batteries (nickel metal hydride).
- Do not mix old and new batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the item before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision.
- Exhausted batteries should be removed immediately and must be recycled or disposed of properly according to state or local government ordinances and regulations.
- The supply terminals are not to be short-circuited.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity (see inside booklet for diagram).
- Do not dispose of batteries in a fire - batteries may leak or explode.


CARE AND MAINTENANCE

- Always remove the batteries from the wireless infrared remote control when it is not being used for an extended period of time.
- To clean, gently wipe the remote control and X09 with a clean damp cloth.
- Keep the toy away from direct heat or sunlight.
- Do not submerge the toy into water. This can damage the unit beyond repair.
- Parental guidance recommended when installing or replacing the batteries.

REPLACING THE PROPELLER BLADE

Your X09 propeller system is a precision instrument that may need repair or replacement from time to time for optimal flight function. Crash landing from high-speed aerial flights may cause damage to your X09 propellers.

1. X09 has four blades, two gray propellers on the front and two black propellers on the back.
2. When taking off the damaged blade, always use the included blade wrench. Refer to the instruction diagrams below. Always use mild force, be gentle!
3. When replacing the new blades, make sure to match the indicating letter embossed on the blades to the diagram below.



Blade Front Left = A
Blade Front Right = B

Blade Rear Left = C
Blade Rear Right = D