


Wall Switch Layout




Instructions

For all following programming commands, the motor must be placed into "Pairing Mode"

To Enter Pairing Mode Press and hold button on motor head for 2-3 seconds (until motor jogs). If your motor doesn't have a button on the motor head, you must disconnect power for 3-5 seconds, then reconnect power. Alternate method: If the wireless wall switch is already Paired, then hold STOP for approximately 5 seconds. Note that the motor will stay in Pairing Mode for 2 minutes. The motor will time out on it's own, and you do not need to save and exit from Pairing Mode.

Pair Handsender to Motor / Learn Channel Expected Response:

Select desired channel, then hold Open and Close.



- The wallswitch will give a slow blink
- After 3-5 seconds, the motor will jog
- Motor will now work on this channel
- Note: Each motor can learn up to 4 channels

Delete Channel from Motor

Select desired channel, then hold Stop and Open.



- The wallswitch will give a slow blink
- After 3-5 seconds, the motor will jog
- Motor will no longer respond to this channel

Reverse Motor Direction (Electronic Limit Motors)

Select desired channel, then hold Stop and Close to enter Programming Mode, then



Hold Open and Close to Reverse Direction, then



Hold Stop to save settings and exit Programming Mode



- The wallswitch will give a slow blink
- After 3-5 seconds, the motor will jog
- Motor is in Programming Mode
- The wallswitch will give a slow blink
- After 3-5 seconds, the motor will jog
- Travel direction is now reversed
- The wallswitch will give a slow blink
- After 3-5 seconds, the motor will jog
- Settings are now saved

Reverse Motor Direction (Mechanical Limit Motors)

Select desired channel, then hold Stop and Close.



- The wallswitch will give a slow blink
- After 3-5 seconds, the motor will jog
- Travel direction is now reversed

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.