

# 9906PCB-2 车载无线充电模块


充电使用说明书




红色线连接汽车电源DC12V+,黑色线连接汽车电源 DC12-,蓝色LED点亮,进入待机模式。



将具有无线电源接收功能的手机放置产品线圈中间 位置,绿色LED点亮,即可以实现无线充电功能。



充电完成,取走手机。绿色LED熄灭。蓝色LED点亮。



## LED模式功能说明

模式1		支持	充电	充满	错误
当于态灯着颜能右功能 与传机,是自和根这图 是一种,是一种,是一种,是一种,是一种,是一种,是一种,是一种,是一种。 是一种,是一种,是一种。	红色LED	开	关	关	闪烁
	绿色LED	关	关	开	关
	蓝色LED	关	开	关	关

模	模式2		充电	充满	错误
当pcba处 于待机状 态时,led	红色LED	关	关	关	闪烁
灯着颜能之 制度 新的功据 是 的 的 的 的 的 的 的 的 的 的 的 的 的 的 的 的 的 的	绿色LED	关	关	开	关
	蓝色LED	关	开	关	关

A:关机功能: 待机红色LED灯状态下长按三秒,红色LED闪烁后关机. B:开机功能:关机状态下长按三秒红色LED灯闪烁后开机。 C:模式切换:短按一下由模式1与模式2循环切换。

- 当充电器上的接收装置放置的位置不对,或放置非Ql标 准指定发射装置时充电器不进行充电。 · 当手机放上去的时候出现错误,需拿起来重放,而不是
- 继续放著左右对位。

本无线充电产品可以对市场上符合WPC标准的接收器相 容使用。

# FCC声明:

该设备符合FCC规则的第15部分。操作受以下 条款限制两个条件,

- (1)本设备不会造成有害干扰,并且
- (2)本设备必须接受任何收到的干扰,包括可 能产生的干扰导致不希望的操作。

警告: 未经责任方明确批准的变更或修改 合规性可能会使用户操作设备的权限失效。 注意: 本设备已经过测试, 符合B类限制 数字设备,依照FCC规则的第15部分。这些限

制旨在提供合理保护,防止住宅内的有害干扰。 这个设备会产生使用并可能辐射无线电频率能 量,如果没有安装并按照说明使用,可能会对 收音机造成有害干扰通信。但是,不能保证干 扰不会发生在a

特别安装。如果此设备确实会对无线电或电台 造成有害干扰电视接收,可以通过关闭和打开 设备来确定鼓励用户尝试通过以下一项或多项

措施来纠正干扰措施: 重新调整或摆放接收天线。

增加设备和接收器之间的距离。

将设备连接到不同干该设备的电路上的插座 接收器已连接。

咨询经销商或有经验的无线电/电视技术人员寻 求帮助。


### FCC辐射暴露声明:

本设备符合FCC规定的辐射暴露限值 不受控制的环境。这个设备应该安装和操作 散热器和身体之间的距离至少为20厘米


# 9906PCB-2

# Wireless Charging Module for Vehicle


**Using Guide** 




Connect red line to car power DC12V+, Connect black line to car power DC12V-. When red light on the device is in standby mode.



Put mobile phone with wireless charging receiver into the area of 3 coils. The blue light will be on which means wireless charging is working.



Green light on means charging full. When take mobile phone away, the green light will be off and red light will be on.



## LED Mode Function Guide

Mode1		Standby	Charging	Charging Full	Error
Mode 1. While the PCBA is in standby the LED light will be on. The LED color and function will be according to this diagram.	Red	On	Off	Off	Blink Slow
	Green	Off	Off	On	Off
	Blue	Off	On	Off	Off

Mode2		Standby	Charging	Charging Full	Error
Mode 2. While the PCBA is in standby the LED light will be on. The LED color and function will be according to this diagram.	Red	Off	Off	Off	Blink Slow
	Green	Off	Off	On	Off
	Blue	Off	On	Off	Off

- A: Switch Off: When under standby mode, red light is on, push switch last for 3 seconds. Red light flashes then power of
- B: Switch on: When under power off, push switch last for 3 seconds. Red light flashes then power on.
- C: Mode Switch: Push switch one time will switch mode1 to mode 2 circularly.

- · Please use qualified Oi receiving device for charging. If the position of receiver is not right, It may show no connection or cannot charge. Please adjust the position. Compatibility:
- · This production is compatible with all wireless charging receiver with WPC standard.

### FCC STATEMENT

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following
- two conditions:
  (1) This device may not cause harmful interference, and
  (2) This device must accept any interference received, including
- (2) This device that may cause undesired energy interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the
- compilarities could viol the user's actioning to operate the equipment.

  NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, presuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This
- installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

- Interterence will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following
- measures:

  Reorient or relocate the receiving an tenna.

  Increase the separation between the equipment and receiver.

  Connect the equipment into an outlet on a circuit different from that to which the
- receiver is connected.

  Consult the dealer or an experienced radio/TV technician for help.
- FCC Radiation Exposure Statement:
  This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and
- operated with minimum distance 20cm between the radiator & your body

# Integration instructions for host product manufacturers according to KDB 996369 D03 OEM Manual v01

# 2.2 List of applicable FCC rules

FCC Part 15 Subpart C 15.207 & 15.209

## 2.3 Specific operational use conditions

The module is a Wireless charger module with Wireless charger function.

Operation Frequency: 110.1-205KHz

Modulation: MSK

Type: Inductive loop coil Antenna

Gain: 0 dBi Max.

This module should be installed and operated with minimum distance 20cm between the radiator & your body with a maximum 0dBi antenna. The host manufacturer installing this module into their product must ensure that the final composit product complies with the FCC requirements by a technical assessment or evaluation to the FCC rules, including the transmitter operation. The host manufacturer has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The end user manual shall include all required regulatory information/warning as show in this manual.

# 2.4 Limited module procedures

The module is approved as a "limited module" without shielding. The device can be used in mobile exposure conditions only. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

# 2.5 Trace antenna designs

Not applicable. The module has its own antenna, and doesn't need a host's printed board microstrip trace antenna etc.

## 2.6 RF exposure considerations

The module must be installed in the host equipment such that at least 20cm is maintained between the antenna and users' body; and if RF exposure statement or module layout is changed, then the host product manufacturer required to take responsibility of the module through a change in FCC ID or new application. The FCC ID of the module cannot be used on the final product. In these circumstances, the host manufacturer will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

# 2.7 Antennas

Antenna Specification are as follows:

Type: Inductive loop coil Antenna

Gain: 0 dBi

This device is intended only for host manufacturers under the following conditions:

The transmitter module may not be co-located with any other transmitter or antenna;

The module shall be only used with the internal antenna(s) that has been originally tested and certified with this module. The antenna must be either permanently attached or employ a 'unique' antenna coupler.

As long as the conditions above are met, further transmitter test will not be required. However, the host manufacturer is still responsible for testing their end-product for any additional compliance requirements required with this module installed (for example, digital device emissions, PC peripheral requirements, etc.).

# 2.8 Label and compliance information

Host product manufacturers need to provide a physical or e-label stating "Contains FCC ID: **2AQPB-9906PCB-2**" with their finished product.

# 2.9 Information on test modes and additional testing requirements

Operation Frequency: 110.1-205KHz

Modulation: MSK

Host manufacturer must perfom test of radiated & conducted emission and spurious emission, etc according to the actual test modes for a stand-alone modular transmitter in a host, as well as for multiple simultaneously transmitting modules or other transmitters in a host product.

Only when all the test results of test modes comply with FCC requirements, then the end product can be sold legally.

# 2.10 Additional testing, Part 15 Subpart B disclaimer

The modular transmitter is **only** FCC authorized for FCC Part 15 Subpart C 15.207 & 15.209 and that the host product manufacturer is responsible for compliance to any other FCC rules that apply to the host not covered by the modular transmitter grant of certification. If the grantee markets their product as being Part 15 Subpart B compliant (when it also contains unintentional-radiator digital circuity), then the grantee shall provide a notice stating that the final host product still requires Part 15 Subpart B compliance testing with the modular transmitter installed.