



English | Spanish | French | German | Italian | Polish | Finnish



United States.....	888 587 2673
Australia.....	1800 061 046
Canada.....	877 721 9154
China.....	86 400 880 2266
Germany.....	0800 2673 444
Hong Kong.....	852 2123 9000
Hungary.....	6040434 31
India.....	1800 11 2673
Italy.....	800 83 22 77
Japan.....	0570 080 021
Latin Markets, Other.....	508 614 6000
Mexico.....	001 866 693 2673
New Zealand.....	0800 501 511
Taiwan.....	886 2 2514 7977
United Arab Emirates.....	+97148861300
UK.....	0800 279 7347
Austria.....	www.bose.at
Belgium.....	www.bosebelgium.be
Denmark.....	www.bose.dk
Finland.....	www.bose.fi
France.....	www.bose.fr
Hungary.....	www.bose.hu
Ireland.....	www.bose.ie
Luxemburg.....	www.bose.lu
Netherlands.....	www.bose.nl
Norway.....	www.bose.no
Poland.....	www.bose.pl
Sweden.....	www.bose.se
Switzerland.....	www.bose.ch

For additional European countries, please visit <http://global.bose.com>

**BOSE**  
Better sound through research®  
©2014 Bose Corporation, The Mountain,  
Frammingham, MA 01701-9168 USA  
AM722305 Rev.00

ENGLISH

Please read and follow this Quick Start Guide and the Important Safety Information and keep for future reference.

Pairing a mobile device

- Slide the Power/Bluetooth button **E** all the way up to the symbol and hold until you hear, "Ready to pair" or you see the Bluetooth indicator blinking blue. **E F**
- On your mobile device, turn on Bluetooth. Select **Bose OE SoundLink** in your mobile device's Bluetooth list. You will hear, "Connected to <device name>" or you will see the Bluetooth indicator glow solid white.

**Note:** Visit [owners.bose.com/SoundLinkOE](http://owners.bose.com/SoundLinkOE) to see how-to videos (English only), or refer to your mobile device's owner's guide to learn how it pairs/connects.

To change the voice prompt language **C**

With the headphones on your head, press and hold **+** and **+** together for five seconds. Press the volume buttons to move through the list of available languages: English, Spanish, French, German, Mandarin, Japanese, Italian, Portuguese, Dutch, Russian, and Polish. When you hear the language you want, press and hold **+**.

Headphone controls **C**

	Volume up	Press once to play/pause or answer/end a call.
	Multi-function button	Double press to track forward. Triple press to track back. Press and hold to ignore an incoming call.
	Volume down	Press and hold to activate voice dial (Sir).

To add another device

Repeat Step 1 and Step 2 above for each new device.

The headphones can store eight devices in memory. When powered on, the headphones will automatically connect to the first two devices in memory, for example a tablet for audio, and a phone for calls.

Managing devices

Slide up and release the Power/Bluetooth button **E** to move through the list of devices in memory. Repeat until you hear the device you want to control. **E**

**Note:** If a device is not present, move to the next device.

Indicators **F**

	Blue blinking: Ready to pair White blinking: Connecting White solid: Connected
	Green: Full charge Amber: Medium charge Red blinking: Charge needed

Charging **B**

Plug the small end of the USB cable into the micro-USB connector on the right earcup. Plug the other end into a USB wall charger or computer that is on.

**Note:** The headphones will not play while charging.

Using the back-up audio cable **A**

Use the supplied back-up audio cable to connect a non-wireless device or if the headphones battery is depleted.

Please refer to the Owner's Guide, available online, for more information about your headphones, including advanced functions, additional troubleshooting suggestions, and information on accessories and replacement parts. To request a printed copy of the complete Owner's Guide, please refer to the contact information on this sheet for phone numbers for your region.

Troubleshooting

Headphones do not connect with mobile device

- On your device, turn off Bluetooth and turn it back on.
- Remove the headphones from the Bluetooth list on your mobile device. Then repeat steps 1-2 above.
- Try pairing another mobile device.
- Visit [owners.bose.com/SoundLinkOE](http://owners.bose.com/SoundLinkOE) to see how-to videos (English only).
- Reset the headphones: Make sure **Bose OE SoundLink** is removed from the Bluetooth list on your mobile device. Slide up and hold **E** for 10 seconds. Then repeat steps 1-2 above.

No sound

- Make sure the headphones power is on and battery is charged.
- Make sure the volume is turned up on the headphones and on your mobile device (or music app).
- Your mobile device may be connected to another Bluetooth speaker or headset. Make sure that **Bose OE SoundLink** is selected in the Bluetooth device list.
- Try pairing another mobile device.

Poor sound quality

- Move the mobile device closer to the headphones, and away from any interference.
- Try pairing another mobile device.

Technical Information

Operating time: 15 hours  
Bluetooth range: 33 ft. (10 m)

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Bose Corporation is under license.

iPad, iPhone, iPod, iPod touch, iPod shuffle, and Retina are trademarks of Apple Inc., registered in the U.S. and other countries. iPad Air and iPad mini are trademarks of Apple Inc. The trademark "iPhone" is used with a license from Apple K.K.

"Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance.

©2014 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.

SPANISH

FRENCH