


Bright Star Engineering

VCI POD

User Guide



Bright Star Engineering

299 Ballardvale Street, Suite 5
Wilmington, MA 01887

Tel: (978) 642-3200

Fax: (978) 642-3199

www.brightstareng.com

Notice

The information in this document is subject to change without notice. THE SOFTWARE AND DOCUMENTATION ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FURTHER, Bright Star Engineering DOES NOT, GUARANTEE, OR MAKE ANY REPRESENTATIONS REGARDING USE, OR THE RESULTS OF THE USE, OF THE SOFTWARE OR WRITTEN MATERIAL IN TERMS OF CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE.

Restricted Rights Legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

This document may not, in whole or in part, be copied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior consent, in writing, from Bright Star Engineering, Inc.

Copyright © 2008 Bright Star Engineering, Inc.

All Rights Reserved
Printed in the USA

Table of Contents

Revision History	1
Getting Started with the Device	2
Setting Up and Powering On	2
Connecting to the Network	2
LAN with DHCP	2
LAN with Static IP Addressing	2
Device Discovery Mechanism	2
Device Overview	3
LEDs	3
Reset Button.....	3
Configuring Device and Network Settings.....	4
Using the HTTP Interface	4
System Settings.....	5
Network Settings.....	6
Wireless Settings	7
Manage Networks.....	9
Reset to Factory Defaults	11
Backup Settings.....	12
Software.....	13
Software Upgrades.....	13
Using the HTTP Installer	13
Recovering from a Failed Upgrade	13
Installing Applications.....	14

Revision History

Revision	Date	Description
1.0	July 28, 2008	Initial release of platform documentation

Getting Started with the Device

Setting Up and Powering On

Attach the DC power supply to the device. Verify the green PWR LED is on. As soon as power is supplied to the device it will begin a boot sequence. The BUSY LED will be on during the boot phase. Once the device is booted into normal operational mode the PWR LED will be on and all other LEDs will remain off.

Connecting to the Network

Connect an Ethernet cable to the device. You can connect the other end of the Ethernet cable to a computer or network device such as a switch or router depending on your local area network configuration (see below).

LAN with DHCP

The default TCP/IP settings for the Ethernet network interface will use DHCP to obtain an IP Address, subnet mask, gateway, and DNS information. If your local area network supports this configuration, connect the Ethernet cable to a switch, hub, or router on your LAN.

LAN with Static IP Addressing

If the device requires a static IP Address to communicate with other nodes on your local area network you will first have to connect the Ethernet cable to another computer running software that supports ZCIP. The device is equipped to use a ZCIP address when DHCP is not available. An address of 169.254.253.252 is used if possible; otherwise a random ZCIP address is assigned.

Device Discovery Mechanism

Both the Service Location Protocol (SLP) and Multicast DNS (mDNS) are supported for device discovery.

If you do not have a copy of the Bright Star Engineering device locator utility, dFind, use a web browser to download the utility from:

<http://www.brightstareng.com/support/dfind.html>.

Start dFind on a computer connected to the same network as the device. dFind uses the mDNS protocol to advertise as a service. The IP Address and serial number for the device will be shown on the dFind screen. Double click with your mouse on the line for the device you wish to connect to. The device configuration web site will appear.

Device Overview

LEDs

The device has three (3) LEDs on an end panel. Moving from left to right the LEDs are described below.

BUSY	Busy LED will be on during system boot. During normal device operation this LED is not used, remains off, and is available to applications that wish to show the device is processing data, for example vehicle traffic or application data crunching. When the device boots into Recovery Mode, this LED will blink rapidly in unison with the WLAN LED.
SAFE	This LED will be turned on whenever the device enters a mode of operation where a known good network configuration is used. The default SAFE configuration uses DHCP to acquire a TCP/IP address.
WLAN	This led will be on when the WLAN is being used and blink to indicate network traffic across the interface.
REC	This is an application specific LED, not used directly by the device system software,
PWR	Power LED indicates the device has power from a vehicle source and/or an DC adapter


Reset Button

- On the front panel is a small opening for the reset button. This button serves two purposes. First, the button can be pressed when applying power to force the device into Recovery Mode. The device will boot into a limited configuration that will allow you to apply a product software upgrade via the provided web interface. This mode should be used to re-install the system software in the event the device is not operating as expected.
- The second use of the reset button is to put the Ethernet network interface into a default state. Pressing and holding the reset button for 5 or more seconds, then releasing it when the device is running normally will restart the Ethernet network interface with configuration settings for connecting to a TCP/IP local area network using DHCP. The subnet mask, gateway, and DNS information is expected to be provided via the DHCP server. The device can then be located on the network using dFind, Bright Star Engineering provided device location utility (see **Device Discovery Mechanism** above).

Configuring Device and Network Settings

Using the HTTP Interface

Shown below is the main screen for the device configuration web site. The Overview page will provide you with version information for the hardware and software and the device serial number.



System Settings

The screenshot shows a web browser window titled "Home - Mozilla Firefox" with the address bar displaying "http://192.168.1.168/". The page has a blue header with the "System Settings" title and "Save", "Reset", and "Help" buttons. On the left is a sidebar with a "wiTECH VCI POD" logo and a menu: Overview, System Settings (selected), Network Settings, Wireless Settings, Manage Networks, Software Upgrades, Factory Defaults, Backup Settings, Help, and License Information. The main content area includes a section "Assign a Name to the device" with a "Device Name" field containing "0050150C002F". Below this is a section "wiTECH VCI POD is a member of Work Group" with a "Work Group Name" field containing "defaultWorkgroup". A "Date" section contains dropdowns for "Month" (July), "Day" (28), and "Year" (2008), along with a "Set Date & Time" button. A "Time" section contains dropdowns for "Hour" (14), "Min" (20), and "Sec" (44). A warning message states: "Rebooting the device will cause a temporary loss of connection between your Web browser and the device." Below this is a "Reboot Device" button. The browser's status bar at the bottom shows "Done".

You can assign a name to the device that will be shown on the device discovery utility screen in place of the default serial number. You may also wish to set the date and time on the device.

Device Name Assign a name to the device. This name will appear on the device locator utility screen that shows the devices available on the network. Click on the **Save** button to store the new device name.

Work Group Assign a work group name to the device. Click on the **Save** button to store the new device name.

Date & Time Set the date and time for the device. Use the drop down selection boxes to select the current date and time. Click on the **Set Date & Time** button to store the new date and time.

Reboot Device Use this button to force the device to perform a system reboot.

Network Settings

Home - Mozilla Firefox

File Edit View History Bookmarks Tools Help

http://192.168.1.168/

Issue Navigator - DaimlerChrysler

Home

Network Settings

Profile: netsafe [v] [New...] [Save] [Reset] [Delete] [Help]

You can choose to have your network address and settings automatically assigned if your network supports it. Otherwise, please check with your Network Systems Coordinator to obtain the appropriate settings to enter on this screen.

☒ Obtain an IP address automatically from a DHCP server
☐ Use the following IP address and settings

IP Settings

IP Addr: [text box]
Net Mask: [text box]
Gateway: [text box]
DNS 1: [text box]
DNS 2: [text box]

Overview
System Settings
Network Settings
Wireless Settings
Manage Networks
Software Upgrades
Factory Defaults
Backup Settings
Help
License Information

Done

You can choose to have your network address and settings automatically assigned if your network supports it. Otherwise, please check with your Network Systems Coordinator to obtain the appropriate settings to enter on this screen.

Automatic or Static To have an automatically assigned network address choose **Obtain an IP address automatically from a DHCP server**

If you will be using static IP addressing for the device, choose **Use the following IP address and settings**

IP Settings IP Address

Enter the IP address assigned to this device, typically provided to you by your network or system administrator, for example 192.168.1.100.

Net Mask

Enter the network address mask used by the device, typically provided to you by your network or system administrator, for example 255.255.255.0.

Gateway

Enter the IP address for the machine on your network that

DNS1

acts as a gateway to other networks. Your network or system administrator typically provides this address, for example 192.168.1.1, to you.

DNS2

Enter the IP address for the machine that should be used as the primary Domain Name Server. If your network is configured to use DNS your network or system administrator will provide this to you.

Enter the IP address for the machine that should be used as the secondary Domain Name Server. If your network is configured to use DNS your network or system administrator will provide this to you.

Wireless Settings

Home - Mozilla Firefox

File Edit View History Bookmarks Tools Help

http://192.168.1.168/

Issue Navigator - DaimlerChrysler

Home

Wireless Settings

Profile: default [New...] [Save] [Reset] [Delete] [Help]

☒ Obtain an IP address from DHCP server
☐ Use the following IP address and settings

IP Settings

IP Addr: []
Net Mask: []
Gateway: []
DNS 1: [] DNS 2: []

☒ Connect to an Access Point
☐ Connect to another computer using Adhoc network (not supported)

Security Settings

SSID: my-essid
Security: WEP 128
Enter Key: [] ☒ Key in HEX
Confirm Key: []
Note: Key can only be saved when confirmed.
Edit Key: 1 Use Key: 1

Overview
System Settings
Network Settings
Wireless Settings
Manage Networks
Software Upgrades
Factory Defaults
Backup Settings
Help
License Information

Done

You can choose to have your network address and settings automatically assigned if your network supports it. Otherwise, please check with your Network Systems Coordinator to obtain the appropriate settings to enter on this screen.

Automatic or Static

To have an automatically assigned network address, choose **Obtain an IP address automatically from a DHCP server**.

If you will be using static IP addressing for the Device, choose **Use the following IP address and settings**.

IP Settings

IP Address

Enter the IP address assigned to this Device, typically provided to you by your network or system administrator, for example 192.168.1.100.

Net Mask

Enter the network address mask used by the Device, typically provided to you by your network or system administrator, for example 255.255.255.0.

Gateway

Enter the IP address for the machine on your network that acts as a gateway to other networks. Your network or system administrator typically provides this address, for example 192.168.1.1, to you.

DNS1

Enter the IP address for the machine that should be used as the primary Domain Name Server. If your network is configured to use DNS your network or system administrator will provide this to you.

DNS2

Enter the IP address for the machine that should be used as the secondary Domain Name Server. If your network is configured to use DNS your network or system administrator will provide this to you.

Type of Wireless Network

To connect your Device to the network via a wireless access point, choose **Connect to an Access Point**. If you need to connect your Device directly to PC or some other computer, choose **Connect to another computer using Adhoc network**.

Security Settings

SSID

Enter the Service Set Identification that should be used by your Device to join a 802.11 wireless network.

Security

Select the encryption technique to be used when communicating on the wireless network. This must be the same as is being used by the access point or other computer you will be connecting to.

Enter Key

Enter the key to be used by the encryption software used when communicating on the wireless network. This key must match the key being used by the access point or other computer you will be connecting to.

Confirm Key

Re-enter the key to be used by the encryption software used when communicating on the wireless network. This is done to confirm the value since it is hidden on entry.

Key in HEX

Select this option if the value entered for the encryption key was entered using HEX values.

Edit Key


For security mechanisms that allow multiple keys, use this selection box to select the key that is to be edited.

Use Key

For security mechanisms that allow multiple keys, use this selection box to select the key that is to be used when

communicating on the wireless network. If multiple keys are present, the one selected must match the key being used on the access point or other computer the Device will be connecting to.

Manage Networks



You will have one or more network interfaces on the device, such as Ethernet and WLAN. Each interface can have one or more sets of configuration data, referred to as a profile. Profiles are manipulated on the Network and Wireless Settings pages. The Manage Networks page allows you to make a configuration profile active for an interface, restart the Ethernet interface, and stop/start/restart the WLAN or other optional network interface.

Ethernet Adapter

The Ethernet network interface is always present and active on this device. The device is factory configured with a default profile that is initially set to obtain an IP Address via DHCP. You can change this profile on the Network Settings page.

Enable Button

Enable the interface when it has been previously disabled

Disable Button

Disable the interface, preventing any traffic across the interface

Restart Button

This button can be used to restart the Ethernet network interface with the currently active profile settings.

IP Address The IP address currently assigned to this device, either via DHCP or static assignment. If no IP Address is listed the network connection may be down or the Ethernet cable might be unplugged.

Profiles A list of profiles containing configuration settings for the Ethernet network interface is provided here. The settings in use will be shown as **Currently Active**. Other available profiles will have a **Make Active** button next to the profile name that allows you to change the settings used by the Ethernet interface and restart the network.

Wireless Adapter (optional)

The Wireless LAN network interface is a device hardware option. When it is present, a factory configured default profile initially set to obtain an IP Address via DHCP is provided. However, the access point and security information will need to be entered via the Wireless Settings page.

Enable Button Enable the interface when it has been previously disabled

Disable Button Disable the interface, preventing any traffic across the interface


Restart Button This button can be used to restart the Wireless LAN network interface with the currently active profile settings.

IP Address The IP address currently assigned to the WLAN interface, either via DHCP or static assignment. If no IP Address is listed the network connection may be down, the access point security settings are incorrect, or the wireless access point is unreachable.

AP Address The access point hardware address is provided here. It is taken directly from the access point when a wireless connection is established. If the address shows as all 0s no connection is present.


Profiles A list of profiles containing configuration settings for the Wireless LAN network interface is provided here. The settings in use will be shown as **Currently Active**. Other available profiles will have a **Make Active** button next to the profile name that allows you to change the settings used by the Wireless LAN interface and restart the network.

Reset to Factory Defaults



Use this page to reset the device configuration settings back to the factory default values. **Note:** Please use this option with caution, as configuration data and network settings will be overwritten to default values.

Backup Settings




Back up the device's configuration data via this page. This will allow you to save and restore the configuration if it is inadvertently changed or lost. It is recommended that you backup your current settings prior to making significant configuration changes.

Software

Software Upgrades

Using the HTTP Installer



The Software Upgrades page on the device configuration web site allows you to install platform software and firmware upgrades. Use the **Browse** button on this screen to locate the software package on the local machine and click on the **Install** button to initiate the upload of the package file. Once uploaded the upgrade will be automatically started. Once the upgrade begins you will lose your browser connection to the device. **The LEDs will flash to indicate the upgrade is being performed. The software upgrade notification screen will attempt to refresh to indicate the upgrade is complete.**

Recovering from a Failed Upgrade

In the event a platform software and firmware upgrade fails in such a way that the device cannot operate normally, a recovery mode will be activated. In this mode the device will boot into a limited configuration that will allow you to apply a product software upgrade via the provided web interface. You should not

attempt to use the device for anything but a software upgrade when in recovery mode.

Installing Applications

Applications are installed in the same manner as platform software and firmware upgrades, using the **Software Upgrades** web page. Use the **Browse** button on this screen to locate the software package on the local machine and click on the **Install** button to initiate the upload of the package file. Once uploaded the upgrade will be automatically started. If the application provides progress information, it will be displayed in a popup window opened by the **Software Upgrades** web page.