







Creative Headset CB2455 With **Bluetooth Technology**



When your headset is not in use, clip the earpiece to your headset as shown below.























Getting Started



Charge your headset

Fully charge your headset before using it for the first time. This takes approximately five hours. Consequently, charging your headset takes three hours.

Reading your headset's LED

The table below shows you the various LED indications available.

LED		Meaning
Red	On (when charging)	Battery is charging.
	Blinks every five seconds	Battery low.
Blue	On (when charging)	Fully charged.
	Blinks once every five seconds	Headset is paired to your mobile phone and is in standby mode.
	Blinks once every 15 seconds	Call in progress.
Blue and red	Blinks alternately	Headset is in pairing mode and is ready for pairing. OR Headset is paired, connected and the microphone is muted.

























Pair your headset and mobile phone

- If your headset is turned on, turn it off by pressing and holding the Multi-function button until the LED turns red.
- 2. Place your headset within one meter of your mobile phone.
- 3. Press and hold the **Multi-function** button and one of the **Volume** buttons simultaneously, until the LED alternately blinks red and blue.
- 4. Turn on your mobile phone's Bluetooth feature. For more information, see your mobile phone's documentation.
- Set your mobile phone to detect Bluetooth devices.
- 6. From the list that appears, select CB2455Creative.
- 7. When prompted for a passkey, enter **0000** to complete pairing.



If the pairing is not completed within two minutes, your headset turns itself off automatically.























Using Your Headset

Usage	Action
Turning on headset	Press and hold the Multi-function button for three seconds. The LED turns blue.
Turning off headset	Press and hold the Multi-function button until the LED turns red.
Making a call	Make sure that your headset is turned on (it may be in standby mode when inactive), dial the number, and then proceed with your call.
Answering a call	If there is an incoming call, your earpiece and mobile phone rings, and your headset beeps. Press the Multi-function button.
Ending a call	Press the Multi-function button to end a call. You can also end a call using your mobile phone.
Voice Dial*	Press the Multi-function button and when you hear a beep, say the voice tag.
Last Number Redial*	Press the Multi-function button twice within one second.
Adjusting volume	Press the Volume Increase or Volume Decrease button to gradually increase or decrease the volume.
Rejecting a call	Press and hold the Multi-function button for three seconds.
Putting a call on hold	Press and hold the Volume Increase and Volume Decrease buttons simultaneously, for one second.
Switching between calls	Press the Volume Increase and Volume Decrease buttons simultaneously.
Mute	Press and hold one of the Volume buttons until the LED alternately blinks red and blue. To unmute the microphone, press and hold one of the Volume buttons until the LED blinks blue.
Clearing all headset pairings	Make sure that your headset is turned off. Press and hold one of the Volume buttons for 20 seconds. The LED alternately blinks red and blue. Press and hold one of the Volume buttons again until you hear two beeps. Charge your headset for a few seconds to reset your headset. All current pairings are cleared.

^{*}Some features are available only for certain mobile phones. Refer to your mobile phone's documentation.





















Frequently Asked Questions



- Check that your mobile phone's Bluetooth feature is turned on.
- · Make sure that your headset is turned on, fully charged and is within one meter of your mobile phone.
- Recharge your headset and mobile phone, and try pairing both devices again.

What causes poor signal quality?

Keep your headset within 10 meters of your mobile phone and make sure that there are no obstructions, such as walls or other electronic devices, between your headset and mobile phone (for example, cordless phones and some wireless networking devices).

Will my headset interfere with my computer or car's electronic devices?

You should not experience any interference when using your headset near standard consumer-grade electronics equipment.

Can other Bluetooth-enabled mobile phone users accidentally tune in on my conversation?

When you pair your headset to your mobile phone, you are creating a private link between both devices. The wireless Bluetooth technology prevents monitoring by third parties.

Can I use my headset with other Bluetooth products?

Your headset will work with all Bluetooth version 1.1 or higher devices. These devices, however, must have the Headset or Handsfree profile. For more information on international Bluetooth standards, go to www.bluetooth.com.

How do I change my headset's cover?










































General Specifications

Bluetooth operation: • Bluetooth version 1.2 compliance

Bluetooth 2.4 GHz Class 2 radio, up to a radius of 10 meters

(32.8 feet) (varies depending on environment)

Supported Bluetooth profile: Headset and handsfree profiles

Frequency range: 2.4000 - 2.4835 GHz

Battery type: Built-in Lithium-ion battery (rechargeable)

Talk Time: Up to 6 hours *

Standby Time: Up to 200 hours *

More Information

Creative Knowledge Base

Resolve and troubleshoot technical gueries at Creative's 24-hour self-help Knowledge Base. Go to www.creative.com and select your region.

Register your product!

Enjoy a host of benefits by registering your product during installation, or at www.creative.com/register.

Benefits include:

- · Service and product support from Creative
- Exclusive updates on promotions and events.

Please note that your warranty rights are not dependent on product registration.

For more information on Creative Customer Support Services and Warranty, go to www.europe.creative.com/support.













^{*} May vary depending on operation mode and mobile phone settings.



























Power Adapter Safety Notice

Power Source

This product is specially designed for operation within the electrical range(s) specified on the provided power adapter. Any usage outside of these ranges is at your own risk. If you are not sure of the type of power supply to your home, consult your product dealer or local Power Company.

Safety Advice



Unplug your headset from the power source and turn your headset off before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.

Servicing

Do not attempt to service the product or change the battery on your own. Refer all servicing to your local Customer Support Services center.



Copyright © 2005 Creative Technology Ltd. All rights reserved. Bluetooth is a registered trademark of the Bluetooth SIG, Inc., USA. All other products are trademarks or registered trademarks of their respective owners and are hereby recognized as such. All specifications are subject to change without prior notice. Actual contents may differ slightly from those pictured.




























Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications made by the user to this equipment. Such modifications could void the user's authority to operate the equipment.

General Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.











